

# ACS800

## Hardware Manual ACS800-07 Drives (500 to 2800 kW)



# ACS800 Single Drive Manuals

## **HARDWARE MANUALS** (appropriate manual is included in the delivery)

---

ACS800-01/U1 Hardware Manual 0.55 to 160 kW (0.75 to 200 HP)  
3AFE64382101 (English)

ACS800-01/U1/04 Marine Supplement 0.55 to 160 kW (0.75 to 200 HP)  
3AFE64291275 (English)

ACS800-11/U11 Hardware Manual 5.5 to 110 kW (7.5 to 125 HP)  
3AFE68367883 (English)

ACS800-31/U31 Hardware Manual 5.5 to 110 kW (7.5 to 125 HP)  
3AFE68599954 (English)

ACS800-02/U2 Hardware Manual 90 to 500 kW (125 to 600 HP)  
3AFE64567373 (English)

ACS800-04/U4 Hardware Manual 0.55 to 160 kW (0.75 to 200 HP)  
3AFE68372984 (English)

ACS800-04/04M/U4 Hardware Manual 45 to 560 kW (60 to 600 HP)  
3AFE64671006 (English)

ACS800-04/04M/U4 Cabinet Installation 45 to 560 kW (60 to 600 HP)  
3AFE68360323 (English)

ACS800-07/U7 Hardware Manual 45 to 560 kW (50 to 600 HP)  
3AFE64702165 (English)

ACS800-07/U7 Dimensional Drawings 45 to 560 kW (50 to 600 HP)  
3AFE64775421

ACS800-07 Hardware Manual 500 to 2800 kW  
3AFE64731165 (English)

ACS800-17 Hardware Manual 55 to 2500 kW (75 to 2800 HP)  
3AFE68397260 (English)

ACS800-37 Hardware Manual 55 to 2700 kW (75 to 3000 HP)  
3AFE68557925 (English)

- Safety instructions
- Electrical installation planning
- Mechanical and electrical installation
- Motor control and I/O board (RMIO)
- Maintenance
- Technical data
- Dimensional drawings
- Resistor braking

## **FIRMWARE MANUALS, SUPPLEMENTS AND GUIDES** (appropriate documents are included in the delivery)

---

Standard Control Program Firmware Manual  
3AFE64527592 (English)

System Application Program Firmware Manual  
3AFE64670646 (English)

Application Program Template Firmware Manual  
3AFE64616340 (English)

Master/Follower 3AFE64590430 (English)

Pump Control Application Program Firmware Manual  
3AFE68478952 (English)

Extruder Control Program Supplement 3AFE64648543 (English)

Centrifuge Control Program Supplement 3AFE64667246 (English)

Traverse Control Program Supplement 3AFE64618334 (English)

Crane Control Program Firmware Manual 3BSE11179 (English)

Adaptive Programming Application Guide  
3AFE64527274 (English)

## **OPTION MANUALS** (delivered with optional equipment)

---

Fieldbus Adapters, I/O Extension Modules etc.

ACS800-07 Drives  
500 to 2800 kW

## **Hardware Manual**

3AFE64731165 REV E EN  
EFFECTIVE: 15.2.2008

© 2008 ABB Oy. All Rights Reserved.





# Update Notice

The notice concerns the following *ACS800-07 Drives (500 to 2800 kW) Hardware Manuals*:

Code	Revision	Language	
3AFE64731165	E	English	EN
3AFE64772911	E	German	DE
3AFE64772929	E	Spanish	ES
3AFE64772937	E	Finnish	FI
3AFE64774239	E	French	FR
3AFE64772945	E	Italian	IT
3AFE68588235	E	Russian	RU
3AFE64772953	E	Swedish	SV

**Code:** 3AUA0000059446 Rev A

**Valid:** from 01.02.2010 until the release of the next revision of the manual

**Contents:**

The headings in this update notice refer to the modified subsections in the original English manual. Each heading also includes a page number and a classifier NEW, CHANGED, or DELETED. The page number refers to the page number in the original English manual. The classifier describes the type of the modification.

## **NEW (page 6): Safety / Installation and maintenance work**

- After maintaining or modifying a drive safety circuit or changing circuit boards inside the module, retest the functioning of the safety circuit according to the start-up instructions.
- Do not change the electrical installations of the drive except for the essential control and power connections. Changes may affect the safety performance or operation of the drive unexpectedly. All customer-made changes are on the customer's responsibility.

[...]

**Note:**

- The Safe torque off function (option +Q968) does not remove the voltage from the main and auxiliary circuits.

## **NEW/CHANGED (page 37): Type code**

The table below contains the valid option code definitions for the emergency stop.

Code	Description
+Q951	Emergency stop, stop category 0 with opening the main contactor/breaker
+Q952	Emergency stop, stop category 1 with opening the main contactor/breaker
+Q963	Emergency stop, stop category 0 without opening the main contactor/breaker
+Q964	Emergency stop, stop category 1 without opening the main contactor/breaker SS1

**NEW (page 37): Type code**

The table below contains the new option code definition for the Safe torque off function.

Code	Description
+Q968	Safe torque off (STO) with a safety relay


**NEW (page 61): Emergency stop**

**Note:** If you add or modify the wiring in the drive safety circuits, ensure that the appropriate standards (e.g. IEC 61800-5-1, EN 62061, EN/ISO 13849-1 and -2) and the ABB guidelines are met. After making the changes, verify the operation of the safety function by testing it.

**NEW (page 61): Safe torque off**

The drive supports the Safe torque off (STO) function according to standards EN 61800-5-2:2007; EN/ISO 13849-1:2008, IEC 61508, and EN 62061:2005. The function also corresponds to an uncontrolled stop in accordance with category 0 of EN 60204-1 and prevention of unexpected start-up of EN 1037.

The STO may be used where power removal is required to prevent an unexpected start. The function disables the control voltage of the power semiconductors of the drive output stage, thus preventing the inverter from generating the voltage required to rotate the motor (see the diagram below). By using this function, short-time operations (like cleaning) and/or maintenance work on non-electrical parts of the machinery can be performed without switching off the power supply to the drive.





**WARNING!** The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the drive. Therefore maintenance work on electrical parts of the drive or the motor can only be carried out after isolating the drive system from the main supply.

**Note:** The Safe torque off function can be used for stopping the drive in emergency stop situations. In the normal operating mode, use the Stop command instead. If a running drive is stopped by using the function, the drive will trip and stop by coasting. If this is not acceptable, e.g. causes danger, the drive and machinery must be stopped using the appropriate stopping mode before using this function.

**Note concerning permanent magnet motor drives in case of a multiple IGBT power semiconductor failure:** In spite of the activation of the Safe torque off function, the drive system can produce an alignment torque which maximally rotates the motor shaft by  $180/p$  degrees.  $p$  denotes the pole pair number.

**Note:** If you add or modify the wiring in the drive safety circuits, ensure that the appropriate standards (e.g. IEC 61800-5-1, EN 62061, EN/ISO 13849-1 and -2) and the ABB guidelines are met.

## **NEW (page 101): On-load checks**

The following information has been added to the procedure:

Action	Additional information
<input type="checkbox"/> Check the correct operation of the emergency stop circuits from each operating location.  If the drive is equipped with the category 1 emergency stop function (option +Q952 or +Q964), adjust the delay time of the emergency stop relay and the deceleration time of the drive emergency stop function. The factory default settings do not necessarily meet the application needs.	

## **NEW (page 101): On-load checks**

The following information has been added to the procedure:

Action	Additional information
<input type="checkbox"/> Check that the Safe torque off function (option +Q968, if installed) works: <ul style="list-style-type: none"> <li>• Ensure that the drive can be run and stopped freely during the commissioning.</li> <li>• Stop the drive (if running), switch the input power off and isolate the drive from the power line by a disconnecter.</li> <li>• Check the STO circuit connections against the circuit diagram.</li> </ul>	Optional function. See delivery specific circuit diagrams.

Action	Additional information
<ul style="list-style-type: none"> <li>• Close the disconnecter and switch the power on.</li> <li>• Test the operation of the STO function when the motor is stopped: <ul style="list-style-type: none"> <li>- Give a stop command for the drive (if running) and wait until the motor shaft is at standstill.</li> <li>- Activate the STO circuit and give a start command for the drive.</li> <li>- Ensure that the motor stays at standstill.</li> <li>- Deactivate the STO circuit.</li> </ul> </li> <li>• Restart the drive and check that the motor runs normally.</li> <li>• Test the operation of the STO function when the motor is running: <ul style="list-style-type: none"> <li>- Start the drive and ensure that the motor is running.</li> <li>- Activate the STO circuit.</li> <li>- Ensure that the motor stops and the drive trips.</li> <li>- Reset the fault and try to start the drive.</li> <li>- Ensure that the motor stays at standstill.</li> <li>- Deactivate the STO circuit.</li> </ul> </li> <li>• Restart the drive and check that the motor runs normally.</li> </ul>	

### **CHANGED (page 115): LEDs**

LED	Indication
V309 (red)	Prevention of unexpected start (option +Q950) or Safe torque off (option +Q968) is ON.

### **NEW (page 126): Ambient conditions**

Cabinets with option +Q968: the installation site altitude in operation is 0 to 2000 m.

	<b>Operation</b> installed for stationary use
<b>Installation site altitude</b>	[...] Cabinets with option +Q968: 0 to 2000 m



# Safety instructions

---

## What this chapter contains

This chapter contains safety instructions you must follow when installing, operating and servicing the drive. If ignored, physical injury or death may follow, or damage may occur to the drive, the motor or driven equipment. Read the safety instructions before you work on the unit.

## Usage of warnings and notes

There are two types of safety instructions throughout this manual: warnings and notes. Warnings caution you about conditions which can result in serious injury or death and/or damage to the equipment, and advise on how to avoid the danger. Notes draw attention to a particular condition or fact, or give information on a subject. The warning symbols are used as follows:



**Dangerous voltage warning** warns of high voltages which can cause physical injury and/or damage to the equipment.



**General warning** warns about conditions, other than those caused by electricity, which can result in physical injury and/or damage to the equipment.



**Electrostatic discharge warning** warns of electrostatic discharge which can damage the equipment.

## Installation and maintenance work

These warnings are intended for all who work on the drive, motor cable or motor. Ignoring the instructions can cause physical injury or death, or damage the equipment.

---

### WARNING!



- Only qualified electricians are allowed to install and maintain the drive.
- The main switch on the cabinet door does not remove the voltage from the input busbars of the drive. Before working on the drive, isolate the whole drive from the supply.
- Never work on the drive, the motor cable or the motor when main power is applied. After switching off the input power, always wait for 5 min to let the intermediate circuit capacitors discharge before you start working on the drive, the motor or the motor cable. Measure the voltage between terminals UDC+ and UDC- (L+ and L-) with a multimeter (impedance at least 1 Mohm) to ensure that the drive is discharged before beginning work.
- Apply temporary grounding before working on the unit.
- Do not work on the control cables when power is applied to the drive or to the external control circuits. Externally supplied control circuits may cause dangerous voltages to exist inside the drive even when the main power of the drive is switched off.
- Do not make any insulation or voltage withstand tests on the drive or drive modules.
- When reconnecting the motor cable, always check that the phase order is correct.
- When joining shipping splits (if any), check the cable connections at the joints before switching on the supply voltage.
- Live parts on the inside of the doors are protected against direct contact. Special attention shall be paid when handling metallic shrouds.

### Note:

- The motor cable terminals on the drive are at a dangerously high voltage when the input power is on, regardless of whether the motor is running or not.
  - The brake control terminals (UDC+, UDC-, R+ and R- terminals) carry a dangerous DC voltage (over 500 V).
  - Depending on the external wiring, dangerous voltages (115 V, 220 V or 230 V) may be present on the relay outputs of the drive system.
  - The Prevention of Unexpected Start function does not remove the voltage from the main and auxiliary circuits.
-



---

**WARNING!**

- During the installation procedure, the inverter modules may have to be temporarily extracted from the cabinet. The modules have a high centre of gravity. In order to minimise the danger of toppling over, keep the support legs of the modules extended whenever manoeuvring the modules outside the cabinet.
- Electrically conductive dust inside the unit may cause damage or lead to malfunction. Make sure that dust from drilling does not enter the drive when installing.
- Fastening the cabinet by riveting or welding is not recommended. However, if welding is necessary, ensure the return wire is properly connected in order not to damage the electronic equipment in the cabinet. Also ensure that welding fumes are not inhaled.
- Ensure sufficient cooling of the unit.
- Cooling fans may continue to rotate for a while after the disconnection of the electrical supply.
- Some parts inside the drive cabinet, such as heatsinks of power semiconductors, remain hot for a while after the disconnection of the electrical supply.

---

**WARNING!**

- The printed circuit boards contain components sensitive to electrostatic discharge. Wear a grounding wrist band when handling the boards. Do not touch the boards unnecessarily.
-

## Grounding

These instructions are intended for all who are responsible for the grounding of the drive. Incorrect grounding can cause physical injury, death or equipment malfunction and increase electromagnetic interference.

---

### WARNING!



- Ground the drive, the motor and adjoining equipment to ensure personnel safety in all circumstances, and to reduce electromagnetic emission and pick-up.
- Make sure that grounding conductors are adequately sized as required by safety regulations.
- In a multiple-drive installation, connect each drive separately to protective earth (PE).
- Do not install a drive equipped with an EMC (line) filter to an ungrounded power system or a high resistance-grounded (over 30 ohms) power system.

### Note:

- Power cable shields are suitable for equipment grounding conductors only when adequately sized to meet safety regulations.
  - As the normal leakage current of the drive is higher than 3.5 mA AC or 10 mA DC (stated by EN 50178, 5.2.11.1), a fixed protective earth connection is required.
- 

## Fibre optic cables

---

### WARNING!



- Handle the fibre optic cables with care. When unplugging optic cables, always grab the connector, not the cable itself. Do not touch the ends of the fibres with bare hands as the fibre is extremely sensitive to dirt. The minimum allowed bend radius is 35 mm (1.4").
-

## Operation

These warnings are intended for all who plan the operation of the drive or operate the drive. Ignoring the instructions can cause physical injury or death or damage the equipment.

---

### WARNING!





- If the drive is equipped with an optional brake unit, make sure there are inverters connected to the intermediate circuit before start. As a rule of thumb, the sum capacitance of the inverters connected must be at least 30% of the sum capacitance of all inverters.
- Close the switch fuses of all parallel-connected inverters before start.
- Do not open the DC switch fuse of an inverter when the inverter is running.


---

### WARNING!



- Before adjusting the drive and putting it into service, make sure that the motor and all driven equipment are suitable for operation throughout the speed range provided by the drive. The drive can be adjusted to operate the motor at speeds above and below the speed provided by connecting the motor directly to the power line.
- Do not activate automatic fault reset functions of the Standard Application Program if dangerous situations can occur. When activated, these functions will reset the drive and resume operation after a fault.
- Do not control the motor with the disconnecting device (means); instead, use the control panel keys  and , or commands via the I/O board of the drive. The maximum allowed number of charging cycles of the DC capacitors (i.e. power-ups by applying power) is five in ten minutes.

### Note:

- If an external source for start command is selected and it is ON, the drive (with Standard Application Program) will start immediately after fault reset unless the drive is configured for 3-wire (a pulse) start/stop.
  - When the control location is not set to Local (L not shown in the status row of the display), the stop key on the control panel will not stop the drive. To stop the drive using the control panel, press the LOC/REM key and then the stop key .
-

## Permanent magnet motor drives

These are additional warnings concerning permanent magnet motor drives.



**WARNING!** Do not work on the drive when the permanent magnet motor is rotating. Also when the supply power is switched off, a rotating permanent magnet motor feeds power to the intermediate circuit of the drive and also the supply connections become live (even when the inverter is stopped!).

### Installation and maintenance work

- Disconnect the motor from the drive with a safety switch and additionally, if possible,
- lock the motor shaft and ground the motor connection terminals temporarily by connecting them together as well as to the PE.

### Operation

Do not run the motor above the rated speed. Motor overspeed leads to overvoltage which may result in explosion of the capacitors in the intermediate circuit of the drive.

### Application program

Controlling a permanent magnet motor is only allowed using the ACS800 Permanent Magnet Synchronous Motor Drive Application Program, or using other application programs in scalar control mode only.

# Table of contents

---

ACS800 Single Drive Manuals .....	2
-----------------------------------	---

## ***Safety instructions***

What this chapter contains .....	5
Usage of warnings and notes .....	5
Installation and maintenance work .....	6
Grounding .....	8
Fibre optic cables .....	8
Operation .....	9
Permanent magnet motor drives .....	10
Installation and maintenance work .....	10
Operation .....	10
Application program .....	10

## ***Table of contents***

### ***About this manual***

What this chapter contains .....	17
Target audience .....	17
Common chapters for multiple products .....	17
Categorization according to the frame size .....	17
Contents .....	17
Installation and commissioning flowchart .....	18
Product and service inquiries .....	19
Product training .....	19
Providing feedback on ABB Drives manuals .....	19
Terms and abbreviations .....	20

### ***Hardware description***

What this chapter contains .....	21
The ACS800-07 .....	21
Cabinet line-up .....	21
Swing-out frame .....	23
Cabling direction .....	24
Single-line circuit diagram of the drive .....	25
Controls .....	26
Door switches .....	26
Load switch-disconnector .....	26
Auxiliary voltage switch .....	26
Earthing/Grounding switch .....	26
Other door controls .....	26
Supply unit control electronics .....	27

---

Reading and setting of values (page 1 of 2) .....	28
Reading and setting of values (page 2 of 2) .....	29
Terminal blocks .....	30
Digital input and relay output terminals .....	31
Emergency stop input .....	32
Earth (ground) current function .....	33
Power loss ride-through function .....	34
Inverter unit control .....	34
Motor control .....	35
Reduced run capability .....	35
Type code .....	36

## ***Mechanical installation***

What this chapter contains .....	39
General .....	39
Required tools .....	39
Moving the unit .....	40
...by crane .....	40
...by fork-lift or pallet truck .....	41
...on rollers .....	41
Laying the unit on its back .....	41
Final placement of the unit .....	42
Before installation .....	43
Delivery check .....	43
Installation procedure .....	44
Fastening the cabinet to the floor (Non-marine units) .....	45
Clamping .....	45
Holes inside the cabinet .....	46
Fastening the unit to the floor and wall (Marine units) .....	47
Joining the shipping splits .....	48
Procedure .....	48
Connecting the DC busbars and the PE busbar .....	49
DC busbars .....	50
PE busbar .....	50
Miscellaneous .....	51
Cable duct in the floor below the cabinet .....	51
Cooling air intake through bottom of cabinet .....	52
Example .....	52
Electric welding .....	53

## ***Planning the electrical installation***

What this chapter contains .....	55
Motor selection and compatibility .....	55
Protecting the motor insulation and bearings .....	56
Requirements table .....	57
Permanent magnet synchronous motor .....	59
Thermal overload and short-circuit protection .....	59
Thermal overload protection of the drive and the input and motor cables .....	59

Thermal overload protection of the motor	60
Protection against short-circuit in the motor cable	60
Protection against short-circuit inside the drive or in the supply cable	60
Earth fault (Ground fault) protection	60
Emergency stop devices	61
Restarting after an emergency stop	61
Prevention of unexpected start	61
Selecting the power cables	61
General rules	61
Alternative power cable types	63
Motor cable shield	63
Additional US requirements	63
Conduit	64
Armored cable / shielded power cable	64
Power factor compensation capacitors	65
Equipment connected to the motor cable	65
Installation of safety switches, contactors, connection boxes, etc.	65
Bypass connection	65
Before opening an output contactor (in DTC motor control mode)	65
Relay output contacts and inductive loads	66
Selecting the control cables	67
Relay cable	67
Control panel cable	67
Coaxial cable (for use with Advant Controllers AC 80/AC 800)	67
Connection of a motor temperature sensor to the drive I/O	68
Installation sites above 2000 metres (6562 feet)	68
Routing the cables	68
Control cable ducts	69

## **Electrical installation**

What this chapter contains	71
Before installation	71
Checking the insulation of the assembly	71
Motor and motor cable	71
IT (ungrounded) systems	72
Setting the earth fault (ground fault) trip level	72
Grounded systems	72
IT (ungrounded) systems	72
Input power connection – Units without load switch-disconnector or air circuit breaker	73
Connection diagrams	73
6-pulse connection, two supply modules in parallel	73
12-pulse connection, two supply modules in parallel	74
Connection procedure	75
Use of the dual-cable screw lug connector	76
Removal of the dual-cable screw lug connector	76
Input power connection – Units with load switch-disconnector or air circuit breaker	77
Connection diagrams	77
6-pulse connection, two supply modules in parallel	77
12-pulse connection, two supply modules in parallel	78

Connection procedure .....	79
Motor connection – Units without common motor terminal cubicle .....	80
Output busbars .....	80
Connection diagram .....	80
Connection procedure .....	82
Motor connection – Units with common motor terminal cubicle .....	84
Connection diagram .....	84
Connection procedure .....	84
Control connections .....	85
Drive control connections .....	85
Supply unit control connections .....	85
Connection procedure .....	86
Installation of optional modules and PC .....	88
Cabling of I/O and fieldbus modules .....	88
Cabling of pulse encoder interface module .....	88
Fibre optic link .....	88
Connections and tap settings of the auxiliary voltage transformer .....	89
Installation of brake resistors .....	89

### ***Motor control and I/O board (RMIO)***

What this chapter contains .....	91
To which products this chapter applies .....	91
Note on cabinet-installed ACS800 drives .....	91
Note on terminal labelling .....	91
Note on external power supply .....	92
Parameter settings .....	92
External control connections (non-US) .....	93
External control connections (US) .....	94
RMIO board specifications .....	95
Analogue inputs .....	95
Constant voltage output .....	95
Auxiliary power output .....	95
Analogue outputs .....	95
Digital inputs .....	95
Relay outputs .....	96
DDCS fibre optic link .....	96
24 VDC power input .....	96

### ***Installation checklist and start-up***

Installation checklist .....	99
Start-up procedure .....	100
Basic checks with no voltage connected .....	100
Connecting voltage to input terminals and auxiliary circuit .....	100
Starting the supply unit .....	101
Checks with the supply unit running .....	101
Application program set-up .....	101
On-load checks .....	101



## **Maintenance**

What this chapter contains .....	103
Safety instructions .....	103
Maintenance intervals .....	104
Replacing the PPCS branching unit (APBU-xx) memory backup battery .....	105
Checking and replacing the air filters .....	106
Power connections .....	106
Cooling fans .....	107
Power module cooling fans .....	107
Supply module fan replacement .....	107
Inverter module fan replacement .....	108
Control and I/O cubicle cooling fans .....	109
Air circuit breaker cubicle fans .....	110
IP54 (UL type 12) fan replacement .....	110
Heatsinks .....	112
Capacitors .....	112
Reforming .....	112
Capacitor replacement .....	112
Other maintenance actions .....	112
Power module replacement .....	112

## **Fault tracing**

What this chapter contains .....	113
Supply unit status, fault and warning LEDs .....	113
Other LEDs of the drive .....	115

## **Technical data**

What this chapter contains .....	117
Ratings .....	117
Symbols .....	118
Derating .....	118
Temperature derating .....	118
Altitude derating .....	118
ACS800-07 frame sizes and power module types .....	119
Internal AC fuses .....	120
DC fuses at inverter module input .....	121
Fuses for main circuit voltage measurement .....	121
DC fuses for the DSU module .....	121
Input power connection .....	122
Motor connection .....	124
Efficiency .....	125
Cooling .....	126
Degrees of protection .....	126
Ambient conditions .....	126
Materials .....	127
Tightening torques for power connections .....	127
Applicable standards .....	127

CE marking	128
Definitions	128
Compliance with the EMC Directive	128
Compliance with the EN 61800-3 + Amendment A11 (2000)	128
First environment (restricted distribution)	128
Second environment	129
Machinery Directive	129
“C-tick” marking	130
Definitions	130
Compliance with IEC 61800-3	130
First environment (restricted distribution)	130
Second environment	131

## **Dimensions**

Cabinet line-ups	133
Frame size 1×D4 + 2×R8i	138
Frame size 1×D4 + 2×R8i (with load switch-disconnector)	141
Frame size 1×D4 + 2×R8i (with top entry/exit)	147
Frame size 2×D4 + 2×R8i	150
Frame size 2×D4 + 2×R8i (with load switch-disconnector)	153
Frame size 2×D4 + 3×R8i	156
Frame size 2×D4 + 3×R8i (with load switch-disconnector)	159
Frame size 2×D4 + 3×R8i (with air circuit breaker)	163
Frame size 3×D4 + 4×R8i	167
Frame size 3×D4 + 4×R8i (with load switch-disconnector)	170
Frame size 3×D4 + 4×R8i (with air circuit breaker)	174
Common motor terminal cubicle	178
300 mm	178
400 mm	179
600 mm	180

## **Resistor braking**

What this chapter contains	181
Resistor braking options	181
Chopper/Resistor combinations – Technical data	182
Brake resistors – Technical data	182
Verifying the capacity of the braking equipment	183
Custom resistors	183
Calculating the maximum braking power ( $P_{br}$ )	184
Example 1	184
Example 2	184
Example 3	185
Custom resistor installation and wiring	186
Brake circuit commissioning	187

# About this manual

---

## What this chapter contains

This chapter describes the intended audience and contents of the manual. It contains a flowchart of steps in checking the delivery, installing and commissioning the drive. The flowchart refers to chapters/sections in this manual and other manuals.

## Target audience

This manual is intended for people who plan the installation, install, commission, use and service the drive. Read the manual before working on the drive. The reader is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The manual is written for readers worldwide. Both SI and imperial units are shown. Special US instructions for installations within the United States that must be installed per the National Electrical Code and local codes are marked with (US).

## Common chapters for multiple products

Some chapters in this manual apply to several products including the ACS800-07. Other product types may be mentioned in these chapters.

## Categorization according to the frame size

Some instructions, technical data and dimensional drawings which concern only certain drive frame sizes are marked with the symbol of the frame size (such as “1×D4 + 2×R8i”, etc.). The frame size is not marked on the drive designation label. To identify the frame size of your drive, see the rating tables in chapter [Technical data](#).

## Contents

The chapters of this manual are briefly described below.

[Safety instructions](#) gives safety instructions for the installation, commissioning, operation and maintenance of the drive.

[About this manual](#) introduces this manual.

[Hardware description](#) describes the drive.

[Mechanical installation](#) instructs how to move, place and mount the drive.

[Planning the electrical installation](#) provides advice on motor and cable selection, the protective functions of the drive, and cable routing.

[Electrical installation](#) describes the cabling and wiring of the drive.

[Motor control and I/O board \(RMIO\)](#) shows external control connections to the motor control and I/O board and its specifications.

[Installation checklist and start-up](#) helps in checking the mechanical and electrical installation of the drive.

[Maintenance](#) contains preventive maintenance instructions.


[Fault tracing](#) contains troubleshooting instructions.


[Technical data](#) contains the technical specifications of the drive, e.g. ratings, frame sizes and technical requirements, provisions for fulfilling the requirements for CE and other markings and warranty policy.

[Dimensions](#) contains information on the dimensions of the drive.

[Resistor braking](#) describes how to select, protect and wire optional brake choppers and resistors.

## Installation and commissioning flowchart





## Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type code and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to ABB website and selecting *Drives – Sales, Support and Service network*.

## Product training

For information on ABB product training, navigate to ABB website and select *Drives – Training courses*.

## Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Go to ABB website and select *Document Library – Manuals feedback form (LV AC drives)*.

## Terms and abbreviations

Term/Abbreviation	Explanation
APBU	Type of optical branching unit used for connecting parallel-connected converter modules to the RDCU.
DSSB	Diode Supply System Board
DSU	Diode Supply Unit
Frame (size)	<p>Relates to the construction type of the component in question. For example, several drive types with different power ratings may have the same basic construction, and this term is used in reference to all those drive types.</p> <p>With the ACS800-07 (&gt; 500 kW), the frame size of the drive indicates the quantity and frame size of the supply modules, plus the quantity and frame size of the inverter modules, e.g. "2×D4 + 4×R8i".</p> <p>To determine the frame size of a drive type, see the rating tables in the chapter <a href="#">Technical data</a>.</p>
RDCU	Drive control unit.
THD	Total Harmonic Distortion

# Hardware description

## What this chapter contains

This chapter describes the construction of the drive in short.


## The ACS800-07

The ACS800-07 is a cabinet-mounted drive for controlling AC motors.

### Cabinet line-up


The drive consists of several cubicles that contain the supply and motor terminals, 1 to 4 diode supply module(s), 2 to 6 inverter modules, and optional equipment. The actual arrangement of the cubicles vary from type to type and the selected options. See the chapter *Dimensions* for the different line-up variations.

The picture below shows the main components of a frame 1×D4 + 2×R8i drive.



No.	Description
1	Supply (input) cable lead-throughs. Top entry optional.
2	Supply module.
3	Input terminals (behind module). Input cables connect here if a load switch-disconnector cubicle is not present.
4	Chassis socket for quick supply module connection (behind module).
5	Supply module switch-disconnector. Not present if the drive is equipped with an optional load switch-disconnector cubicle.
6	Supply unit control board (DSSB; mounted sideways). Contains an actual value display and status LEDs.
7	Inverter DC fuses.
8	Inverter modules.
9	Chassis socket for inverter module output connection (behind each module).
10	Output terminals (behind each module). Motor cables connect here if a common motor terminal cubicle is not present.
11	Motor (output) cable lead-throughs. Not used if optional common motor terminal cubicle is present.
12	Swing-out frame. Contains the drive control unit with I/O terminals, and provides space for standard and optional electrical equipment.
13	Auxiliary voltage transformer (accessible by opening the swing-out frame).
14	Auxiliary voltage switch with fuses.

The following drawing represents a 2×D4 + 2×R8i drive with optional load switch-disconnector.



No.	Description
1	Supply (input) cable lead-throughs. Top entry optional.
2	Input busbars.
3	Load switch-disconnector.
4	Earthing/Grounding switch (optional).
5	AC fuses. Only present if the drive is equipped with a load switch-disconnector or air circuit breaker.
6	Supply modules.
7	Chassis socket for quick supply module connection (behind each module).
8	Supply module switch-disconnectors (coupled to an operating handle on the cabinet door). Not present if the drive is equipped with a load switch-disconnector or air circuit breaker.
9	Supply unit control board (DSSB; mounted sideways). Contains an actual value display and status LEDs.

No.	Description
10	Inverter DC fuses.
11	Inverter modules.
12	Chassis socket for inverter module output connection (behind each module).
13	Output terminals (behind each module). Motor cables connect here if a common motor terminal cubicle is not present.
14	Motor (output) cable lead-throughs. Not used if optional common motor terminal cubicle is present.
15	Swing-out frame. Contains the drive control unit with I/O terminals, and provides space for standard and optional electrical equipment.
16	Auxiliary voltage transformer (accessible by opening the swing-out frame).
17	Auxiliary voltage switch.


#### Hardware description



### *Swing-out frame*


The swing-out frame inside the control and I/O cubicle provides space for the control electronics of the drive, I/O terminal blocks, and optional electrical equipment. The lead-throughs for I/O cables, the auxiliary voltage transformer, and further space for additional equipment are available behind the frame. The frame can be opened by removing the two locking screws (arrowed in the picture below) and moving the swing-out frame aside. (Depending on selected options, actual equipment of the drive may differ from what is depicted below.)

Remove screws (arrowed) to  
release swing-out frame




Cabling direction

The drawing below shows the available power cabling directions of the drive. Note that the desired cabling direction must be specified on ordering.



Description	
1	Main supply – Bottom entry at each supply module (without load switch-disconnector or air breaker)
2	Main supply – Bottom entry with load switch-disconnector or air circuit breaker
3	Main supply – Top entry at each supply module (without load switch-disconnector or air circuit breaker) (not for IP54)
4	Main supply – Top entry with load switch-disconnector or air circuit breaker
5	Motor output – Bottom exit at each inverter module (without common motor terminal cubicle)
6	Motor output – Top exit at each inverter module (without common motor terminal cubicle). Added depth: 130 mm
7	Motor output – Bottom exit with common motor terminal cubicle
8	Motor output – Top exit with common motor terminal cubicle
A	Load switch-disconnector or air circuit breaker cubicle (optional)
B	Control, I/O and supply cubicle
C	Inverter unit cubicle
D	Common motor terminal cubicle (optional)

## Single-line circuit diagram of the drive



Controls

Door switches

*Load switch-disconnector*

The drive has a load switch-disconnector handle. In units without an optional load switch-disconnector (+F253), the handle operates the internal switch-disconnector contained within each supply module.



**WARNING!** The load switch-disconnector does not switch off the auxiliary voltages inside the cabinet. In units without option +F253, the switch-disconnector does not switch off the voltage at the input terminals of the supply module(s).

**Note:** On units without the line contactor option (+F250) and the load switch-disconnector option (+F253), the supply unit will start rectifying as soon as the switch-disconnector(s) within the supply module(s) is closed.

*Auxiliary voltage switch*


The auxiliary voltage switch controls the voltage supply to the auxiliary voltage transformer.

*Earthing/Grounding switch*

An earthing/grounding switch for temporary grounding is optionally available.

*Other door controls*

The following switches are mounted on the door of the control and I/O cubicle:




**Auxiliary voltage switch-disconnector (not shown)**  
Controls the power supply to the auxiliary voltage transformers, ground fault supervision, motor fan supply, and the voltage display of the DSSB board.

## Supply unit control electronics


The supply module(s) is controlled by the DSSB (Diode supply system board), located inside the control and I/O cubicle. The DSSB is connected to – and powered from – the supply module(s) via the quick connectors at the back of the modules.

The DSSB contains the following LEDs:




DSU\_DISPLAY.TIF

## Reading and setting of values (page 1 of 2)



## Reading and setting of values (page 2 of 2)



● LED on

○ LED off

3) No. of modules (1...5). DSSB needs the value for scaling the current output signal connected to current meters on cabinet door (optional equipment).

4) Displays earth current peak value

5) Displays module count set in AOS

6) Displays VAC phase balance





### Terminal blocks

X500	Ribbon cable to DSCB board via module quick connector	
X2	Measurement for actual value display (factory-wired)	
1	DC+	Intermediate circuit voltage (+ and - busbars)
2	DC-	
X3	Measurement for actual value display (factory-wired)	
1	U	Phase voltage
2	V	Phase voltage
3	W	Phase voltage
X4	24 V (or 48 V) output, short-circuit protected, live when AC power input of DSU is live	
1	-24V	Power supply output: +24 VDC / max. 3 A and -24 VDC / max. 0.5 A (or 48 VDC / max 0.5 A) <b>Note:</b> Terminals can also be used to supply DSU control boards externally during input power break. Use two 24 V / 1 A floating power supplies. Connect between +24V & Ground and Ground & -24V.
2	+24V	
3	Ground	
X5	Remote digital inputs	
	See <a href="#">Digital input and relay output terminals</a> on page 31.	
X6, X7	Relay outputs	
	See <a href="#">Digital input and relay output terminals</a> on page 31.	
X8	Emergency stop input	
	See <a href="#">Emergency stop input</a> on page 32.	
X9	Phase current output for an external display device (e.g. a meter on the cabinet door). For scaling, see <a href="#">Reading and setting of values (page 2 of 2)</a> on page 29. Use single phase meters. Connect the meter between the current output terminal and ground (cabinet frame). Type tested and used by ABB: BQ307 by <i>Iskra</i> ( <a href="http://www.iskra-mis.si">www.iskra-mis.si</a> ).	
1	U1.1	Phase current value as a 0...1 mA signal (= 0...nominal DSU current)
2	V1.1	Phase current value as a 0...1 mA signal (= 0...nominal DSU current)
3	W1.1	Phase current value as a 0...1 mA signal (= 0...nominal DSU current)
4	U1.2	Phase current value as a 0...1 mA signal (= 0...nominal DSU current)
5	V1.2	Phase current value as a 0...1 mA signal (= 0...nominal DSU current)
6	W1.2	Phase current value as a 0...1 mA signal (= 0...nominal DSU current)
X10	Local digital inputs	
	See <a href="#">Digital input and relay output terminals</a> on page 31.	



### Digital input and relay output terminals


The DSU can be controlled through two control interfaces: local and remote. The operation switches placed on the cabinet door are connected to the local control interface. The remote control interface can be used in parallel when control by other external devices is needed.



#### Digital input data

Input voltage: "1" = 15...48 VDC or 15...230 VAC. All inputs must be of the same type (AC or DC).


Internal connection:



#### Relay output data

Contact rating:  
230 VAC / 1 A continuous

Internal connection:



DSSB board terminals

X10 Local digital inputs		
1	START	0 -> 1: DSU closes main contactors and starts rectifying. <b>Note:</b> Local ON input must be switched on.
2	ON	1: DSU is rectifying. <sup>1)</sup> 0: DSU stops rectifying and opens contactors.
3	+24 V	+24 VDC
4	RESET	0 -> 1: Reset
5	RESET LED	Ground for reset button LED
6	+24 V	+24 VDC
X5 Remote digital inputs <sup>2)</sup>		
1-2	ON	1: DSU is rectifying. <sup>1)</sup> 0: DSU stops rectifying and opens contactors. <b>Note:</b> If start command was given through local START input, DSU stops only after local ON input is switched off.
3-4	START	0 -> 1: DSU closes main contactors and starts rectifying. <b>Note:</b> Local and remote ON inputs must be switched on.
5-6	RESET	0 -> 1: Reset
7-8	EXT.FAULT	1: External fault. DSU trips. 0: No external fault.
X6 Relay outputs <sup>2)</sup>		
1-2	RO1	Off: Fault
3		-
4-5	RO2	On: Running
X7 Relay outputs <sup>2)</sup>		
1-2	RO3	Overtemperature warning
3		-
4-5	RO4	Off: Earth (ground) fault detected
6		-
7-8	RO5	Off: Emergency stop acknowledgement to inverter

<sup>1)</sup> After the power switch-on, the DSU first charges the contactor control capacitors (~ 3 s at first start) and checks the fault status. DSU starts rectifying only after the contactors are closed by the START input.

<sup>2)</sup> These DSSB board terminals are wired to a separate terminal block to which the user connections are to be made. See the circuit diagrams delivered with the unit.

Emergency stop input


The DSSB board has a built-in logic that fulfils the emergency stop requirements according to IEC/EN60204-1 / Category 0 (Immediate removal of power) provided that:

- the Diode Supply Unit (DSU) is equipped with optional main contactors, and
- an emergency stop button is wired to the emergency stop input of the DSU. See the figure below for connection to the DSSB board.

When the emergency stop is activated, the DSU stops and opens the main contactors. Normal operation resumes after the emergency stop is deactivated and the DSU is reset.

**Note:** Emergency stop according to category 0 and category 1 (controlled emergency stop) are available as factory-installed options. The category 1 option requires additional wirings that are not visible in the figure below. See the circuit diagrams delivered with the unit for more information.

Emergency stop button wired to DSSB board




**Note:** The DSSB board terminals are wired to a separate terminal block to which the user connections are made. See circuit diagrams delivered with the unit.

Additional emergency stop buttons can be connected in series.

### Earth (ground) current function

The control board (DSSB) measures the input currents of the diode supply unit. The earth current function constantly monitors the sum of the phase currents. The chart below describes the operation.



1) Function is inactive when the wake up level is set to NONE (default setting). See page [28](#).

2) See page [28](#) for setting/checking the wake up level of the earth current function.

3) See page [28](#) for the fault trip selection (ON = fault trip, OFF = warning).

For information on the LEDs, see the chapter [Fault tracing](#).

### Power loss ride-through function

The power loss ride-through function keeps the supply unit operative over an unexpected input power break. The user can activate the function by setting the power loss ride-through delay with the buttons on the DSSB board.

---

**Note:** Units with an air circuit breaker require an external UPS for the function to be available.

---

The table below describes the operation of the function.

Duration of the break	What happens during the break	What happens after the break
Shorter than power loss ride-through time.	If the DC voltage drops less than 30%, <ul style="list-style-type: none"> <li>• the diode bridge stays in normal operating mode, and</li> <li>• the supply unit keeps the internal contactors energised.</li> </ul>	The supply unit resumes rectifying automatically.
	If the DC voltage drops more than 30%, <ul style="list-style-type: none"> <li>• the diode bridge switches into charging mode and further into stand-by (only the DSSB board is kept live by a backup capacitor),</li> <li>• relay output RO2 (Running) de-energises, and</li> <li>• the internal contactors open.</li> </ul>	The supply unit “wakes up” automatically and <ul style="list-style-type: none"> <li>• closes the internal contactors,</li> <li>• charges the DC bus,</li> <li>• starts rectifying, and</li> <li>• energises relay output RO2.</li> </ul>
Longer than power loss ride-through time.	The supply unit stops and opens the main contactors.	Operation continues only after manual reset and restart.


The delay setting range is 0 to 40 seconds. For instructions on the setting, see page [28](#).

### Inverter unit control

The inverter unit is controlled by an RDCU drive control unit located in the swing-out frame. The RDCU is connected to the inverter modules by a fibre optic link, distributed through an optical branching unit. In the inverter modules, the optic link connects to the AINT board, the terminals of which are accessible through a hole on the front panel of the module.

A control panel (type CDP-312R) is installed on the door of the drive. The CDP-312R is the user interface of the inverters of the drive, providing the essential controls such as Start/Stop/Direction/Reset/Reference, and the parameter settings for the drive application program. See the *Firmware Manual* for further information.

This diagram shows the control interfaces of the inverter unit.



### Motor control

The motor control is based on the Direct Torque Control (DTC) method. Two phase currents and DC link voltage are measured and used for the control. The third phase current is measured for earth fault protection.

### Reduced run capability

If one of parallel-connected supply or inverter modules must be taken out of the cabinet for service, it is possible to continue operation using the remaining modules, albeit at reduced power. For directions, contact your local ABB representative.

## Type code

The type code of the drive is indicated on the type designation label, attached on the supply cubicle door. The type code contains information on the specifications and configuration of the drive. The first digits from left express the basic configuration (e.g. ACS800-07-0610-3). The optional selections are given thereafter, separated by + signs (e.g. +E202). The main selections are described below.

**Note:** The information below is for quick reference only and does not contain all conditions and details. For more information, refer to *ACS800 Ordering Information* (code: 64556568), available through ABB representatives.

Selection	Alternatives
<b>Product series</b>	ACS800 product series
<b>Type</b>	<b>07</b> = cabinet-mounted When no options are selected: IP21 (UL Type 1), main switch/disconnector(s), 230 V auxiliary voltage, du/dt filtering (+E205), common mode filtering (CMF) (+E208), EMC/RFI filtering for second environment (+E210), Standard Application Program, bottom entry/exit of cables, coated circuit boards, set of English manuals.
<b>Size</b>	Refer to <i>Technical data: Ratings</i> .
<b>Voltage range</b> (nominal rating in <b>bold</b> )	<b>3</b> = 380/400/415 VAC <b>5</b> = 380/400/415/440/460/480/500 VAC <b>7</b> = 525/575/600/690 VAC
+ options	
<b>I/O options</b>	Refer to <i>ACS800 Ordering Information</i> (3AFY64556568 [English]).
<b>Fieldbus adapter</b>	
<b>Application program</b>	
<b>Degree of protection</b>	<b>B053</b> = IP22 (UL Type 1) <b>B054</b> = IP42 (UL Type 1) <b>B055</b> = IP54 (UL Type 12) (Not available with +C134) <b>B059</b> = IP54R (with connection to air outlet duct)
<b>Construction</b>	<b>C121</b> = Marine construction (reinforced mechanical parts and fastening, marking of conductors [A1], door handles, self-extinctive materials) <b>C129</b> = UL Listed (115 V AC auxiliary voltage, cable conduit entries, all components UL listed/recognized, max. supply voltage 600 V; +F253, +F260 and top entry of cables are standard) <b>C134</b> = CSA Approved (as +C129, with CSA approved components)
<b>Filters</b>	<b>E202</b> = EMC/RFI filtering for first environment TN (grounded) system, restricted (A-limits). Only for 6-pulse ACS800-07-0610-3 and -0760-5. Requires +F253 and +F260. <b>E206</b> = Sine output filters (Not available with +C121, +C129 or +C134) <b>Note:</b> du/dt filtering (+E205), common mode filtering (CMF) (+E208), and EMC/RFI filtering for second environment (+E210) are standard equipment.
<b>Resistor braking</b>	<b>D150</b> = brake choppers <b>D151</b> = brake resistors (not available in IP54 or IP54R)

Selection	Alternatives
<b>Line options</b>	<b>F250+Q951</b> = line contactor + emergency stop (Category 0) <b>F250+Q952</b> = line contactor + emergency stop (Category 1) <b>F253+F260</b> = aR AC fuses + load switch-disconnector (6-pulse) (Load switch-disconnectors in DSU modules removed) <b>A004+F253+F260</b> = aR AC fuses + load switch-disconnector (12-pulse) (Load switch-disconnectors in supply modules removed) (with +C129 and +C134, second cubicle for load switch-disconnector added) <b>F255+F260+Q951</b> = air circuit breaker + emergency stop (Category 0) (6-pulse only) (Not available with frame 1xD4 + n×R8i) (Load switch-disconnectors and main contactors in supply modules removed) <b>F255+F260+Q952</b> = air circuit breaker + emergency stop (Category 1) (6-pulse only) (Not available with frame 1xD4 + n×R8i) (Load switch-disconnectors and main contactors in supply modules removed) <b>F259</b> = earthing switch (only with +F253 or +F255) (Not available with +C129 or +C134)
<b>Cabling</b>	<b>H351</b> = top entry (IP54 and IP54R require +F253 or +F255) <b>H353</b> = top exit <b>H358</b> = US/UK gland/conduit plate (standard with +C129 and +C134) <b>H359</b> = common motor terminal cubicle
<b>Auxiliary voltage</b>	<b>G304</b> = 115 VAC auxiliary voltage (standard with +C129 and +C134)
<b>Cabinet options</b>	<b>G300</b> = cabinet heaters (external supply) (Not available with +C129 or +C134) <b>G313</b> = motor heater output (external supply) <b>G307</b> = terminals for external control voltage (UPS) <b>G317</b> = busbar supply conductors (6-pulse only) (Requires +F253 or +F255) <b>G330</b> = halogen-free wiring and materials (Not available with +C129 or +C134)
<b>Language of manuals</b>	<b>Rxxx</b> Refer to <i>ACS800 Ordering Information</i> (3AFY64556568 [English]).
<b>Starter of auxiliary motor fan</b>	<b>M602</b> = 2.5 ... 4 A (1, 2 or 4 pcs) <b>M603</b> = 4 ... 6.3 A (1, 2 or 4 pcs) <b>M604</b> = 6.3 ... 10 A (1, 2 or 4 pcs) <b>M605</b> = 10 ... 16 A (1 or 2 pcs) <b>M606</b> = 16 ... 25 A (1 pc)
<b>Safety features</b>	<b>Q950</b> = prevention of unexpected start (Category 3) <b>Q954</b> = earth fault monitoring (IT [ungrounded] system) <b>Q959</b> = red-coloured trip pushbutton for external breaker
<b>Special</b>	<b>P902</b> = customised (described in Technical appendix on ordering) <b>P904</b> = extended warranty <b>P913</b> = special colour





# Mechanical installation

---

## What this chapter contains

This chapter describes the mechanical installation procedure of the drive.

## General

See chapter [Technical data](#) for allowable operating conditions and requirements for free space around the unit.

The unit should be installed in an upright vertical position.

**The floor** that the unit is installed on should be of non-flammable material, as smooth as possible, and strong enough to support the weight of the unit. The floor flatness must be checked with a spirit level before the installation of the cabinets into their final position. The maximum allowed deviation from the surface level is 5 mm in every 3 metres. The installation site should be levelled, if necessary, as the cabinet is not equipped with adjustable feet.

**The wall** behind the unit should be of non-flammable material.

Provide the drive with the amount of fresh **cooling air** given in [Technical data](#).

**Note:** Very wide cabinet line-ups are delivered as “shipping splits”.


## Required tools

The tools required for moving the unit to its final position, fastening it to the floor and tightening the connections are listed below.

- crane, fork-lift or pallet truck (check load capacity!); iron bar, jack and rollers
- Pozidrive and Torx (2.5–6 mm) screwdrivers for the tightening of the frame screws
- torque wrench
- set of wrenches or sockets for joining shipping splits.


## Moving the unit

...by crane



Use the steel lifting lugs attached to the top of the cabinet. Insert the lifting ropes or slings into the holes of the lifting lugs.


The lifting lugs can be removed (not mandatory) once the cabinet is in its final position. **If the lifting lugs are removed, the bolts must be refastened to retain the degree of protection of the cabinet.**



### IP54 units

Allowed minimum height of lifting ropes or slings for IP54 units is 2 metres.

### ...by fork-lift or pallet truck




The centre of gravity may be quite high. Be therefore careful when transporting the unit. Tilting the cabinets must be avoided.

The units are to be moved only in the upright position.

If using a pallet truck, check its load capacity before attempting to move the unit.

### ...on rollers

(Not allowed with Marine versions)




Remove the wooden bottom frame which is part of the shipment.

Lay the unit on the rollers and move it carefully until close to its final location.

Remove the rollers by lifting the unit with a crane, fork-lift, pallet truck or jack as described above.

### Laying the unit on its back




If the cabinet needs to be laid on its back, it must be supported from below beside the cubicle seams as shown.

#### Notes:

- Transportation of a unit on its back is only allowed if the unit is equipped for such transportation at the factory.
- Never lay or transport a unit with sine filters (i.e. with option code +E206) on its back.

### Final placement of the unit



The cabinet can be moved into its final position with an iron bar and a wooden piece at the bottom edge of the cabinet. Care is to be taken to properly place the wooden piece so as not to damage the cabinet frame.

## Before installation

### Delivery check

The drive delivery contains:

- drive cabinet line-up
- optional modules (if ordered) installed into the control rack at the factory
- ramp for extracting supply and inverter modules from the cabinet
- hardware manual
- appropriate firmware manuals and guides
- optional module manuals
- delivery documents.





Check that there are no signs of damage. Before attempting installation and operation, check the information on the type designation label of the drive to verify that the unit is of the correct type. The label includes an IEC and NEMA rating, C-UL US, and CSA markings, a type code and a serial number, which allow individual recognition of each unit. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week respectively. The remaining digits complete the serial number so that there are no two units with the same serial number.

The type designation label is located on the supply unit door.



Each power module (i.e. supply and inverter module) is also individually labelled.

## Installation procedure



See detailed instructions in the following few pages.

(1) The cabinet can be installed with its back against a wall, or back-to-back with another unit. Fasten the unit (or first shipping split) to the floor with fastening clamps or through the holes inside the cabinet. See section [Fastening the cabinet to the floor \(Non-marine units\)](#).

With marine versions, fasten the unit (or first shipping split) to the floor and wall/roof as described in section [Fastening the unit to the floor and wall \(Marine units\)](#).

**Note:** A clearance of 400 mm minimum above the basic roof level of the cabinet (see inset on left) is required for cooling.

**Note:** Leave some space at the left-hand and right-hand sides of the line-up (A) to allow the doors to open sufficiently.

**Note:** Any height adjustment must be done before fastening the units or shipping splits together. Height adjustment can be done by using metal shims between the bottom frame and floor.

(2) Remove the lifting bars (if present). In marine units, also replace the lifting lugs with L-profiles (see below). Use the original bolts to block any unused holes.

(3) If the line-up consists of shipping splits, fasten the first split to the second. Each shipping split includes a joining cubicle where the busbars connect to the next split.

(4) Fasten the second shipping split to the floor.

(5) Join the DC busbars and the PE busbars.

(6) Repeat steps (2) to (5) for the remaining shipping splits.


## Fastening the cabinet to the floor (Non-marine units)

The cabinet is to be fastened to the floor by using clamps along the edge of the cabinet bottom, or by bolting the cabinet to the floor through the holes inside.


### Clamping

Insert the clamps into the twin slots along the front and rear edges of the cabinet frame body and fasten them to the floor with a bolt. The recommended maximum distance between the clamps is 800 mm (31.5").


If there is not enough working space behind the cabinet for mounting, replace the lifting lugs at the top with L-brackets (not included) and fasten the top of the cabinet to the wall.



Slot detail, front view  
(dimensions in millimetres)




Clamp dimensions (in millimetres)



Distances between slots

Cubicle Width (mm)	Distance in millimetres and (inches)
300	150 (5.9")
400	250 (9.85")
600	450 (17.7")
700	550 (21.65")
800	650 (25.6")




Fastening the cabinet at the top with L-brackets (side view)


Holes inside the cabinet

The cabinet can be fastened to the floor using the fastening holes inside the cabinet, if they are accessible. The recommended maximum distance between the fastening points is 800 mm (31.5”).

If there is not enough working space behind the cabinet for mounting, replace the lifting lugs at the top with L-brackets (not included) and fasten the top of the cabinet to the wall.




Fastening holes inside the cabinet (arrowed)




Fastening the cabinet at the top with L-brackets (side view)

Distances between fastening holes  
Bolt size: M10 to M12 (3/8” to 1/2”).

Cubicle Width	Distance between holes	
		Outer Ø31 mm (1.22”)
300	150 mm (5.9”)	
400	250 (9.85”)	
600	450 (17.7”)	
700	550 (21.65”)	
800	650 (25.6”)	


**Added width:**  
Side panels of the cabinet: 15 mm (0.6”)  
Back panel of the cabinet: 10 mm (0.4”)  
Gap between cubicles (mm):





## Fastening the unit to the floor and wall (Marine units)

The unit must be fastened to the floor and roof (wall) as follows:




① Bolt the unit to the floor through the holes in each flat bar at the base of the cabinet using M10 or M12 screws.

② If there is not enough room behind the cabinet for installation, clamp the rear ends of the flat bars as shown in figure (2).


③ Fasten the top of the cabinet to the rear wall and/or roof using brackets.

①




Use M10 or M12 screws; welding is not recommended (see section [Electric welding](#) below).

②




③




Fastening the cabinet at the top with brackets (side view)

## Joining the shipping splits

The busbar systems and wiring harnesses of two shipping splits are joined in the common motor terminal cubicle (if present) or a busbar joining cubicle. Special M6 screws for fastening the shipping splits together are enclosed in a plastic bag inside the rightmost cubicle of the first shipping split. The threaded bushings are already mounted on the post.




### Procedure



- Fasten the front post of the joining section with 7 screws to the front frame post of the next cubicle.

- Remove any intermediate or partitioning plates covering the rear posts of the joining cubicle.



- Fasten the rear post of the joining section with seven screws (below the busbar joining part) to the rear post of the next cubicle.
- Replace all partitioning plates in the upper part of it after connecting the DC busbars (see section [Connecting the DC busbars and the PE busbar](#)).


### Connecting the DC busbars and the PE busbar

Horizontal main DC busbars and the PE busbar are connected from the front of the joining cubicle. All necessary materials are located in the joining cubicle.


- Remove the front metal partitioning plate located in the busbar joining cubicle.
- Unscrew the bolts of the joint pieces.
- Connect the busbars with the joint pieces (see figure below). For aluminium busbars, suitable anti-oxidant joint compound must be used to avoid corrosion and to ensure good electrical connection. The oxide layer must be scrubbed off from the joints before applying the compound.
- Refit all shrouds for safety of personnel.

### DC busbars

The DC busbar connection is shown below.




Side view of single busbar connection



### PE busbar


The PE busbar runs continuously through the line-up near the floor at the back. The connection is shown below. No separate nuts are needed.




## Miscellaneous

### Cable duct in the floor below the cabinet

A cable duct can be constructed below the 400 mm wide middle part of the cabinet. The cabinet weight lies on the two 100 mm wide transverse sections which the floor must carry.



Prevent the cooling air flow from the cable duct to the cabinet by bottom plates. To ensure the degree of protection for the cabinet use the original bottom plates delivered with the unit. With user-defined cable entries, take care of the degree of protection, fire protection and EMC compliance.




### Cooling air intake through bottom of cabinet

Units with air intake through the bottom of the cabinet (optional feature) are intended for installation on an air duct in the floor. The required air inlets in the floor are as listed below. Refer also to the dimensional drawings delivered with the unit.

- for DSU supply cubicles:  $w \times 505$  mm, where  $w$  equals cubicle width – 50 mm
- for ISU supply cubicles, inverter unit cubicles, control cubicles, switch/breaker cubicles:  $w \times 400$  mm, where  $w$  equals cubicle width – 50 mm
- $w \times 130$  mm at the back of the cabinet line-up, where  $w$  equals the total width of adjacent cubicles with air inlets. This area may or may not be consistent through the width of the whole line-up.

#### Example



#### Notes:

- The plinth of the cabinet must be supported all round.
- The air duct must be able to supply a sufficient volume of cooling air. The minimum air flow values are given in the *Technical data* section of the *Hardware Manual*.
- The cubicles of diode supply units require a larger air inlet area than other cubicles.
- Some cubicles (mainly those without active, heat-generating components) require no air inlet.

## Electric welding

It is not recommended to fasten the cabinet by welding.

### Cabinets without flat bars at the base

- Connect the return conductor of the welding equipment to the cabinet frame at the bottom within 0.5 metres of the welding point.

### Cabinets with flat bars at the base

- Weld only the flat bar under the cabinet, never the cabinet frame itself.
- Clamp the welding electrode onto the flat bar about to be welded or onto the floor within 0.5 metres of the welding point.



---

**WARNING!** If the welding return wire is connected improperly, the welding circuit may damage electronic circuits in the cabinet. The thickness of the zinc coating of the cabinet frame is 100 to 200 micrometres; on the flat bars the coating is approximately 20 micrometres. Ensure that the welding fumes are not inhaled.

---





# Planning the electrical installation

---

## What this chapter contains

This chapter contains the instructions that you must follow when selecting the motor, cables, protections, cable routing and way of operation for the drive system.

---

**Note:** The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

---

## Motor selection and compatibility

1. Select the motor according to the rating tables in chapter *Technical Data*. Use the DriveSize PC tool if the default load cycles are not applicable.
2. Check that the motor ratings lie within the allowed ranges of the drive control program:
  - motor nominal voltage is  $1/2 \dots 2 \cdot U_N$  of the drive
  - motor nominal current is  $1/6 \dots 2 \cdot I_{2hd}$  of the drive in DTC control and  $0 \dots 2 \cdot I_{2hd}$  in scalar control. The control mode is selected by a drive parameter.
3. Check that the motor voltage rating meets the application requirements:
  - The motor voltage is selected according to the AC voltage feeding the drive when the drive is equipped with a diode input bridge (a non-regenerative drive) and will operate in motor mode (i.e. no braking).
  - The motor nominal voltage is selected according to “the equivalent AC power source voltage of the drive” if the intermediate DC circuit voltage of the drive is increased from the nominal level by resistor braking or by the control program of a regenerative IGBT line side converter (parameter selectable function).

The equivalent AC power source voltage for the drive is calculated as follows:

$$U_{ACeq} = U_{DCmax}/1.35$$

where

$U_{ACeq}$  = equivalent AC power source voltage of the drive

$U_{DCmax}$  = maximum intermediate DC circuit voltage of the drive

See notes 6 and 7 below the [Requirements table](#).

4. Consult the motor manufacturer before using a motor in a drive system where the motor nominal voltage differs from the AC power source voltage.
5. Ensure that the motor insulation system withstands the maximum peak voltage in the motor terminals. See the [Requirements table](#) below for the required motor insulation system and drive filtering.

**Example:** When the supply voltage is 440 V and the drive is operating in motor mode only, the maximum peak voltage in the motor terminals can be approximated as follows:  $440 \text{ V} \cdot 1.35 \cdot 2 = 1190 \text{ V}$ . Check that the motor insulation system withstands this voltage.

### Protecting the motor insulation and bearings

The output of the drive comprises – regardless of output frequency – pulses of approximately 1.35 times the equivalent mains network voltage with a very short rise time. This is the case with all drives employing modern IGBT inverter technology.

The voltage of the pulses can be almost double at the motor terminals, depending on the attenuation and reflection properties of the motor cable and the terminals. This in turn can cause additional stress on the motor and motor cable insulation.

Modern variable speed drives with their fast rising voltage pulses and high switching frequencies can cause current pulses that flow through the motor bearings, which can gradually erode the bearing races and rolling elements.

The stress on motor insulation can be avoided by using optional ABB du/dt filters. du/dt filters also reduce bearing currents.

To avoid damage to motor bearings, the cables must be selected and installed according to the instructions given in this manual. In addition, insulated N-end (non-driven end) bearings and output filters from ABB must be used according to the following table. Two types of filters are used individually or in combinations:

- du/dt filtering (protects motor insulation system and reduces bearing currents).
- common mode filtering (CMF) (mainly reduces bearing currents).

### Requirements table

The following table shows how to select the motor insulation system and when an optional ABB du/dt filter, insulated N-end (non-driven end) motor bearings and ABB common mode filters are required. The motor manufacturer should be consulted regarding the construction of the motor insulation and additional requirements for explosion-safe (EX) motors. Failure of the motor to fulfil the following requirements or improper installation may shorten motor life or damage the motor bearings.

Manufacturer	Motor type	Nominal mains voltage (AC line voltage)	Requirement for								
			Motor insulation system	ABB du/dt filter, insulated N-end bearing and ABB common mode filter							
				$P_N < 100 \text{ kW}$ and frame size < IEC 315	$100 \text{ kW} \leq P_N < 350 \text{ kW}$ or frame size $\geq$ IEC 315	$P_N \geq 350 \text{ kW}$ or frame size $\geq$ IEC 400					
				$P_N < 134 \text{ HP}$ and frame size < NEMA 500	$134 \text{ HP} \leq P_N < 469 \text{ HP}$ or frame size $\geq$ NEMA 500	$P_N \geq 469 \text{ HP}$ or frame size > NEMA 580					
A B B	Random-wound M2_ and M3_ 	$U_N \leq 500 \text{ V}$	Standard	-	+ N	+ N + CMF					
		$500 \text{ V} < U_N \leq 600 \text{ V}$	Standard	+ du/dt	+ du/dt + N	+ du/dt + N + CMF					
			or								
			Reinforced	-	+ N	+ N + CMF					
		$600 \text{ V} < U_N \leq 690 \text{ V}$	Reinforced	+ du/dt	+ du/dt + N	+ du/dt + N + CMF					
	Form-wound HX_ and AM_ 	$380 \text{ V} < U_N \leq 690 \text{ V}$	Standard	n.a.	+ N + CMF	$P_N < 500 \text{ kW}$ : + N + CMF					
						$P_N \geq 500 \text{ kW}$ : + N + CMF + du/dt					
	Old* form-wound HX_ and modular	$380 \text{ V} < U_N \leq 690 \text{ V}$	Check with the motor manufacturer.	+ du/dt with voltages over 500 V + N + CMF							
Random-wound HX_ and AM_**	$0 \text{ V} < U_N \leq 500 \text{ V}$	Enamelled wire with fibre glass taping	+ N + CMF								
	$500 \text{ V} < U_N \leq 690 \text{ V}$		+ du/dt + N + CMF								
N O N - A B B	Random-wound and form-wound	$U_N \leq 420 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	-	+ N or CMF	+ N + CMF					
							$420 \text{ V} < U_N \leq 500 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	+ du/dt	+ du/dt + N	+ du/dt + N + CMF
										or	
					+ du/dt + CMF						
		or									
		$420 \text{ V} < U_N \leq 500 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$ , 0.2 $\mu\text{s}$ rise time	-	+ N or CMF	+ N + CMF					
							$500 \text{ V} < U_N \leq 600 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$	+ du/dt	+ du/dt + N	+ du/dt + N + CMF
										or	
					+ du/dt + CMF						
		or									
		$500 \text{ V} < U_N \leq 600 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	-	+ N or CMF	+ N + CMF					
							$600 \text{ V} < U_N \leq 690 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	+ du/dt	+ du/dt + N	+ du/dt + N + CMF
			Reinforced: $\hat{U}_{LL} = 2000 \text{ V}$ , 0.3 $\mu\text{s}$ rise time ***	-	N + CMF	N + CMF					

- \* manufactured before 1.1.1998
- \*\* For motors manufactured before 1.1.1998, check for additional instructions with the motor manufacturer.
- \*\*\* If the intermediate DC circuit voltage of the drive will be increased from the nominal level by resistor braking or by the IGBT supply unit control program (parameter selectable function), check with the motor manufacturer if additional output filters are needed in the applied drive operation range.

**Note 1:** The abbreviations used in the table are defined below.

Abbreviation	Definition
$U_N$	nominal voltage of the supply network
$\hat{U}_{LL}$	peak line-to-line voltage at motor terminals which the motor insulation must withstand
$P_N$	motor nominal power
du/dt	du/dt filtering at the output of the drive (+E205)
CMF	common mode filtering (+E208)
N	N-end bearing: insulated motor non-driven end bearing
n.a.	Motors of this power range are not available as standard units. Consult the motor manufacturer.

**Note 2: Explosion-safe (EX) motors**

The motor manufacturer should be consulted regarding the construction of the motor insulation and additional requirements for explosion-safe (EX) motors.

**Note 3: High-output motors and IP 23 motors**

For motors with higher rated output than what is stated for the particular frame size in EN 50347 (2001) and for IP 23 motors, the requirements of ABB random-wound motor series M3AA, M3AP, M3BP are given below. For other motor types, see the [Requirements table](#) above. Apply the requirements of range “100 kW <  $P_N$  < 350 kW” to motors with  $P_N$  < 100 kW. Apply the requirements of range  $P_N \geq 350$  kW to motors within the range “100 kW <  $P_N$  < 350 kW”. In other cases, consult the motor manufacturer.

Manufacturer	Motor type	Nominal mains voltage (AC line voltage)	Requirement for			
			Motor insulation system	ABB du/dt filter, insulated N-end bearing and ABB common mode filter		
				$P_N < 55$ kW	$55 \text{ kW} \leq P_N < 200$ kW	$P_N \geq 200$ kW
				$P_N < 74$ HP	$74 \text{ HP} \leq P_N < 268$ HP	$P_N \geq 268$ HP
A B B	Random-wound M3AA, M3AP, M3BP	$U_N \leq 500$ V	Standard	-	+ N	+ N + CMF
		$500 \text{ V} < U_N \leq 600$ V	Standard	+ du/dt	+ du/dt + N	+ du/dt + N + CMF
			or			
			Reinforced	-	+ N	+ N + CMF
		$600 \text{ V} < U_N \leq 690$ V	Reinforced	+ du/dt	+ du/dt + N	+ du/dt + N + CMF

**Note 4: HXR and AMA motors**

All AMA machines (manufactured in Helsinki) for drive systems have form-wound windings. All HXR machines manufactured in Helsinki starting 1.1.1998 have form-wound windings.

**Note 5: ABB motors of types other than M2\_, M3\_, HX\_ and AM\_**

Use the selection criteria given for non-ABB motors.

**Note 6: Resistor braking of the drive**

When the drive is in braking mode for a large part of its operation time, the intermediate circuit DC voltage of the drive increases, the effect being similar to increasing the supply voltage by up to 20 percent. The voltage increase should be taken into consideration when determining the motor insulation requirement.


Example: Motor insulation requirement for a 400 V application must be selected as if the drive were supplied with 480 V.

**Note 7: Drives with an IGBT supply unit**

If voltage is raised by the drive (this is a parameter selectable function for special applications only), select the motor insulation system according to the increased intermediate circuit DC voltage level, especially in the 500 V supply voltage range.

**Note 8: Calculating the rise time and the peak line-to-line voltage**

The peak line-to-line voltage at the motor terminals generated by the drive as well as the voltage rise time depend on the cable length. The requirements for the motor insulation system given in the table are "worst case" requirements covering installations with 30-metre and longer cables. The rise time can be calculated as follows:  $\Delta t = 0.8 \cdot \hat{U}_{LL} / (du/dt)$ . Read  $\hat{U}_{LL}$  and  $du/dt$  from the diagrams below. Multiply the values of the graph by the supply voltage ( $U_N$ ). In case of drives with an IGBT supply unit or resistor braking, the  $\hat{U}_{LL}$  and  $du/dt$  values are approximately 20% higher.



**Note 9: Sine filters**

Sine filters protect the motor insulation system. Therefore, a  $du/dt$  filter can be replaced with a sine filter. The peak phase-to-phase voltage with a sine filter is approximately  $1.5 \times U_N$ .

## Permanent magnet synchronous motor

Only one permanent magnet motor can be connected to the inverter output.

It is recommended to install a safety switch between a permanent magnet synchronous motor and the motor cable. The switch is needed to isolate the motor during any maintenance work on the drive.

## Thermal overload and short-circuit protection

### Thermal overload protection of the drive and the input and motor cables

The drive protects itself and the input and motor cables against thermal overload when the cables are dimensioned according to the nominal current of the drive. No additional thermal protection devices are needed.



**WARNING!** If the drive is connected to multiple motors, a separate thermal overload

switch or a circuit breaker must be used for protecting each cable and motor. These devices may require a separate fuse to cut off the short-circuit current.

---

### Thermal overload protection of the motor

According to regulations, the motor must be protected against thermal overload and the current must be switched off when overload is detected. The drive includes a motor thermal protection function that protects the motor and switches off the current when necessary. Depending on a drive parameter value, the function either monitors a calculated temperature value (based on a motor thermal model) or an actual temperature indication given by motor temperature sensors. The user can tune the thermal model further by feeding in additional motor and load data.

See the firmware manual for more information on the motor thermal protection, and the connection and use of the temperature sensors.

### Protection against short-circuit in the motor cable

The drive protects the motor cable and the motor in a short-circuit situation when the motor cable is dimensioned according to the nominal current of the drive. No additional protection devices are needed.

### Protection against short-circuit inside the drive or in the supply cable

- If the drive is equipped with internal AC fuses (option code +F260), install external protection (such as fuses) at the supply to protect the input cable.
- If the drive is not equipped with AC input fuses, install external fuses at the supply to protect the input cable and the drive. Use the AC fuse types listed in the chapter [Technical data](#) on page 120, or equivalent fuses. Six fuses are needed for each DSU module.



**WARNING!** Circuit breakers are not capable of providing sufficient protection because they are inherently slower than fuses. Always use fuses with circuit breakers.

---

## Earth fault (Ground fault) protection

Both the supply unit and the inverter unit are equipped with an internal earth fault protective function to protect the drive against earth faults in the drive, motor and motor cable (This is not a personal safety or a fire protection feature). The function is not active in the supply unit by default. Both earth fault protective functions can be disabled; refer to *User's Manual* of the supply unit and the *Firmware Manual* of the drive application program respectively.

See the *ACS800 Ordering Information* (3AFY64556568 [English], available on request) for other available earth fault protection options.

The EMC filter (if present) includes capacitors connected between the main circuit and the frame. These capacitors and long motor cables increase the earth leakage current and may cause fault current circuit breakers to function.

## Emergency stop devices

For safety reasons, install the emergency stop devices at each operator control station and at other operating stations where emergency stop may be needed. Pressing the stop key (⏻) on the control panel of the drive, or turning the operating switch of the drive from position “1” to “0” does not generate an emergency stop of the motor or separate the drive from dangerous potential.

An emergency stop function is optionally available for stopping and switching off the whole drive. Two modes are available: immediate removal of power (Category 0) and controlled emergency stop (Category 1).

### Restarting after an emergency stop

After an emergency stop, the emergency stop button must be released and a reset performed before the main contactor (or air circuit breaker) can be closed and the drive started.

## Prevention of unexpected start

The drive can be equipped with an optional prevention of unexpected start function according to standards IEC/EN 60204-1: 1997; ISO/DIS 14118: 2000 and EN 1037: 1996. The circuit conforms to EN954-1, Category 3.

The function is achieved by disconnecting the control voltage to the power semiconductors of the inverters of the drive. Thus it is not possible for the power semiconductors to switch and generate the AC voltage needed to rotate the motor. In case of faulty main circuit components, the DC voltage from the busbars can be conducted to the motor but an AC motor cannot rotate without the field generated by an AC voltage.

The operator activates the prevention of unexpected start function using a switch mounted on a control desk. When the function is activated, the switch is opened, and an indicator lamp will light.



**WARNING!** The prevention of unexpected start function does not disconnect the voltage of the main and auxiliary circuits from the drive. Therefore maintenance work on electrical parts of the drive can only be carried out after isolating the drive system from the main supply.

**Note:** If a running drive is stopped by using the prevention of unexpected start function, the drive will cut off the motor supply voltage and the motor will coast to stop.

## Selecting the power cables

### General rules

Dimension the supply (input power) and motor cables **according to local regulations**:

- The cable must be able to carry the drive load current. See chapter *Technical data* for the rated currents.
- The cable must be rated for at least 70 °C maximum permissible temperature of conductor in continuous use. For US, see [Additional US requirements](#).
- The inductance and impedance of the PE conductor/cable (grounding wire) must be rated according to permissible touch voltage appearing under fault conditions (so that the fault point voltage will not rise excessively when an ground fault occurs).
- 600 VAC cable is accepted for up to 500 VAC. For 690 VAC rated equipment, the rated voltage between the conductors of the cable should be minimum 1 kV.

For drive frame size R5 and larger, or motors larger than 30 kW, symmetrical shielded motor cable must be used (figure below). A four-conductor system can be used up to frame size R4 with up to 30 kW motors, but shielded symmetrical motor cable is recommended.

---

**Note:** When continuous conduit is employed, shielded cable is not required.

---

A four-conductor system is allowed for input cabling, but shielded symmetrical cable is recommended. To operate as a protective conductor, the shield conductivity must be as follows when the protective conductor is made of the same metal as the phase conductors:

Cross-sectional area of the phase conductors $S \text{ (mm}^2\text{)}$	Minimum cross-sectional area of the corresponding protective conductor $S_p \text{ (mm}^2\text{)}$
$S \leq 16$	$S$
$16 < S \leq 35$	16
$35 < S$	$S/2$

Compared to a four-conductor system, the use of symmetrical shielded cable reduces electromagnetic emission of the whole drive system as well as motor bearing currents and wear.

---

**Note:** The cabinet configuration of the drive may require multiple supply and/or motor cabling. Refer to the connection diagrams in [Electrical installation](#).


---

The motor cable and its PE pigtail (twisted screen) should be kept as short as possible in order to reduce electromagnetic emission as well as capacitive current.





## Alternative power cable types

Power cable types that can be used with the drive are represented below.




A separate PE conductor is required if the conductivity of the cable shield is < 50 % of the conductivity of the phase conductor.



## Motor cable shield

To effectively suppress radiated and conducted radio-frequency emissions, the shield conductivity must be at least 1/10 of the phase conductor conductivity. The requirements are easily met with a copper or aluminium shield. The minimum requirement of the motor cable shield of the drive is shown below. It consists of a concentric layer of copper wires with an open helix of copper tape. The better and tighter the shield, the lower the emission level and the bearing currents.



## Additional US requirements

Type MC continuous corrugated aluminum armor cable with symmetrical grounds or shielded power cable must be used for the motor cables if metallic conduit is not used. For the North American market, 600 VAC cable is accepted for up to 500 VAC. 1000 VAC cable is required above 500 VAC (below 600 VAC). For drives rated over 100 amperes, the power cables must be rated for 75 °C (167 °F).

### *Conduit*

Where conduits must be coupled together, bridge the joint with a ground conductor bonded to the conduit on each side of the joint. Bond the conduits also to the drive enclosure. Use separate conduits for input power, motor, brake resistors, and control wiring. When conduit is employed, type MC continuous corrugated aluminum armor cable or shielded cable is not required. A dedicated ground cable is always required.

---

Do not run motor wiring from more than one drive in the same conduit.

---

### *Armored cable / shielded power cable*

The motor cables can be run in the same cable tray as other 460 V or 600 V power wiring. Control and signal cables must not be run in the same tray as power cables. Six conductor (3 phases and 3 ground) type MC continuous corrugated aluminum armor cable with symmetrical grounds is available from the following suppliers (trade names in parentheses):

- Anixter Wire & Cable (Philsheath)
- BICC General Corp (Philsheath)
- Rockbestos Co. (Gardex)
- Oaknite (CLX).

Shielded power cables are available from Belden, LAPPKABEL (ÖLFLEX) and Pirelli, among others.

## Power factor compensation capacitors

Power factor compensation is not needed with AC drives. However, if a drive is to be connected to a system with compensation capacitors already installed, note the following restrictions.



**WARNING!** Do not connect power factor compensation capacitors to the motor cables (between the drive and the motor). They are not meant to be used with AC drives and can cause permanent damage to the drive or themselves.

If there are power factor compensation capacitors in parallel with the three-phase input of the drive:

- Do not connect a high-power capacitor to the power line while the drive is connected. The connection will cause voltage transients that may trip or even damage the drive.
- If capacitor load is increased/decreased step by step when the AC drive is connected to the power line, ensure that the connection steps are low enough not to cause voltage transients that would trip the drive.
- Check that the power factor compensation unit is suitable for use in systems with AC drives, i.e. harmonic-generating loads. In such systems, the compensation unit should typically be equipped with a blocking reactor or harmonic filter.

## Equipment connected to the motor cable

### Installation of safety switches, contactors, connection boxes, etc.

To minimize the emission level when safety switches, contactors, connection boxes or similar equipment are installed in the motor cable between the drive and the motor:

- EU: Install the equipment in a metal enclosure with 360 degrees grounding for the shields of both the incoming and outgoing cables, or in another way connect the shields of the cables together.
- US: Install the equipment in a metal enclosure in a way that the conduit or motor cable shielding runs consistently without breaks from the drive to the motor.

### *Bypass connection*



**WARNING!** Never connect the supply power to the drive output terminals U2, V2 and W2. If frequent bypassing is required, employ mechanically connected switches or contactors. Mains (line) voltage applied to the output can result in permanent damage to the unit.

### Before opening an output contactor (in DTC motor control mode)

Stop the drive and wait for the motor to stop before opening a contactor between the output of the drive and the motor when the DTC control mode is selected. (See the

*Firmware Manual* of the drive for the required parameter settings.) Otherwise, the contactor will be damaged.


In scalar control, the contactor can be opened with the drive running.

## Relay output contacts and inductive loads

Inductive loads (such as relays, contactors, motors) cause voltage transients when switched off.

The relay contacts of the RMIO board are protected with varistors (250 V) against overvoltage peaks. In spite of this, it is highly recommended to equip inductive loads with noise attenuating circuits (varistors, RC filters [AC] or diodes [DC]) in order to minimize the EMC emission at switch-off. If not suppressed, the disturbances may connect capacitively or inductively to other conductors in the control cable and form a risk of malfunction in other parts of the system.

Install the protective component as close to the inductive load as possible. Do not install the protective components at the terminal block.




## Selecting the control cables

All control cables must be shielded.

Use a double-shielded twisted pair cable (see figure a) for analogue signals. This type of cable is recommended for the pulse encoder signals also. Employ one individually shielded pair for each signal. Do not use common return for different analogue signals.

A double-shielded cable is the best alternative for low-voltage digital signals but single-shielded twisted multipair cable (figure b) is also usable.



Run analogue and digital signals in separate, shielded cables.

Relay-controlled signals, providing their voltage does not exceed 48 V, can be run in the same cables as digital input signals. It is recommended that the relay-controlled signals be run as twisted pairs.

Never mix 24 VDC and 115 / 230 VAC signals in the same cable.

### Relay cable

The cable type with braided metallic screen (e.g. ÖLFLEX LAPPKABEL, Germany) has been tested and approved by ABB.

### Control panel cable

In remote use, the cable connecting the control panel to the drive must not exceed 3 metres (10 ft). The cable type tested and approved by ABB is used in control panel option kits.

### Coaxial cable (for use with Advant Controllers AC 80/AC 800)

- 75 ohm
- RG59, diameter 7 mm or RG11, diameter 11 mm
- Maximum cable length: 300 m (1000 ft)

## Connection of a motor temperature sensor to the drive I/O

---



**WARNING!** IEC 60664 requires double or reinforced insulation between live parts and the surface of accessible parts of electrical equipment which are either non-conductive or conductive but not connected to the protective earth.

To fulfil this requirement, the connection of a thermistor (and other similar components) to the digital inputs of the drive can be implemented in three alternate ways:

1. There is double or reinforced insulation between the thermistor and live parts of the motor.
  2. Circuits connected to all digital and analogue inputs of the drive are protected against contact and insulated with basic insulation (the same voltage level as the drive main circuit) from other low voltage circuits.
  3. An external thermistor relay is used. The insulation of the relay must be rated for the same voltage level as the main circuit of the drive. For connection, see the *Firmware Manual*.
- 

## Installation sites above 2000 metres (6562 feet)

---



**WARNING!** Protect against direct contact when installing, operating and servicing the RMIO board wiring and optional modules attached to the board. The Protective Extra Low Voltage (PELV) requirements stated in EN 50178 are not fulfilled at altitudes above 2000 m (6562 ft).

---


## Routing the cables

Route the motor cable away from other cable routes. Motor cables of several drives can be run in parallel installed next to each other. It is recommended that the motor cable, input power cable and control cables be installed on separate trays. Avoid long parallel runs of motor cables with other cables in order to decrease electromagnetic interference caused by the rapid changes in the drive output voltage.


Where control cables must cross power cables make sure they are arranged at an angle as near to 90 degrees as possible. Do not run extra cables through the drive.

The cable trays must have good electrical bonding to each other and to the grounding electrodes. Aluminium tray systems can be used to improve local equalizing of potential.


A diagram of the cable routing is below.



### Control cable ducts



Not allowed unless the 24 V cable is insulated for 230/120 V or insulated with insulation sleeving for 230/120 V.



Lead 24 V and 230/120 V control cables in separate ducts inside the cabinet.





# Electrical installation

---

## What this chapter contains

This chapter describes the electrical installation procedure of the drive.



**WARNING!** Only qualified electricians are allowed to carry out the work described in this chapter. Follow the [Safety instructions](#) on the first pages of this manual. Ignoring the safety instructions can cause injury or death.

---



**WARNING!** During the installation procedure, the supply and inverter modules may have to be temporarily extracted from the cabinet. The modules are heavy, and have a high centre of gravity. In order to minimise the danger of toppling over, keep the sheet metal support supplied with the drive attached to the modules whenever manoeuvring them outside the cabinet.

---

## Before installation

### Checking the insulation of the assembly

Every drive has been tested for insulation between the main circuit and the chassis (2500 V rms 50 Hz for 1 second) at the factory. Therefore, do not make any voltage tolerance or insulation resistance tests (e.g. hi-pot or megger) on any part of the drive. When checking the insulation of the assembly, proceed in the following manner:



**WARNING!** Check the insulation before connecting the drive to the supply. Make sure that the drive is disconnected from the supply (input power).


---

### Motor and motor cable

Check the insulation of the motor and motor cable as follows:

1. Check that the motor cable is connected to the motor, and disconnected from the drive output terminals U2, V2 and W2.
2. Measure the insulation resistance of the motor cable and motor between each phase and the Protective Earth using a measuring voltage of 500 VDC. The insulation resistance of an ABB motor must exceed 10 Mohm (reference value at 25 °C). For the insulation resistance of other motors, please consult the manufacturer's instructions.

- **Note:** Moisture inside the motor casing will reduce the insulation resistance. If this is suspected, dry the motor and repeat the measuring.



### IT (ungrounded) systems

EMC filter +E202 is not suitable for use in an IT (ungrounded) system. If the drive is equipped with EMC filter +E202, disconnect the filter before connecting the drive to the supply network. For detailed instructions on how to do this, please contact your local ABB representative.



**WARNING!** If a drive with EMC filter +E202 is installed on an IT system [an ungrounded power system or a high resistance-grounded (over 30 ohms) power system], the system will be connected to earth potential through the EMC filter capacitors of the drive. This may cause danger or damage the unit.

### Setting the earth fault (ground fault) trip level

#### *Grounded systems*

See page [28](#).

#### *IT (ungrounded) systems*


On ungrounded systems, an external monitoring unit (Bender IRDH265 or IRDH275, option **+Q954**) is used. Refer to its documentation for set-up instructions.

**Note:** On ungrounded systems, the internal earth current monitoring must be deactivated. See page [28](#).

## Input power connection – Units without load switch-disconnector or air circuit breaker

### Connection diagrams


*6-pulse connection, two supply modules in parallel*



#### Notes:

- No parallel cabling is shown here.
- Each input terminal of the supply modules must be fed through a dedicated fuse. The fuses are specified in [Technical data](#).
- \*) Contactors are optional

### 12-pulse connection, two supply modules in parallel



#### Notes:

- No parallel cabling (for each module) is shown here.

It is also possible to connect all input power terminals of module 1 to the transformer Y-output and module 2 to the transformer D-output. Note, however, that then the two bridges inside a single module do not form a 12-pulse connection any more. This means that the benefits of the 12-pulse connection are not available during a temporary operation with one module out of use (e.g. for maintenance).

- Each input terminal of the supply modules must be fed through a dedicated fuse. The fuses are specified in [Technical data](#).
- The secondaries of the transformer must not be grounded.
- \*) Contactors are optional


## Connection procedure



**WARNING!** The supply modules are heavy and have a high centre of gravity. Be careful when manoeuvring the modules.


Removal of module:

- (1) Turn the supply (rectifier) module switch-disconnector handle to open position.
- (2) Release the door handle and open the supply unit door.
- (3) Remove the fastening screws at the top of the module.
- (3b) Units with marine construction (+C121) only: Remove fan (see page 107 for instructions) and the two fastening screws at the rear bottom of the module frame.
- (4) Loosen the connector locking screw (hexagonal socket head).
- (5) Place the module pull-out ramp against the cabinet base. Make sure the ramp is secured to the cabinet frame.
- (6) Pull the module carefully out of the cabinet along the ramp.



Remove the plastic insulators covering the input power terminals.

Lead the cables into the inside of the cabinet. Make the 360° earthing arrangement at the cable entries as shown below.



Grommet (in IP54 units only)

Connect the cables as follows:

- Twist the cable shields to bundles and connect to cabinet PE (ground) busbar. Connect the separate ground conductors/cables to cabinet PE (ground) busbar.
- Connect the phase conductors to the input power terminals (U1.1 ...). Depending on the cable size, use cable lugs or dual-cable screw lug connectors. For details on the terminals and tightening torques, see [Technical data – Input power connection](#) on page 122, and section [Use of the dual-cable screw lug connector](#) below.




Refit the plastic insulators onto the input power terminals.


Push the module back in – mind your fingers – and tighten the fastening screws. Tighten the connector locking screw to 4 Nm (3 lbf.ft). Please note that the module can only mate with the quick connector when the switch-disconnector is in open position.

Remove the module pull-out ramp and close the cubicle doors.

### *Use of the dual-cable screw lug connector*




### *Removal of the dual-cable screw lug connector*



## Input power connection – Units with load switch-disconnector or air circuit breaker

### Connection diagrams

*6-pulse connection, two supply modules in parallel*



#### Notes:

\*)

Fuses are not required if the input power line is constructed of busbars that withstand the transformer short circuit current.


\*\*)

The cable lead-through details (number and size of holes), and cable connection details (number and dimensions of busbars, tightening torque) are given in chapter [Technical data](#), section [Input power connection](#).

\*\*\*)

There are no contactors inside the supply module(s) when the drive is equipped with an air circuit breaker.

### 12-pulse connection, two supply modules in parallel



#### Notes:

\*)

Fuses are not required if the input power line is constructed of busbars that withstand the transformer short circuit current.

\*\*)

No bridging (connecting 1L1 to 2L1, 1L2 to 2L2, and 1L3 to 2L3) is allowed!

There are two separate incoming cubicles – one for terminals 1L1, 1L2 and 1L3, the other for 2L1, 2L2 and 2L3 – if **a)** the unit is equipped with air circuit breakers, **b)** the drive is UL listed, or **c)** the incoming cubicle is designed for a busbar connection.


The cable lead-through details (number and size of holes), and cable connection details (number and dimensions of busbars, tightening torque) are given in chapter [Technical data](#), section [Input power connection](#).

\*\*\*)

There are no contactors inside the modules when the drive is equipped with air circuit breakers.



## Connection procedure

Open the door of the incoming (load switch-disconnector or air circuit breaker) cubicle.
Remove any shrouds covering the input terminals and cable entries.
Lead the cables into the cubicle. Make the 360° earthing arrangement at the cable entries as shown below.   <p>Grommet (in IP54 units only)</p>
Cut the cables to suitable length.
Strip the cables and conductors.
Twist the cable screens into bundles and connect to cabinet PE (ground) busbar.
Connect the separate ground conductors/cables to cabinet PE (ground) busbar.
Connect the phase conductors to the input terminals using the torques given in chapter <a href="#">Technical data</a> , section <a href="#">Input power connection</a> .
Refit the shrouds removed earlier.
Close the door.


## Motor connection – Units without common motor terminal cubicle

### Output busbars

The motor cables are to be connected to the output busbars behind each inverter module. The location and dimensions of the busbars are visible in the dimensional drawings delivered with the drive, as well as the example drawings presented in this manual.


### Connection diagram

The diagram below shows a drive with a single inverter module. 360° earthing is to be used at cable entries.



The recommended cable types are given in chapter [Planning the electrical installation](#).


Whenever the inverter unit consists of parallel-connected inverter modules, all the modules (two are shown below) are to be **cabled separately** to the motor.



The recommended cable types are given in chapter [Planning the electrical installation](#).



**WARNING!** The cabling from all inverter modules to the motor must be physically identical considering cable type, cross-sectional area, and length.




## Connection procedure




**WARNING!** The inverter modules are heavy and have a high centre of gravity. Be careful when manoeuvring the modules. In order to minimise the danger of toppling over, keep the support legs of the modules extended whenever manoeuvring the modules outside the cabinet.

Extract each inverter module from the cubicle as follows:

- (1) Open the door of the inverter cubicle.
- (2) Remove the shroud covering the upper part of the cubicle.
- (3) Open the transparent cover on the front of the inverter module and disconnect the fibre optic cables. Move the cables aside.
- (4) Remove the L-shaped DC busbars on top of the module.
- (5) Disconnect the terminal block (X50) next to the DC busbars.
- (6) Remove the two module fastening screws (6a) at the top. At the base of the module, loosen the two fastening screws (6b) but leave them in place; lift the bracket (6c) into the up position.
- (7) Insert the module pull-out ramp under the two screws at the base of the module and tighten.
- (8) Pull the module carefully out of the cubicle along the ramp. Make sure the wires do not catch.
- (9) Extend the support legs of the module. Keep the legs extended until the module is about to be inserted back into the cubicle.



Lead the cables into the cabinet below each inverter module. Make the 360° earthing arrangement at the cable entry as shown.



Cut the cables to suitable length.

Strip the cables and conductors.

Twist the cable screens into bundles and connect to cabinet PE (ground) busbar.

Connect any separate ground conductors/cables to cabinet PE (ground) busbar.

Connect the phase conductors to the output terminals.

Use the tightening torques specified in [Technical data – Motor connection](#) on page 124.

Insert each inverter module into the cubicle as follows:


- (1) Move the inverter module close to the ramp, then retract the support legs of the module.
- (2) Push the module back into the cubicle – mind your fingers.
- (3) Refasten the module fixing screws at the top, reconnect the DC busbars.
- (4) Reconnect the cables (X50, fibre optic cables).
- (5) Loosen the module fastening screws at the base of the module and remove the pull-out ramp. Flip the module fastening bracket into the down position and tighten the screws.

Close the doors.


At the motor, connect the cables according to instructions from the motor manufacturer. Pay special attention to the phase order.

For minimum radio frequency interference:

- ground the cable shield 360 degrees at the lead-through of the motor terminal box




- or ground the cable by twisting the shield as follows: flattened width  $\geq 1/5 \times \text{length}$ .



## Motor connection – Units with common motor terminal cubicle

### Connection diagram



The recommended cable types are given in chapter [Planning the electrical installation](#).

### Connection procedure

See the connection procedure on page [83](#).

## Control connections

### Drive control connections

The control connections are made on the terminal blocks provided in the swing-out frame of the drive. Refer to the circuit diagrams delivered with the drive, and to the chapter *Motor control and I/O board (RMIO)*.






### Supply unit control connections

The supply unit is controlled using the local control devices mounted on the cabinet door, or the buttons on the DSSB board. No external control connections by the user are needed. However, the user can connect certain external devices to the supply module. It is possible to:

- control the supply unit through the remote control inputs (On, Start, Reset, External fault)
- halt the supply unit by an external emergency stop button (if the unit is equipped with a local emergency stop button)
- read supply unit's status information through the relay outputs (Fault, Running, External 48 VDC supply on, Earth fault, emergency stop)
- feed the supply unit's control boards from an external +48 VDC supply.

Refer to the circuit diagrams delivered with the drive for the connection terminals for the external control devices. For additional information on the control connections see the *ACA631/633 Cabinet-installed Diode Supply Unit (DSU) User's Manual* (Code: 64735501 [English]), available through ABB representatives.

## Connection procedure

Turn the supply (rectifier) unit switch-disconnector into open position.	
Release the door handle and open the door of the control and I/O cubicle.	
Remove the two locking screws at the edge of the swing-out frame and open the frame.	
Run the cables into the inside of the cabinet through the grommets provided.	
<i>Top entry units only:</i> If several cables need to be run through one grommet, use Loctite 5221 (cat. no. 25551) under the grommet to seal the cable entry.	
Run the cables between the EMI conductive cushions as shown below. Strip the cable at this location to enable proper connection of the bare shield and the cushions. Tighten the cushions firmly onto the cable shields.	
<p>Side view</p>  <p>If the outer surface of a cable shield is non-conductive, turn the shield inside out as shown below and apply copper foil to keep the shielding continuous. Do not cut the grounding wire (if present).</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p><b>Stripped cable</b></p>  <p>← Cable shield</p> </div> <div style="text-align: center;"> <p><b>Conductive surface of the shield exposed</b></p>  </div> <div style="text-align: center;"> <p><b>Stripped part covered with copper foil</b></p>  </div> </div> <p>On top entry units, sort the cables so that the thinnest and thickest cables are at opposite ends of the opening.</p> <p>Top view</p> 	




Run the cables to the swing-out frame as shown below. Wherever possible, use the existing cable trunking (1) in the cabinet. Use sleeving wherever the cables are laid against sharp edges. Leave some slack in the cable at the hinge (2) to allow the frame to open fully. Tie the cables to the braces (3) to provide strain relief.

Swing-out frame open



Cable routing example



Cut the cables to suitable length. Strip the cables and conductors.

Twist the cable shields into bundles and connect them to the ground terminal nearest to the terminal block. Keep the unshielded portion of the cables as short as possible.


Connect the conductors to appropriate terminals (see the chapter [Motor control and I/O board \(RMIO\)](#) and the circuit diagrams delivered with the unit).

Close the swing-out frame, refasten, and close the doors.


## Installation of optional modules and PC

The optional module (such as fieldbus adapter, I/O extension module and the pulse encoder interface) is inserted into the optional module slot of the RDCU drive control unit) and fixed with two screws. See the appropriate optional module manual for further instructions.

### Cabling of I/O and fieldbus modules



### Cabling of pulse encoder interface module



**Note 1:** If the encoder is of unisolated type, ground the encoder cable at the drive end only. If the encoder is galvanically isolated from the motor shaft and the stator frame, ground the encoder cable shield at the drive and the encoder end.


**Note 2:** Twist the pair cable wires.

### Fibre optic link

A DDCS fibre optic link is provided via the RDCO optional module for PC tools, master/follower link, NDIO, NTAC, NAI0, AIMA I/O module adapter and fieldbus adapter modules of type Nxxx. See *RDCO User's Manual* [3AFE 64492209 (English)] for the connections. Observe colour coding when installing fibre optic cables. Blue connectors go to blue terminals, and grey connectors to grey terminals.

When installing multiple modules on the same channel, connect them in a ring.

## Connections and tap settings of the auxiliary voltage transformer



	3~ input			
Supply voltage	Terminals	Tap settings		
		A1 to...	B1 to...	C1 to...
690 V	A1, B1, C1	C2	A2	B2
660 V	A1, B1, C1	C2	A2	B2
600 V	A1, B1, C1	C3	A3	B3
575 V	A1, B1, C1	C3	A3	B3
525 V	A1, B1, C1	C4	A4	B4
500 V	A1, B1, C1	C4	A4	B4
480 V	A1, B1, C1	C5	A5	B5
460 V	A1, B1, C1	C5	A5	B5
440 V	A1, B1, C1	C6	A6	B6
415 V	A1, B1, C1	C6	A6	B6
400 V	A1, B1, C1	C7	A7	B7
380 V	A1, B1, C1	C7	A7	B7

	1~ output				3~ output	
Supply voltage	230 V		115 V		400 V (50 Hz)	320 V (60 Hz)
	Terminals	Tap setting	Terminals	Tap setting	Terminals	Terminals
690 V	a3, n1	230—	a4, n1	115—	a1, b1, c1	a2, b2, c2
660 V	a3, n1	230+	a4, n1	115+	a1, b1, c1	a2, b2, c2
600 V	a3, n1	230—	a4, n1	115—	a1, b1, c1	a2, b2, c2
575 V	a3, n1	230+	a4, n1	115+	a1, b1, c1	a2, b2, c2
525 V	a3, n1	230—	a4, n1	115—	a1, b1, c1	a2, b2, c2
500 V	a3, n1	230+	a4, n1	115+	a1, b1, c1	a2, b2, c2
480 V	a3, n1	230—	a4, n1	115—	a1, b1, c1	a2, b2, c2
460 V	a3, n1	230+	a4, n1	115+	a1, b1, c1	a2, b2, c2
440 V	a3, n1	230—	a4, n1	115—	a1, b1, c1	a2, b2, c2
415 V	a3, n1	230+	a4, n1	115+	a1, b1, c1	a2, b2, c2
400 V	a3, n1	230—	a4, n1	115—	a1, b1, c1	a2, b2, c2
380 V	a3, n1	230+	a4, n1	115+	a1, b1, c1	a2, b2, c2

## Installation of brake resistors

See the chapter [Resistor braking](#).



# Motor control and I/O board (RMIO)

---

## What this chapter contains

This chapter shows

- external control connections to the RMIO board for the the ACS800 Standard Application Program (Factory Macro)
- specifications of the inputs and outputs of the board.

## To which products this chapter applies

This chapter applies to ACS800 units which employ the RMIO board.

## Note on cabinet-installed ACS800 drives

The terminals of the RMIO board are optionally wired to terminal block X2. The connections shown below apply also to terminal block X2 (the markings are identical to the ones on the RMIO board).

Terminals of X2 accept cables from 0.5 to 4.0 mm<sup>2</sup> (22 to 12 AWG). The tightening torque for screw terminals is 0.4 to 0.8 Nm (0.3 to 0.6 lbf.ft). For disconnecting wires from spring terminals, use a screwdriver with a blade thickness of 0.6 mm (0.024") and width of 3.5 mm (0.138"), e.g. Phoenix Contact SZF 1-0,6X3,5.

## Note on terminal labelling

Optional modules (type Rxxx) may have terminal designations that coincide with those of the RMIO board.

Note on external power supply

External +24 V power supply for the RMIO board is recommended if


- the application requires a fast start after the connection of the input power
- fieldbus communication is required when input power is disconnected.

The RMIO board can be supplied from an external power source via terminal X23 or X34 or via both X23 and X34. The internal power supply to terminal X34 can be left connected when using terminal X23.



**WARNING!** If the RMIO board is supplied from an external power source via terminal X34, the loose end of the cable removed from the RMIO board terminal must be secured mechanically to a location where it cannot come into contact with electrical parts. If the screw terminal plug of the cable is removed, the wire ends must be individually insulated.

**WARNING!** If the RMIO board is powered from two power supplies (connected to X23 and X34), and the external power supply connected to X23 is also used to power external equipment, equip the RMIO branch of the circuit with a diode as shown below. The diode ensures that the RMIO board will not be damaged by overcurrent in case the external power supply fails.



Parameter settings

In the Standard Application Program, set parameter 16.09 CTRL BOARD SUPPLY to EXTERNAL 24V if the RMIO board is powered from an external supply.

## External control connections (non-US)

External control cable connections to the RMIO board for the ACS800 Standard Application Program (Factory Macro) are shown below. For external control connections of other application macros and programs, see the appropriate *Firmware Manual*.

### Terminal block size:

cables 0.3 to 3.3 mm<sup>2</sup> (22 to 12 AWG)

### Tightening torque:

0.2 to 0.4 Nm (0.2 to 0.3 lbf ft)

<sup>1)</sup> Only effective if par. 10.03 is set to REQUEST by the user.

<sup>2)</sup> 0 = open, 1 = closed


DI4	Ramp times according to
0	parameters 22.02 and 22.03
1	parameters 22.04 and 22.05

<sup>3)</sup> See par. group 12 CONSTANT SPEEDS.

DI5	DI6	Operation
0	0	Set speed through AI1
1	0	Constant speed 1
0	1	Constant speed 2
1	1	Constant speed 3

<sup>4)</sup> See parameter 21.09 START INTRL FUNC.

<sup>5)</sup> Total maximum current shared between this output and optional modules installed on the board.



## External control connections (US)


External control cable connections to the RMIO board for the ACS800 Standard Application Program (Factory Macro US version) are shown below. For external control connections of other application macros and programs, see the appropriate *Firmware Manual*.

### Terminal block size:

cables 0.3 to 3.3 mm<sup>2</sup> (22 to 12 AWG)

### Tightening torque:

0.2 to 0.4 Nm (0.2 to 0.3 lbf ft)



<sup>1)</sup> Only effective if par. 10.03 is set to REQUEST by the user.

<sup>2)</sup> 0 = open, 1 = closed

DI4	Ramp times according to
0	parameters 22.02 and 22.03
1	parameters 22.04 and 22.05

<sup>3)</sup> See par. group 12 CONSTANT SPEEDS.

DI5	DI6	Operation
0	0	Set speed through AI1
1	0	Constant speed 1
0	1	Constant speed 2
1	1	Constant speed 3

<sup>4)</sup> See parameter 21.09 START INTRL FUNC.

<sup>5)</sup> Total maximum current shared between this output and optional modules installed on the board.



## RMIO board specifications

### Analogue inputs

	With Standard Application Program two programmable differential current inputs (0 mA / 4 mA ... 20 mA, $R_{in} = 100 \text{ ohm}$ ) and one programmable differential voltage input (-10 V / 0 V / 2 V ... +10 V, $R_{in} > 200 \text{ kohm}$ ). The analogue inputs are galvanically isolated as a group.
Isolation test voltage	500 VAC, 1 min
Max. common mode voltage between the channels	$\pm 15 \text{ VDC}$
Common mode rejection ratio	$\geq 60 \text{ dB}$ at 50 Hz
Resolution	0.025 % (12 bit) for the -10 V ... +10 V input. 0.5 % (11 bit) for the 0 ... +10 V and 0 ... 20 mA inputs.
Inaccuracy	$\pm 0.5 \text{ %}$ (Full Scale Range) at 25 °C (77 °F). Temperature coefficient: $\pm 100 \text{ ppm/}^{\circ}\text{C}$ ( $\pm 56 \text{ ppm/}^{\circ}\text{F}$ ), max.

### Constant voltage output

Voltage	+10 VDC, 0, -10 VDC $\pm 0.5 \text{ %}$ (Full Scale Range) at 25 °C (77 °F). Temperature coefficient: $\pm 100 \text{ ppm/}^{\circ}\text{C}$ ( $\pm 56 \text{ ppm/}^{\circ}\text{F}$ ) max.
Maximum load	10 mA
Applicable potentiometer	1 kohm to 10 kohm

### Auxiliary power output

Voltage	24 VDC $\pm 10 \text{ %}$ , short circuit proof
Maximum current	250 mA (shared between this output and optional modules installed on the RMIO)

### Analogue outputs

	Two programmable current outputs: 0 (4) to 20 mA, $R_L \leq 700 \text{ ohm}$
Resolution	0.1 % (10 bit)
Inaccuracy	$\pm 1 \text{ %}$ (Full Scale Range) at 25 °C (77 °F). Temperature coefficient: $\pm 200 \text{ ppm/}^{\circ}\text{C}$ ( $\pm 111 \text{ ppm/}^{\circ}\text{F}$ ) max.

### Digital inputs

	With Standard Application Program six programmable digital inputs (common ground: 24 VDC, -15 % to +20 %) and a start interlock input. Group isolated, can be divided in two isolated groups (see <a href="#">Isolation and grounding diagram</a> below). Thermistor input: 5 mA, $< 1.5 \text{ kohm} \hat{=}$ "1" (normal temperature), $> 4 \text{ kohm} \hat{=}$ "0" (high temperature), open circuit $\hat{=}$ "0" (high temperature). Internal supply for digital inputs (+24 VDC): short circuit proof. An external 24 VDC supply can be used instead of the internal supply.
Isolation test voltage	500 VAC, 1 min
Logical thresholds	$< 8 \text{ VDC} \hat{=}$ "0", $> 12 \text{ VDC} \hat{=}$ "1"
Input current	DI1 to DI 5: 10 mA, DI6: 5 mA
Filtering time constant	1 ms

## Relay outputs

---

	Three programmable relay outputs
Switching capacity	8 A at 24 VDC or 250 VAC, 0.4 A at 120 VDC
Minimum continuous current	5 mA rms at 24 VDC
Maximum continuous current	2 A rms
Isolation test voltage	4 kVAC, 1 minute

## DDCS fibre optic link

---

With optional communication adapter module RDCO. Protocol: DDCS (ABB Distributed Drives Communication System)


## 24 VDC power input

---

Voltage	24 VDC $\pm$ 10%
Typical current consumption (without optional modules)	250 mA
Maximum current consumption	1200 mA (with optional modules inserted)

The terminals on the RMIO board as well as on the optional modules attachable to the board fulfil the Protective Extra Low Voltage (PELV) requirements stated in EN 50178 provided that the external circuits connected to the terminals also fulfil the requirements and the installation site is below 2000 m (6562 ft). Above 2000 m (6562 ft), see page [68](#).

## Isolation and grounding diagram







# Installation checklist and start-up


## Installation checklist

Check the mechanical and electrical installation of the drive before start-up. Go through the checklist below together with another person. Read the [Safety instructions](#) on the first pages of this manual before you work on the unit.

Check...	
<b>MECHANICAL INSTALLATION</b>	
The ambient operating conditions are allowed. See <a href="#">Electrical installation</a> , <i>Technical data: Ratings or Ambient conditions</i> .	<input type="checkbox"/>
The unit is fixed properly to floor. See <a href="#">Mechanical installation</a> .	<input type="checkbox"/>
The cooling air will flow freely.	<input type="checkbox"/>
<b>ELECTRICAL INSTALLATION</b> See <a href="#">Planning the electrical installation</a> , <a href="#">Electrical installation</a> .	
The motor and the driven equipment are ready for start.	<input type="checkbox"/>
The EMC filter (option +E202) is disconnected if the drive is connected to an IT (ungrounded) system.	<input type="checkbox"/>
The drive is grounded properly.	<input type="checkbox"/>
The supply (input power) voltage matches the nominal input voltage of the drive.	<input type="checkbox"/>
The supply (input power) connection to the input terminals are OK and the phase order is correct.	<input type="checkbox"/>
Appropriate supply (input power) fuses and disconnectors are installed.	<input type="checkbox"/>
The motor connections at the output terminals are OK.	<input type="checkbox"/>
The motor cable is routed away from other cables.	<input type="checkbox"/>
Settings of the auxiliary voltage transformer.	<input type="checkbox"/>
There are no power factor compensation capacitors in the motor cable.	<input type="checkbox"/>
The external control connections inside the drive are OK.	<input type="checkbox"/>
There are no tools, foreign objects or dust from drilling inside the drive.	<input type="checkbox"/>
Supply (input power) voltage cannot be applied to the output of the drive (with a bypass connection).	<input type="checkbox"/>
For drives with Category 1 Emergency stop function: The time relay has been set to a suitable value (e.g. somewhat longer than the stop ramp of the inverter units).	<input type="checkbox"/>
All shrouds are in place.	<input type="checkbox"/>

## Start-up procedure

Action	Additional information
 <b>WARNING!</b> Ensure that the disconnecter of the supply transformer is locked to open position, i.e. no voltage is, or cannot be connected to drive inadvertently. Check also by measuring that there is no voltage connected.	
<b>Basic checks with no voltage connected</b> <ul style="list-style-type: none"> <li><input type="checkbox"/> If the unit is equipped with an air circuit breaker, check the current trip limits of the breaker (preset at the factory).  <i>General rule</i>            Ensure the selectivity condition is fulfilled i.e. the breaker trips at a lower current than the protection device of the supplying network, and that the limit is high enough not to cause unnecessary trips during the intermediate DC circuit load peak at start.  <i>Long-term current limit</i>            As a rule of thumb, this should be set to the rated AC current of the module.  <i>Peak current limit</i>            As a rule of thumb, this should be set to a value 3-4 times the rated AC current of the module.</li> <li><input type="checkbox"/> Check the settings of the relays and breakers/switches of the auxiliary circuits.</li> <li><input type="checkbox"/> Disconnect any unfinished or unchecked 230/115 VAC cables that lead from the terminal blocks to the outside of the equipment.</li> <li><input type="checkbox"/> Locate the PPCS branching unit (APBU-xx). Enable memory backup battery by setting actuator 6 of switch S3 to ON.</li> </ul>	<p>Optional device. See the delivery specific circuit diagrams.</p> <p>Optional devices. See delivery specific circuit diagrams.</p> <p>By default, memory backup is switched off to save the battery.</p>
<b>Connecting voltage to input terminals and auxiliary circuit</b>  <b>WARNING!</b> When voltage is connected to the input terminals, voltage may also be connected to the auxiliary circuits of the drive. Make sure that it is safe to apply voltage. Ensure that: <ul style="list-style-type: none"> <li>• nobody is working on the unit or circuits that are wired from outside into the cabinets</li> <li>• cabinet doors are closed</li> <li>• covers of motor terminal boxes are in place.</li> </ul> <ul style="list-style-type: none"> <li><input type="checkbox"/> Open the earthing/grounding switch (if present).</li> <li><input type="checkbox"/> Close the supply (rectifier) unit switch-disconnector.</li> <li><input type="checkbox"/> Close the main breaker of the supply transformer.</li> <li><input type="checkbox"/> Close the auxiliary circuit On/Off switch.</li> </ul>	<p>The earthing/grounding switch and the main disconnecting device are either mechanically or electrically interlocked so that the earthing/grounding switch can only be closed when the main disconnecting switch is open, and vice versa.</p> <p>On units with line contactors, the supply unit charges the contactor control capacitors (3 s at first start). The supply unit performs a fault status check.</p>

Action	Additional information
<b>Starting the supply unit</b>  <b>WARNING!</b> If the drive is equipped with a brake unit, make sure there are inverters connected to the intermediate circuit before start. As a rule of thumb, the sum capacitance of the inverters connected must be at least 30% of the sum capacitance of all inverters.  <input type="checkbox"/> Units with line contactors: Close the contactors and start the supply unit by turning the start switch on the cabinet door from 0 into START position for 2 seconds.	<p>If there is not enough capacitive load at start, the DC voltage will overshoot the controller voltage limit, causing immediate start of braking. An unloaded supply unit keeps the DC voltage high and the chopper remains conductive.</p>
<b>Checks with the supply unit running</b>  <input type="checkbox"/> Activate and check the operation of the power loss ride-through function. (Only if automatic restart is required/allowed after a short power supply break.)  <input type="checkbox"/> Check the settings of the earth fault (ground fault) monitoring device.	<p>See chapter <a href="#">Hardware description</a>.</p> <p>See chapter <a href="#">Electrical installation</a>.</p>
<b>Application program set-up</b>  <input type="checkbox"/> Follow the instructions in the <i>Firmware Manual</i> to start up the drive and to set the drive parameters.	
<b>On-load checks</b>  <input type="checkbox"/> Check that the Prevention of Unexpected Start function (if installed) works: <ul style="list-style-type: none"> <li>• Start and Stop the drive and wait until the motor has stopped.</li> <li>• Open the Prevention of Unexpected Start switch (mounted on a control desk).</li> <li>• Give a Start command. The drive should not start.</li> <li>• Reset the drive.</li> </ul> <input type="checkbox"/> Check that the cooling fans rotate freely in the right direction, and the air flows upwards.  <input type="checkbox"/> Check the direction of rotation of the motor.  <input type="checkbox"/> Check the correct operation of the emergency-stop circuits from each operating location.	<p>Optional function. See delivery specific circuit diagrams.</p> <p>Check visually that the fans rotate in the direction indicated by an arrow on the fan housing.</p>





# Maintenance

---

## What this chapter contains

This chapter contains preventive maintenance instructions.

## Safety instructions



**Only a qualified electrician is allowed to perform the maintenance.**

Before starting work inside the cabinet,

- isolate the drive from the supply (note that the switch-disconnector on the door does not switch off the voltage from the input terminals)
- wait for 5 minutes to let the intermediate circuit capacitors discharge
- open the cabinet doors
- ensure there is no dangerous voltage present by measuring the voltage of the input terminals and the intermediate circuit terminals.


## Maintenance intervals

If installed in an appropriate environment, the drive requires very little maintenance. This table lists the routine maintenance intervals recommended by ABB.

Interval	Maintenance action	Instructions
Every year of storage	Capacitor reforming	See document <i>ACS 600/800 Capacitor Reforming Guide</i> (Code: 3BFE 64059629 [English]) and <a href="#">Capacitors</a> .
Every 6 to 12 months (depending on dustiness of environment)	Heatsink temperature check and cleaning	See <a href="#">Heatsinks</a> .
Every year (IP22 and IP42 units)	Air filter check; replacement if necessary	See <a href="#">Replacing the PPCS branching unit (APBU-xx) memory backup battery</a> .
Every year (IP54 units)	Air filter replacement	
Every 3 years	Cooling fan check; replacement if necessary	See <a href="#">Cooling fans</a> .
Every 3 years	Power connections check and cleaning	See <a href="#">Power connections</a> .
Every 6 years	Cooling fan change	See <a href="#">Cooling fans</a> .
Every 6 years	PPCS branching unit (APBU-xx) – Memory backup battery renewal	Locate the APBU unit. See section <a href="#">Replacing the PPCS branching unit (APBU-xx) memory backup battery</a> on page 105.
Every 10 years (if drive subjected to high ambient temperature)	Capacitor change	See <a href="#">Capacitors</a> .
Every 12 years	Capacitor change	See <a href="#">Capacitors</a> .

## Replacing the PPCS branching unit (APBU-xx) memory backup battery

1. Switch off the power to the unit.
2. Open the screws on the cover (3 pcs).
3. Slide off the cover.
4. Remove the battery.
5. Insert the new CR 2032 battery and reattach the cover.



## Checking and replacing the air filters

1. Read and repeat the steps in *Safety instructions* above.
2. Open the cabinet doors.
3. Check the air filters and replace if necessary (see [Technical data](#) for the correct filter types). The inlet (door) filters can be accessed by removing the fastener(s) at the top of the grille, then lifting the grille and pulling it away from the door. The outlet (roof) filter in IP54 units has a similar mechanism.
4. Check the cleanliness of the cabinet. Clean the interior of the cabinet if necessary using a soft brush and a vacuum cleaner.
5. Close the cabinet doors.

## Power connections

1. Read and repeat the steps in section *Safety instructions* above.
2. Open the cabinet doors.
3. Extract one supply or inverter module from the cabinet as described in the connection procedures in the chapter [Electrical installation](#).
4. Check the tightness of the cable connections at the quick connector. Use the tightening torque table in [Technical data](#).
5. Clean all contact surfaces of the quick connector and apply a layer of suitable joint compound (e.g. Isoflex® Topas NB 52 from Klüber Lubrication) onto them.
6. Re-insert the supply/inverter module.
7. Repeat steps 3 to 6 for all remaining supply and inverter modules.

## Cooling fans


### Power module cooling fans

The lifespan of the cooling fans of the supply and inverter modules is about 50 000 hours. The actual lifespan depends on the running time of the fan, ambient temperature and dust concentration. Each supply and inverter module has its own cooling fan. Replacements are available from ABB. Do not use other than ABB specified spare parts.

The application program keeps track of the running time of the cooling fan of the **inverter** modules. See the *Firmware Manual* delivered with the drive for the actual signal which indicates the running time.


### Supply module fan replacement

1. Read and repeat the steps in section *Safety instructions* above.
2. Open the supply cubicle doors.
3. Loosen the locking screw (1).
4. Disconnect the fan wiring plug (2).
5. Pull out the fan (3).
6. Install a new fan in reverse order.



### *Inverter module fan replacement*


1. Read and repeat the steps in section *Safety instructions* above.
2. Open the inverter cubicle doors.
3. Disconnect the fan wiring plug (1).
4. Remove the locking screws (2).
5. Pull the fan out along its sliding rails (3).
6. Install a new fan in reverse order.



### Control and I/O cubicle cooling fans


The cooling fans inside the control and I/O cubicle can be replaced as follows:

1. Read and repeat the steps in section *Safety instructions* above.
2. Open the door of the control and I/O cubicle (or combined control, I/O and supply cubicle).
3. Detach the wiring from each fan (AC plug and grounding wire).
4. Undo the four fastening screws of the fan assembly and pull the assembly outwards to gain access to the fan fastening screws.
5. Undo the fastening screws of the fans (there are four for each fan) from below. Remove the fans.
6. Install new fans in reverse order. Before fastening the fans, make sure the airflow arrow on both fans is pointed up.



### Air circuit breaker cubicle fans










Some IP2x/IP4x units with an air circuit breaker are also fitted with two fans at the air outlet on the roof. The fans are fastened to the grating (1) which can be removed by undoing the four screws (2). If necessary, undo the screws labelled (3) to remove the airflow guide (4).



### IP54 (UL type 12) fan replacement

1. Remove the front and back gratings of the fan cubicle by lifting them upwards.
2. Remove the shrouds by undoing the fastening screws.
3. Undo the fastening screws of the side/top cover of the fan.
4. Lift the side/top cover of the fan off.
5. Disconnect the fan supply wire connector from the cabinet roof (on top and inside the cabinet).
6. Undo the fastening screws of the fan cassette at each corner.
7. Lift the fan cassette off.
8. Undo the cable ties on the top of the fan cassette.
9. Disconnect the cables (detachable terminals).
10. Remove the fan capacitor by undoing the fastening screw of the clamp.
11. Undo the fastening screws of the fan.
12. Pull the fan out.
13. Install the new fan and fan capacitor in reverse order to the above. Ensure that the fan is centred and rotates freely.





## Heatsinks

The heatsink fins of the power modules pick up dust from the cooling air. The module runs into overtemperature warnings and faults if the heatsinks are not clean. In a “normal” environment (not especially dusty nor clean) the heatsinks should be checked annually, in a dusty environment more often.

Whenever necessary, clean the heatsinks as follows:

1. Remove the cooling fan (see section [Cooling fans](#)).
2. Blow dry clean compressed air from bottom to top and simultaneously use a vacuum cleaner at the air outlet to trap the dust. **Note:** Prevent the dust from entering adjoining equipment.
3. Refit the cooling fan.

## Capacitors

The inverter modules employ several electrolytic capacitors. Their lifespan is at least 90 000 hours depending on the operating time of the drive, loading and ambient temperature. Capacitor life can be prolonged by lowering the ambient temperature.

It is not possible to predict capacitor failure. Capacitor failure is usually followed by damage to the unit and an input cable fuse failure, or a fault trip. Contact ABB if capacitor failure is suspected.

### Reforming

Reform (re-age) spare part capacitors once a year according to *ACS 600/800 Capacitor Reforming Guide* (code: 64059629 [English], available through your local ABB representative).

### Capacitor replacement

Contact an ABB service representative.

## Other maintenance actions

### Power module replacement

To replace power modules (i.e. supply and inverter modules), follow the instructions on module removal and refitting given in the chapter [Electrical installation](#).

# Fault tracing


## What this chapter contains

This chapter instructs in interpreting the LED indications of the ACS800-07.


**Note:** Information on warnings and faults reported by the application program (and displayed on the CDP-312R drive control panel on the cabinet door) are contained within the *Firmware Manual* delivered with the drive.

## Supply unit status, fault and warning LEDs

LEDs on DSSB board  
(inside control and I/O cubicle)



LEDs on supply module front



LED	Cause	What to do
LEDs on the DSSB board		
FAN FAILURE	Cooling fan failure.	Change fan.
SUPPLY MISSING	LED blinks and Phase L__ Missing LED on module cover blinks: Main circuit AC fuse has blown, fuse on DSAB-01C board has blown, or input power terminal is loose.	Change main circuit AC fuse. Change fuse on DSAB board or DSAB board. Check and tighten input power terminals.
	LED blinks but no Phase L__ Missing LED on module cover blinks: Auxiliary circuit AC fuse of Diode Supply Unit has blown, main circuit AC fuse of branches L1.1, L2.1 or L3.1 of the first DSU module has blown, or input power terminal is loose.	Change blown auxiliary circuit AC fuse. Change blown main circuit AC fuse. Check and tighten input power terminals.
	LED on: DSU overload or faulty DSSB control board.	Check load. Are all parallel-connected supply modules in place? Decrease load or replace missing module. Change faulty DSSB board.

LED	Cause	What to do
OVER TEMP FAULT	Supply unit has exceeded temperature fault limit.	Check ambient temperature. Check cooling air flows freely. Check fan operation. Check inlet and outlet air filters. Check heatsink for dust pick-up.
DC FUSE	DC fuse blown.	Change DC fuse.
EXTERNAL FAULT	Digital input indicates external fault.	Fix external fault. Check status of digital input.
EM STOP / OTHER FAULT	Blinking: Internal fault detected by DSU control program, e.g: - DSU charging failed or exceeded allowed duration (5 s.). - Module switch-disconnectors do not open/close, or DSSB board receives false switch-disconnector status signal (auxiliary contact). - Emergency stop circuit is open, or not connected correctly. - Loose connectors -X4 or -X8 on DSSB board. - 4A fuse(s) blown on DSSB board.	Check fuses on circuit boards.  Reset DSU and restart.  Check operation of switch-disconnectors (optional equipment). Check status signal. Check/tighten signal connections. Replace module (or switchdisconnector.) Release emergency stop button. Check connections of the emergency stop circuit. Check that connectors -X4 and -X8 are properly fastened. Measure +/-24VDC from DSSB board connectors -X4 and -X8. Change the 4A circuit board fuses F1 and F2 of DSSB board.
	On: - Module contactors do not open, or DSSB board receives false contactor status signal (auxiliary contact).	Check operation of contactors (optional). Check status signal. Check/tighten signal connections. Replace module (or contactor). Reset DSU and restart.
EARTH FAULT	Supply load imbalance due to earth fault leakage current in drive, motor cable or motor.	Check motor, and motor cable. Ensure there are no power factor correction capacitors or surge absorbers connected to the system. If all of the above are OK, raise earth fault trip level; see the <i>ACA631/633 User's Manual for Cabinet-installed Diode Supply Unit</i> (code: 64735501 [English]).
OVER TEMP WARN	Supply unit has exceeded temperature warning limit.	See <a href="#">OVER TEMP FAULT</a> above.
READY	Blinking: Supply module contactor is off or module is charging intermediate circuit. Input terminals are live and module switch-disconnectors are switched on. However, unit cannot be loaded yet.	Contactors off: Close contactors.  Contactors on: Wait until supply unit has charged intermediate circuit (i.e LED illuminates steadily) and start to load the unit.
	On: DSU is in operation and can be loaded; Input terminals are live, module switch-disconnectors and contactors are on, intermediate circuit capacitors have been charged.	Load/control DSU.
LEDs on supply module front		
DC Fuse Failure	See <a href="#">DC FUSE</a> above.	See <a href="#">DC FUSE</a> above.
Power	See <a href="#">READY</a> above.	See <a href="#">READY</a> above.

LED	Cause	What to do
Fan Failure	See <a href="#">FAN FAILURE</a> above.	See <a href="#">FAN FAILURE</a> above.
Fan Full Speed	Cooling fan rotates at maximum speed.	-
Over Temp Fault	See <a href="#">OVER TEMP FAULT</a> above.	See <a href="#">OVER TEMP FAULT</a> above.
Over Temp Warning	See <a href="#">OVER TEMP WARN</a> above.	See <a href="#">OVER TEMP FAULT</a> above.
Phase L_ _ Missing	See <a href="#">SUPPLY MISSING</a> above.	See <a href="#">SUPPLY MISSING</a> above.

---

**Note:** A fault indication LED normally stays lit after the fault is detected. However, the LED will blink during an input power break to minimise back-up battery current consumption. The battery discharge time is 30 ... 60 minutes.

---

## Other LEDs of the drive

Location	LED	Indication
RMIO board (RDCU drive control unit)	Red	Drive in fault state.
	Green	The power supply on the board is OK.
Control panel mounting platform (with the control panel removed)	Red	Drive in fault state
	Green	The main + 24 V power supply for the control panel and the RMIO board is OK.
AINT board (visible through the transparent cover on the front of the inverter modules)	V204 (green)	+5 V voltage of the board is OK.
	V309 (red)	Prevention of unexpected start is ON.
	V310 (green)	IGBT control signal transmission to the gate driver control boards is enabled.



# Technical data

## What this chapter contains

This chapter contains the technical specifications of the drive, e.g. ratings, frame sizes and technical requirements, provisions for fulfilling the requirements for CE and other markings, and warranty information.

## Ratings

The ratings for the ACS800-07 with 50 Hz and 60 Hz supplies are given below. The symbols are described below the table.

ACS800-07 type	Nominal ratings		No-over-load use	Light-overload use		Heavy-duty use		Heat dissipation	Air flow	Noise level
	$I_{\text{cont.max}}$ A	$I_{\text{max}}$ A	$P_{\text{cont.max}}$ kW	$I_{2N}$ A	$P_N$ kW	$I_{2hd}$ A	$P_{hd}$ kW	kW	m <sup>3</sup> /h	dBA
Three-phase supply voltage 380 V, <b>400 V</b> or 415 V										
ACS800-07-0610-3	879	1315	500	844	500	657	400	13.0	3120	73
ACS800-07-0770-3	1111	1521	630	1067	630	831	450	17.2	3840	74
ACS800-07-0870-3	1255	1877	710	1205	710	939	500	18.5	3840	74
ACS800-07-1030-3	1452	1988	800	1394	800	1086	630	23.9	3840	74
ACS800-07-1230-3	1770	2648	1000	1699	1000	1324	710	27.5	5040	75
ACS800-07-1540-3	2156	2951	1200	2070	1200	1613	900	35.4	5760	76
ACS800-07-1850-3	2663	3894	1450	2556	1450	1992	1120	42.7	6960	76
Three-phase supply voltage 380 V, 400 V, 415 V, 440 V, 460 V, 480 V or <b>500 V</b>										
ACS800-07-0760-5	883	1321	630	848	630	660	500	14.0	3120	73
ACS800-07-0910-5	1050	1524	710	1008	710	785	560	17.2	3840	74
ACS800-07-1090-5	1258	1882	900	1208	900	941	630	19.9	3840	74
ACS800-07-1210-5	1372	1991	1000	1317	1000	1026	710	23.8	3840	74
ACS800-07-1540-5	1775	2655	1250	1704	1200	1328	900	29.4	5040	75
ACS800-07-1820-5	2037	2956	1450	1956	1400	1524	1120	35.0	5760	76
ACS800-07-2310-5	2670	3901	1900	2563	1850	1997	1400	45.4	6960	76
Three-phase supply voltage 525 V, 550 V, 575 V, 600 V, 660 V, or <b>690 V</b>										
ACS800-07-0750-7	628	939	630	603	630	470	500	13.9	3120	73
ACS800-07-0870-7	729	1091	710	700	710	545	560	17.1	3120	73
ACS800-07-1060-7	885	1324	800	850	800	662	630	18.4	3120	73
ACS800-07-1160-7	953	1426	900	915	900	713	710	20.8	3840	74
ACS800-07-1500-7	1258	1882	1200	1208	1200	941	900	27.0	5040	75
ACS800-07-1740-7	1414	2115	1400	1357	1400	1058	1000	32.5	5040	75
ACS800-07-2120-7	1774	2654	1700	1703	1700	1327	1250	40.1	6240	76
ACS800-07-2320-7	1866	2792	1900	1791	1800	1396	1400	43.3	6960	76
ACS800-07-2900-7	2321	3472	2300	2228	2200	1736	1600	51.5	8160	77
ACS800-07-3190-7	2665	3987	2600	2558	2500	1993	1900	58.0	9360	78
ACS800-07-3490-7	2770	4144	2800	2659	2700	2072	2100	63.6	10080	78

PDM-184674-0.36

## Symbols

### Nominal ratings

- $I_{\text{cont.max}}$  Continuous RMS output current. No overloadability at 40 °C.  
 $I_{\text{max}}$  Maximum output current. Allowable for 10 seconds at start, otherwise as long as allowed by drive temperature.

### Typical ratings for no-overload use

- $P_{\text{cont.max}}$  Typical motor power. The power ratings apply to most IEC 34 motors at nominal voltage (400, 500 or 690 V).

### Typical ratings for light-overload use (10% overloadability)

- $I_{2N}$  Continuous rms current. 10% overload is allowed for 1 minute every 5 minutes.  
 $P_N$  Typical motor power. The power ratings apply to most IEC 34 motors at nominal voltage (400, 500 or 690 V).

### Typical ratings for heavy-duty use (50% overloadability)

- $I_{2hd}$  Continuous rms current. 50% overload is allowed for 1 minute every 5 minutes.  
 $P_{hd}$  Typical motor power. The power ratings apply to most IEC 34 motors at nominal voltage (400, 500 or 690 V).

## Derating

The load capacity (current and power) decreases if the installation site altitude exceeds 1000 metres (3281 ft), or if the ambient temperature exceeds 40 °C (104 °F).

### Temperature derating

In the temperature range +40 °C (+104 °F) to +50 °C (+122 °F), the rated output current is decreased by 1% for every additional 1 °C (1.8 °F). The output current is calculated by multiplying the current given in the rating table by the derating factor.

Example If the ambient temperature is 50 °C (+122 °F), the derating factor is  $100\% - 1 \frac{\%}{^{\circ}\text{C}} \cdot 10^{\circ}\text{C} = 90\%$  or 0.90. The output current is then  $0.90 \times I_{2N}$  or  $0.90 \times I_{\text{cont.max}}$ .

### Altitude derating

At altitudes from 1000 to 4000 m (3281 to 13123 ft) above sea level, the derating is 1% for every 100 m (328 ft). For a more accurate derating, use the *DriveSize* PC tool. If the installation site is higher than 2000 m (6600 ft) above sea level, please contact your local ABB distributor or office for further information.



## ACS800-07 frame sizes and power module types

ACS800-07 type	Frame size (supply+inverter modules)	Supply module(s) used		Inverter modules used	
		Qty	Type	Qty	Type
Three-phase supply voltage 380 V, <b>400 V</b> or 415 V					
ACS800-07-0610-3	1×D4 + 2×R8i	1	ACS800-704-0910-7	2	ACS800-104-0390-3
ACS800-07-0770-3	2×D4 + 2×R8i	2	ACS800-704-0640-7	2	ACS800-104-0390-3
ACS800-07-0870-3	2×D4 + 2×R8i	2	ACS800-704-0640-7	2	ACS800-104-0510-3
ACS800-07-1030-3	2×D4 + 2×R8i	2	ACS800-704-0910-7	2	ACS800-104-0510-3
ACS800-07-1230-3	2×D4 + 3×R8i	2	ACS800-704-0910-7	3	ACS800-104-0510-3
ACS800-07-1540-3	3×D4 + 3×R8i	3	ACS800-704-0910-7	3	ACS800-104-0510-3
ACS800-07-1850-3	3×D4 + 4×R8i	3	ACS800-704-0910-7	4	ACS800-104-0510-3
Three-phase supply voltage 380 V, 400 V, 415 V, 440 V, 460 V, 480 V or <b>500 V</b>					
ACS800-07-0760-5	1×D4 + 2×R8i	1	ACS800-704-0910-7	2	ACS800-104-0460-5
ACS800-07-0910-5	2×D4 + 2×R8i	2	ACS800-704-0640-7	2	ACS800-104-0460-5
ACS800-07-1090-5	2×D4 + 2×R8i	2	ACS800-704-0640-7	2	ACS800-104-0610-5
ACS800-07-1210-5	2×D4 + 2×R8i	2	ACS800-704-0910-7	2	ACS800-104-0610-5
ACS800-07-1540-5	2×D4 + 3×R8i	2	ACS800-704-0910-7	3	ACS800-104-0610-5
ACS800-07-1820-5	3×D4 + 3×R8i	3	ACS800-704-0910-7	3	ACS800-104-0610-5
ACS800-07-2310-5	3×D4 + 4×R8i	3	ACS800-704-0910-7	4	ACS800-104-0610-5
Three-phase supply voltage 525 V, 550 V, 575 V, 600 V, 660 V, or <b>690 V</b>					
ACS800-07-0750-7	1×D4 + 2×R8i	1	ACS800-704-0640-7	2	ACS800-104-0440-7
ACS800-07-0870-7	1×D4 + 2×R8i	1	ACS800-704-0910-7	2	ACS800-104-0440-7
ACS800-07-1060-7	1×D4 + 2×R8i	1	ACS800-704-0910-7	2	ACS800-104-0580-7
ACS800-07-1160-7	2×D4 + 2×R8i	2	ACS800-704-0640-7	2	ACS800-104-0580-7
ACS800-07-1500-7	2×D4 + 3×R8i	2	ACS800-704-0640-7	3	ACS800-104-0580-7
ACS800-07-1740-7	2×D4 + 3×R8i	2	ACS800-704-0910-7	3	ACS800-104-0580-7
ACS800-07-2120-7	2×D4 + 4×R8i	2	ACS800-704-0910-7	4	ACS800-104-0580-7
ACS800-07-2320-7	3×D4 + 4×R8i	3	ACS800-704-0910-7	4	ACS800-104-0580-7
ACS800-07-2900-7	3×D4 + 5×R8i	3	ACS800-704-0910-7	5	ACS800-104-0580-7
ACS800-07-3190-7	3×D4 + 6×R8i	3	ACS800-704-0910-7	6	ACS800-104-0580-7
ACS800-07-3490-7	4×D4 + 6×R8i	4	ACS800-704-0910-7	6	ACS800-104-0580-7

PDM-184674-0.32

## Internal AC fuses

ACS800-07... type	Input current (A)	Qty.	Type (IEC/UL/CSA)	Rated current (A RMS)	Voltage (V)	I <sup>2</sup> t Pre-arc	I <sup>2</sup> t Clearing at 660V
U <sub>N</sub> = 400 V (Range 380-415 V)							
-0610-3	790	6	170M4417 Bussmann	700	690	69500	465000
-0770-3	999	12					
-0870-3	1128	12					
-1030-3	1305	12					
-1230-3	1591	12					
-1540-3	1938	18					
-1850-3	2394	18					
U <sub>N</sub> = 500 V (Range 380-500 V)							
-0760-5	793	6	170M4417 Bussmann	700	690	69500	465000
-0910-5	944	12					
-1090-5	1131	12					
-1210-5	1233	12					
-1540-5	1596	12					
-1820-5	1831	18					
-2310-5	2400	18					
U <sub>N</sub> = 690 V (Range 525-690 V)							
-0750-7	565	6	170M4417 Bussmann	700	690	69500	465000
-0870-7	655	6					
-1060-7	795	6					
-1160-7	856	12					
-1500-7	1131	12					
-1740-7	1271	12					
-2120-7	1595	12					
-2320-7	1678	18					
-2900-7	2086	18					
-3190-7	2396	18					
-3490-7	2490	24					

\*If the drive is not equipped with internal AC fuses (option code +F260), install specified fuses externally at the AC supply. See the diagram on page 73 for the cabling arrangement at each supply module.

## DC fuses at inverter module input

ACS800-07... type	Input current (A)	Qty.	Type (IEC)	Type (UL/CSA)	Rated current (A RMS)	Voltage (V)
U <sub>N</sub> = 400 V (Range 380-415 V)						
-0610-3	790	4	170M8547 Bussmann	170M6216 Bussmann	1250	690
-0770-3	999	4				
-0870-3	1128	4	170M8550 Bussmann	170M6219 Bussmann	1600	690
-1030-3	1305	4				
-1230-3	1591	6				
-1540-3	1938	6				
-1850-3	2394	8				
U <sub>N</sub> = 500 V (Range 380-500 V)						
-0760-5	793	4	170M8547 Bussmann	170M6216 Bussmann	1250	690
-0910-5	944	4				
-1090-5	1131	4	170M8550 Bussmann	170M6219 Bussmann	1600	690
-1210-5	1233	4				
-1540-5	1596	6				
-1820-5	1831	6				
-2310-5	2400	8				
U <sub>N</sub> = 690 V (Range 525-690 V)						
-0750-7	565	4	170M8647 Bussmann	170M8637 Bussmann	800	1000
-0870-7	655	4				
-1060-7	795	4	170M8650 Bussmann	170M8639 Bussmann	1000	1000
-1160-7	856	4				
-1500-7	1131	6				
-1740-7	1271	6				
-2120-7	1595	8				
-2320-7	1678	8				
-2900-7	2086	10				
-3190-7	2396	12				
-3490-7	2490	12				

## Fuses for main circuit voltage measurement

Fuses F7 (2 pcs) and F8 (3 pcs) are used for DC voltage and AC supply voltage measurement respectively. The recommended type for replacement is Ferraz Shawmut A070GRB01T13 (1 A, 700 V, UL Recognized).

## DC fuses for the DSU module

Each D4 type DSU module uses four fuses. The fuses are in two pairs, each pair consisting of a 170M4417 (with a micro switch) and 170M4467 (with a red fuse indicator) fuse connected in parallel.

Qty.	Type	Rated current (A RMS)	Voltage (V)
2	170M4417 Bussmann	700	690
2	170M4467 Bussmann	700	690

## Input power connection

<b>Voltage (<math>U_1</math>)</b>	380/400/415 VAC 3-phase $\pm$ 10 % for 400 VAC units 380/400/415/440/460/480/500 VAC 3-phase $\pm$ 10 % for 500 VAC units 525/550/575/600/660/690 VAC 3-phase $\pm$ 10 % for 690 VAC units									
<b>Prospective short-circuit current (IEC 60439-1, UL508C)</b>	Units without earthing/grounding switch: <table><tr><td colspan="2"><math>I_{cf}</math></td></tr><tr><td colspan="2">65 kA</td></tr></table> Units with earthing/grounding switch: <table><tr><td><math>I_{cw} / 1\text{ s}</math></td><td><math>I_{pk}</math></td></tr><tr><td>50 kA</td><td>105 kA</td></tr></table> US/Canada: The drive is suitable for use in a circuit capable of delivering not more than 65,000 A rms symmetrical at drive nominal voltage when protected by T-class fuses.		$I_{cf}$		65 kA		$I_{cw} / 1\text{ s}$	$I_{pk}$	50 kA	105 kA
$I_{cf}$										
65 kA										
$I_{cw} / 1\text{ s}$	$I_{pk}$									
50 kA	105 kA									
<b>Frequency</b>	48 to 63 Hz, maximum rate of change 17 %/s									
<b>Imbalance</b>	Max. $\pm$ 3 % of nominal phase to phase input voltage									
<b>Fundamental power factor (<math>\cos \phi_1</math>)</b>	0.98 (at nominal load)									
<b>Transformer for 12-pulse supply</b>	Connection	Dy 11 d0 or Dyn 11 d0								
	Phase shift between secondaries	30° electrical								
	Voltage difference between secondaries	< 0.5%								
	Short-circuit impedance of secondaries	> 5%								
	Short-circuit impedance difference between secondaries	< 10% of short-circuit impedance								
	Other	No grounding of the secondaries allowed. Static screen recommended								
<b>Input power cable lead-throughs</b>	Units without load switch-disconnector or air circuit breaker: 4 $\times$ Ø60 mm (2.36") at each supply module Units with load switch-disconnector (+F253): 9 $\times$ Ø60 mm (2.36") (frame 1 $\times$ D4 + 2 $\times$ R8i) 12 $\times$ Ø60 mm (2.36") (frame 2 $\times$ D4 + n $\times$ R8i) 18 $\times$ Ø60 mm (2.36") (frame 3 $\times$ D4 + n $\times$ R8i and 4 $\times$ D4 + n $\times$ R8i) Units with air circuit breaker (+F255): 18 $\times$ Ø60 mm (2.36")									

**Input terminals at each supply module** (units without load switch-disconnector or air circuit breaker)

Conductor size	Max. no. and size of cable lugs per phase	Lug hole	Bolt	Tightening torque
IEC Cabling				
$\leq 150 \text{ mm}^2$	$2 \times 150 \text{ mm}^2$	$1 \times 11$	M10	40 Nm
185 ... 240 $\text{mm}^2$	OL $2 \times 185\text{-}240 \text{ mm}^2$ (with dual-cable screw lug included with delivery)	—	—	15 Nm
US Cabling				
300 ... 350 MCM	$2 \times 350 \text{ MCM}$	$2 \times 1\frac{3}{4}"$	7/16"	30 lbf.ft

**Input terminals** (units with load switch-disconnector or air circuit breaker)

Busbar dimensions	No. of busbars <sup>2)</sup>	Bolt size	Tightening torque
	See below	M12 or $\frac{1}{2}"$	70 Nm (50 lb.ft)

Number of input busbars (6-pulse units)			
No. of supply modules (n×D4)	No. of busbars per connection point		
	1L1	1L2	1L3
1	1	1	1
2	2	2	2
3	3	3	3
4	3	3	3

Number of input busbars (12-pulse units)						
No. of supply modules (n×D4)	No. of busbars per connection point					
	1L1	1L2	1L3	2L1	2L2	2L3
1	1	1	1	1	1	1
2	2	2	2	2	2	2
3	3	3	3	3	3	3
4	3	3	3	3	3	3


## Motor connection

---

<b>Voltage (<math>U_2</math>)</b>	0 to $U_1$ , 3-phase symmetrical, $U_{\max}$ at the field weakening point
<b>Frequency</b>	<p>DTC mode: 0 to <math>3.2 \times f_{\text{FWP}}</math>. Maximum frequency 300 Hz.</p> $f_{\text{FWP}} = \frac{U_{\text{Nmains}}}{U_{\text{Nmotor}}} \cdot f_{\text{Nmotor}}$ <p>where <math>f_{\text{FWP}}</math> = frequency at field weakening point; <math>U_{\text{Nmains}}</math> = mains (input power) voltage;  <math>U_{\text{Nmotor}}</math> = rated motor voltage; <math>f_{\text{Nmotor}}</math> = rated motor frequency</p>
<b>Frequency resolution</b>	0.01 Hz
<b>Current</b>	See section <a href="#">Ratings</a> .
<b>Power limit</b>	$2 \times P_{\text{hd}}$ . After approximately 2 minutes at $2 \times P_{\text{hd}}$ , the limit is set at $P_{\text{cont.max}}$ .
<b>Field weakening point</b>	8 to 300 Hz
<b>Switching frequency</b>	2 kHz (average)
<b>Motor cable lead-throughs</b>	<p><math>3 \times \varnothing 60</math> mm at each inverter module (units without common motor terminal cubicle)</p> <p>Units with common motor terminal cubicle: See the chapter <a href="#">Dimensions</a>.</p>


**Output terminals at each R8i inverter module** (units without common motor terminal cubicle)

Bottom exit  
Side view  
Bolt size: M12 or ½"  
Tightening torque: 70 Nm (52 lbf.ft)



68265631-A0

Top exit  
Side view  
Bolt size: M12 or ½"  
Tightening torque: 70 Nm (52 lbf.ft)



cabinet\_400\_generic.asm

**Output terminals** (units with common motor terminal cubicle)

8 × Ø13 mm per phase. See the chapter [Dimensions](#).

**Maximum recommended motor cable length**

100 m (328 ft). Motor cables up to 500 m (1640 ft) long are allowed but EMC filtering within the specified limits will not be realised.

## Efficiency

Approximately 98% at nominal power level

## Cooling

**Method** Internal fans, flow direction from bottom to top

Filter material	Inlet (door)	Outlet (roof)
	IP22/IP42 units	Lufffilter airTex G150
	IP54 units	Lufffilter airComp 300-50

**Free space around the unit** See chapter [Mechanical installation](#).

**Cooling air flow** See [Ratings](#).

## Degrees of protection

IP21; IP22; IP42; IP54, IP54R (with air outlet duct)

## Ambient conditions

Environmental limits for the drive are given below. The drive must be used in a heated, indoor controlled environment.

	Operation installed for stationary use	Storage in the protective package	Transportation in the protective package
<b>Installation site altitude</b>	0 to 4000 m (13123 ft) above sea level [above 1000 m (3281 ft), see section <a href="#">Derating</a> ]	-	-
<b>Air temperature</b>	-15 to +50 °C (5 to 122 °F), no frost allowed. See section <a href="#">Derating</a> .	-40 to +70 °C (-40 to +158°F)	-40 to +70 °C (-40 to +158°F)
<b>Relative humidity</b>	5 to 95%	Max. 95%	Max. 95%
	No condensation allowed. Maximum allowed relative humidity is 60% in the presence of corrosive gases.		
<b>Contamination levels</b> (IEC 60721-3-3, IEC 60721-3-2, IEC 60721-3-1)	No conductive dust allowed.		
	<b>Boards without coating:</b> Chemical gases: Class 3C1 Solid particles: Class 3S2  <b>Boards with coating:</b> Chemical gases: Class 3C2 Solid particles: Class 3S2	<b>Boards without coating:</b> Chemical gases: Class 1C2 Solid particles: Class 1S3  <b>Boards with coating:</b> Chemical gases: Class 1C2 Solid particles: Class 1S3	<b>Boards without coating:</b> Chemical gases: Class 2C2 Solid particles: Class 2S2  <b>Boards with coating:</b> Chemical gases: Class 2C2 Solid particles: Class 2S2
<b>Atmospheric pressure</b>	70 to 106 kPa 0.7 to 1.05 atmospheres	70 to 106 kPa 0.7 to 1.05 atmospheres	60 to 106 kPa 0.6 to 1.05 atmospheres
<b>Vibration</b> (IEC 60068-2)	Max. 1 mm (0.04 in.) (5 to 13.2 Hz), max. 7 m/s <sup>2</sup> (23 ft/s <sup>2</sup> ) (13.2 to 100 Hz) sinusoidal	Max. 1 mm (0.04 in.) (5 to 13.2 Hz), max. 7 m/s <sup>2</sup> (23 ft/s <sup>2</sup> ) (13.2 to 100 Hz) sinusoidal	Max. 3.5 mm (0.14 in.) (2 to 9 Hz), max. 15 m/s <sup>2</sup> (49 ft/s <sup>2</sup> ) (9 to 200 Hz) sinusoidal
<b>Shock</b> (IEC 60068-2-29)	Not allowed	Max. 100 m/s <sup>2</sup> (330 ft./s <sup>2</sup> ), 11 ms	Max. 100 m/s <sup>2</sup> (330 ft./s <sup>2</sup> ), 11 ms
<b>Free fall</b>	Not allowed	100 mm (4 in.) for weight over 100 kg (220 lb)	100 mm (4 in.) for weight over 100 kg (220 lb)



## Materials

<b>Cabinet</b>	Hot-dip zinc-coated (thickness approx. 20 µm) steel sheet (thickness 1.5 mm) with polyester thermosetting powder coating (thickness approx. 80 µm) on visible surfaces except back panel. Colour: RAL 7035 (light beige, semigloss).
<b>Busbars</b>	Tin- or silver-plated copper
<b>Fire safety of materials</b> (IEC 60332-1)	Insulating materials and non-metallic items: Mostly self-extinctive
<b>Packaging</b>	Frame: Wood or plywood. Plastic wrapping: PE-LD. Bands: PP or steel.
<b>Disposal</b>	<p>The drive contains raw materials that should be recycled to preserve energy and natural resources. The package materials are environmentally compatible and recyclable. All metal parts can be recycled. The plastic parts can either be recycled or burned under controlled circumstances, according to local regulations. Most recyclable parts are marked with recycling marks.</p> <p>If recycling is not feasible, all parts excluding electrolytic capacitors and printed circuit boards can be landfilled. The DC capacitors (C1-1 to C1-x) contain electrolyte and the printed circuit boards contain lead, both of which are classified as hazardous waste within the EU. They must be removed and handled according to local regulations.</p> <p>For further information on environmental aspects and more detailed recycling instructions, please contact your local ABB distributor.</p>

## Tightening torques for power connections

Screw size	Torque
M5	3.5 Nm (2.6 lbf.ft)
M6	9 Nm (6.6 lbf.ft)
M8	20 Nm (14.8 lbf.ft)
M10	40 Nm (29.5 lbf.ft)
M12	70 Nm (52 lbf.ft)
M16	180 Nm (133 lbf.ft)

## Applicable standards

	The drive complies with the following standards. The compliance with the European Low Voltage Directive is verified according to standards EN 50178 and EN 60204-1.
• EN 50178 (1997)	Electronic equipment for use in power installations.
• EN 60204-1 (1997)	Safety of machinery. Electrical equipment of machines. Part 1: General requirements. <i>Provisions for compliance:</i> The final assembler of the machine is responsible for installing - an emergency-stop device - a supply disconnecting device.
• EN 60529: 1991 (IEC 529)	Degrees of protection provided by enclosures (IP code).
• IEC 60664-1 (1992)	Insulation coordination for equipment within low-voltage systems. Part 1: Principles, requirements and tests.
• EN 61800-3 (1996) + Amendment A11 (2000)	EMC product standard including specific test methods
• UL 508C	UL Standard for Safety, Power Conversion Equipment, second edition
• CSA C22.2 No. 14-95	Industrial control equipment

Technical data

## CE marking

A CE mark is attached to the drive to verify that the unit follows the provisions of the European Low Voltage and EMC Directives (Directive 73/23/EEC, as amended by 93/68/EEC and Directive 89/336/EEC, as amended by 93/68/EEC).

### Definitions

EMC stands for **E**lectromagnetic **C**ompatibility. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

*First environment* includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

*Second environment* includes establishments connected to a network not supplying domestic premises.

*Restricted distribution*: mode of sales distribution in which the manufacturer restricts the supply of equipment to suppliers, customers or users who separately or jointly have technical competence in the EMC requirements of the application of drives.

*Unrestricted distribution*: mode of sales distribution in which the supply of equipment is not dependent on the EMC competence of the customer or user for the application of drives.

### Compliance with the EMC Directive

The EMC Directive defines the requirements for immunity and emissions of electrical equipment used within the European Union. The EMC product standard (EN 61800-3 + Amendment A11 [2000]) covers requirements stated for drives.

### Compliance with the EN 61800-3 + Amendment A11 (2000)

#### *First environment (restricted distribution)*

The requirements of the EMC Directive can be met as follows for restricted distribution:

1. The drive is equipped with EMC filter +E202.
2. The motor and control cables are selected as specified in the *Hardware Manual*.
3. The drive is installed according to the instructions given in the *Hardware Manual*.
4. Maximum cable length is 100 metres (328 ft).

**WARNING!** The drive may cause radio interference if used in a residential or domestic environment. The user is required to take measures to prevent interference, in addition to the requirements for CE compliance listed above, if necessary.

**Note:** It is not allowed to install a drive equipped with EMC filter +E202 on IT (unearthed) systems. The supply network becomes connected to earth potential through the EMC filter capacitors which may cause danger or damage the unit.


## Second environment

The requirements of the EMC Directive can be met as follows:

1. The drive is equipped with EMC filter +E210. The filter is suitable for TN (earthed) and IT (unearthed) networks.
2. The motor and control cables are selected as specified in the drive manuals.
3. The drive is installed according to the instructions given in the drive manuals.
4. Maximum cable length is 100 metres (328 ft).

If the above listed provisions cannot be met, the requirements of the EMC Directive can be met as follows for restricted distribution:

1. It is ensured that no excessive emission is propagated to neighbouring low-voltage networks. In some cases, the natural suppression in transformers and cables is sufficient. If in doubt, the supply transformer with static screening between the primary and secondary windings can be used.



2. An EMC plan for preventing disturbances is drawn up for the installation. A template is available from the local ABB representative.
3. The motor and control cables are selected as specified in the drive manuals.
4. The drive is installed according to the instructions given in the drive manuals.

## Machinery Directive

The drive complies with the European Union Machinery Directive (98/37/EC) requirements for an equipment intended to be incorporated into machinery.



## “C-tick” marking

A “C-tick” mark is attached to each drive in order to verify compliance with the relevant standard (IEC 61800-3 (1996) – Adjustable speed electrical power drive systems – Part 3: EMC product standard including specific test methods), mandated by the Trans-Tasman Electromagnetic Compatibility Scheme.

### Definitions

EMC stands for **E**lectromagnetic **C**ompatibility. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

The Trans-Tasman Electromagnetic Compatibility Scheme (EMCS) was introduced by the Australian Communication Authority (ACA) and the Radio Spectrum Management Group (RSM) of the New Zealand Ministry of Economic Development (NZMED) in November 2001. The aim of the scheme is to protect the radiofrequency spectrum by introducing technical limits for emission from electrical/electronic products.

*First environment* includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

*Second environment* includes establishments connected to a network not supplying domestic premises.

*Restricted distribution:* mode of sales distribution in which the manufacturer restricts the supply of equipment to suppliers, customers or users who separately or jointly have technical competence in the EMC requirements of the application of drives.

*Unrestricted distribution:* mode of sales distribution in which the supply of equipment is not dependent on the EMC competence of the customer or user for the application of drives.

### Compliance with IEC 61800-3

#### *First environment (restricted distribution)*

The drive complies with the limits of IEC 61800-3 with the following provisions:


1. The drive is equipped with EMC filter +E202.
2. The drive is installed according to the instructions given in the drive manuals.
3. The motor and control cables used are selected as specified in the drive manuals.
4. Maximum cable length is 100 metres.

**Note:** The drive must not be equipped with the EMC filter E202 when installed to IT (unearthed) systems. The mains becomes connected to earth potential through the EMC filter capacitors. In IT systems this may cause danger or damage the unit.

## Second environment

The drive complies with the limits of IEC 61800-3 with the following provisions:

1. It is ensured that no excessive emission is propagated to neighbouring low-voltage networks. In some cases, the natural suppression in transformers and cables is sufficient. If in doubt, the supply transformer with static screening between the primary and secondary windings is strongly recommended.



2. The drive is installed according to the instructions given in the drive manuals.
3. The motor and control cables used are selected as specified in the drive manuals.



# Dimensions

---

## Cabinet line-ups

The drive consists of cubicles built into a cabinet line-up. The tables below show the composition of cabinet line-ups for each frame size and the standard combinations of options. The dimensions are in millimetres.

**Notes:**

- The side panels increase the total line-up width by 30 millimetres (1.2”).
- The standard depth of the cabinet line-up is 650 mm (excluding door equipment such as switches and air inlet gratings). This is increased by 130 millimetres (5.1”) with top entry/exit models as well as units with cooling air intake through the bottom of the cabinet.
- The measurements given apply to 6-pulse-input, non-UL/CSA units. For dimensions of 12-pulse-input or UL/CSA units, contact your local ABB representative.

The tables are followed by example dimensional drawings.

1xD4 + 2xR8i														
Control, I/O & supply cubicle	EMC/RFI filter	Load switch-disconnector	Inverter unit	Joining cubicle	Common motor terminal cubicle	*Brake chopper 1	*Brake resistor 1	*Brake chopper 2	*Brake resistor 2	*Brake chopper 3	*Brake resistor 3	Shipping split widths	Line-up width	Net weight (kg approx.)
700			600									1300	1300	890
700	300	400	600									2000	2000	1490
700		400	600									1700	1700	1190
700			600		300							1600	1600	1060
700	300	400	600		300							2300	2300	1660
700		400	600		300							2000	2000	1360
700			600			400		400				2100	2100	1250
700	300	400	600			400		400				2800	2800	1850
700		400	600			400		400				2500	2500	1550
700			600		300	400		400				2400	2400	1420
700	300	400	600		300	400		400				3100	3100	2020
700		400	600		300	400		400				2800	2800	1720
700			600	200		400	800	400	800			1500 + 2400	3900	980 + 800
700	300	400	600	200		400	800	400	800			2200 + 2400	4600	1580 + 800
700		400	600	200		400	800	400	800			1900 + 2400	4300	1280 + 800
700			600		300	400	800	400	800			1600 + 2400	4000	1060 + 800
700	300	400	600		300	400	800	400	800			2300 + 2400	4700	1660 + 800
700		400	600		300	400	800	400	800			2000 + 2400	4400	1360 + 800
700			600			400		400		400		2500	2500	1430
700	300	400	600			400		400		400		3200	3200	2030
700		400	600			400		400		400		2900	2900	1730
700			600		300	400		400		400		2800	2800	1600
700	300	400	600		300	400		400		400		3500	3500	2200
700		400	600		300	400		400		400		3200	3200	1900
700			600	200		400	800	400	800	400	800	1500 + 3600	5100	980 + 1200
700	300	400	600	200		400	800	400	800	400	800	2200 + 3600	5800	1580 + 1200
700		400	600	200		400	800	400	800	400	800	1900 + 3600	5500	1280 + 1200
700			600		300	400	800	400	800	400	800	1600 + 3600	5200	1060 + 1200
700	300	400	600		300	400	800	400	800	400	800	2300 + 3600	5900	1660 + 1200
700		400	600		300	400	800	400	800	400	800	2000 + 3600	5600	1360 + 1200

\*The number of brake choppers depends on drive type. See the chapter [Resistor braking](#).



2×D4 + 2×R8i															
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit	Joining cubicle	Common motor terminal cubicle	*Brake chopper 1	*Brake resistor 1	*Brake chopper 2	*Brake resistor 2	*Brake chopper 3	*Brake resistor 3	Shipping split widths	Line-up width	Net weight (kg approx.)
400			600	600									1600	1600	1200
400	500		600	600									2100	2100	1580
400		600	600	600									2200	2200	1900
400			600	600		300							1900	1900	1370
400	500		600	600		300							2400	2400	1750
400		600	600	600		300							2500	2500	2070
400			600	600			400		400				2400	2400	1560
400	500		600	600			400		400				2900	2900	1940
400		600	600	600			400		400				3000	3000	2260
400			600	600		300	400		400				2700	2700	1730
400	500		600	600		300	400		400				3200	3200	2110
400		600	600	600		300	400		400				3300	3300	2430
400			600	600	200		400	800	400	800			1800 + 2400	4200	1290 + 800
400	500		600	600	200		400	800	400	800			2300 + 2400	4700	1670 + 800
400		600	600	600	200		400	800	400	800			2400 + 2400	4800	1990 + 800
400			600	600		300	400	800	400	800			1900 + 2400	4300	1370 + 800
400	500		600	600		300	400	800	400	800			2400 + 2400	4800	1750 + 800
400		600	600	600		300	400	800	400	800			2500 + 2400	4900	2070 + 800
400			600	600			400		400		400		2800	2800	1740
400	500		600	600			400		400		400		3100	3100	2120
400		600	600	600			400		400		400		3400	3400	2440
400			600	600		300	400		400		400		3100	3100	1910
400	500		600	600		300	400		400		400		3600	3600	2290
400		600	600	600		300	400		400		400		3700	3700	2610
400			600	600	200		400	800	400	800	400	800	1800 + 3600	5400	1290 + 1200
400	500		600	600	200		400	800	400	800	400	800	2300 + 3600	5900	1670 + 1200
400		600	600	600	200		400	800	400	800	400	800	2400 + 3600	6000	1990 + 1200
400			600	600		300	400	800	400	800	400	800	1900 + 3600	5500	1370 + 1200
400	500		600	600		300	400	800	400	800	400	800	2400 + 3600	6000	1750 + 1200
400		600	600	600		300	400	800	400	800	400	800	2500 + 3600	6100	2070 + 1200

\*The number of brake choppers depends on drive type. See chapter [Resistor braking](#).

<b>2×D4 + 3×R8i</b>								
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit	Common motor terminal cubicle	Shipping split widths	Line-up width	Net weight (kg approx.)
400			600	800		1800	1800	1350
400	500		600	800		2300	2300	1730
400		600	600	800		2400	2400	2050
400			600	800	400	2200	2200	1540
400	500		600	800	400	2700	2700	1920
400		600	600	800	400	2800	2800	2240

<b>2×D4 + 4×R8i</b>									
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit (1)	Common motor terminal cubicle	Inverter unit (2)	Shipping split widths	Line-up width	Net weight (kg approx.)
400			600	600		600	2200	2200	1680
400	500		600	600		600	2700	2700	2060
400		600	600	600		600	2800	2800	2380
400			600	600	400	600	2600	2600	1870
400	500		600	600	400	600	3100	3100	2250
400		600	600	600	400	600	3200	3200	2570

<b>3×D4 + 3×R8i</b>								
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit	Common motor terminal cubicle	Shipping split widths	Line-up width	Net weight (kg approx.)
400			800	800		2000	2000	1540
400	600		800	800		2600	2600	1940
400		600	800	800		2600	2600	2240
400			800	800	400	2400	2400	1730
400	600		800	800	400	3000	3000	2130
400		600	800	800	400	3000	3000	2430

<b>3×D4 + 4×R8i</b>									
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit (1)	Common motor terminal cubicle	Inverter unit (2)	Shipping split widths	Line-up width	Net weight (kg approx.)
400			800	600		600	2400	2400	1870
400	600		800	600		600	3000	3000	2270
400		600	800	600		600	3000	3000	2570
400			800	600	400	600	2800	2800	2060
400	600		800	600	400	600	3400	3400	2460
400		600	800	600	400	600	3400	3400	2760


<b>3×D4 + 5×R8i</b>									
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit (1)	Common motor terminal cubicle	Inverter unit (2)	Shipping split widths	Line-up width	Net weight (kg approx.)
400			800	800		600	2600	2600	2020
400	600		800	800		600	3200	3200	2420
400		600	800	800		600	3200	3200	2720
400			800	800	400	600	3000	3000	2210
400	600		800	800	400	600	3600	3600	2610
400		600	800	800	400	600	3600	3600	2910

### Dimensions

<b>3×D4 + 6×R8i</b>									
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit (1)	Common motor terminal cubicle	Inverter unit (2)	Shipping split widths	Line-up width	Net weight (kg approx.)
400			800	800		800	2800	2800	2170
400	600		800	800		800	3400	3400	2570
400		600	800	800		800	3400	3400	2870
400			800	800	600	800	3400	3400	2390
400	600		800	800	600	800	4000	4000	2790
400		600	800	800	600	800	4000	4000	3090


<b>4×D4 + 6×R8i</b>									
Control & I/O cubicle	Load switch-disconnector	Air circuit breaker	Supply unit	Inverter unit (1)	Common motor terminal cubicle	Inverter unit (2)	Shipping split widths	Line-up width	Net weight (kg approx.)
400			600 + 600	800		800	3200	3200	2520
400	600		600 + 600	800		800	3800	3800	2920
400		600	600 + 600	800		800	3800	3800	3220
400			600 + 600	800	600	800	3800	3800	2740
400	600		600 + 600	800	600	800	4400	4400	3840
400		600	600 + 600	800	600	800	4400	4400	4140

Frame size 1×D4 + 2×R8i




Dimensions

Frame size 1xD4 + 2xR8i (continued)





Frame size 1×D4 + 2×R8i (continued)



### Dimensions


Frame size 1xD4 + 2xR8i (with load switch-disconnector)








Frame size 1xD4 + 2xR8i (with load switch-disconnector) (continued)




Frame size 1×D4 + 2×R8i (with load switch-disconnector) (continued)




Dimensions


Frame size 1×D4 + 2×R8i (with load switch-disconnector) (continued)




Frame size 1×D4 + 2×R8i (with load switch-disconnector) (continued)




Frame size 1xD4 + 2xR8i (with top entry/exit)




Frame size 1xD4 + 2xR8i (with top entry/exit) (continued)



Frame size 1xD4 + 2xR8i (with top entry/exit) (continued)



Frame size 2×D4 + 2×R8i




Dimensions







Frame size  $2 \times D4 + 2 \times R8i$  (continued)




Frame size 2xD4 + 2xR8i (with load switch-disconnector)






Frame size 2xD4 + 2xR8i (with load switch-disconnector) (continued)




**Frame size  $2 \times D4 + 3 \times R8i$**




### Dimensions

Frame size 2×D4 + 3×R8i (continued)




Frame size 2×D4 + 3×R8i (continued)




Dimensions



Frame size 2xD4 + 3xR8i (with load switch-disconnector)




Frame size 2×D4 + 3×R8i (with load switch-disconnector)



Dimensions





Frame size 2×D4 + 3×R8i (with load switch-disconnector)



### Dimensions


Frame size 2×D4 + 3×R8i (with air circuit breaker)






### Dimensions


Frame size 2×D4 + 3×R8i (with air circuit breaker) (continued)








Frame size 3×D4 + 4×R8i






Frame size 3×D4 + 4×R8i (continued)




Frame size 3×D4 + 4×R8i (with load switch-disconnector)



Dimensions




Frame size 3×D4 + 4×R8i (with load switch-disconnector) (continued)




Dimensions

Frame size 3×D4 + 4×R8i (with load switch-disconnector) (continued)




**Frame size 3×D4 + 4×R8i (with air circuit breaker)**




### Dimensions



Frame size 3xD4 + 4xR8i (with air circuit breaker) (continued)




Frame size 3×D4 + 4×R8i (with air circuit breaker) (continued)



Dimensions


### Dimensions



Common motor terminal cubicle


Depending on the drive size, the common motor terminal cubicle is either 300, 400 or 600 mm wide. Refer to the cabinet line-up tables at the beginning of this chapter.

300 mm




Dimensions

**400 mm**



600 mm



Dimensions

# Resistor braking

---

## What this chapter contains

This chapter describes the resistor braking options of the ACS800-07.

## Resistor braking options

The following ACS800-07 (>500 kW) drives are available with brake choppers and resistors. For information on braking equipment for other ACS800-07 types, or custom resistor braking equipment, contact your local ABB representative.

$U_N$	ACS800-07 type	Brake chopper type (+D150)	Brake resistor type (+D151)
400 V	ACS800-07-0610-3	2 × NBRA-659	2 × (2 × SAFUR180F460)
	ACS800-07-0770-3	2 × NBRA-659	2 × (2 × SAFUR180F460)
	ACS800-07-0870-3	3 × NBRA-659	3 × (2 × SAFUR180F460)
	ACS800-07-1030-3	3 × NBRA-659	3 × (2 × SAFUR180F460)
500 V	ACS800-07-0760-5	2 × NBRA-659	2 × (2 × SAFUR200F500)
	ACS800-07-0910-5	2 × NBRA-659	2 × (2 × SAFUR200F500)
	ACS800-07-1090-5	3 × NBRA-659	3 × (2 × SAFUR200F500)
	ACS800-07-1210-5	3 × NBRA-659	3 × (2 × SAFUR200F500)
690 V	ACS800-07-0750-7	2 × NBRA-669	2 × (2 × SAFUR200F500)
	ACS800-07-0870-7	2 × NBRA-669	2 × (2 × SAFUR200F500)
	ACS800-07-1060-7	3 × NBRA-669	3 × (2 × SAFUR200F500)
	ACS800-07-1160-7	3 × NBRA-669	3 × (2 × SAFUR200F500)

### Chopper/Resistor combinations – Technical data

The following table contains the technical data of some chopper/resistor combinations.

$U_N$	Chopper(s)	Resistors	$R$ (ohm)	$P_{brmax}$ (kW)	$P_{cont}$ (kW)	$I_{max}$ (A)	Duty Cycle (10/60 s)		Duty Cycle (1/5 min)	
							$P_{br}$ (kW)	$I_{rms}$ (A)	$P_{br}$ (kW)	$I_{rms}$ (A)
400 V	1 × NBRA-659	2 × SAFUR180F460	1.2	353	54	545	287	444	167	257
	2 × NBRA-659	2 × (2 × SAFUR180F460)	1.2	706	108	1090	575	888	333	514
	3 × NBRA-659	3 × (2 × SAFUR180F460)	1.2	1058	162	1635	862	1332	500	771
500 V	1 × NBRA-659	2 × SAFUR200F500	1.35	403	54	605	287	355	167	206
	2 × NBRA-659	2 × (2 × SAFUR200F500)	1.35	806	108	1210	575	710	333	412
	3 × NBRA-659	3 × (2 × SAFUR200F500)	1.35	1208	162	1815	862	1065	500	618
690 V	1 × NBRA-669	2 × SAFUR200F500	1.35	404	54	835	287	355	167	206
	2 × NBRA-669	2 × (2 × SAFUR200F500)	1.35	807	108	1670	575	514	333	298
	3 × NBRA-669	3 × (2 × SAFUR200F500)	1.35	1211	162	2505	862	771	500	447

$U_N$  = Nominal voltage

$R$  = Resistance of specified resistors (per chopper)

$P_{brmax}$  = Maximum short-term (1 min every 10 mins) braking power

$P_{cont}$  = Maximum continuous braking power

$I_{max}$  = Maximum peak current

$P_{br}$  = Braking power for the specified duty cycle

$I_{rms}$  = Corresponding RMS current

### Brake resistors – Technical data

The following table contains the technical data for the resistors supplied by ABB.

Type	$U_N$ (V)	$R$ (ohm)	$E_R$ (kJ)	$P_{Rcont}$ (kW)
SAFUR125F500	500	4.0	3600	9.0
SAFUR210F575	575	3.4	4200	10.5
SAFUR200F500	500	2.7	5400	13.5
SAFUR180F460	460	2.4	6000	15.0

$U_N$  Nominal voltage

$R$  Resistance

$E_R$  Short energy pulse that the resistor assembly will withstand each 400 seconds

$P_{Rcont}$  Continuous power (heat) dissipation of the resistor when placed correctly. Energy  $E_R$  dissipates in 400 seconds.



## Verifying the capacity of the braking equipment

1. Calculate the maximum power ( $P_{\max}$ ) generated by the motor during braking.
2. Ensure the following condition is met:

$$P_{\text{brmax}} \geq P_{\max}$$

The  $P_{\text{brmax}}$  values specified in the technical data table above are for the reference braking cycle (1 minute of braking, 9 minutes of rest). If the actual duty cycle does not correspond to the reference cycle, the maximum allowed braking power  $P_{\text{br}}$  must be used instead. In the technical data table,  $P_{\text{br}}$  is given for two additional braking cycles. See below for directions for calculating  $P_{\text{br}}$  for other braking cycles.

3. Check the resistors selection. The energy generated by the motor during a 400-second period must not exceed the heat dissipation capacity  $E_R$ .

If the  $E_R$  value is not sufficient, it is possible to use a four-resistor assembly in which two standard resistors are connected in parallel, two in series. The  $E_R$  value of the four-resistor assembly is four times the value specified for the standard resistor.

### Custom resistors

Resistors other than the standard resistors can be used provided that:

- the resistance is not lower than with the standard resistors



**WARNING!** Never use a brake resistor with a resistance below the value specified for the particular drive / brake chopper / resistor combination. The drive and the chopper are not able to handle the overcurrent caused by the low resistance.

- the resistance does not restrict the braking capacity needed, i.e.,

$$P_{\max} < \frac{U_{\text{DC}}^2}{R}$$

where

$P_{\max}$	maximum power generated by the motor during braking
$U_{\text{DC}}$	voltage over the resistor during braking, e.g., 1.35 · 1.2 · 415 VDC (when supply voltage is 380 to 415 VAC), 1.35 · 1.2 · 500 VDC. (when supply voltage is 440 to 500 VAC) or 1.35 · 1.2 · 690 VDC (when supply voltage is 525 to 690 VAC).
$R$	resistor resistance (ohm)

- the heat dissipation capacity ( $E_R$ ) of the resistors is sufficient for the application (see step 3 above).

### Calculating the maximum braking power ( $P_{br}$ )

- Braking energy transferred during any ten minute period must be less than or equal to the energy transferred during the reference braking cycle.
- The braking power must not exceed the rated maximum value  $P_{brmax}$ .

$$1. \quad n \times P_{br} \times t_{br} \leq P_{brmax} \times 60 \text{ s}$$

$$2. \quad P_{br} \leq P_{brmax}$$

$n$  = Number of braking pulses during a ten minute period

$P_{br}$  = Maximum allowed braking power (kW).

$t_{br}$  = Braking time (s)

$P_{brmax}$  = Maximum Braking Power for a reference cycle (kW)

#### Example 1


Duration of a braking cycle is 30 minutes. The braking time is 15 minutes.

**Result:** If the braking time exceeds 10 minutes, the braking is considered continuous. The allowed continuous braking power is 10% of the Maximum Braking Power ( $P_{brmax}$ ).

#### Example 2

Duration of a braking cycle is three minutes. The braking time is 40 seconds.

$$1. \quad P_{br} \leq \frac{P_{brmax} \times 60 \text{ s}}{4 \times 40 \text{ s}} = 0.375 \times P_{brmax}$$




$$2. \quad P_{br} < P_{brmax} \quad \text{O.K.}$$

**Result:** The maximum allowed braking power for the cycle is 37 % of the rated value given for the reference cycle.

**Example 3**

Duration of a braking cycle is three minutes. The braking time is 10 seconds.

$$\underline{1.} \quad P_{br} \leq \frac{P_{brmax} \times 60 \text{ s}}{4 \times 10 \text{ s}} = 1.5 \cdot P_{brmax}$$



$$\underline{2.} \quad P_{br} > P_{brmax} \quad \text{Not allowed.}$$

**Result:** The maximum allowed braking power for the cycle is equal to the Maximum Braking Power ( $P_{brmax}$ ) given for the reference cycle.

## Custom resistor installation and wiring

Effective cooling of the resistors must be ensured.



**WARNING!** All materials near the brake resistors must be non-flammable. The surface temperature of the resistors is high. The temperature of the air rising from the resistors is hundreds of degrees Celsius. Protect the resistors against contact.

For resistor cable, use the type specified for drive input cabling (specified under chapter *Technical Data*) so the input fuses will protect the resistor cable also. Two-conductor shielded cable with the same cross-sectional area can alternatively be used. The maximum length of the resistor cable is 10 m.

For protection against overheating, resistors with thermal circuit breakers (standard in ABB resistors) should be used. The circuit breakers should be wired to the ENABLE inputs of the brake choppers.




**WARNING!** The ENABLE input terminal blocks of the choppers are at intermediate circuit potential when the supply unit of the ACS800-07 is running. This voltage is extremely dangerous and may cause serious damage or injuries if the isolation level and protection conditions for the thermal circuit breakers are not sufficient. The normally-closed breakers should always be properly isolated (over 2.5 kV) and shrouded against contact.

**Note:** For the ENABLE input wiring, use cable rated as follows:

- twisted pair (screened type recommended)
- rated operating voltage between a core and earth ( $U_0$ ):  $\geq 750$  V
- insulation test voltage  $> 2.5$  kV

The following is a wiring diagram example of the resistor connection.



## Brake circuit commissioning

In the drive application program, overvoltage control of the drive must be disabled for correct operation of the brake chopper. This has been done at the factory for units with brake choppers.