

Operating Instructions (Overall)

AC Servo Motor & Driver MINAS A5II/A5 series



- Thank you for purchasing this Panasonic product.
- Before operating this product, please read the instructions carefully, and save this manual for future use.
- This product is for industrial equipment. Don't use this product at general household.

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Thank you for purchasing Digital AC Servo Motor & Driver, MINAS A5 series. This instruction manual contains information necessary to correctly and safely use the MINAS A5I/A5 series motor and driver. By reading this instruction manual, you will learn how to identify the model of the motor and driver that will be best suitable your application, how to wire and set up them, how to set parameters, and how to locate possible cause of symptom and to take corrective action.

This is the original instruction.

- **Caution** : 1) Any part or whole of this document shall not be reproduced without written permission from us.
 - 2) Contents of this document are subject to change without notice.

Before Using the Products

Check of the Driver Model ... Installation

Describes how to identify and select the desired product and components, how to read the specifications, and how to install the equipment.

2. Preparation Operating requirements and procedure

Shows the timing chart and the list of parameters, and describes how to make wiring and to use the front panel.

3. Connection

Wiring ... I/O settings

Shows block diagrams for each control mode and connection diagrams to the host controllor, I/O settings.

4. Setup Describes parameters ... JOG running

Shows describes parameters and procedure of test operation.

5. Adjustment

Gain adjustment ... Auto tuning

Describes various adjusting method including auto tuning and manual gain tuning.

6. When in Trouble

Read this section when you encounter trouble or error.

7. Supplement

Contains S-T characteristic diagram, dimensional outline drawing, supplemental description on communications and operation.

5

Organization of this manual	page 3
Safety Precautions	
Conformance to international standards	
Maintenance and Inspections	
1. Before Using the Products	1-1
1. Introduction	1-2
2. Driver	1-3
3. Motor	1-21
4. Check of the Combination of the Driver and the Motor	1-23
6. Installation	1-30
7. Permissible Load at Output Shaft	1-37
2. Preparation	2-1
1. Conformance to international standards	2-2
2. System Configuration and Wiring	2-10
3. Wiring to the Connector, X1	2-51
4. Wiring to the Connector, X2	2-51
5. Wiring to the Connector, X3	2-53
6. Wiring to the Connector, X4	2-54
7. Wiring to the Connector, X5	2-55
8. Wiring to the Connector, X6	2-57
9. Wiring to the Connector, X7	2-60
10. Timing Chart	2-61
11. Built-in Holding Brake	2-65
12. Dynamic Brake	2-67
13. Setup of Parameter and Mode	2-72
14. Setup of command division and multiplication ratio (electronic gear ratio)	2-86
15. How to Use the Front Panel	2-88
3. Connection	3-1
1. Outline of mode	3-2
2. Control Block Diagram	3-14
3. Wiring to the Connector, X4	3-20
4. Inputs and outputs on connector X4	3-32

5

6

7

1. Describes parameters	
2. JOG running	4-66
-	
5. Adjustment	5-1

1. Gain Adjustment	5-2
2. Real-Time Auto-Gain Tuning	5-4
3. Adaptive Filter	5-24
4. Manual Auto-Gain Tuning (Basic)	5-27
5. Manual Auto-Gain Tuning (Application)	5-38
6. About Homing Operation	5-60

6. When in Trouble		
1. When in Trouble	6-2	
2. Setup of gain pre-adjustment protection	6-20	
3. Troubleshooting	6-23	


1. Safety function	7-2
2. Absolute System	7-10
3. Setup Support Software, PANATERM	7-26
4. Communication	7-27
5. Motor Characteristics (S-T Characteristics)	7-55
6. Dimensions	7-73
7. Options	7-94

Warranty	
Cautions for Proper Use	
After-Sale Service	Back cover

The following explanations are for things that must be observed in order to prevent harm to people and damage to property.

• Misuses that could result in harm or damage are shown as follows, classified according to the degree of potential harm or damage.

🔥 Danger	Indicates great possibility of death or serious injury.	
A Caution	Indicates the possibility of injury or property damage.	
 The following indications show things that must be observed. 		





Do not subject the Product to water, corrosive or flammable gases, and combustibles.	Failure to observe this instruc- tion could result in fire, electrical	
Do not place combustibles near by the motor, driverd regenerative resistor and dynamic brake resister	shocks, damages and break- downs.	
Don't use the motor in a place subject to exces- sive vibration or shock.	Failure to observe this instruc- tion could result in electrical shock, injury or fire.	
Don't use cables soaked in water or oil.	Failure to observe this instruc- tion could result in electrical shocks, damages and break- downs.	
The installation area should be away from heat generating objects such as a heater and a large wire wound resistor.	Failure to observe this instruc- tion could result in fire and	
Never connect the motor directly to the commer- cial power supply.	breakdowns.	
Don't attempt to carry out wiring or manual opera- tion with wet hand.	Failure to observe this instruc- tion could result in electrical shock, injury or fire.	
Do not put your hands in the servo driver.	Failure to observe this instruc- tion could result in burn and electrical shocks.	

	In the case of the motor with shaft end keyway, do not touch the keyway with bare hands.	Failum to above this isstere	
\bigcirc	Do not touch the rotating portion of the motor while it is running. Failure to observe this instruction could result in damages and breakdowns.	Failure to observe this instruc- tion could result in personal injury.	
	Do not touch the motor, servo driver, heat sink, regenerative resistor and dynamic brake resister, since they become very hot.	Failure to observe this instruc- tion could result in burns.	
	Do not drive the motor with external power	Failure to observe this instruc- tion could result in fire.	
	Do not subject the cables to excessive force, heavy object, or pinching force, nor damage the cables.	Failure to observe this instruc- tion could result in electrical shocks, damages and break- downs.	
	Installation area should be free from excessive dust, and from splashing water and oil.	Failure to heed this precaution will result in electric shock, per- sonal injury, fire, malfunction or damage.	
	Mount the motor, driver and peripheral equip- ments on incombustible material such as metal.	Installation on a flammable ma- terial may cause fire.	
	Wiring has to be carried out by the qualified and authorized specialist.	Allowing a person with no ex- pertise to carry out wiring will result in electrical shocks.	
Correctly run and arrange wirin	Correctly run and arrange wiring.	Incorrect wiring will result in short circuit, electric shock, per- sonal injury, etc.	
	After correctly connecting cables, insulate the live parts with insulator.	Incorrect wiring will result short circuit, electric shock, fire or malfunction.	
	Ground the earth terminal of the motor and driver without fail.	Floating ground circuit will cause electric shock.	
	Install and mount the Product and machinery securely to prevent any possible fire or accidents incurred by earthquake.	Failure to heed this requirement will result in electric shock, per-	
	Install an emergency stop circuit externally so that you can stop the operation and shut off the power immediately.	sonal injury, fire, malfunction or damage.	
	Install an overcurrent protection, earth leakage breaker, over-temperature protection and emer- gency stop apparatus without fail. Check and confirm the safety of the operation	Failure to heed these require- ments will result in electric shock, personal injury or fire.	
	after the earthquake. Before transporting, wiring and inspecting the driver, turn off power and wait for a time longer than that specified on the name plate on the side panel of the product; and make sure that there is no risk of electrical shock.	Energized circuit will cause electric shock.	

2

Preparation

5

Safety Precautions Please observe safety precautions fully.



	Do not hold the motor cable or motor shaft during the transportation.	Failure to observe this instruc- tion could result in injuries.	
	Don't drop or cause topple over of something dur- ing transportation or installation.	Failure to observe this instruc- tion could result in injuries and breakdowns.	
	Do not step on the Product nor place the heavy object on them.	Failure to observe this instruc- tion could result in electrical shocks, injuries, breakdowns and damages.	
	Don't use the equipment under direct sunshine.	Failure to heed these instruc- tions will cause personal injury or fire.	
	Do not block the heat dissipating holes or put the foreign particles into them.	Failure to observe this instruc- tion could result in electrical shocks and fire.	
	Do not give strong impact shock to the Product.	Failure to observe this instruc- tion could result in breakdowns.	
\bigcirc	Do not give strong impact shock to the motor shaft.	Failure to observe this instruc- tion could result in a failure of the detector etc.	
•	Do not turn on and off the main power of the driv- er repeatedly.	Failure to observe this instruc-	
	Never run or stop the motor with the electro-mag- netic contactor installed in the main power side.	tion could result in breakdowns.	
-	Do not make an extreme gain adjustment or change of the drive. Do not keep the machine running/operating unsta- bly.	Failure to observe this instruc- tion could result in injuries.	
	Do not use the built-in brake as a "Braking" to stop the moving load.	Failure to observe this instruc- tion could result in injuries and breakdowns.	
	Do not approach to the machine since it may sud- denly restart after the power resumption. Design the machine to secure the safety for the operator even at a sudden restart.	Failure to observe this instruc- tion could result in injuries.	
	Never attempt to perform modification, dismantle or repair.	Failure to heed this instruction will result in fire, electric shock, personal injury or malfunction.	

Make an appropriate mounting of the Product matching to its wight and output rating.	Failure to heed these require-
Observe the specified mounting method and di- rection.	 ments will result in personal injury or malfunction.
Use the eye bolt of the motor for transportation of the motor only, and never use this for transporta- tion of the machine.	Using it for transportation of the machine will cause personal injury or malfunction.
Don't place any obstacle object around the motor and peripheral, which blocks air passage.	Temperature rise will cause burn injury or fire.
Adjust the motor and driver ambient environmen- tal condition to match the motor operating tem- perature and humidity.	Failure to heed these require-
Create the specified clearance between the driver and the control panel inner surface or other de- vices.	 ments will result in personal injury or malfunction.
Observe the specified voltage.	Operation from a voltage out- side the rated voltage will cause electric shock, personal injury or fire.
Connect the brake control relay to the relay which is to shut off at emergency stop in series.	Missing of one of these devices will result in personal injury or malfunction.
Provide protection device against idling of electro- magnetic brake or gear head, or grease leakage from gear head.	No protection will cause per- sonal injury, damage, pollution or fire.
Use the motor and the driver in the specified com- bination.	Not using the motor and the driver in the specified combina- tion will result in fire.
Test-run the securely fixed motor without loading to verify normal operation, and then connect it to the mechanical system.	Operation using a wrong mode or wrong wiring connection will result in personal injury.
When any error occurs, remove the cause and release the error after securing the safety, then restart.	Not removing the cause of the error will result in personal in- jury.
If the driver fails, shut off the power on the power supply side of the driver.	Allowing a large current to con- tinue to pass will result in fire.
Maintenance must be performed by an experi- enced personnel.	Wrong wiring will cause person al injury or electric shock.
Always keep power disconnected when the power is not necessary for a long time.	Improper operation will cause personal injury.

insulating them with tape.

This Product shall be treated as Industrial Waste when you dispose.

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

7

Supplement













Conformed Standards

		Driver	Motor
	EMC Directives	EN55011 EN61000-6-2 EN61800-3	_
EC Direc-		EN61800-5-1	
tives		_	
UL Standards		UL508C (E164620)	UL1004-1, UL1004-6 (E327868)
CSA Standards		C22.2 No.14	C22.2 No.100
Radio Waves Act (South Korea) (KC) *2		KN11 KN61000-4-2, 3, 4, 5, 6, 8, 11	_

IEC : International Electrotechnical Commission

EN : Europaischen Normen

EMC : Electromagnetic Compatibility

UL : Underwriters Laboratories

CSA: Canadian Standards Association

Pursuant to the directive 2004/108/EC, article 9(2)

Panasonic Testing Centre

Panasonic Service Europe, a division of Panasonic Marketing Europe GmbH

Winsbergring 15, 22525 Hamburg, F.R. Germany

· When export this product, follow statutory provisions of the destination country.

*1 A5IE and A5E series doesn't correspond to the functional safety standards.

*2 Information related to the Radio Waves Act (South Korea)

This servo driver is a Class A commercial electromagnetic radio wave generator not designed for home use. The user and distributor should be aware of this fact.

A 급 기기 (업무용 방송통신기자재)

이 기기는 업무용(A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

(대상기종 : Servo Driver)

This product is not an object of China Compulsory Certification (CCC).



For details on compatibility with international standard, refer to P.2-2 Conformance to international standards.

Routine maintenance and inspection of the driver and motor are essential for the proper and safe operation.

Notes on Maintenance and Inspection

- Turn on and turn off should be done by operators or inspectors themselves. When establishing a system using safety functions, completely understand the applicable safety standards and the operating instruction manual or technical documents for the product.
- 2) Internal circuit of the driver is kept charged with high voltage for a while even after power-off. Turn off the power and allow 15 minutes or longer after LED display of the front panel has gone off, before performing maintenance and inspection.
- 3) Disconnect all of the connection to the driver when performing megger test (Insulation resistance measurement) to the driver, otherwise it could result in breakdown of the driver.
- 4) Do not use benzine, thinner, alcohol, acidic cleaner and alkaline cleaner because they can discolor or damage the exterior case.
- 5) The upper fan on H-frame driver is kept deactivated while servo is off, for the purpose of energy saving. This is normal.

Inspection Items and Cycles

General and normal running condition

Ambient conditions : 30 °C (annual average), load factor of 80 % or lower, operating hours of 20 hours or less per day.

Perform the daily and periodical inspection as per the items below.

Туре	Cycles	Items to be inspected			
Daily inspection	Daily	 Ambient temperature, humidity, speck, dust or foreign object Abnormal vibration and noise Main circuit voltage Odor Lint or other particles at air holes Cleanness at front portion of the driver and connector Damage of the cables Loose connection or misalignment between the motor and machine or equipment Pinching of foreign object at the load 			
Motor with Gear Reducer	Annual	 Loose tightening Trace of overheat Damage to the terminal block Loose fasteners on terminal block 			

Note

Inspection cycle may change when the running conditions of the above change.

Guideline for Parts Replacement

Use the table below for a reference. Parts replacement cycle varies depending on the actual operating conditions. Defective parts should be replaced or repaired when any error have occurred.



Disassembling for inspection and repair should be carried out only by authorized dealers or service company.

Product	Component	Standard replacement cycles (hour)	Note	
	Smoothing condenser	Approx. 5 years		
	Cooling fan	2 to 3 years (10000 to 30000 hours)		
	Aluminum electrolytic capacitor (on PCB)	Approx. 5 years		
Driver	Rush current preventive relay	Approx. 100000 times (depending on working condition)		
	Rush current preventive resistor	Approx. 20000 times (depending on working condition)	These hours or cycles are reference. When you experience any	
	Bearing	3 to 5 years (20000 to 30000 hours)	error, replacement is required even before this standard	
	Oil seal	5000 hours	replacement cycle.	
	Encoder	3 to 5 years (20000 to 30000 hours)		
Motor	Battery for absolute encoder	Life time varies depending on working conditions. Refer to the Operating Instructions attached to the battery for absolute encoder.		

Related page P.7-126 "Warranty"

1. Before Using the Products

1. Introduction	
Outline1-2	
On Opening the Product Package1-2	
2. Driver	
Check of the Model1-3	
Parts Description	
A to E-frame1-4	
F-frame1-5	
G-frame1-6	
H-frame1-7	
D to F-frame (400 V)1-8	
G-frame (400 V)1-9	
H-frame (400 V)1-10	
Specifications1-11	
Block Diagram1-15	
3. Motor	
Check of the Model1-21	
Parts Description1-22	
4. Check of the Combination of the Driver and the Motor	
Incremental Specifications, 20-bit1-23	
Absolute Specifications, 17-bit1-25	
Special Order Product1-27	
Junction cable for motor1-29	
5. Installation	
Driver1-30	
Motor1-34	
C. Dermissible Load at Output Chaft	
6. Permissible Load at Output Shaft Motor1-37	

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

7

Supplement

1. Introduction

Outline

The AC Servo Motor & Driver, MINAS A5 series is the latest servo system that meets all demands from a variety of machines which require high speed, high precision and high performance or which require simplified settings.

Compared with the preceding A4 series, product of A5 series offers superior performance while requiring simple setup and adjustment by the user.

Newly designed motors have wide range of outputs from 50 W to 15.0 kW, associated with 20-bit incremental encoder and reduced cogging torque. (Only for position control type have range of outputs from 50 W to 5.0 kW.)

They are compatible with 2 closed controls (serial communication type and A-/B-phase output type) and provided with various automatic adjusting functions such as real time auto tuning with many automatic setting parameters to make complex tuning easy. (Only for position control type do not conform to full-closed control.)

In addition to the functions of MINAS A5 series, MINAS A5I series adopted two-degreeof-freedom control system which enables faster and more precise adjustment. It also supports the new feature "fit gain" function of PANATERM, which provides an automatic gain adjustment in a simple and short time.

These motors assure higher stability with low stiffness machine and high-speed, high accurate operation with high stiffness machine. They can be used in combination with a wide variety of machines.

This manual is written as a complete guide for you so that you can fully and correctly make use of all functions available from MINAS A5.

When describing A5I series specific functions and features, this manual distinguishes them by using **A5I** symbols and notes.

Before Using the Products


1. Introduction

On Opening the Product Package

- Make sure that the model is what you have ordered.
- Check if the product is damaged or not during transportation.
- Check if the Operating Instructions (safety) are included or not.
- Check if the power connector, motor connectors, connector for external regenerative resistor connection (D-frame (400 V) and E-frame) and safety by-pass plug are included or not.

(Neither the power connector nor motor connector are included to F-frame to H-frame.) (Safety bypass plug is not supplied with only for position control type because it does not use this plug.)

Contact to a dealer if you find any failures.



Related page • P.1-23 "Check of the Combination of the Driver and the Motor"


1-3



2. Driver

Parts Description

A to D-frame



regenerative resistor B2 Connector X5: NC (Normally short-circuit for feedback scale B3 to B2) connection V Connector X6: Terminals for motor Ø for encoder connection connection Connector XB: 0 for motor connection 03JFAT-SAXGSA-L (JST) Charge lamp Screws for earth Connector XC: (x2) Connector for external LED cover regenerative resistor 04JFAT-SAXGSA-L (JST) * NC is no connect. Safety by-pass prug




• Connector XA and XB are attached in A to D-frame driver.

Connector XA, XB and XC are attached in E-frame driver.

• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

F-frame



Terminal cover



Preparation


7

Note 🤟

• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

Related page :• P.1-23 "Check of the Combination of the Driver and the Motor"• P.1-30 "Installation"• P.2-10 "Driver and List of Applicable Peripheral Equipments"• P.7-73 to 7-78 "Dimensions"


G-frame



• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

Related page ··• P.1-23 "Check of the Combination of the Driver and the Motor"• P.1-30 "Installation"• P.2-10 "Driver and List of Applicable Peripheral Equipments"• P.7-73 to 7-78 "Dimensions"

H-frame




Before Using the Products


1

3

D, E-frame (400 V)



F-frame (400 V)






Connector X1 and X2 are attached in A to D-frame driver.


- Connector XA, XB, XC and XD are attached in D and E-frame (400 V) driver.
- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

G-frame (400 V)



Related page ...
 P.1-23 "Check of the Combination of the Driver and the Motor"
 P.2-10 "Driver and List of Applicable Peripheral Equipments"
 P.7-73 to 7-78 "Dimensions"

H-frame (400 V)



Related page ↔
 P.1-23 "Check of the Combination of the Driver and the Motor"
 P.2-10 "Driver and List of Applicable Peripheral Equipments"
 P.7-73 to 7-78 "Dimensions"

5

6

7

Before Using
the Products

2. Driver

Specifications (Velocity, position, torque, full-closed control type)

	100 V	Main circuit		Single phase, 100 V to 120 V +10 % -15 % 50 Hz/60 Hz			
		Control circuit		Single phase, 100 V to 120 V +10 % -15 % 50 Hz/60 Hz			
-		Main	A to D-frame	Single/3-phase, 200 V to 240 V +10 % -15 % 50 Hz/60 Hz			
Input power	200 V	circuit	E to H-frame	3-phase, 200 V to 230 V +10 % -15 % 50 Hz/60 Hz			
ower	200 V	Control	A to D-frame	Single phase, 200 V to 240 V +10 % -15 % 50 Hz/60 Hz			
		circuit	E to H-frame	Single phase, 200 V to 230 V +10 % 50 Hz/60 Hz			
	400 V		circuit	3-phase, 380 V to 480 V +10 % -15 % 50 Hz/60 Hz			
	*1	Contro	ol circuit	DC24 V ± 15 %			
Wit	hstand vo	ltage		Primary to earth: withstand 1500 VAC, 1 min, (sensed current: 20 mA) [100 V/200 V] withstand 1960 VAC, 1 min, (sensed current: 20 mA) [400 V] * 400 V control circuit is excluded.			
		tempe	erature	Ambient temperature: 0°C to 55°C (free from freezing) Storage temperature: -20°C to 65°C (Max. temperature guarantee: 80 °C for 72 hours free from condensation*2)			
Env	vironment	hun	nidity	Both operating and storage : 20 % to 85 %RH or less (free from condensation*2)			
			tude	Lower than 1000 m			
			ration	5.88 m/s ² or less, 10 Hz to 60 Hz (No continuous use at resonance frequency)			
	ntrol meth		allon	IGBT PWM Sinusoidal wave drive			
		lou		17-bit (131072 resolution) absolute encoder, 7-wire serial			
Enc	coder feed	lback		20-bit (1048576 resolution) incremental encoder, 5-wire serial			
-				A/B phase, initialization signal defferential input.			
				Manufacturers that support serial communication scale:			
Fee	edback so	ale feed	back	Mitsutoyo Corp.			
				Magnescale Co., Ltd. (old Sony Manufacturing Systems Corp.)			
	Control signal		Input	General purpose 10 inputs The function of general-purpose input is selected by parameters.			
Pa			Output	General purpose 6 outputs The function of general-purpose input is selected by parameters.			
rall	Analog	anal	Input	3 inputs (16-bit A/D : 1 input, 12-bit A/D : 2 inputs)			
el	Analog	signal	Output	2 outputs (Analog monitor: 2 output)			
Parallel I/O con				2 inputs (Photocoupler input, Line receiver input)			
CO I			Input	Photocoupler input is compatible with both line driver I/F and open collector I/F.			
Ine				Line receiver input is compatible with line driver I/F.			
nector	Pulse si	gnal		4 outputs (Line driver: 3 output, open collector: 1 output)			
Ĩ		-		Feed out the encoder feedback pulse (A, B and Z-phase) or feedback scale pulse (EXA,			
			Output	EXB and EXZ-phase) in line driver. Z-phase and EXZ-phase pulse is also fed out in open			
				collector.			
	L		USB	Connection with PC etc.			
	mmunicat	ion	RS232	1 : 1 communication to a host.			
fun	ction		RS485				
S ₀ ⁴	ety functi	<u></u>	113463	1 : n communication to a host.			
Sal	ery functi	011		Used for functional safety.			
Fro	nt panel			 (1) 5 keys (MODE, SET, UP, DOWN, SHIFT) (2) LED (6-digit) (3) Monitor connector (Analog monitor output (2 ch), Digital monitor output (1 ch)) 			
Reg	generatio	n		A, B, G and H-frame: no built-in regenerative resistor (external resistor only) C to F-frame: Built-in regenerative resistor (external resistor is also enabled.)			
Dyr	namic bra	ke		A to G-frame: Built-in (external resistor is also available to G-frame) H-frame: External only			
Control mode				Switching among the following 7 mode is enabled, (1) Position control (2) Velocity control (3) Toque control (4) Position/Velocity control (5) Position/Torque control (6) Velocity/Torque control (7) Full-closed control			

Caution 🔅

*1 The specification out of Japan.

*2 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

Related page • P.1-30 "Installation of Driver" • P.1-34 "Installation of Motor"

	ntrol input	1		 (1) Servo-ON input (2) Alarm clear input (3) Gain switching input (4) Positive direction over-travel inhibition input (5) Negative direction over-travel inhibition input (6) Forced alarm input (7) Inertia ratio switching input 				
Control output				 (1) Servo-Alarm output (2) Servo-Ready output (3) External brake release signal (4) Speed arrival output (5) Torque in-limit signal output (6) Zero-speed detection output signal (7) Alarm output (8) Alarm attribute output (9) Servo on status output* 				
	Control input			 (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increase switching (4) Damping control switching (5) Torque limit switching (6) Control mode switching 				
I	Control output			(1) Positioning complete (In-position) (2) Positional command ON/OFF output				
		frequency		Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps				
Posit	Pulse input			Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction)				
Position control		Electronic (Division/M command p	lultiplication of	Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times.				
ntro		Smoothing filter		Primary delay filter or FIR type filter is adaptable to the command input				
<u> </u>	Analog input	log Torque limit command		Individual torque limit for both positive and negative direction is enabled.				
I	mput	Torque feed	I forward input	Analog voltage can be used as torque feed forward input.				
I			d Observer	Available				
1	Damping	g Control		Available				
L	Two-deg system	ree-of-free	edom control	Only available at A5I Series				
-	Control	· · · · · · · · · · · · · · · · · · ·		 (1) Selection of internal velocity setup (2) Speed zero clamp (3) Speed command sign input (4)Control mode switching 				
1	Control of	· ·		(1) Speed coincidence output (2)Speed command ON/OFF output				
<	Analog	Velocity c input		Speed command input can be provided by means of analog voltage. Parameters are used for scale setting and command polarity. (6 V/Rated rotational speed Defau				
Velocity control	input	input	nit command	Individual torque limit for both positive and negative direction is enabled.				
2	Torque feed forward input			Analog voltage can be used as torque feed forward input. Switching the internal 8speed is enabled by command input.				
ontrol	Internal velocity command Soft-start/down function			Individual setup of acceleration and deceleration is enabled, with 0 s/1000 r/min to 10 s/1000 r/min Sigmoid acceleration/deceleration is also enabled.				
1	Zero-sp	ed clamp		0-clamp of internal velocity command with speed zero clamp input is enabled.				
1			Observer	Available				
	Instantaneous Speed Observer Two-degree-of-freedom control system			Only available at A5I Series				
L L	Control i	nput		(1) Speed zero clamp (2) Torque command sign input (3) Control mode switching				
q	Control	output		(1) Speed coincidence output (2) Speed in-limit output				
Torque control	Analog Torque command input input		ommand	Torque command input can be provided by means of analog voltage. Parameters are used for scale setting and command polarity. (3 V/rated torque Default)				
ontro	Speed limit function							
Itrol			n	Speed limit value with parameter t is enabled.				
ntrol	Speed li Control i	mit function	n	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching				
ntrol	Speed li	mit function nput putput		Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output				
ntrol	Speed li Control i	mit function nput output Max. com frequency	nmand pulse	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps				
	Speed li Control i Control o Pulse	mit function nput putput Max. com frequency Input puls format	nmand pulse / se signal	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction)				
	Speed li Control i Control o	nput Max. com frequency Input puls format Electronic (Division/M command p	nmand pulse y se signal c gear fultiplication of pulse)	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio ($\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}$) as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times.				
ntrol Full-closed control	Speed li Control i Control o Pulse	nput Max. com frequency Input puls format Electronic (Division/M command p Smoothin Torque lin	nmand pulse y se signal c gear fultiplication of pulse)	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio ($\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}$) as positional command input.				
	Speed li Control d Control d Pulse input	mit function nput Max. com frequency Input puls format Electronic (Division/M command p Smoothin Torque lin input	nmand pulse y se signal c gear fultiplication of pulse) ig filter	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for Photocoupler: 500 kpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times. Primary delay filter or FIR type filter is adaptable to the command input				
	Speed li Control d Control d Pulse input Analog input Setup ra	mit function nput Max. com frequency Input puls format Electronic (Division/M command p Smoothin Torque lin input Torque feed nge of divi	nmand pulse y se signal c gear fultiplication of pulse) ng filter nit command forward input	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for Photocoupler: 500 kpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times. Primary delay filter or FIR type filter is adaptable to the command input Individual torque limit for both positive and negative direction is enabled. Analog voltage can be used as torque feed forward input. 1/40 times to 160 times The ratio of encoder pulse (numerator) to external scale pulse (denominator) can be set to 1 to 2 ²⁰				
	Speed li Control d Control d Pulse input Analog input Setup ra multiplic	mit function nput Max. com frequency Input puls format Electronic (Division/M command p Smoothin Torque lin input Torque feed nge of divi	armand pulse y se signal c gear fultiplication of pulse) ng filter nit command I forward input ision/	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for Photocoupler: 500 kpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio ($\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}$) as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times. Primary delay filter or FIR type filter is adaptable to the command input Individual torque limit for both positive and negative direction is enabled. Analog voltage can be used as torque feed forward input. 1/40 times to 160 times				
Full-closed control	Speed li Control d Control d Pulse input Analog input Setup ra multiplic	mit function nput Max. com frequency Input puls format Electronic (Division/M command µ Smoothin Torque lin input Torque feed ange of divi ation of fee	armand pulse y se signal c gear fultiplication of pulse) ng filter nit command I forward input ision/	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times. Primary delay filter or FIR type filter is adaptable to the command input Individual torque limit for both positive and negative direction is enabled. Analog voltage can be used as torque feed forward input. 1/40 times to 160 times The ratio of encoder pulse (numerator) to external scale pulse (denominator) can be set to 1 to 2 ²⁰ (numerator) to 1 to 2 ²⁰ (denominator), but should be set to a ratio within the range shown above. Available The load inertia is identified in real time by the driving state of the motor operating according to th command given by the controlling device and set up support software "PANATERM".				
Full-closed control	Speed li Control d Control d Pulse input Analog input Setup ra multiplic Damping Auto tun	mit function nput Max. com frequency Input puls format Electronic (Division/M command p Smoothin Torque lind input Torque feed ation of fee g Control	armand pulse / se signal c gear fultiplication of pulse) ug filter nit command forward input ision/ edback scale	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increases switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times. Primary delay filter or FIR type filter is adaptable to the command input Individual torque limit for both positive and negative direction is enabled. Analog voltage can be used as torque feed forward input. 1/40 times to 160 times The ratio of encoder pulse (numerator) to external scale pulse (denominator) can be set to 1 to 2 ²⁰ (numerator) to 1 to 2 ²⁰ (denominator), but should be set to a ratio within the range shown above. Available The load inertia is identified in real time by the driving state of the motor operating according to th command given by the controlling device and set up support software "PANATERM". The gain is set automatically in accordance with the rigidity setting.				
Full-closed control	Speed li Control d Control d Pulse input Analog input Setup ra multiplic Damping Auto tum Division o	mit function nput Max. com frequency Input puls format Electronic (Division/M command µ Smoothin Torque lin input Torque feed ation of fee g Control ing f encoder fee	armand pulse / se signal c gear fultiplication of pulse) ig filter nit command forward input ision/ edback scale	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increas switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for Ine driver : 4 Mpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times. Primary delay filter or FIR type filter is adaptable to the command input Individual torque limit for both positive and negative direction is enabled. Analog voltage can be used as torque feed forward input. 1/40 times to 160 times The ratio of encoder pulse (numerator) to external scale pulse (denominator) can be set to 1 to 2 ²⁰ (numerator) to 1 to 2 ²⁰ (denominator), but should be set to a ratio within the range shown above. Available The load inertia is identified in real time by the driving state of the motor operating according to th command given by the controlling device and set up support software "PANATERM". The gain is set automatically in accordance with the rigidity setting. Set up of any value is enabled (encoder feedback pulses count is the max				
	Speed li Control d Control d Pulse input Analog input Setup ra multiplic Damping Auto tun	mit function nput Max. com frequency Input puls format Electronic (Division/M command µ Smoothin Torque lin input Torque feed ation of fee g Control ing f encoder fee	armand pulse / se signal c gear fultiplication of pulse) ug filter nit command forward input ision/ edback scale	Speed limit value with parameter t is enabled. (1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increases switching (4) Damping control switching (5) Torque limit switching (1) Full-closed positioning complete (2) Positional command ON/OFF output Exclusive interface for Photocoupler: 500 kpps Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction) Process command pulse frequency × electronic gear ratio ($\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}$) as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times. Primary delay filter or FIR type filter is adaptable to the command input Individual torque limit for both positive and negative direction is enabled. Analog voltage can be used as torque feed forward input. 1/40 times to 160 times The ratio of encoder pulse (numerator) to external scale pulse (denominator) can be set to 1 to 2 ²⁰ (numerator) to 1 to 2 ²⁰ (denominator), but should be set to a ratio within the range shown above. Available The load inertia is identified in real time by the driving state of the motor operating according to the command given by the controlling device and set up support software "PANATERM". The gain is set automatically in accordance with the rigidity setting.				

* ASI : Only available on A5I series.

Before Using the Products

2. Driver

Specifications (Only for position control type)

		100 V	Main circuit		Single phase, 100 V to 120 V +10 % -15 % 50 Hz/60 Hz			
			Control circuit		Single phase, 100 V to 120 V $\begin{array}{c} +10 \ \% \\ -15 \ \% \end{array}$ 50 Hz/60 Hz			
			Main	A to D-frame	Single/3-phase, 200 V to 240 V +10 % -15 % 50 Hz/60 Hz			
	Input power	200 V	circuit	E to F-frame	3-phase, 200 V to 230 V +10 % -15 % 50 Hz/60 Hz			
	oower	200 V	Control	A to D-frame	Single phase, 200 V to 240 V +10 % -15 % 50 Hz/60 Hz			
			circuit	E to F-frame	Single phase, 200 V to 230 V +10 % -15 % 50 Hz/60 Hz			
		400 V	Main circuit	D to F-frame	3-phase, 380 V to 480 V +10 % -15 % 50 Hz/60 Hz			
			Control circuit	D to F-frame	DC24 V ± 15 %			
	Withstand voltage				Primary to earth: withstand 1500 VAC, 1 min, (sensed current: 20 mA) [100 V/200 V] withstand 1960 VAC, 1 min, (sensed current: 20 mA) [400 V] * 400 V control circuit is excluded.			
Bas	temperature		erature	Ambient temperature: 0°C to 55°C (free from freezing) Storage temperature: -20°C to 65°C (Max. temperature guarantee: 80 °C for 72 hours free from condensation ^{*2})				
ic (Env	vironment	humidity		Both operating and storage : 20 % to 85 %RH or less (free from condensation)			
òpe			Altitude		Lower than 1000 m			
oific			Vibr	ation	5.88 m/s ² or less, 10 Hz to 60 Hz (No continuous use at resonance frequency)			
Basic Specifications	Control method				IGBT PWM Sinusoidal wave drive			
ร	End	coder feed	dback		20-bit (1048576 resolution) incremental encoder, 5-wire serial			
		Control			General purpose 10 inputs The function of general-purpose input is selected by parameters.			
	Para	Control	Signal	Output	General purpose 6 outputs The function of general-purpose input is selected by parameters.			
	allel	Analog signal Output		Output	2 outputs (Analog monitor: 2 output)			
	Parallel I/O connector			Input	2 inputs (Photocoupler input, Line receiver input) Photocoupler input is compatible with both line driver I/F and open collector I/F. Line receiver input is compatible with line driver I/F.			
	ctor	Pulse si	gnal	Output	4 outputs (Line driver: 3 output, open collector: 1 output) Feed out the encoder feedback pulse (A, B and Z-phase) or feedback scale pulse (EXA, EXB and EXZ-phase) in line driver. Z-phase and EXZ-phase pulse is also fed out in open collector.			
		Communication USB function			Connection with PC etc.			
	Fro	nt panel			(1) 5 keys (2) LED (6-digit) (3) Analog monitor output (2 ch)			
	Re	generatio	n		A, B-frame: no built-in regenerative resistor (external resistor only) C to F-frame: Built-in regenerative resistor (external resistor is also enabled.)			
	Dyr	Dynamic brake			A to F-frame: Built-in			
	Cor	Control mode			(1) Position control (2) Internal velocity control (3) Position/ Internal velocity control			

Caution 🔅

*1 The specification out of Japan.

*2 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

Related page • P.1-30 "Installation of Driver" • P.1-34 "Installation of Motor"

Caution \Rightarrow Only for position control type is provided A-Frame to F-frame.

5

6


		Control inp	but	 Servo-ON input (2) Alarm clear input (3) Gain switching input Positive direction over-travel inhibition input Negative direction over-travel inhibition input Forced alarm input (7) Inertia ratio switching input 		
		Control output		 (1) Servo-Alarm output (2) Servo-Ready output (3) External brake release signal (4) Speed arrival output (5) Torque in-limit signal output (6) Zero-speed detection output signal (7) Alarm output (8) Alarm attribute output (9) Servo on status output* 		
			Max. command pulse frequency	Exclusive interface for Photocoupler: 500 kpps Exclusive interface for line driver : 4 Mpps		
	Position contro	Pulse	Input pulse signal format	Differential input ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction)		
	control	input	Electronic gear (Division/ Multiplication of command pulse)	Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 times to 1000 times.		
			Smoothing filter	Primary delay filter or FIR type filter is adaptable to the command input		
		Instantaneous Speed Observer		Available		
		Damping Control		Available		
Function		Two-degree-of-freedom control system		Only available at A5I Series		
ction		Control inp	out	(1) Selection of internal velocity setup (2) Speed zero clamp		
		Control output		Speed arrival		
	Interr	Internal velocity command		Switching the internal 8speed is enabled by command input.		
	Internal velocity contro	Soft-start/o	down function	Individual setup of acceleration and deceleration is enabled, with 0 s/1000 r/min 10 s/1000 r/min. Sigmoid acceleration/deceleration is also enabled.		
	ity co	Zero-speed clamp		0-clamp of internal velocity command with speed zero clamp input is enabled.		
	ntrol	Instantaneous Speed Observer		Available		
		Two-degree-of-freedom control system		Only available at A5II Series		
		Auto tuning		The load inertia is identified in real time by the driving state of the motor operating according to the command given by the controlling device and set up support software "PANATERM". The gain is set automatically in accordance with the rigidity setting.		
	Common	Division of pulse	encoder feedback	Set up of any value is enabled (encoder pulses count is the max.).		
	non	Protective function	Hard error	Over-voltage, under-voltage, over-speed, over-load, over-heat, over-current and encoder error etc.		
			Soft error	Excess position deviation, command pulse division error, EEPROM error etc.		
		Traceabilit	y of alarm data	The alarm data history can be referred to.		

* **A5II** : Only available on A5II series.




2. Driver **Block Diagram**

A, B-frame (100 V/200 V)



C, D-frame (100 V/200 V)



Note

• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

Before Using the Products

2

Preparation


3

Connection


4

5

E-frame (200 V)




F-frame (200 V)




Note

• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

G-frame (200 V)



H-frame (200 V)




Note


• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5. 3

Setup

D-frame (400 V)




E-frame (400 V)




Note

• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

F-frame (400 V)



G-frame (400 V)



Note

• The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5. G-frame: Only for position control type is not provided. Connection

Preparation


5

Setup


Supplement


When in Trouble

H-frame (400 V)




Note • The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided.





- MSME 750 W(400 V), 1.0 kW to 5.0 kW
- MDME 400 W to 15.0 kW
- MFME 1.5 kW to 4.5 kW
- MGMA 0.9 kW to 6.0 kW
- MHME 1.0 kW to 7.5 kW



e.g.) : Middle inertia type (MDME series, 1.0 kW)

Note 🔅 For details of specific model, refer to the Dimensions of Supplement. (P.7-79 to 7-93)

2

Preparation

3

Connection

4

Setup

4. Check of the Combination of the Driver and the Motor Incremental Specifications, 20-bit

This driver is designed to be used in a combination with the motor which are specified by us. Check the series name of the motor, rated output torque, voltage specifications and encoder specifications.

		Motor				Driver	
Power supply	Туре	Rated rotational speed	Model *1	Rated output	Model of velocity, position, torque and full-closed control type *2	Model of Only for position control type *3	Frame
Single			MSMD5AZG1 *	50 W	MAD�T1105	MAD�T1105E	A-frame
phase,			MSMD011G1 *	100 W	MAD�T1107	MAD�T1107E	A-II allie
100 V			MSMD021G1 *	200 W	MBD�T2110	MBD�T2110E	B-frame
100 V	MSMD		MSMD041G1 *	400 W	MCD�T3120	MCD�T3120E	C-frame
	_	3000 r/min	MSMD5AZG1 *	50 W	MAD�T1505	MAD�T1505E	A-frame
Single/	Low inertia		MSMD012G1 *	100 W			
3-phase,			MSMD022G1 *	200 W	MAD \bigcirc T1507	MAD�T1507E	
200 V			MSMD042G1 *	400 W	MBD�T2510	MBD�T2510E	B-frame
			MSMD082G1 *	750 W	MCD�T3520	MCD�T3520E	C-frame
Cinala			MSME5AZG1 *	50 W	MAD \bigcirc T1105	MAD�T1105E	A-frame
Single			MSME011G1 *	100 W	MAD�T1107	MAD�T1107E	A-Irame
phase, 100 V			MSME021G1 *	200 W	MBD�T2110	MBD�T2110E	B-frame
100 V			MSME041G1 *	400 W	MCD\CT3120	MCD OT3120E	C-frame
			MSME5AZG1 *	50 W			
			MSME012G1 *	100 W	MAD◇T1505	MAD�T1505E	A-frame
Single/			MSME022G1 *	200 W	MAD (>T1507	MAD \bigcirc T1507E	
3-phase,			MSME042G1 *	400 W	MBD\C72510	MBD O T2510E	B-frame
200 V (MSME082G1 *	750 W	MCD\CT3520	MCD O T3520E	C-frame
			MSME102G *	1.0 kW			1
	MSME		MSME152G *	1.5 kW	MDD \bigcirc T5540	MDD◇T5540E	D-frame
	Low inertia	3000 r/min	MSME202G *	2.0 kW	MED \bigcirc T7364	MED \bigcirc T7364E	E-frame
3-phase,	Low mertia		MSME302G *	3.0 kW	MFD \bigcirc TA390	MFD�TA390E	
200 V			MSME402G *	4.0 kW			F-frame
			MSME502G *	5.0 kW	MFD \bigcirc TB3A2	MFD \bigcirc TB3A2E	
			MSME084G1 *	750 W	MDD \bigcirc T2412	MDD O T2412E	D-frame
			MSME104G *	1.0 kW	MDD 	MDD O T3420E	
			MSME154G *	1.5 kW	MDD\0T3420	MDDOT3420E	
3-phase,			MSME204G *	2.0 kW	MED�T4430	MED T4430E	E-frame
400 V			MSME304G *	3.0 kW	MFD�T5440	MFD O T5440E	
			MSME404G *	4.0 kW	- MFD \bigcirc TA464		F-frame
			MSME504G *	5.0 kW		MFD�TA464E	
Single/			MDME102G *	1.0 kW	MDD 	MDD O T3530E	
3-phase, 200 V			MDME152G *	1.5 kW	MDD T5540	MDD 	D-frame
<u>, priaco</u> , <u>200</u>			MDME202G *	2.0 kW	MED T7364	MED T7364E	E-frame
		2000 r/min	MDME302G *	3.0 kW	MFD \bigcirc TA390	MFD TA390E	
			MDME402G *	4.0 kW			F-frame
3-phase,			MDME502G *	5.0 kW	MFD \bigcirc TB3A2	MFD \bigcirc TB3A2E	
200 V			MDME752G1 *	7.5 kW	MGD TC3B4		G-frame
		1500 r/min	MDMEC12G1 *	11.0 kW		_	
		1000 1/11	MDMEC52G1 *	15.0 kW	MHD \bigcirc TC3B4		H-frame
	MDME		MDME032G1 *	400 W			
	Middle inertia		MDME064G1 *	600 W	MDD \bigcirc T2407	MDD�T2407E	
	Midule mertia		MDME104G *	1.0 kW	MDD \bigcirc T2412	MDD O T2412E	D-fram
			MDME104G *	1.5 kW	MDD\\$T3420	MDD T3420E	
		2000 r/min	MDME194G *	2.0 kW	MED T4430	MED T4430E	E-frame
3-phase,			MDME304G *	3.0 kW	MFD\75440	MFD T5440E	name
400 V							E_from
				4.0 kW	MFD�TA464	MFD�TA464E	F-frame
				5.0 kW			0.6
		1500 r/min	MDME754G1 *	7.5 kW	MGD \bigcirc TB4A2	l C	G-frame
			MDMEC14G1 * MDMEC54G1 *	11.0 kW 15.0 kW	MHD \bigcirc TB4A2	—	H-frame
			NUDN/EC54(31 *				1

Remarks 🔅 Do not use in other combinations than those listed below.

Note

*1 Suffix of " \Box " in the applicable motor model represents design order.

Suffix of " * " in the applicable motor model represents the motor structure.

*2 \bigcirc : Drivers series K: A5II series H: A5 series

*3 \diamond : Drivers series K: A5IIE series H: A5E series

6

Incremental Specifications, 20-bit

		Motor	Driver				
Power supply	Туре	Rated rotational speed	Model *1	Rated output	Model of velocity, position, torque and full-closed control type *2	Model of Only for position control type *3	Frame
Single/ 3-phase, 200 V			MFME152G1 *	1.5 kW	MDD◇T5540	MDD 令T5540E	D-frame
3-phase,	MFME		MFME252G1 *	2.5 kW	MED \bigcirc T7364	MED�T7364E	E-frame
200 V	Middle inertia	2000 r/min	MFME452G1 *	4.5 kW	MFD \bigcirc TB3A2	MFD�TB3A2E	F-frame
2 phase]		MFME154G1 *	1.5 kW	MDD \bigcirc T3420	MDD�T3420E	D-frame
3-phase, 400 V			MFME254G1 *	2.5 kW	MED�T4430	MED�T4430E	E-frame
400 V			MFME454G1 *	4.5 kW	MFD�TA464	MFD�TA464E	F-frame
Single/ 3-phase, 200 V			MGME092G *	0.9 kW	MDD◇T5540	MDD ◇T5540E	D-frame
			MGME202G *	2.0 kW	MFD \bigcirc TA390	MFD�TA390E	
3-phase,			MGME302G *	3.0 kW			E-frame
200 V	MGME		MGME452G1 *	4.5 kW	MFD \bigcirc TB3A2	MFD ◇TB3A2E	
	Middle inertia	1000 r/min	MGME602G1 *	6.0 kW	MGD�TC3B4	_	G-frame
			MGME094G *	0.9 kW	MDD \bigcirc T3420	MDD�T3420E	D-frame
0 mbaaa			MGME204G *	2.0 kW	MFD \bigcirc T5440	MFD�T5440E	
3-phase, 400 V			MGME304G * MGME454G1 *	3.0 kW 4.5 kW	MFD◇TA464	MFD◇TA464E	F-frame
			MGME604G1 *	6.0 kW	MGD�TB4A2	_	G-frame
Single			MHMD021G1 *	200 W	MBD\\$T2110	MBD�T2110E	B-frame
phase, 100 V	MHMD		MHMD041G1 *	400 W	MCD\CT3120	MCD \bigcirc T3120E	C-frame
Single/	High inertia	3000 r/min	MHMD022G1 *	200 W	MAD◇T1507	MAD◇T1507E	A-frame
3-phase,	riigiriirertia		MHMD042G1 *	400 W	MBD�T2510	MBD \bigcirc T2510E	B-frame
200 V			MHMD082G1 *	750 W	MCD 	MCD \bigcirc T3520E	C-frame
Single/			MHME102G *	1.0 kW	MDD 	MDD \bigcirc T3530E	
3-phase, 200 V			MHME152G *	1.5 kW	MDD 	MDD O T5540E	D-frame
		2000 r/min	MHME202G *	2.0 kW	MED公T7364	MED�T7364E	E-frame
			MHME302G *	3.0 kW	MFD \bigcirc TA390	MFD TA390E	
3-phase,			MHME402G *	4.0 kW			F-frame
200 V			MHME502G *	5.0 kW	MFD \bigcirc TB3A2	MFD◇TB3A2E	
	MHME	1500 r/min	MHME752G1 *	7.5 kW	MGD \bigcirc TC3B4	_	G-frame
	High inertia		MHME104G *	1.0 kW	MDD\0T2412	MDD T2412E	
			MHME154G *	1.5 kW	MDD\0T3420	MDD O T3420E	D-frame
		0000	MHME204G *	2.0 kW	MED\74430	MED ^O T4430E	E-frame
3-phase,		2000 r/min	MHME304G *	3.0 kW	MFD\C_T5440	MFD O T5440E	
400 V			MHME404G *	4.0 kW	MFD�TA464		F-frame
			MHME504G *	5.0 kW		MFD�TA464E	
		1500 r/min	MHME754G1 *	7.5 kW	MGD�TB4A2	_	G-frame

*1 Suffix of "
]" in the applicable motor model represents design order.

Suffix of "* " in the applicable motor model represents the motor structure.

- *2 ◇ : Drivers series K: A5I series H: A5 series *3 ◇ : Drivers series K: A5IE seriesH: A5E series

2

5

Supplement

*1 Suffix of "] in the applicable motor model represents design order. Suffix of " * " in the applicable motor model represents the motor structure.

- *2 \diamond : Drivers series K: A5II series H: A5 series
- Default of the driver is set for the incremental encoder specifications.
 - When you use in absolute, make the following operations.
 - a) Install a battery for absolute encoder.

Note

- b) Switch the parameter Pr0.15 (Absolute encoder setup) from "1 (default)" to "0".
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Before Using the Products 4. Check of the Complitation of the Driver and the Motor Absolute Specifications, 17-bit This driver is designed to be used in a combination with the motor which are specified by us. Check the series name of the motor, rated output torque, voltage specifications and encoder specifications.

4. Check of the Combination of the Driver and the Motor

		Motor			Driver		
Power supply	Туре	Rated rotational speed	Model *1	Rated output	Model of velocity, position, torque and full-closed control type *2	Frame	
			MSMD5AZS1 *	50 W	MAD◇T1105	A fromo	
Single phase,			MSMD011S1 *	100 W	MAD�T1107	A-frame	
100 V			MSMD021S1 *	200 W	MBD�T2110	B-frame	
	MSMD		MSMD041S1 *	400 W	MCD\CT3120	C-frame	
		3000 r/min	MSMD5AZS1 *	50 W			
Single/	Low inertia		MSMD012S1 *	100 W	MAD�T1505	A-frame	
3-phase,			MSMD022S1 *	200 W	MAD◇T1507		
200 V			MSMD042S1 *	400 W	MBD\C72510	B-frame	
			MSMD082S1 *	750 W	MCD\CT3520	C-frame	
			MSME5AZS1 *	50 W	MAD\C1105	A 4	
Single phase, 100 V			MSME011S1 *	100 W	MAD◇T1107	A-frame	
			MSME021S1 *	200 W	MBD\C12110	B-frame	
			MSME041S1 *	400 W	MCD\CT3120	C-frame	
			MSME5AZS1 *	50 W		A-frame	
	MSME		MSME012S1 *	100 W	MAD \bigcirc T1505		
Single/			MSME022S1 *	200 W	MAD◇T1507		
3-phase,			MSME042S1 *	400 W	MBD\C72510	B-frame	
200 V			MSME082S1 *	750 W	MCD\CT3520	C-frame	
			MSME102S *	1.0 kW	- MDD◇T5540	D (
			MSME152S *	1.5 kW		D-frame	
	Low inertia		MSME202S *	2.0 kW	MED\C7364	E-frame	
3-phase,			MSME302S *	3.0 kW	MFD�TA390		
200 V			MSME402S *	4.0 kW		F-frame	
			MSME502S *	5.0 kW	MFD \bigcirc TB3A2		
			MSME084S1 *	750 W	MDD \bigcirc T2412		
			MSME104S *	1.0 kW	MDD\\73420	D-frame	
			MSME154S *	1.5 kW	MDD\\73420		
3-phase,			MSME204S *	2.0 kW	MED\74430	E-frame	
400 V			MSME304S *	3.0 kW	MFD�T5440		
			MSME404S *	4.0 kW		F-frame	
			MSME504S *	5.0 kW	MFD�TA464		
Single/3-phase,			MDME102S *	1.0 kW	MDD\C73530	. (
200 V			MDME152S *	1.5 kW	MDDOT5540	D-frame	
			MDME202S *	2.0 kW	MED�T7364	E-frame	
		2000 r/min -	MDME302S *	3.0 kW	MFD \bigcirc TA390		
	MDME		MDME402S *	4.0 kW		F-frame	
3-phase,	Middle inertia		MDME502S *	5.0 kW	MFD \bigcirc TB3A2		
200 V			MDME752S1 *	7.5 kW	MGD TC3B4	G-frame	
		1500 r/min	MDMEC12S1 *	11.0 kW			
			MDMEC52S1 *	15.0 kW	MHD \bigcirc TC3B4	H-frame	

Remarks 🔅 Do not use in other combinations than those listed below.

Absolute Specifications, 17-bit

		Motor			Driver	
Power supply	Type Rated rotations speed		Model		Model of velocity, position, torque and full-closed control type */	Frame
			MDME044S1 *	400 W		
			MDME064S1 *	600 W	MDD \bigcirc T2407	D
			MDME104S *	1.0 kW	MDD \bigcirc T2412	D-frame
			MDME154S *	1.5 kW	MDD \bigcirc T3420	1
	MDME	2000 r/min	MDME204S *	2.0 kW	MED◇T4430	E-frame
3-phase, 400 V			MDME304S *	3.0 kW	MFD \bigcirc T5440	
400 V	Middle inertia		MDME404S *	4.0 kW		F-frame
			MDME504S *	5.0 kW	MFD◇TA464	
			MDME754S1 *	7.5 kW	MGD \bigcirc TB4A2	G-frame
		1500 r/min	MDMEC14S1 *	11.0 kW		11 640 400 4
			MDMEC54S1 *	15.0 kW	MHD�TB4A2	H-frame
Single/3-phase, 200 V			MFME152S1 *	1.5 kW	MDD◇T5540	D-frame
3-phase,			MFME252S1 *	2.5 kW	MED\C7364	E-frame
200 V	MFME	2000 r/min	MFME452S1 *	4.5 kW	MFD OTB3A2	F-frame
	Middle inertia		MFME154S1 *	1.5 kW	MDD\0T3420	D-frame
3-phase,			MFME254S1 *	2.5 kW	MED T4430	E-frame
400 V			MFME454S1 *	4.5 kW	MFD \bigcirc TA464	F-frame
Single/3-phase, 200 V			MGME092S *	0.9 kW	MDD 	D-frame
200 1	MGME	1000 r/min	MGME202S *	2.0 kW	MFD \bigcirc TA390	
3-phase,			MGME302S *	3.0 kW		F-frame
200 V			MGME452S1 *	4.5 kW	MFD \bigcirc TB3A2	
200 1			MGME602S1 *	6.0 kW	MGD TC3B4	G-frame
	Middle inertia		MGME094S *	0.9 kW	MDD T3420	D-frame
			MGME204S *	2.0 kW	MFD T5440	Dirana
3-phase,		-	MGME304S *	3.0 kW	İ	F-frame
400 V			MGME454S1 *	4.5 kW	MFD�TA464	1 Indine
			MGME604S1 *	6.0 kW	MGD \bigcirc TB4A2	G-frame
Single phase,			MHMD021S1 *	200 W	MBD T2110	B-frame
100 V		-	MHMD02131 *	400 W	MCD\CT3120	C-frame
100 V	MHMD	3000 r/min	MHMD022S1 *	200 W	MAD T1507	A-frame
Single/3-phase,	High inertia	3000 1/1111	MHMD022S1 *	400 W	MBD\\$T2510	B-frame
200 V		-	MHMD042S1 *	750 W	MCD\CT3520	C-frame
Single/3-phase,			MHME102S *	1.0 kW	MDD T3530	0-iraine
200 V		-	MHME1023 *	1.5 kW	MDD T5540	D-frame
200 V		-	MHME202S *	2.0 kW	MED T7364	E-frame
		2000 r/min	MHME302S *	3.0 kW	MED TA390	
3-phase,		-	MHME402S *	4.0 kW	MFD VIA390	F-frame
200 V		-	MHME4025 *	4.0 kW	MFD \bigcirc TB3A2	r-irame
	МНМЕ	1500 r/min				C from
			MHME752S1 *	7.5 kW 1.0 kW	MGD \bigcirc TC3B4 MDD \bigcirc T2412	G-frame
	High inertia					D-frame
			MHME154S *	1.5 kW	MDD\0T3420	Г f m m m
3-phase,		2000 r/min	MHME204S *	2.0 kW	MED T4430	E-frame
400 V			MHME304S *	3.0 kW	MFD◇T5440	
			MHME404S *	4.0 kW	MFD \bigcirc TA464	F-frame
		4500 / 1	MHME504S *	5.0 kW		0.1
		1500 r/min	MHME754S1 *	7.5 kW	MGD \bigcirc TB4A2	G-frame

Note

*1 Suffix of " \Box " in the applicable motor model represents design order.

Suffix of "*" in the applicable motor model represents the motor structure.

*2 \bigcirc : Drivers series K: A5I series H: A5 series

• Default of the driver is set for the incremental encoder specifications.

When you use in absolute, make the following operations.

a) Install a battery for absolute encoder.

b) Switch the parameter Pr0.15 (Absolute encoder setup) from "1 (default)" to "0".

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.



Before Using the Products

2

Preparation

3

4

5

∆djustment

6


When in Trouble

7

Supplement

A5I drivers can be used in combination with Special Order Products.

Model Designation



Note • Motors displayed at P.1-27 to P.1-28 are Special Order Products. Please contact us for more information.
 • Connectors and cables of MSMJ is same as MSMD.
 • Connectors and cables of MHMJ is same as MHMD.
 Related page
 • P.7-55 to P.7-72 "Motor characteristics (S-T characteristics)", P.7-79 to P.7-93 "Dimensions"

Conbination of the Driver and the Motor

		Motor				Driver			
Power supply	Туре	Rated rotational speed	Model	Rated output	Model of velocity, position, torque and full-closed control type	Model of Only for position control type	Frame		
	MONT		MSMJ022 1*	200 W	MADKT1507	MADKT1507E	A-frame		
Single	MSMJ Low inertia	3000 r/min	MSMJ042 1*	400 W	MBDKT2510	MBDKT2510E	B-frame		
phase/ 3-phase	Low monda		MSMJ082 1*	750 W	MCDKT3520	MCDKT3520E	C-frame		
200 V			MSME102 C*M	1.0 kW	MDDKT5540	MDDKT5540E	D-frame		
			MSME152 C*M	1.5 kW	MDDKT5540	MDDKT5540E	D-Irame		
	MSME	3000 r/min	MSME202 C*M	2.0 kW	MEDKT7364	MEDKT7364E	E-frame		
3-phase	Low inertia	3000 1/11111	MSME302 C*M	3.0 kW	MFDKTA390	MFDKTA390E			
200 V			MSME402 C*M	4.0 kW	MFDKTB3A2	MFDKTB3A2E	F-frame		
			MSME502 C*M	5.0 kW	MFDKTB3A2	MFDKTB3A2E			
Single			MDME102 C*M	1.0 kW	MDDKT3530	MDDKT3530E			
phase/ 3-phase 200 V	- MDME Middle inertia				MDME152 C*M	1.5 kW	MDDKT5540	MDDKT5540E	D-frame
		2000 r/min	MDME202 C*M	2.0 kW	MEDKT7364	MEDKT7364E	E-frame		
3-phase			MDME302 C*M	3.0 kW	MFDKTA390	MFDKTA390E			
200 V			MDME402 C*M	4.0 kW	MFDKTB3A2	MFDKTB3A2E	F-frame		
			MDME502 C*M	5.0 kW	MFDKTB3A2	MFDKTB3A2E			
Single phase/ 3-phase 200 V	MGME High inertia	1000 r/min	MGME092⊡C*M	0.9 kW	MDDKT5540	MDDKT5540E	D-frame		
3-phase			MGME202 C*M	2.0 kW	MFDKTA390	MFDKTA390E	F-frame		
200 V			MGME302 C*M	3.0 kW	MFDKTB3A2	MFDKTB3A2E	r-irame		
			MHMJ022 1*	200 W	MADKT1507	MADKT1507E	A-frame		
Single	MHMJ High inertia	3000 r/min	MHMJ042 1*	400 W	MBDKT2510	MBDKT2510E	B-frame		
phase/ 3-phase	Tight incrud		MHMJ082[]1*	750 W	MCDKT3520	MCDKT3520E	C-frame		
200 V			MHME102 C*M	1.0 kW	MDDKT3530	MDDKT3530E	D-frame		
			MHME152 C*M	1.5 kW	MDDKT5540	MDDKT5540E	D-Irame		
	MHME	2000 r/min	MHME202 C*M	2.0 kW	MEDKT7364	MEDKT7364E	E-frame		
3-phase	High inertia	2000 1/11111	MHME302 C*M	3.0 kW	MFDKTA390	MFDKTA390E			
200 V			MHME402 C*M	4.0 kW	MFDKTB3A2	MFDKTB3A2E	F-frame		
			MHME502 C*M	5.0 kW	MFDKTB3A2	MFDKTB3A2E			

4. Check of the Combination of the Driver and the Motor Junction cable for motor

Encoder cable

Motor series		Incremental Specifications, 20-bit Note)1	Absolute Specifications, 17-bit Note)1	Detail page
MSMD	50 W to 750 W	MFECA0 ** 0EAM	MFECA0 ** 0EAE note)4	7-98
		MFECA0 ** 0MJD (Highly bendable type, Direction of motor shaft)	MFECA0 ** 0MJE (Highly bendable type, Direction of motor shaft)	
MSME	50 W	MFECA0 ** 0MKD (Highly bendable type, Opposite direction of motor shaft)	MFECA0 ** 0MKE (Highly bendable type, Opposite direction of motor shaft)	7-98
	to 750 W (200 V)	MFECA0 ** 0TJD (Standard bendable type, Direction of motor shaft)	MFECA0 ** 0TJE (Standard bendable type, Direction of motor shaft)	7-99
		MFECA0 ** 0TKD (Standard bendable type, Opposite direction of motor shaft)	MFECA0 ** 0TKE (Standard bendable type, Opposite direction of motor shaft)	
MSME	750 W (400 V),	MFECA0 ** 0ESD note)2	MFECA0 ** 0ESE note)2	
	1.0 kW to 5.0 kW	MFECA0 ** 0ETD note)3	MFECA0 ** 0ETE note)3	
	400 W/ to 15 0 K/M	MFECA0 ** 0ESD note)2	MFECA0 ** 0ESEnote)2	
MDME	400 W to 15.0 kW	MFECA0 ** 0ETD note)3	MFECA0 ** 0ETE note)3	7-99
MFME	1.5 kW to 4.5 kW	MFECA0 ** 0ETD	MFECA0 ** 0ETE	
	0.0.1.00.1.00.1.00.1	MFECA0 ** 0ESD note)2	MFECA0 ** 0ESE note)2	to
MGME	0.9 kW to 6.0 kW	MFECA0 ** 0ETD note)3	MFECA0 ** 0ETE note)3	7-100
MHMD	200 W to 750 W	MFECA0 ** 0EAM	MFECA0 ** 0EAE note)4]
MHME	1.0 kW to 7.5 kW	MFECA0 ** 0ESD note)2 MFECA0 ** 0ETD note)3	MFECA0 ** 0ESE note)2 MFECA0 ** 0ETE note)3	

Note)1 "** " represents the cable length. Note)2 Design order: C (0.9 kW to 5.0 kW (MGME: to 3.0 kW)) Note)3 Design order: 1 Note)4 When you use a 17-bit absolute encoder as an incremental encoder, please use the encoder cable MFECA0**0EAD.

Motor cable/ Brake cable

Mataxaariaa	Motor ca	ble Note)1	Brake eable Note)1	Detail
Motor series	without Brake	with Brake	Brake cable Note)1	page
MSMD 50 W to 750 W	MFMCA0 ** 0EED	_	MFMCB0 ** 0GET	7-101 7-106
MSME 50 W to 750 W	MFMCA0 ** 0NJD (Highly bendable type, Direction of motor shaft) MFMCA0 ** 0NKD (Highly bendable type, Opposite direction of motor shaft) MFMCA0 ** 0RJD (Standard bendable type, Direction of motor shaft) MFMCA0 ** 0RKD (Standard bendable type, (Opposite direction of motor shaft)	_	MFMCB0 ** 0PJT (Highly bendable type, Direction of motor shaft) MFMCB0 ** 0PKT (Highly bendable type, Opposite direction of motor shaft) MFMCB0 ** 0SJT (Standard bendable type, Direction of motor shaft) MFMCB0 ** 0SKT (Standard bendable type, Opposite direction of motor shaft)	7-101 7-106
MSME 1.0 kW to 2.0 kW (200 V)	MFMCD0 ** 2ECD	MFMCA0 ** 2FCD		
MSME 750 W to 2.0 kW (400 V)		MFMCE0 ** 2FCD] —	
MSME 3.0 kW to 5.0 kW	MFMCA0 ** 3ECT	MFMCA0 ** 3FCT		
MDME 1.0 kW to 2.0 kW (200 V)	MFMCD0 ** 2ECD	MFMCA0 ** 2FCD		7
MDME 400 W to 2.0 kW (400 V)		MFMCE0 ** 2FCD] —	
MDME 3.0 kW to 5.0 kW	MFMCA0 ** 3ECT	MFMCA0 ** 3FCT		
MFME 1.5 kW (200 V)	MFMCA0 ** 2ECD	MFMCA0 ** 2FCD		7
MFME 1.5 kW (400 V)	MFMCF0 ** 2ECD	MFMCE0 ** 2FCD		7-102
MFME 2.5 kW			_	
MFME 4.5 kW	MFMCD0 ** 3ECT	MFMCA0 ** 3FCT		to
MGME 0.9 kW (200 V)		MFMCA0 ** 2FCD		7-106
MGME 0.9 kW (400 V)	MFMCD0 ** 2ECD	MFMCE0 ** 2FCD] —	
MGME 2.0 kW to 4.5 kW	MFMCA0 ** 3ECT	MFMCA0 ** 3FCT		
MHMD 200 W to 750 W	MFMCA0 ** 0EED	_	MFMCB0 ** 0GET	1
MHME 1.0 kW, 1.5 kW (200 V)		MFMCA0 ** 2FCD		1
MHME 1.0 kW, 1.5 kW (400 V)	MFMCD0 ** 2ECD		1	
MHME 2.0 kW	MFMCE0 ** 2ECD	MFMCE0 ** 2FCD	_	
MHME 3.0 kW to 5.0 kW	MFMCA0 ** 3ECT	MFMCA0 ** 3FCT		
Note)1 "** " represents the cable ler	nath.			÷

Caution 🔶 • Motor cable (for MHME 7.5 kW, MGME 6.0 kW, MDME 7.5 kW to 15.0 kW) is not prepared in option.

Related page … • For other cable, connector and connector kit, refer to P.7-100 "Options" 7

3

Connection

5. Installation

Driver

Install the driver properly to avoid a breakdown or an accident.

Installation Place

- 1) Install the driver in a control panel enclosed in noncombustible material and placed indoor where the product is not subjected to rain or direct sunlight. The products are not waterproof.
- 2) Where the products are not subjected to corrosive atmospheres such as hydrogen sulfide, sulfurous acid, chlorine, ammonia, sulfur, chloric gas, sulfuric gas, acid, alkaline and salt and so on, and are free from splash of inflammable gas.
- 3) Where the motor is free from grinding oil, oil mist, iron powder or chips.
- 4) Well-ventilated and low humidity and dust-free place.
- 5) Vibration-free place.
- 6) Do not use benzine, thinner, alcohol, acidic cleaner and alkaline cleaner because they can discolor or damage the exterior case.

Environmental Conditions

Item	Conditions
Ambient temperature	0 °C to 55 °C ^{*1} (free from freezing)
Ambient humidity	20 % to 85 % RH (free from condensation)
Storage temperature*2	-20 °C to 65 °C (Max. temperature guarantee: 80 °C for 72 hours free from condensation*3)
Storage humidity	20 % to 85 % RH (free from condensation ^{*2})
Vibration	Lower than 5.88 m/s ² (0.6 G), 10 Hz to 60 Hz (Do not continuously use the driver for along time at the resonance point.)
Altitude	Lower than 1000 m

*1 50 °C for position control only type.

*2 Extreme temperatures are permissible only for short period such as during transportation.


*3 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

How to Install

- 1) Rack-mount type. Install in vertical position, and reserve enough space around the servo driver for ventilation.
- 2) Base mount (rear mount) is standard for A/B/C/D-frame driver.
- 3) To change the mounting surface of A/B/C/D-frame driver, use the optional mounting bracket. For choosing the correct optional mounting bracket, refer to P.7-119 "Mounting Bracket".
- 4) In consideration of strength of the screws and the material of the mounting base, select appropriate fastening torque for the product mounting screws, so that the screws will not be loosened or damaged.

Example) To tighten a steel screw into a steel base

A to G-frame: M5 2.7 N·m to 3.3 N·m, H-frame: M6 4.68 N·m to 5.72 N·m



2

Preparation


3

Connection

4

Mounting Direction and Spacing

- Reserve enough surrounding space for effective cooling.
- Install fans to provide uniform distribution of temperature in the control panel.
- D to H-frame is provided with a cooling fan at the bottom. (On the H-frame, the cooling fan is also installed on the upper side.)
- Observe the environmental conditions of the control panel described in the previous page.



Note

It is recommended to use the conductive paint when you make your own mounting bracket, or repaint after peeling off the paint on the machine for installing the products, in order to make noise countermeasure.

Caution on Installation

Caution 🔅

• Whenever lifting the product (during transportation/installation of H frame servo driver), two or more persons should hold it by metallic member, **not by plastic member**.

- We have been making the best effort to ensure the highest quality, however, application of exceptionally large external noise disturbance and static electricity, or failure in input power, wiring and components may result in unexpected action. It is highly recommended that you make a fail-safe design and secure the safety in the operative range.
- If stranded wires are used as the cable, bunch the conductors of the cable using a rod terminals or a round terminals. If stranded wires are used as they are, unexpected accidents such as an electric shock and short circuit or injury may result.
- There might be a chance of smoke generation due to the failure of these products. Pay an extra attention when you apply these products in a clean room environment.
- Be sure to install a no-fuse breaker in the power supply. In addition, be sure to ground the grounding terminal or grounding wire provided. (In order to prevent electric shock and malfunctions, Class D grounding [grounding resistance of 100 Ω or less] is recommended.)
- If the product is grounded insufficiently, not only the driver may not deliver its performance sufficiently, but also safety hazards such as a malfunction due to a electrification or a disturbance may be caused.
- If electric wires are bound and run through metal duct, they cannot carry the rated current due to temperature rise. If they are forced to carry the rated current, they may burn. When determining size of the wire.
- Do not use or store the product in a place subject to 5.88 m/s² or more vibration or shock, foreign materials such as dust, metallic powder and oilmist, liquids such as water, oil and grinding fluid, close to flammable materials, or in an atmosphere of corrosive gas (H₂S, SO₂, NO₂, Cl₂, etc.) or inflammable gas under any circumstance.

Related page ···• P.1-11 "Specifications"• P.1-34 "Installation of motor"• P.7-73 "Dimensions"• P.7-119 "Mounting bracket"

5

- Secure the screws and earth screw on the terminal block with the torque specified in the specification.
- When establishing a system using safety functions, completely understand the applicable safety standards and the operating instruction manual or technical documents for the product.
- Never make an approach to the motor and the machines driven by the motor while power is applied because they may become failure or malfunction.
- Do not use servo-on signal (SRV-ON) as the start/stop signal. Doing so may damage the built-in dynamic brake circuit in the driver.
- Pay attention to the heat dissipation. The driver will generate heat while the motor is in operation. Using the driver in a sealed control box may cause an abnormal heating of the control box. A proper consideration should be given to cool the driver so that the ambient temperature matches the specified operating temperature range.
- There is a possibility that the motor will be damaged by heat or emit smoke or dust due to a fault in the motor itself or the driver coupled with it. A proper consideration should be given if the motor is used in a clean room or similar environment.
- The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal.
- If the dynamic brake is applied during operation at a high speed, provide approx. 10-minute dwell period.

Restarting the motor earlier may cause a broken wire in the dynamic brake making the brake inoperable.

- The capacitance of capacitor in the power supply rectifier circuit decreases its capacitance with age.
- To prevent a secondary accident due to malfunction, it should be replaced with new one after 5-year use.

Replacement should be performed by us or our authorized distributor.

• Before using the product, be sure to read the instruction manual (Safety part).

Recommended Electric Wires for Driver

- \cdot For the main circuit, use electric wire that withstands at least 600 VAC with temperature rating 75 °C or higher.
- When using bundled wires running through metallic conduit, the amounts of current determined according to the reduction rate must be subtracted from the nominal allow-able current.
- Electric wires

<In high ambient temperature>

Use heat resistant wire.

Common polyvinyl chloride wires will deteriorate by heat at a higher rate.

<In low ambient temperature>

The surface of vinyl chloride insulation becomes hardened and brittle at low temperature and needs specific protective measure when used in cold region.

- Bend radius of the cable must be 10 times or more its finish outside diameter.
- Cables cannot be used for continuous regeneration because they are not designed for such application.

• When selecting a cable, refer to the following selection guide showing relationship between cable specification and current carrying capacity.

Example: Power supply 3-phase, 200 V, 35 A, ambient temperature 30 °C

Determine the fundamental permissible current according to the cable conductor material (example: stranded copper wire). (For the purpose of this example, the ampere indicated by \diamondsuit is selected from the table right.)

Next, determine the number of conductors. (In this example, the cable contains 4 conductors (3 + ground).) Determine the applicable permissible current using the following formula.

Applicable permissible current

= fundamental permissible current x current reduction coefficient x current correction coefficient

- = 37 x 0.7 x 1.414
- ÷ 36.6 (A)

This permissible value is larger than 35 A to be carried though the cable. Therefore, according to the list of recommended eco-cables, the cable to be selected for the cable with nominal cross section 3.5 mm² is a polyethylene-insulated heat-resistant 4-conductor power cable having 13.5 mm finish O.D. (approx. 14.5 mm with shield).

<Supplement>

- · The current correction coefficient is determined using the following formula:
 - $\sqrt{(Max. permissible temp. ambient temp.) \div 30}$

Caution 🔅

Caution 🔅

The current correction coefficient is determined according to the cable. Check the specification of the cable used.

 \bigcirc

 The current reduction coefficient is provided for the case where the cable (4-conductor cable in the case of example), is housed in plastic race/sheath, plastic tube, metal race/ sheath, metal tube or flexible conduit.

Because the neutral conductor is not counted as a wire, the current reduction coefficient for "3 or less" is applied as indicated by (\bigcirc) in the table right.

Recommended eco-cable

Wire category: 4-conductor polyethylene-insulated power cable with heat-resistant polyethylene sheath (Standard: EM JIS C 3605) Maximum permissible temperature: 90 °C

	Conductor					Max.		Minimum (Refere	(Deference)
Nominal cross section (mm²)	Structure or shape (wires/mm ²)	Outside diameter (mm)	Insulation thickness (mm)	Sheath thickness (mm)	(Reference) Finish O.D. (mm)	conductor resistance (20 °C) (W/km)	Test voltage (V/1 min.)	insulation resistance (MW•km)	(Reference) Approx. mass (kg/km)
2	7/0.6	1.8	0.8	1.5	12.0	9.42	1500	2500	170
3.5	7/0.8	2.4	0.8	1.5	13.5	5.30	1500	2500	250
5.5	7/1.0	3.0	1.0	1.5	16.0	3.40	1500	2500	360
8	7/1.2	3.6	1.0	1.5	17.0	2.36	1500	2000	475
14	Circular compression	4.4	1.0	1.5	19.0	1.34	2000	1500	730
22	Circular compression	5.5	1.2	1.6	23	0.849	2000	1500	1100
38	Circular compression	7.3	1.2	1.8	28	0.491	2500	1500	1800
60	Circular compression	9.3	1.5	2.0	35	0.311	2500	1500	2790
100	Circular compression	12.0	2.0	2.4	44	0.187	2500	1500	4630
150	Circular compression	14.7	2.0	2.6	51	0.124	3000	1000	6710
200	Circular compression	17.0	2.5	2.9	60	0.0933	3000	1500	8990

Caution 🔅

Note

Shield will increase finish outside diameter by approx. 1 mm.

- Appropriate cable should be selected to have sufficient allowance for parameters such as operating ambient temperature and current.
- Current reduction coefficient, fundamental permissible current, etc., stated on this page are subject to change due to e.g. standard revision. Consult cable manufacturers for the latest information.

current Copper Stranded conductor wire (nominal cross section: mm²) (unit: A) 2 to 3.5 (excl.) 27 3.5 to 5.5 (excl.) 37 5.5 to 8 (excl.) 49 8 to 14 (excl.) 61 14 to 22 (excl.) 88 11 to 30 (excl.) 115 30 to 38 (excl.) 139 38 to 68 (excl.) 162 60 to 100 (excl.) 217 100 to 150 (excl.) 298 150 to 200 (excl.) 395

 \Diamond

Fundamental permissible

 Current reduction coefficient 						
No. of wires in a tube	Coefficient					
Up to 3	0.70					
4	0.63					
5 or 6	0.56					
7 to 15	0.49					
16 to 40	0.43					
41 to 60	0.39					
61 or more	0.34					

2

5

Adjustment

5. Installation

Motor

Install the motor properly to avoid a breakdown or an accident.

Installation Place

Since the conditions of location affect a lot to the motor life, select a place which meets the conditions below.

- 1) Indoors, where the products are not subjected to rain or direct sun beam. The products are not waterproof.
- 2) Where the products are not subjected to corrosive atmospheres such as hydrogen sulfide, sulfurous acid, chlorine, ammonia, sulfur, chloric gas, sulfuric gas, acid, alkaline and salt and so on, and are free from splash of inflammable gas.
- 3) Where the motor is free from grinding oil, oil mist, iron powder or chips.
- 4) Well-ventilated and humid and dust-free place, far apart from the heat source such as a furnace.
- 5) Easy-to-access place for inspection and cleaning
- 6) Vibration-free place.
- 7) Avoid enclosed place. Motor may gets hot in those enclosure and shorten the motor life.

Environmental Conditions

lt	em	Conditions			
Ambient te	mperature ^{*1}	0 °C to 40 °C (free from freezing)			
Ambient hu	umidity	20 % to 85 % RH (free from condensation)			
Storage temperature*2		-20 °C to 65 °C (Max. temperature guarantee: 80 °C for 72 hours free from condensation*5)			
Storage hu	imidity	20 % to 85 % RH (free from condensation ^{*5})			
Vibration	Motor only	Lower than 49 m/s ² (5 G) at running, 24.5 m/s ² (2.5 G) at stall			
Impact	Motor only	Lower than 98 m/s ² (10 G)			
Enclosure	Motor only	IP67 (except rotating portion of output shaft and connecting pin			
rating (Connector type)		part of the motor connector and the encoder connector)*3*4			
Alti	itude	Lower than 1000 m			

*1 Ambient temperature to be measured at 5 cm away from the motor.

- *2 Permissible temperature for short duration such as transportation.
- *3 These motors conform to the test conditions specified in EN standards (EN60529, EN60034-5). Do not use these motors in application where water proof performance is required such as continuous wash-down operation.
- *4 This condition is applied when the connector mounting screw in case of motor 750 W or less are tightened to the recommended tightening torque (Refer to P.2-11, 2-48). Be sure to use mounting screw supplied with the connector. Correctly install and secure the gasket supplied with the cable connector.
- *5 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

How to Install

You can mount the motor either horizontally or vertically as long as you observe the followings.

- 1) Horizontal mounting
 - Mount the motor with cable outlet facing downward for water/oil countermeasure.
- 2) Vertical mounting
 - Use the motor with oil seal (make-to-order in case of motor 750 W or less) when mounting the motor with gear reducer to prevent the reducer oil/grease from entering to the motor.


2

Motor

Oil/Water Protection

1) Don't submerge the motor cable to water or oil.

- 2) Install the motor with the cable outlet facing downward.
- 3) Avoid a place where the motor is always subjected to oil or water.
- 4) Use the motor with an oil seal when used with the gear reducer, so that the oil may not enter to the motor through shaft.



Stress to Cables

- 1) Avoid a stress application to the cable outlet and connecting portion by bending or selfweight.
- 2) Especially in an application where the motor itself travels, fix the junction cable into the bearer so that the stress by bending can be minimized.
- 3) Take the cable bending radius as large as possible. (When you use our optional cable, Minimum R20 mm)


Permissible Load to Output Shaft

- 1) Design the mechanical system so that the applied radial load and/or thrust load to the motor shaft at installation and at normal operation can meet the permissible value specified to each model.
- 2) Pay an extra attention when you use a rigid coupling. (Excess bending load may damage the shaft or deteriorate the bearing life.)
- 3) Use a flexible coupling with high stiffness designed exclusively for servo application in order to make a radial thrust caused by micro misalignment smaller than the permissible value.
- **Note** \rightarrow For permissible load of each model, refer to P.1-37, "Permissible Load at Output Shaft".

Notes on Installation

 Do not apply direct impact to the shaft by hammer while attaching/detaching a coupling to and from the motor shaft.

(Or it may damage the encoder mounted on the other side of the shaft.)



- 2) Make a full alignment. (incomplete alignment may cause vibration and damage the bearing.)
- 3) If the motor shaft is not electrically grounded, it may cause electrolytic corrosion to the bearing depending on the condition of the machine and its mounting environment, and may result in the bearing noise. Check and verification by customer is required.

• P.1-37 "Permissible Load at Output Shaft" • P.7-79 "Dimensions"

Wiring Precautions on Movable Section

When wiring cable bear, take the following precautions:


Cable bear wiring

The bend radius of the cable must be 10 times or more its finish outside diameter. (For finish outside diameter, refer to P.1-33 How to Install, "Relationship between Wire Diameter and Permissible Current" and associated tables.)

Do not fix or bundle wires in the cable bear.

When securing the cable, fix it only at non-movable ends of the cable bear where the cable is free from any stress (e.g. tension). (Avoid tight lock.)

[Recommended cable bear wiring]



Caution 🔅

Do not keep the cable loosened (too long) or under tension (too short).

Otherwise, the sheath will be cracked by internal wall of the cable bear, tangled by other cable, etc., causing unpredictable troubles.

Cable distortion

Keep the cable free from twists or kinks.

Distorted cable will cause loose connection, lowering performance and reliability.


Lamination factor of cable in cable bear

Place cables on a flat surface in parallel without bringing them into contact with each other and measure the dimension necessary to cover these cables. Then select a cable bear which is wider than the measured dimension.

The lamination factor of cables should be lower than 60 % (recommended factor is 30 % or below).

Do not run smaller and larger size cables in the same cable bear. Thin cables may break under the pressure of thick cables. If it is necessary to mix cables of different size, isolate them by using suitable separating material such as partition.

[Wiring arrangement in cable bear – example]



2


5

6




6. Permissible Load at Output Shaft

Motor




Thrust load (A and B) direction



		A	t assembly	During running			
Motor	Motor output		Thrus	t load		Thrust load A	
series		Radial thrust	A-direction	B-direction	Radial thrust	and B-direction	
	50 W, 100 W	147	88	117.6	68.6	58.8	
MSMD	200 W, 400 W	392	147	196	245	98	
	750 W	686	294	392	392	147	
	50 W, 100 W	147	88	117.6	68.6	58.8	
	200 W, 400 W	392	147	196	245	98	
	750 W (200 V)	686	294	392	392	147	
MSME	750 W (400 V), 1.0 kW, 1.5 kW, 2.0 kW, 3.0 kW	980	588	686	490	196	
	4.0 kW, 5.0 kW				784	343	
	400 W to 2.0 kW	980	500	588 686	490	196	
	3.0 kW	960	500		784		
MDME	4.0 kW	1666	784	980		343	
	5.0 kW	1000					
	7.5 kW	2058	980	1176	1176	490	
	11.0 kW, 15.0 kW	4508	1470	1764	2254	686	
	0.9 kW	980	588	686	686	196	
	2.0 kW	1666	784	980	1176		
MGME	3.0 kW 4.5 kW	2058	980	1176	1470	490	
	6.0 kW	-			1764	588	
	1.5 kW	980	588	000	490	196	
MFME	2.5 kW, 4.0 kW	1862	686	686	784	294	
	200 W, 400 W	392	147	196	245	98	
MHMD	750 W	686	294	392	392	147	
	1.0 kW, 1.5 kW	980	588	686	490	196	
MHME	2.0 kW to 5.0 kW	1666	784	980	784	343	
	7.5 kW	2058	980	1176	1176	490	

Note 🔅

When the load point varies, calculate the permissible radial load, P (N) from the distance of the load point, L (mm) from the mounting flange based on the formula of the right table, and make it smaller than the calculated result.



Motor series	Motor output	Formula of Load and load point relation	Motor series	Motor output	Formula of Load and load point relation
	50 W	$P = \frac{3533}{L+39}$		0.9 kW	$P = \frac{33957}{L+14.5}$
	100 W	$P = \frac{4905}{L+59}$	MGME	2.0 kW	$P = \frac{69384}{L+19}$
MSMD	200 W	$P = \frac{14945}{L+46}$		3.0 kW	$P = \frac{86730}{L+19}$
	400 W	$P = \frac{19723}{L+65.5}$		4.5 kW 6.0 kW	$P = \frac{89964}{L+20}$
	750 W	$P = \frac{37044}{L+77}$		1.5 kW	$P = \frac{25235}{L+19}$
	50 W	$P = \frac{3533}{L+39}$	MFME	2.5 kW	$P = \frac{40376}{L+19}$
	100 W	$P = \frac{4905}{L+59}$		4.0 kW	P= <u>42336</u> L+19
	200 W	$P = \frac{14945}{L+46}$		200 W	$P = \frac{14945}{L+46}$
MSME	400 W	P= ¹⁹⁷²³ L+65.5	MHMD	400 W	P= ¹⁹⁷²³ L+65.5
	750 W (200 V)	P=37044 L+77		750 W	$P = \frac{37044}{L+77}$
	750 W (400 V) 1.0 kW to 3.0 kW	$P = \frac{20090}{L+13.5}$		1.0 kW 1.5 kW	$P = \frac{24255}{L+14.5}$
	4.0 kW 5.0 kW	$P = \frac{36848}{L+14.5}$	MHME	2.0 kW to 5.0 kW	$P = \frac{46256}{L+19}$
	400 W 600 W	$P = \frac{20090}{L+13.5}$		7.5 kW	P= <u>89964</u> L+20
	1.0 kW to 2.0 kW	$P = \frac{20580}{L+14.5}$			
	3.0 kW	$P = \frac{36848}{L+14.5}$			
MDME	4.0 kW 5.0 kW	P=42336 L+19			
	7.5 kW	P= ⁸⁹⁹⁴⁶ / _{L+20}			
	11.0 kW 15.0 kW	$P = \frac{200606}{L+31}$			

¹⁻³⁸ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

2

Setup

5

6

7

2. Preparation

	-
1. C	onformance to international standards
	EC Directives
	Composition of Peripheral Equipments2-6
2. S	ystem Configuration and Wiring
	Driver and List of Applicable Peripheral Equipments2-10
	A to G-frame, 100 V/200 V type:
	Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram
	E-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-16
	F-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-20
	G-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-24
	H-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-28
	D, E-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-32 F-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-36
	G-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-40
	H-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram2-44
	Specifications of Motor connector
	Wiring method to connector
	/iring to the connector, X1
J. W	Connecting host computer
лм	/iring to the connector, X2
4. VI	Connecting communication connector
E 14	-
5. W	/iring to the connector, X3
~ ~	Safety function connector2-53
6. W	/iring to the connector, X4
	Connection to Host Controller2-54
	/iring to the connector, X5
	Connect on to External Scale2-55
8. W	/iring to the connector, X6
	Connection to Encoder2-57
9. W	/iring to the connector, X7
	Monitor output2-60
10. '	Timing Chart
	Timing on power-up2-61
	Alarm
	Servo-Lock2-63
	Servo-ON/OFF2-64
11.	Built-in Holding Brake
	Outline2-65
	Specifications
12.	Dynamic Brake
	Outline2-67
	Connections of external dynamic brake resistor (Example) 2-68
	Condition setting chart2-70
13. 9	Setup of Parameter and Mode
	Outline / Setup / Connection2-72
	Composition and List of Parameters
	List of Parameters
	Setup of Torque Limit2-84
14. 9	Setup of command division and multiplication ratio
	(electronic gear ratio)
	Relation between Electronic Gear and Position Resolution or Traveling Speed 2-86
	How to Use the Front Panel
10.1	Setup2-88
	Structure of Each Mode
	Setup of front panel lock
	Monitor Mode (SELECTION display)
	Monitor Mode (EXECUTION display)
	Parameter Setup Mode
	EEPROM Writing Mode
	Auxiliary Function Mode (SELECTION display)2-110
	Auxiliary Function Mode (EXECUTION display)2-111

EC Directives

EC Directives

The EC Directives apply to all such electronic products as those having specific functions and have been exported to EU and directly sold to general consumers. Those products are required to conform to the EU unified standards and to furnish the CE marking on the products.

However, our AC servos meet the relevant EC Directives for Low Voltage Equipment so that the machine or equipment comprising our AC servos can meet EC Directives.

EMC Directives

MINAS Servo System conforms to relevant standard under EMC Directives setting up certain model (condition) with certain locating distance and wiring of the servo motor and the driver. And actual working condition often differs from this model condition especially in wiring and grounding. Therefore, in order for the machine to conform to the EMC Directives, especially for noise emission and noise terminal voltage, it is necessary to examine the machine incorporating our servos.

Conformity to UL Standards

Observe the following conditions of (1) and (2) to make the system conform to UL508C (E164620).

- (1) Use the driver in an environment of Pollution Degree 2 or 1 prescribed in IEC60664-1.
 (e.g. Install in the control box with IP54 enclosure.)
- (2) Make sure to install a circuit breaker or fuse which are UL recognized (Listed (1)) marked) between the power supply and the noise filter.

Remarks 🔅

Note

Use a copper cable with temperature rating of 75 °C or higher.

For rated current of circuit breaker and fuse, refer to P.2-10 "Driver and List of Applicable Peripheral Equipments".

(3) Over-load protection level

Over-load protective function will be activated when the effective current exceeds 115 % or more than the rated current based on the time characteristics (see the next page). Confirm that the effective current of the driver does not exceed the rated current. Set up the peak permissible current with Pr0.13 (Setup of 1st torque limit) and Pr5.22 (Setup 2nd torque limit).

(4) Motor over-temperature protection is not provided. Motor over-load-temperature protection shall be provided at the final installation upon required by the NEC (National Electric Code).

SEMI F47

- Includes a function in compliance with the SEMI F47 standard for voltage sag immunity under no load or light load.
- · Ideal for the semiconductor and LCD industries.

Caution 🔅

- (1) Excluding the single-phase 100-V type.
- (2) Please verify the actual compliance of your machine with the F47 standard for voltage sag immunity.

Conformed Standards

		Driver	Motor
	EMC Directives	EN55011 EN61000-6-2 EN61800-3	_
EC Direc-	Low-Voltage Directives	EN61800-5-1	EN60034-1 EN60034-5
tives	Machinery Directives Functional safety *1	ISO13849-1 (PL d) (Cat. 3) EN61508 (SIL 2) EN62061 (SIL 2) EN61800-5-2 (STO) IEC61326-3-1	_
UL Standard	ls	UL508C (E164620)	UL1004-1, UL1004-6 (E327868)
CSA Standa	ırds	C22.2 No.14	C22.2 No.100
Radio Waves Act (South Korea) (KC) *2		KN11 KN61000-4-2, 3, 4, 5, 6, 8, 11	_

IEC : International Electrotechnical Commission

- EN : Europaischen Normen
- EMC : Electromagnetic Compatibility
- UL : Underwriters Laboratories CSA : Canadian Standards Association
- Pursuant to the directive 2004/108/EC, article 9(2) Panasonic Testing Centre Panasonic Service Europe, a division of Panasonic Marketing Europe GmbH Winsbergring 15, 22525 Hamburg, F.R. Germany

• When export this product, follow statutory provisions of the destination country.

*1 A5IIE and A5E series doesn't correspond to the functional safety standards.

*2 Information related to the Radio Waves Act (South Korea)

This servo driver is a Class A commercial electromagnetic radio wave generator not designed for home use. The user and distributor should be aware of this fact.

A 급 기기 (업무용 방송통신기자재)

이 기기는 업무용(A 급) 전자파적합기기로서 판매자

또는 사용자는 이 점을 주의하시기 바라며, 가정외의

지역에서 사용하는 것을 목적으로 합니다.

(대상기종 : Servo Driver)

This product is not an object of China Compulsory Certification (CCC).

Caution \Rightarrow Use options correctly after reading Operating Instructions of the options to better understand the precautions.


Take care not to apply excessive stress to each optional part.

2

3


Installation Environment

Use the servo driver in the environment of Pollution Degree 1 or 2 prescribed in IEC-60664-1 (e.g. Install the driver in control panel with IP54 protection structure.)



For NF1 to NF3, refer to the Table "Noise Filter for Signal Line" (P.2-5).

* A5IIE, A5E is not provided with X3 terminal.





For NF1 to NF3, refer to the Table "Noise Filter for Signal Line" (P.2-5).

* A5IIE, A5E is not provided with X3 terminal.

Mandatory requirements to conform to EMC directive

- · Install the servo driver on the metallic casing (control board).
- · Install noise filter and lightning surge absorber in the power supply line.
- · Use braided shield cable (tin plated annealed copper wire) for I/O signal cable and encoder cable.
- Provide the noise filter, as shown in the figure, for each cable, I/O line and power source line to be connected to the servo driver.
- · Shield of cables not shown on the figure should be directly grounded through PE.

Because these conditions for EMC directive are affected by status of connected devices, wiring, connection and location, compliance should be checked after completing installation.

Noise Filter for Signal Lines

Install noise filters for signal lines to all cables (power cable, motor cable, encoder cable
and interface cable)

Symbol ^{*1}	Cable Name	100 V/200 V Amp. frame symbol	400 V Amp. frame symbol	Option part No.	Manufacturer's part No.	Manufacturer	Qty.
		A, B, C, D	D, E, F	DV0P1460	ZCAT3035-1330	TDK Corp.	4
NF1	Power cable	E, F	_	Recommended components	RJ8035	KK-CORP.CO.JP	1
		G, H	G, H	Recommended components RJ8095		KK-CORP.CO.JP	1
		A, B, C, D, E, F	D, E, F	DV0P1460	ZCAT3035-1330	TDK Corp.	4
NF2	Motor cable	G, H	G, H	Recommended components	T400-61D	MICROMETALS	1
NF3	 24 V Power cable Encoder cable Interface cable USB cable Control power cable 	Common (to all frames)		DV0P1460	ZCAT3035-1330	TDK Corp.	4

*1 For symbols, refer to the Block Diagram "Installation Environment" (P.2-4).

Remarks : To connect the noise filter to the connector XB connection cable, adjust the sheath length at the tip of the cable, as required.

Caution 🔅

Fix the signal line noise filter in order to prevent excessive stress to the cables.

<Fig.2: Dimensions>

	Part No. Curre	Current	100 kHz				Size	e (Unit:	mm]		
		Current	/// (μH)	Α	В	С	D1	D2	Core thickness	Е	F
	RJ8035	35 A	9.9±3	170	150	23	80	53	24	R3.5	7
	RJ8095	95 A	7.9±3	200	180	34	130	107	35	R3.5	7

Fig.1: DV0P1460(Option)





Fig.3: T400-61D (Recommended components)







Fig.2: RJ8035, RJ8095



Caution 🔅

Use options correctly after reading Operating Instructions of the options to better understand the precautions.

Take care not to apply excessive stress to each optional part.

1

5

Setup

7


1. Conformance to international standards Composition of Peripheral Equipments

Power Supply

100 V type: (A to C-frame)	Single phase, 100 V $^{+10}_{-15}$ % to 120 V $^{+10}_{-15}$ % 50 Hz/60 Hz
200 V type: (A to D-frame)	Single/3-phase, 200 V $^{+10\%}_{-15\%}$ to 240 V $^{+10\%}_{-15\%}$ 50 Hz/60 Hz
200 V type: (E to H-frame)	3-phase, 200 V $^{+10}_{-15}$ % to 230 V $^{+10}_{-15}$ % 50 Hz/60 Hz
400 V type: Main power supply (D to H-frame)	3-phase, 380 V $^{+10}_{-15}$ % to 480 V $^{+10}_{-15}$ % 50 Hz/60 Hz
400 V type : Control power supply (D to H-frame)	DC 24 V ±15 %

Remarks 🔅

- (1) This product is designed to be used in over-voltage category (installation category) III of EN 61800-5-1:2007.
- (2) Use an insulated power supply of DC12 to 24 V which has CE marking or complies with EN60950.
- Use sheathed (jacketed) cable, twisted cable or closely bundled cable for power cable.
- Power cable and signal wires must be sufficiently isolated from each other.



Circuit Breaker

Install a circuit breaker which complies with IEC Standards and UL recognized (Listed and ()) marked) between power supply and noise filter.

The short-circuit protection circuit on the product is not for protection of branch circuit. The branch circuit should be protected in accordance with NEC and the applicable local regulations in your area.

Note

For driver and applicable peripheral equipments, refer to P.2-10 "Driver and List of Applicable Peripheral Equipments".

Composition of Peripheral Equipments

Noise Filter

Option part No.	Voltage specifications for driver	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
DV0P4170	Single phase 100 V/200 V	SUP-EK5-ER-6	A, B-frame	
	3-phase 200 V		A, B-frame	
DV0PM20042	Single phase 100 V/200 V 3-phase 200 V	3SUP-HU10-ER-6	C-frame	Okaya Electric Ind.
DV0P4220	Single/ 3-phase 200 V	3SUP-HU30-ER-6	D-frame	
DV0PM20043	3-phase 200 V	3SUP-HU50-ER-6	E-frame	
DV0P3410	3-phase 200 V	3SUP-HL50-ER-6B	F-frame	


Recommended components

Model No.	Voltage specifications for driver	Rated current	Applicable driver (frame)	Manufacturer	
RTHN-5010		10	A, B, C-frame		
RTHN-5030		30	D-frame	TDK-Lambda Corp.	
RTHN-5050	3-phase 200 V	50	E, F-frame		
FS5559-60-34		60	G-frame		
FS5559-80-34		80	H-frame		
FN258L-16-07		16	D, E-frame	Schaffner	
FN258L-30-07	2 phase 400 V	30	F-frame	Schallner	
FN258-42-07	3-phase 400 V	42			
FN258-42-33		42	G, H-frame		


Remarks 🔅

· Select a noise filter whose capacity is commensurate with the power source capacity (in consideration of the load condition).

- For the detailed specifications of each noise filter, contact the manufacturer.
- When two or more servo drivers are used with a single noise filter at the common power source, consult with the noise filter manufacturer.
- Do not run the input and output wiring on the same passage: noise resistance will drop. (Figure at lower right)
- · Isolate the input and output line from each other. (Figure at lower left)



The effect of the noise filter is a little.



Do not place the input and output lines in the same duct or do not tie both in a bundle.

Surge Absorber

Option part No.	Voltage specifications for driver	Manufacturer's part No.	Manufacturer
DV0P1450	3-phase 200 V	R·A·V-781BXZ-4	
DV0P4190	Single phase 100 V/200 V	R·A·V-781BWZ-4	Okaya Electric Ind.
DV0PM20050	3-phase 400 V	R·A·V-801BXZ-4	

Remarks 🔅

When performing withstand voltage test of machine and equipment, be sure to remove the surge absorber; otherwise, it will be damaged.

• P.2-10 "Driver and List of Applicable Peripheral Equipments" • P.7-94 "Option" Related page …

2

5

6

Composition of Peripheral Equipments

Noise Filter for Signal Lines


Signal line, Encoder line, Control power line, Power line (A to D-frame: 100 V/ 200 V and D to F-frame: 400 V) and Motor line (A to F-frame).

Option part No.	Manufacturer's part No.	Manufacturer		
DV0P1460	ZCAT3035-1330	TDK Corp.		

Recommended components

Option part No.	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
Power cable	RJ8035 E-frame 200 V, F-fr		KK-CORP.CO.JP
Fower cable	RJ8095	G, H-frame	KK-COHF.CO.JF
Motor cable	T400-61D	G, H-frame	MICROMETALS

<Attaching signal noise filter>



2

5

Adjustment

6

When in Trouble

7

Supplement

Composition of Peripheral Equipments

Residual current device

Install a residual current device (RCD) at primary side of the power supply. Select a RCD of type.B prescribed in IEC60947-2, JISC8201-2-2

Grounding

- (1) To prevent electric shock, be sure to connect the ground terminal ((\pm)) of the driver, and the ground terminal (PE) of the control panel.
- (2) The ground terminal (()) must not be shared with other equipment. Two ground terminals are provided.

Structure of control board

If there is a gap at cable inlet/outlet, mounting hole of operation panel or a door, radio waves will penetrate into or radiate out through the gap. To prevent unfavorable conditions due to radio frequency activities, observe the following control board design and selection instruction.

- The control board should be made of metal which provides electrical continuity.
- The control board should not have electrically-isolated conductor.
- All units installed in the casing should be grounded to the case.

Increasing noise resistance of control I/O signal

When noise is applied to the control input/output, it causes displacement and malfunctioning of I/O signal.

- X1 to X7 are secondary side circuit which should be isolated from the primary power source (24 VDC control power source, 24 VDC braking power source and 24 VDC for regenerative resistor). Do not connect the secondary side circuit to the primary power source and ground wire. Otherwise, I/O signal will cause error operation.
- · Control power source (particularly 24 VDC) should be completely isolated from external operating power source. Never connect the ground of the control power source to that of external power source.
- The signal line should have shield, the both end of which should be connected to the ground.

Note

For driver and applicable peripheral equipments, refer to P.2-10 "Driver and List of Applicable Peripheral Equipments".

Caution 🔅 Use options correctly after reading Operating Instructions of the options to better understand the precautions.

Take care not to apply excessive stress to each optional part.



2. System Configuration and Wiring

Driver and List of Applicable Peripheral Equipments

Driver	Applicable motor	Voltage *1	Rated output	Required Power (at the (rated load)	Circuit breaker (rated (current)	Noise filter (Single phase 3-phase)	Surge absorber (Single phase 3-phase)	Noise filter for signal	Rated operating current of magnetic contactor Contact configuration *2	Diameter and withstand voltage of main circuit cable	Crimp terminal for main circuit terminal block	Diameter and withstand voltage of control power supply cable	Crimp terminal for control power supply terminal block	Diameter and withstand voltage of motor cable *4	Diameter and withstand voltage of brake cable					
MADH	MSME	Single phase, 100 V	50 W to 100 W	approx. 0.4 kVA		DV0P4170	DV0P4190													
MADK	MSMD MHMD	Single/ 3-phase, 200 V	50 W to 200 W	approx. 0.5 kVA		DV0P4170 DV0PM20042							-							0.28 mm²/
MDDU	MSME	Single 100 V	200 W	approx. 0.5 kVA	10 A	DV0P4170	DV0P4190		20 A	0.75 mm²/ AWG18				0.75 mm²/ AWG18	AWG22 to 0.75 mm ² /					
MBDH MBDK	MSMD MHMD	Single/ 3-phase, 200 V	400 W	approx. 0.9 kVA		DV0P4170 DV0PM20042	DV0P4190 DV0P1450		(3P+1a)	600 VAC or more				600 VAC or more	AWG18 100 VAC or more					
MCDH	MSME	Single 100 V	400 W	approx. 0.9 kVA			DV0P4190					0.75 mm²/ AWG18								
MCDK	MSMD MHMD	Single/ 3-phase, 200 V	750 W	approx. 1.3 kVA	15 A	DV0PM20042						600 VAC or more								
	MDME MHME		1.0 kW	approx. 1.8 kVA				DV0P1460				ç		ç						
	MGME		0.9 kW	approx. 1.8 kVA			DV0P4190				onnect		onnect							
	MSME	3-phase, 200 V	1.0 kW	approx. 1.8 kVA		DV0P4220	DV0P1450		30 A (3P+1a)		tion to		tion to							
MDDH	MHME MDME MFME	200 1	1.5 kW	approx. 2.3 kVA	20 A				(01 110)		Connection to exclusive connector		Connection to exclusive connector							
MDDK	MSME MSME MDME MHME		1.0 kW	approx. 1.8 kVA					2.0 mm²/ 20 A AWG14 (3P+1a) 600 VAC	connector	0.52 mm ² /	onnector	2.0 mm²/							
	MGME MSME	3-phase, 400 V	0.9 kW		10 A	FN258L-16-07 (Recommended) component	DV0PM20050					AWG20 100 VAC		AWG14 600 VAC or more						
	MDME MFME MHME		1.5 kW	approx. 2.3 kVA		(component)						or more								
	MDME MSME MHME	3-phase, 200 V	2.0 kW	approx. 3.3 kVA	30 A	DV0PM20043	DV0P1450	DV0P1460 RJ8035 (Recommended) component	60 A (3P+1a)			0.75 mm²/ AWG18 600 VAC								
MEDH	MFME		2.5 kW	approx. 3.8 kVA				*5				or more								
MEDK	MSME MDME MHME	3-phase, 400 V 2.0 kW 3.3 kVA 15 A	15 A	FN258L-16-07 (Recommended)	ed) DV0PM20050	DV0P1460	30 A (3P+1a)			0.52 mm²/ AWG20 100 VAC										
	MFME		2.5 kW	approx. 3.8 kVA		Component /			(3P+1a)			or more			0.75 mm²/					
	MGME		2.0 kW	approx. 3.8 kVA											AWG18 100 VAC					
	MDME MHME MSME MGME		3.0 kW	approx. 4.5 kVA				DV0P1460	60 A (3P+1a)		11 mm or smaller		11 mm or smaller		or more					
	MDME MHME MSME	3-phase, 200 V	4.0 kW	approx. 6.0 kVA	50 A	DV0P3410	DV0P1450	RJ8035 (Recommended) component *5			<u>ø5.3</u> Terminal	0.75 mm ² / AWG18 600 VAC or more	J Ø5.3 Terminal							
	MFME		4.5 kW	approx. 6.8 kVA				*5	100 A (3P+1a)		block M5		block M5							
	MGME MDME MHME		5.0 kW	approx. 7.5 kVA					(51 +14)	3.5 mm²/				3.5 mm²/						
MFDH MFDK	MSME MGME		2.0 kW	approx.						AWG12 600 VAC				AWG12 600 VAC						
	MSME		2.0 KW	3.8 kVA						or more				or more						
	MDME MGME MHME		3.0 kW	approx. 4.5 kVA							10 mm or smaller	0.75 mm²/	7 mm or smaller							
	MSME MDME MHME	3-phase, 400 V	4.0 kW	approx. 6.0 kVA	30 A	FN258L-30-07 (Recommended component)	DV0PM20050	DV0P1460	60 A (3P+1a)		/ 	0.75 mm²/ AWG18 100 VAC or more	/ / 							
	MFME MGME		4.5 kW	approx. 6.8 kVA							block M4									
	MSME MDME MHME		5.0 kW	approx. 7.5 kVA																

*1 Select peripheral equipments for single/3phase common specification according to the power source.

*2 For the external dynamic brake resistor, use the magnetic contactor with the same rating as that for the main circuit.

*3 When use the external regenerative resistor of the option (DV0PM20058, DV0PM20059), use the cable with the same diameter as the main circuit cable.

*4 The diameter of the ground cable and the external dynamic brake resistor cable must be equal to, or larger than that of the motor cable. The motor cable is a shield cable, which conforms to the EC Directives and UL Standards. (G, H-frame only)

*5 Use thses products to suit an international standard.

Related page Noise filter...P.7-94 Surge absorber...P.7-98 Noise filter for signal...P.7-99 Motor/brake connector...P.2-48

Driver	Applicable motor	Voltage *1	Rated output	Required Power (at the (rated load)	Circuit breaker (rated (current)	Noise filter	Surge absorber	Noise filter for signal	Rated operating current of magnetic contactor Contact configuration *2	Diameter and withstand voltage of main circuit cable	Crimp terminal for main circuit terminal block	Diameter and withstand voltage of control power supply cable	Crimp terminal for control power supply terminal block	Diameter and withstand voltage of motor cable *4	Diameter and withstand voltage of brake cable
	MDME	3-phase, 200 V	7.5 kW	approx. 11 kVA	60 A	FS5559-60-34 (Recommended) component	DV0P1450	DV0P1460 RJ8095 (Recommended) component T400-61D (Recommended) component *5	100 A (3P+1a)	5.3 mm²/ AWG10 600 VAC or more	smaller 05.3 Terminal	0.75 mm²/	10 mm or	13.3 mm²/ AWG6 600 VAC or more	0.75 mm²/ AWG18 100 VAC or more
	MGME		6.0 kW	approx. 9.0 kVA								AWG18 600 VAC	10 mm or smaller		
MGDH	MHME		7.5 kW	approx. 11 kVA								or more			
MGDK	MDME			approx. 11 kVA	30 A	FN258-42-07 or FN258-42-33 (Recommended) component	DV0PM20050		60 A (3P+1a)			0.75 mm²/	Terminal block		
	MGME	400 V	6.0 kW	approx. 9.0 kVA								AWG18 M5 100 VAC or more			
	MHME		7.5 kW	approx. 11 kVA											
	H K MDME 3-	3-phase, 200 V	11 kW	approx. 17 kVA	100 A	ESEE0 90 24			150 A (3P+1a) 13.3 mm²/ AWG6 600 VAC or more *3 (3P+1a)			0.75 mm²/			
MHDH MHDK			15 kW	approx. 22 kVA	125 A	(Recommended component)				16 mm or smaller	AWG18 600 VAC or more	10 mm or smaller	21.1 mm ² / AWG4 600 VAC or more		
		3-phase,	11 kW	approx. 17 kVA	50 A	FN258-42-07 or	DV0PM20050	0050		600 VAC or more	/ <u>ø6.4</u> Terminal block M6	0.75 mm²/ AWG18	/ <u>ø4.3</u> Terminal block M4 -	13.3 mm ² / AWG6 600 VAC or more	
		400 V	15 kW	approx. 22 kVA	60 A	FN258-42-33 (Recommended) component	DV0PM20050					100 VAC or more		21.1 mm ² / AWG4 600 VAC or more	

About circuit breaker and magnetic contactor

To comply to EC Directives, install a circuit breaker between the power and the noise filter without fail, and the circuit breaker should conform to IEC Standards and UL recognized (Listed and (1)) marked).

Suitable for use on a circuit capable of delivering not more than 5,000 Arms symmetrical amperes, below the maximum input voltage of the product.

Select a circuit breaker and noise filter which match to the capacity of power

Remarks 🔅

supply (including a load condition).

Terminal block and protective ground terminals

- \cdot Use a copper conductor cables with temperature rating of 75 $^\circ\text{C}$ or higher.
- Use the attached exclusive connector for A to E-frame, and maintain the peeled off length of 8 to 9 mm. (Refer to P.2-50)

• Fastening torque list (Terminal block screw/Terminal cover fastening screw)

	Driver	Term	inal block screw	Terminal cover fastening screw		
Frame	Terminal name	Nominal size	Fastening torque (N·m) Note 1	Nominal size	Fastening torque (N·m) Note 1	
F200 V	L1, L2, L3, L1C, L2C, B1, B2, B3, NC, U, V, W	M5	1.0 to 1.7			
F400 V	24V、0V		0.4 to 0.6	МЗ	0.19 to 0.21	
	L1, L2, L3, B1, B2, B3, NC, U, V, W	0.7 to 1.0	0.19100.21			
G	L1C, L2C, 24V, 0V, DB1, DB2, DB3, DB4, NC	M5	1.0 to 1.7			
u	L1, L2, L3, B1, B2, NC, U, V, W	M5	2.0 to 2.4	M3	0.3 to 0.5	
н	L1C, L2C, 24V, 0V, DB1, DB2	M4	0.7 to 1.0	M5	0.0 to 0.5	
	L1, L2, L3, B1, B2, NC, U, V, W	M6	2.2 to 2.5	CIVI	2.0 to 2.5	

Fastening torque list (Ground terminal screw/Connector to host controller (X4))

Driver frame	Term	inal block screw	Connector to host controller (X4)		
Driver frame	Nominal size	Fastening torque (N·m) Note 1	Nominal size	Fastening torque (N·m) Note 1	
A to E	M4	0.7 to 0.8			
F, G	M5	1.4 to 1.6	M2.6	0.3 to 0.35	
Н	M6	2.4 to 2.6			

Caution Note 1 • Applying fastening torque larger than the maximum value may result in damage to the product.

Do not turn on power without tightening all terminal block screws properly.

- · Do not turn on power without tightening all terminal block screws properly, other-
- wise, loose contacts may generate heat (smoking, firing).
- To check for looseness, conduct periodic inspection of fastening torque once a year.




Be sure to conduct wiring properly and securely. Insecure or improper wiring may cause the motor running out of control or being damaged from overheating. In addition, pay attention not to allow conductive materials, such as wire chips, entering the driver during the installation and wiring.

2

6


2. System Configuration and Wiring Overall Wiring (A to D-frame, 100 V/200 V type)



Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page • P.7-94... "Options"



2. System Configuration and Wiring


Wiring of the Main Circuit (A to D-frame, 100 V/200 V type)

A to D-frame, 100 V / 200 V type

- · Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the power connector (XA and XB) to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring

- 1) Wire connector (XA and XB).
- Connect the wired connector to the driver.
 Fully insert the connector to the bottom until it clicks.




P.7-112 "Connector kit for XA"
 P.7-113 "Connector kit for XB"

2 Preparation

2. System Configuration and Wiring Wiring Diagram (A to D-frame, 100 V/200 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of Single Phase, A to D-frame, 100 V / 200 V type




Before Using

the Product

2

2. System Configuration and Wiring


Overall Wiring (E-frame, 200 V type)



This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page • P.7-94... "Options"

Note



2. System Configuration and Wiring


Wiring of the Main Circuit (E-frame, 200 V type)

E-frame, 200 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the power connector (XA, XB and XC) to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring

- 1) Wire connector (XA, XB and XC).
- Connect the wired connector to the driver.
 Fully insert the connector to the bottom until it clicks.



Note The wiring indicated with the broken line shall be provided only when required. **Related page** ••• P.2-48 "Specifications of Motor connector" • P.2-50 "Wiring method to connector"


• P.7-112 "Connector kit for XA" • P.7-113 "Connector kit for XB, XC"

2. System Configuration and Wiring Wiring Diagram (E-frame, 200 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, E-frame, 200 V type

Power supply 3-phase, 200 V –15 % to 230 V +10 %



Note.1)

Frama	Chort wire	Built-in regenerative resistor	Connection of the connector XC				
Frame No.	Short wire (Accessory)		In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.			
E-frame	with with		 Remove the short wire accessory from between B2-B3. Connect an external regenerative resistor between B1-B2 	 Shorted between B2-B3 with an attached short wire 			


Setup

6

2. System Configuration and Wiring

Overall Wiring (F-frame, 200 V type)


Connecting Example of F-frame



Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page • P.7-94... "Options"



2. System Configuration and Wiring

Wiring of the Main Circuit (F-frame, 200 V type)

F-frame, 200 V type

- · Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring


- 1) Take off the cover fixing screws, and detach the terminal cover.
- 2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, reter to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque between 1.0 N·m and 1.7 N·m.

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with a torque written on P.2-11.



Note 🔅

Related page

P.2-48 "Specifications of Motor connector"


The wiring indicated with the broken line shall be provided only when required.

2. System Configuration and Wiring Wiring Diagram (F-frame, 200 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, F-frame, 200 V type

Power supply 3-phase, 200 V –15 % to 230 V +10 %



Built-in thermal protector of an external regenerative resistor (light yellow)

Connection

3

Before Using the Products

2

Preparation

7


Note.1)

Frama	Short bar	Built-in		terminal block
Frame No.	(Accessory)	regenerative resistor	In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.
F-frame	with	with	 Remove the short bar accessory from between B2-B3. Connect an external regenerative resistor between B1-B2 	Shorted between B2-B3 with an attached short bar

NoteThe wiring indicated with the broken line shall be provided only when required.Related page P.2-48 "Specifications of Motor connector"

Overall Wiring (G-frame, 200 V type)

Connecting Example of G-frame



Regenerative resistor (optional)

Remarks 🔅

- When you use an external regenerative resistor, install an external protective apparatus, such as thermal fuse without fail.
- Thermal fuse and thermal protector are built in to the regenerative resistor (Option). If the thermal fuse is activated, it will not resume.
- Mount the regenerative resistor on incombustible material such as metal.

Note

The wiring indicated with the broken line shall be provided only when required.

Pin B1 and B2

• When you connect an external regenerative resistor, connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin DB1, DB2, DB3 and DB4


- ·Normally, leave DB3 and DB4 short-circuited.
- To connect the external dynamic brake resistor, refer to "Dynamic Brake" on P.2-67 **Do not use** the external dynamic brake resistor together with the built-in resistor.

Pin NC

• Do not connect anything.

Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.
 • P.7-94... "Options"



2-25

Wiring of the Main Circuit (G-frame, 200 V type)

G-frame, 200 V type

- · Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring

1) Take off the cover fixing screws, and detach the terminal cover.


2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, reter to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque between 2.0 N \cdot m and 2.4 N \cdot m (left side) and 1.0 N \cdot m and 1.7 N \cdot m (right side).

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.



Related page …

• P.2-48 "Specifications of Motor connector"


Preparation

2. System Configuration and Wiring Wiring Diagram (G-frame, 200 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, G-frame, 200 V type

Power supply 3-phase, 200 V –15 % to 230 V +10 %



Note.1) About regenerative resistor

Frame	Short bar	Built-in	Connection of	terminal block
No.	(Accessory)	regenerative resistor	In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.
G-frame	without	without	Connect an external regenerative resistor between B1-B2	Open between B1-B2

Note.2) About dynamic brake resistor

Frame	Chart bar	Built-in	Connection of	terminal block
No.	Short bar (Accessory)	dynamic brake resistor.	In case of using an external dynamic brake resistor.	In case of not using an external dynamic brake resistor.
G-frame	ne with with		 Remove attached short bar between DB3-DB4. Connect external dynamic brake resistor as shown above. 	 Shorted with attached short bar between DB3-DB4 Open between DB1-DB2

Note.3) A magnetic contactor MC2 must be the same rating as the contactor MC1 in the main circuit.

Note.4) Servo may be turned on in the external sequence if the contact deposits: to protect the system, provide the auxiliary contact.

Note.5) Provide an external protective device (e.g. thermal fuse) to monitor the temperature of the external dynamic brake resistor.

Note.6) Reactor should be prepared by the customer.

Note 💮 The wiring indicated with the broken line shall be provided only when required.


Related page P.2-48 "Specifications of Motor connector"

5

6


Overall Wiring (H-frame, 200 V type)





Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required. Related page … • P.7-94... "Options"



Wiring of the Main Circuit (H-frame, 200 V type)

H-frame, 200 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring

1) Take off the cover fixing screws, and detach the terminal cover.


2)Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, reter to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque between 0.7 N·m and 0.8 N·m (upper side) and 2.2 N·m and 2.5 N·m (lower side).

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.





Related page

P.2-48 "Specifications of Motor connector"


Preparation

2. System Configuration and Wiring Wiring Diagram (H-frame, 200 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, H-frame, 200 V type

Power supply 3-phase, 200 V –15 % to 230 V +10 %



Note.1) About regenerative resistor

Frame	Short bar	Built-in	Connection of term	ninal block
No.	(Accessory)	regenerative resistor	In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.
H-frame	without	without	 (External regenerative resistor terminal) Terminal R1, R2 connect to B1, B2 Terminal T1, T2 connection as shown above Terminal 24 V, 0 V connect to DC power supply of DC24 V. E terminal connect to the ground 	• Open between B1-B2

Specification of external regenerative resistor, please refer to P.7-122, "Options Components".

Note.2) About dynamic brake resistor

	Short bar	Built-in	Connection of term	ninal block
	(Accessory)	dynamic brake resistor.	In case of using an external dynamic brake resistor.	In case of not using an external dynamic brake resistor.
H-frame	without	without	 Connect external dynamic brake resistor as shown above. 	Open between DB1-DB2

Note.3) A magnetic contactor MC2 must be the same rating as the contactor MC1 in the main circuit.

Note.4) Servo may be turned on in the external sequence if the contact deposits: to protect the system, provide the auxiliary contact.

Note.5) Provide an external protective device (e.g. thermal fuse) to monitor the temperature of the external dynamic brake resistor.

Note.6) Reactor should be prepared by the customer.


Note The wiring indicated with the broken line shall be provided only when required.

Related page P.2-48 "Specifications of Motor connector"

5

Overall Wiring (D, E-frame, 400 V type)


Connecting Example of D, E-frame



Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page • P.7-94... "Options"



Wiring of the Main Circuit (D, E-frame, 400 V type)


D, E-frame, 400 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the power connector (XA, XB, XC and XD) to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring

- 1) Wire connector (XA, XB, XC and XD).
- Connect the wired connector to the driver.

Fully insert the connector to the bottom until it clicks.



The wiring indicated with the broken line shall be provided only when required.


Related page • P.2-48 "Specifications of Motor connector" • P.2-50 "Wiring method to connector" • P.7-112, 113 "Connector kit for XA" • P.7-113 "Connector kit for XB, XC" • P.7-112 "Connector kit for XD"

2. System Configuration and Wiring Wiring Diagram (D, E-frame, 400 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, D, E-frame, 400 V type

Power supply 3-phase, 380 V –15 % to 480 V +10 %




Note.1) Shielding the circuit is recommended for the purpose of noise reduction. Note.2)

Frame	Short wire	Built-in		ne connector XC
No.	(Accessory)	regenerative resistor	In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.
E-frame	with	with	 Remove the short wire accessory from between B2-B3. Connect an external regenerative resistor between B1-B2 	 Shorted between B2-B3 with an attached short wire

Note The wiring indicated with the broken line shall be provided only when required. **Related page** P.2-48 "Specifications of Motor connector" P.2-50 "Wiring method to connector" 5

Overall Wiring (F-frame, 400 V type)


Connecting Example of F-frame



Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page • P.7-94... "Options"



Wiring of the Main Circuit (F-frame, 400 V type)

F-frame, 400 V type

- · Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring


- 1) Take off the cover fixing screws, and detach the terminal cover.
- 2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, reter to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque written on P.2-11.

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with a torque written on P.2-11.




Related page P.2-48 "Specifications of Motor connector"

2. System Configuration and Wiring Wiring Diagram (F-frame, 400 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, F-frame, 400 V type

Power supply 3-phase, 380 V -15 % to 480 V +10 %



Built-in thermal protector of an external regenerative resistor (light yellow)

Connection

Before Using the Products

2

Preparation

Adjustment

7


Note.1) Shielding the circuit is recommended for the purpose of noise reduction. Note.2)

Frame	Short bar	Built-in		terminal block
No.	(Accessory)	regenerative resistor	In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.
F-frame	with	with	 Remove the short bar accessory from between B2-B3. Connect an external regenerative resistor between B1-B2 	 Shorted between B2-B3 with an attached short bar

Note The wiring indicated with the broken line shall be provided only when required.

Related page P.2-48 "Specifications of Motor connector"

Overall Wiring (G-frame, 400 V type)



Regenerative resistor (optional)

Remarks 🔅

- When you use an external regenerative resistor, install an external protective apparatus, such as thermal fuse without fail.
- Thermal fuse and thermal protector are built in to the regenerative resistor (Option). If the thermal fuse is activated, it will not resume.
- Mount the regenerative resistor on incombustible material such as metal.

Note

The wiring indicated with the broken line shall be provided only when required.

Pin B1 and B2

• When you connect an external regenerative resistor, connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin DB1, DB2, DB3 and DB4

- · Normally, leave DB3 and DB4 short-circuited.
- To connect the external dynamic brake resistor, refer to "Dynamic Brake" on P.2-67.
 Do not use the external dynamic brake resistor

together with the built-in resistor.


Pin NC

Do not connect anything.

Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.
 P.7-94... "Options"

Related page …



Wiring of the Main Circuit (G-frame, 400 V type)

G-frame, 400 V type

- · Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring

1) Take off the cover fixing screws, and detach the terminal cover.


2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, reter to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque between 2.0 N \cdot m and 2.4 N \cdot m (left side) and 1.0 N \cdot m and 1.7 N \cdot m (right side).

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.



Related page ···· P.2-48

• P.2-48 "Specifications of Motor connector"


Preparation

2. System Configuration and Wiring Wiring Diagram (G-frame, 400 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, G-frame, 400 V type

Power supply 3-phase, 380 V –15 % to 480 V +10 %



Note.1) About regenerative resistor

Fromo	Short bar	Built-in	Connection of terminal block		
Frame No.	(Accessory)	regenerative resistor	In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.	
G-frame	Connect an external regenerative		5	Open between B1-B2	

Note.2) About dynamic brake resistor

Frame	Short bar	Built-in	Connection of	terminal block	
No.	(Accessory)	dynamic brake resistor.	In case of using an external dynamic brake resistor.	In case of not using an external dynamic brake resistor.	
G-frame	with with		 Remove attached short bar between DB3-DB4. Connect external dynamic brake resistor as shown above. 	Shorted with attached short bar between DB3-DB4	

Note.3) Shielding the circuit is recommended for the purpose of noise reduction.

Note.4) A magnetic contactor MC2 must be the same rating as the contactor MC1 in the main circuit.

Note.5) Servo may be turned on in the external sequence if the contact deposits: to protect the system, provide the auxiliary contact.

Note.6) Provide an external protective device (e.g. thermal fuse) to monitor the temperature of the external dynamic brake resistor.

Note.7) Reactor should be prepared by the customer.

Note \Rightarrow The wiring indicated with the broken line shall be provided only when required.

Related page P.2-48 "Specifications of Motor connector"


_____f, ____

Before Using the Products

2


5

Overall Wiring (H-frame, 400 V type)



Note

application. The wiring indicated with the broken line shall be provided only when required. Related page … • P.7-94... "Options"



Wiring of the Main Circuit (H-frame, 400 V type)

H-frame, 400 V type

- · Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

Tips on Wiring

1) Take off the cover fixing screws, and detach the terminal cover.


2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, reter to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque between 0.7 N \cdot m and 1.0 N \cdot m (upper side) and 2.2 N \cdot m and 2.5 N \cdot m (lower side).

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.



Related page 🔅 • P.2-

• P.2-48 "Specifications of Motor connector"


Preparation

2. System Configuration and Wiring Wiring Diagram (H-frame, 400 V type)

Compose the circuit so that the main circuit power will be shut off when an error occurs. However, if you want to use "immediate stop function" and the main circuit power turns off, please be aware that you will no longer be able to use "immediate stop function".

In Case of 3-Phase, H-frame, 400 V type

Power supply 3-phase, 380 V –15 % to 480 V +10 %



Note.1) About regenerative resistor

Frame No.	Short bar	Built-in	Connection of term	ninal block
	(Accessory)	regenerative resistor	In case of using an external regenerative resistor.	In case of not using an external regenerative resistor.
H-frame	without	without	 (External regenerative resistor terminal) Terminal R1, R2 connect to B1, B2 Terminal T1, T2 connection as shown above Terminal 24 V,0 V connect to DC power supply of DC24 V. E terminal connect to the ground 	• Open between B1-B2

Specification of external regenerative resistor, please refer to P.7-122, "Options Components".

Note.2) About dynamic brake resistor

Fromo	Short bor	Built-in	Connection of term	inal block
Frame No.	Short bar (Accessory)	dynamic brake resistor.	In case of using an external dynamic brake resistor.	In case of not using an external dynamic brake resistor.
H-frame	without	without	 Connect external dynamic brake resistor as shown above. 	Open between DB1-DB2

Note.3) Shielding the circuit is recommended for the purpose of noise reduction.

Note.4) A magnetic contactor MC2 must be the same rating as the contactor MC1 in the main circuit.

- Note.5) Servo may be turned on in the external sequence if the contact deposits: to protect the system, provide the auxiliary contact.
- Note.6) Provide an external protective device (e.g. thermal fuse) to monitor the temperature of the external dynamic brake resistor.

Note.7) Reactor should be prepared by the customer.

Note 💮 The wiring indicated with the broken line shall be provided only when required.


Related page P.2-48 "Specifications of Motor connector"

6


Specifications of Motor connector

• When the motors of <MSMD, MHMD> are used, they are connected as shown below.

Connector: Made by Tyco Electronics k.k, (The figures below show connectors for the motor.)



- When the motors of <MSME (50 W to 750 W)> are used, they are connected as shown below. Connector: Made by Japan Aviation Electronics Industry, Ltd. (The figures below show connectors for the motor.)
 - * Do not remove the gasket supplied with the junction cable connector. Securely install the gasket in place. Otherwise, the degree of protection of IP67 will not be guaranteed.



Remarks is Do not connect anything to NC.

• When the motors of <MSME (750 W (400 V), 1.0 kW to 5.0 kW), MDME, MFME, MGME, MHME> are used, they are connected as shown below.

Connector: Made by Japan Aviation Electronics Industry, Ltd. (The figures below show connectors for the motor.)

 Connector for encoder <IP65 Encoder connector for motor>

IP65 motor Connector for encoder (Large type)



IP67 motor **Connector for encoder** (Small type)



	G								
	N/MS3102A20-29P								
20-bit In	cremental		17-bit Absolute						
PIN No.	Application		PIN No.	Application					
Α	NC		Α	NC					
В	NC		В	NC					
С	NC		С	NC					
D	NC		D	NC					
E	NC		E	NC					
F	NC		F	NC					
G	E0V		G	E0V					
Н	E5V		Н	E5V					
J	FG(SHIELD)		J	FG(SHIELD)					
K	PS		K	PS					
L	PS		L	PS					
М	NC		М	NC					
N	NC		N	NC					
Р	NC		Р	NC					
R	NC		R	NC					
S	NC		S	BAT–					
Т	NC		Т	BAT+					

<IP67 Encoder connector for motor>

JN2AS10ML3-R

20-bit Incremental			17-bit Absolute		
PIN No.	Application		PIN No.	Application	
1	E0V		1	E0V	
2	NC		2	NC	
3	PS		3	PS	
4	E5V		4	E5V	
5	NC		5	BAT–	
6	NC		6	BAT+	
7	PS		7	PS	
8	NC		8	NC	
9	FG(SHIELD)		9	FG(SHIELD)	

10

NC

Remarks 🔅

10


Do not connect anything to NC.

NC

Connector for motor/brake

Table of Connector for motor and Connector for brake

Motor	Motor conscitut 200 V 400 V Moto	Motor	Notor Mater consolity	200 V		400 V					
model	Motor capacity	with Brake	without Brake	with Brake	without Brake	model	Motor capacity	with Brake	without Brake	with Brake	without Brake
	750 W	_	_	D	Α	MFME	1.5 kW	С	С	D	D
MSME	1.0 kW to 2.0 kW	С	Α	D	Α		2.5 kW, 4.5 kW	D	D	D	D
	3.0 kW to 5.0 kW	D	В	D	В		0.9 kW	С	Α	D	Α
	400 W, 600 W	_	_	D	Α	MGME	2.0 kW to 4.5 kW	D	В	D	В
	1.0 kW to 2.0 kW	С	Α	D	Α	МНМЕ	6.0 kW	E, F	E	E, F	E
MDME	3.0 kW to 5.0 kW	D	В	D	В		1.0 kW to 1.5 kW	С	Α	D	Α
	7.5 kW to 15.0 kW	E, F	E	E, F	E		2.0 kW to 5.0 kW	D	В	D	В
							7.5 kW	E, F	E	E, F	E



Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 2-49 6

Connection

8 to 9 mm

Wiring method to connector

• Follow the procedures below for the wiring connection to the Connector XA, XB and XC.


How to connect

- 1. Peel off the insulation cover of the cable.
 - For single wire (Please obey the length in figure.)
 - For stranded wires (ferrules must be used as illustrated below).

Example: Ferrules with plastic insulating sleeve (AI series, Phoenix Contact, Ltd.)


- 1) Peel off the sheath so that the conductor portion of the cable will protrude from the tip of the ferrule. (It should protrude 1 mm or more from the ferrule.)
- Insert the cable into the ferrule and crimp it with an appropriate crimping tool.
- After crimping, cut off the cable conductor portion protruding from the ferrule. (The allowable protruding length after cutting should be 0 to 0.5 mm.)
 - Part No. of the crimping tool: CRIMPFOX U-D66 (1204436)

Available from Phoenix Contact, Ltd.



Examples: Nylon-insulated ferrule (NTUB series, J.S.T. Mfg. Co., Ltd.) Vinyl-insulated ferrule

- (VTUB series, J.S.T. Mfg. Co., Ltd.) 1) Peel off the sheath of the cable conductor
- portion to the length equal to that of sheath on the ferrule.
- 2) Insert the cable into the ferrule and crimp it with an appropriate crimping tool.
 - Part No. of the crimping tool: YNT-1614 Available from J.S.T. Mfg. Co., Ltd




- When peeling off the sheath of the cable, take care not to damage other portions.
- When crimping the ferrule, sufficiently check the status of the ferrule and cable. If the conductors of the cable stick out from the insulation cover or protrude excessively from the tip of the ferrule, accidents such as an electric shock and fire from a short circuit may result.

100 V/200 V specificat	tions	400 V specifications	
<cables compatible="" th="" with<=""><th>Connector></th><th>XA, XB, XC</th><th></th></cables>	Connector>	XA, XB, XC	
Conductor Size	AWG18 to 12	<cables compatible="" th="" with<=""><th>Connector></th></cables>	Connector>
Sheath Outline	φ2.1 mm to φ4.2 mm	Conductor Size	AWG18 to 12
<recommended connec<="" td=""><td>tor Bar Terminal></td><td>Sheath Outline</td><td>φ2.1 mm to φ4.2 mm</td></recommended>	tor Bar Terminal>	Sheath Outline	φ2.1 mm to φ4.2 mm
Conductor Size	AWG18	<recommended connect<="" td=""><td>or Bar Terminal></td></recommended>	or Bar Terminal>
Terminal Model Number	AI0.75-8GY (Phoenix Contact, Ltd.)	Conductor Size	AWG16 to 14
Conductor Size	AWG16 to 14	Terminal Model Number	VTUB-2 or NTUB-2 (J.S.T. Mfg. Co., Ltd)
Terminal Model Number	VTUB-2 or NTUB-2 (J.S.T. Mfg. Co., Ltd)	XD	
		<cables compatible="" td="" with<=""><td>Connector></td></cables>	Connector>
		Conductor Size	AWG24 to 20
		Sheath Outline	φ1.2 mm to φ2.6 mm
		<recommended connect<="" td=""><td>or Bar Terminal></td></recommended>	or Bar Terminal>
		Conductor Size	AWG24 to 22
		Terminal Model Number	VTUB-0.5 (J.S.T. Mfg. Co., Ltd)

Insert the cable to the connector in the following 2 methods.
 (a) Insert the cable using the supplied handle lever.

(b) Insert the cable using a flat-blade screwdriver (Edge width: 3.0 mm to 3.5 mm).



Take off the connector from the Servo Driver before making connection.

- Insert only one cable into each one of cable insertion slot.
- Pay attention to injury by screw driver.

3. Wiring to the connector, X1

Connecting host computer

This is used for USB connection to a personal computer. It is possible to change the parameter setting and perform monitoring.

Application	Symbol	Connector Pin No.	Contents
USB signal terminal	VBUS	1	
	D-	2	Use for communication with personal computer.
	D+	3	
	_	4	Do not connect.
	GND	5	Connected to ground of control circuit.

Caution 🔅

Use commercially available USB mini-B connector for the driver.

2 Preparation

4. Wiring to the connector, X2 Connecting communication connector

This is used for connection to the host controller when two or more units are used. RS232 and RS485 interfaces are supplied.

Application	Symbol	Connector Pin No.	Contents
Signal ground	GND	1	Connected to ground of control circuit.
NC	_	2	Do not connect.
	TXD	3	RS232
RS232 signal	RXD	4	The transmission / reception method.
	485–	5	
	485+	6	RS485
RS485 signal	485-	7	The transmission / reception method.
	485+	8	
Frame ground	FG	Shell	Connected with protective earth terminal in the servo driver.

Connector (plug): 2040008-1 (optional, available from Tyco Electronics) [Connector pin assignment]



(Viewed from cable)

Remarks :: • X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.



• Only for position control type is not provided with X2.

P.7-110 "Connector Kit for Communication Cable (for RS485, RS232)"

Before Using the Products


2

• This servo driver features 2 kinds of communication function, RS232 and RS485, and you can use in 3 connecting methods.

To communicate with a single driver through RS232

Connect the host (PC or controller) to an driver through RS232.


[How to connect]



Shut off both powers of the PC andthe driver before inserting/pulling out the connector.

To communicate with multiple drivers through RS232 and RS485

By connecting the host (PC and host controller) and one driver via RS232 and connecting other drivers via RS485 each other, you can connect multiple drivers.



Set the axis number (Pr5.31) of driver to be connected through RS485 to a value in the range 1 to 31. Set the axis number (Pr5.31) of driver to be connected to the host through RS232 to 0.




You can connect up to 32 drivers with the host.

• For details, refer to P.7-27, "Communication" of Supplement.

To communicate with multiple drivers only through RS485

Communications between the host (PC or controller) and multiple drivers can be made through RS485.



2

Preparation

3

Connection

4

5

Adjustment

6

When in Trouble

7

Supplement

2

Safety function connector

A safety by-pass plug is supplied as standard equipment. Do not disconnect it in normal times.

When controlling the safety function from the connected host controller, accessory connector cannot be used. Prepare and wire the connector (option) as specified below. Since the standard connector cannot be used when controlling the safety function from the host controller, purchase the optional connector and make connection as shown below. When you do not configuring a safety circuit, please use the safety bypass plug of

accessory to the driver. For wiring of the safety bypass plug supplied with the driver, refer to the figure below.

Application	Symbol	Connector Pin No.	Contents
NC	-	1	Do not connect
NC .	-	2	Do not connect.
Cofoty input 1	SF1-	3	
Safety input 1	SF1+	4	These are two independent circuits that
Cofoty input 0	SF2-	5	turn off the operation signal to the power module to shut off the motor current.
Safety input 2	SF2+	6	
	EDM-	7	This is an output for monitoring the failure
EDM output	EDM+	8	of the safety function.
Frame ground	FG	Shell	Connected with protective earth terminal in the servo driver.


Connector (plug): 2013595-1 (optional, available from Tyco Electronics)

[Connector pin assignment]



(Viewed from cable)

Safety bypass plug supplied with the driver (internal wiring)



Wiring if the safety circuit is not configured. When using the safety function, do not make these connections.


Remarks 🔅	• X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.
Caution 🔅	Disconnecting this connector during operation results in immediate stop.
Note	 Only for position control type is not provided with X2.

Related page P.7-110 "Connector Kit for Safety"

6. Wiring to the connector, X4

Connection to Host Controller

Tips on wiring




COM+

COM-

FG

Connector X4

GND



- ^o Separate the main circuit at least 30 cm away. Don't pass them in the same duct, nor bind them together.
- Power supply for control signals (Vcc) between COM+ and COM- (VDc) should be prepared by customer.
- ^o Use shield twisted pair for the wiring of command pulse input and encoder signal output.
- Don't apply more than 24 V to the control signal output terminals, nor run 50 mA or more to them.
- ^o When the relay is directly driven by the control output signals, install a diode in parallel with a relay, and in the direction as the Fig. shows. The driver might be damaged without a diode installment, or by reverse direction.
- Frame ground (FG) and the shell of connector is connected to the earth terminal inside of the driver.
- Related page : For details, refer to P.3-20, "Wiring Diagram to the connector, X4" and P.3-32, "Inputs and outputs on connector X4".

Specifications of the Connector, X4

Connector at	Connecter to be prep	Manufacturer			
driver side	Part name	Part No.	Wanutacturei		
52986-5079	Connecter (soldering type)	54306-5019 equivalent	Molex Inc.		
equivalent	Connector cover	54331-0501 equivalent			
or					
10250-52A2** equivalent	Connecter (soldering type)	10150-3000PE equivalent	Sumitomo 3M		
	Connector cover	10350-52A0-008 equivalent	Sumitomo Sivi		

Note

- For details, refer to P.7-109, "Options" of Supplement.
- Remarks ↔

 Tightening torque of the screws for connector (X4) for the connection to the host to be
 0.3 N·m to 0.35 N·m. Larger tightening torque than these may damage the connector at the driver side.

Remarks ☆


 X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

²⁻⁵⁴ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Provide a power supply for the external scale on your part or use the following power output (250 mA or less).

Application	Symbol	Connector Pin No.	Contents
Power supply	EX5V	1	Supply the power of external scale or A, B, Z phase encoder.
output	EX0V	2	Connected to ground of control circuit.
I/F of external	EXPS	3	Serial signal
scale signals	/EXPS	4	The transmission / reception method.
	EXA	5	
	/EXA	6	Parallel signal
A, B, Z phase	EXB	7	reception
Endoder signal input	/EXB	8	Correspondence speed :
	EXZ	9	4 Mpps (after quadruple)
	/EXZ	10	
Frame ground	FG	Shell	Connected with protective earth terminal in the servo driver.

Connector (plug) sirial external signal: MUF-PK10K-X (by J.S.T. Mfg. Co., Ltd.)



Caution

Preparation


1) The manufacturers applicable external scales for this product are as follows.

- Mitutoyo Corp.
- Magnescale Co., Ltd.

For the details of the external scale product, contact each company.


2) Recommended external scale ratio is 1/40 ≤ External scale ratio ≤ 160

If you set up the external scale ratio to smaller value than 50/position loop gain (Pr1.00 and Pr.1.05), you may not be able to control per 1 pulse unit, even if within the range as described above. Setup of larger scale ratio may result in larger noise.



Connect on to Feedback Scale

Wiring Diagram of X5




How to Wiring

Wire the signals from the external scale to the external scale connector, X5.

- 1) Cable for the external scale to be the twisted pair with bundle shielding and to having the twisted core wire with diameter of 0.18 mm².
- 2) Cable length to be max. 20 m. Double wiring for 5 V power supply is recommended when the wiring length is long to reduce the voltage drop effect.
- 3) Connect the outer film of the shield wire of the external scale to the shield of the junction cable. Also connect the outer film of the shield wire to the shell (FG) of connector X5 of the driver without fail.
- 4) Separate the wiring to X7 from the power line (L1, L2, L3, B1, B2, B3, U, V, W, ⊕) as much as possible (30 cm or more). Do not pass these wires in the same duct, nor bundle together.
- 5) Do not connect anything to the vacant pins of X5.
- 6) The maximum power available from the connector X5 is 250 mA at 5 V ±5 %. If you use an external scale requiring more power, you should provide the suitable power source by yourself. Some external scales need longer initialization period after power up. Your design should meet this operation timing after power up.
- 7) When driving the external scale from an external power supply, keep the EX5V pin open circuit so that it does not receive any external voltage. Connect the GND circuit (0 V) to EX0V (connector X5, pin 2) of the driver to eliminate potential difference.

Input circuit

• EXA, EXB, EXZ input circuit



Remarks • X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Note • Only for position control type is not provided with X5.


7



8. Wiring to the connector, X6

Connection to Encoder

Tips on Wiring



- Maximum cable length between the driver and the motor to be 20 m. Consult with a dealer or distributor if you want to use the longer cable than 20 m. (Refer to the back cover.)
- •Keep this wiring away from the main circuit by 30 cm or more. Don't guide this wiring through the same duct with the main, nor bind them together.
- The voltage of input power to encoder side connector should be in the range 4.90 VDC - 5.25 VDC.
- When you make your own encoder junction cable (for connectors, refer to P.7-111, "Options (Connector Kit for Motor and Encoder connection)" of Supplement.
 - 1) Refer to the Wiring Diagram below.
 - 2) Cable to be : Shielded twisted pair cable with core diameter of 0.18 mm² or larger (AWG24), and with higher bending resistance.
 - 3) Use twisted pair cable for corresponding signal/power wiring.
- 4) Shielding treatment
 - · Shield wall of the driver side : It solders the shell of Connector X6.
 - · Shield wall of the motor side :

manufactured by JAE

Small type motor (50 W to 750 W): connect to 6-pins Large type motor (0.9 kW to 15.0 kW): connect to 9-pins

5) Connect nothing to the empty terminals of each connector.

Encoder junction cable F5V E5V E0V E0V PS PS PS PS FG Encoder side Driver side connector Connector X6




• X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.


Related page … • P.7-111 "Connector Kit for Encoder"


2-57

Wiring Diagram

In case of 20-bit incremental encoder








Remarks :: X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

²⁻⁵⁸ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com



In case of 17-bit absolute encoder

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 2-59

Do not connect these terminals to the same power supply.

Before Using the Products

2

3

4

6

When

Ξ

Supplement

Preparation

9. Wiring to the connector, X7


Monitor output

The connector X7 of the front panel is for monitor output.

Analogue output : 2 systems

Digital output : 1 systems

In both cases, it is possible to switch the output signal by setting parameters.



Connector X7 Manufacturer's part No.: 530140610 Manufacturer: Japan Molex Inc.

	01	
0	output circuit	
	<u>1 kΩ AM1 i 1</u>	z
		Measuring
	2.2 kΩ DM 4	instrument
	GND 3	·'
i	#i	

Application	Symbol	Connector Pin No.	Contents
Analogue monitor output 1	AM1	1	 Output the analogue signal for monitor. The amplitude of the output signal is ±10 V.
Analogue monitor output 2	AM2	2	 Output impedance is 1 kW. When connecting a measuring instrument, check its input circuit for impedance matching.
Signal ground	GND	3	Connected to ground of control circuit.
Digital monitor output ^{*1}	DM	4	 Output the digital signal for monitor. Output voltage is CMOS level compatible. Output impedance is 2.2 kW. When connecting a measuring instrument, check its input circuit for impedance matching.
NC	_	5	Do not connect.
NC	_	6	Do not connect.

*1 Position, Velocity, torque, Full closed type.

NC on Only for position control type. Leave this pin unconnected.

Parameter rerated to monitor output.

Param	etr No.	Title	Function
Class	No.	The	Function
4	16	Type of analog monitor 1	Select the type of monitor for analog monitor 1.
4	17	Analog monitor 1 output gain	Set up the output gain of analog monitor 1.
4	18	Type of analog monitor 2	Select the type of monitor for analog monitor 2.
4	19	Analog monitor 2 output gain	Set up the output gain of analog monitor 2.
4	20	Type of digital monitor *2	Select type of the digital monitor.
4	21	Analog monitor output setup	Select output format of the analog monitor.

*2 Position, Velocity, torque, Full closed type.

Only for position control type is not provided with this function.

Remarks ☆
• X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Related page 🔅 • P.4-40... "Details of parameter" • P.7-111 "Connector Kit for Analog Monitor Signal"

10. Timing Chart

approx.100 ms to 300 ms

approx.2 s

approx.1.5 s

ON

established

Timing on power-up

3

Action of (initialization) usually operation reset *3 driver CPU 0 s or longer Main power supply OFF ON (L1,L2,L3) *2 10 ms or longer Servo-Ready output output Tr OFF 10 ms or longer output Tr ON (S-RDY) *2 ↔ 0 ms or longer Servo-ON input input coupler OFF input coupler ON (SRV-ON) approx.2 ms Dynamic engaged released brake approx.25 ms 😽 Servo on status A5I output Tr OFF output Tr ON output(SRV-ST) +approx.60 ms Motor not-energized energized energization approx.4 ms External brake output Tr OFF (brake engaged) ON release output (BRK-OFF) (brake released) 100 ms or longer Position/Speed/ Command No command entry *1 Torque command entry The above chart shows the timing from AC power-ON to command input. Activate the external command input according to the above timing chart. Caution 🔅 *1. In this term Servo-ON input (SRV-ON) turns ON as a hard ware, but operation command can not be received. *2. S-RDY output will turn on when both conditions are met, initialization of micro computer has been completed and the main power has been turned on. *3. After Internal control power supply, protective functions are active from approx. 1.5 sec after the start of initializing microcomputer. Please set the signals, especially for protective function, for example over-travel inhibit input (POT, NOT) or external scale input, so as to decide their logic until this term. The lapse time can be changed with Pr6.18 Wait time after power-up. *4. ASII : Only available on A5II series. Servo ON status output (SRV-ST) is a signal indicating that it has received the Servo-On input; please note that it is not an indication showing command input is possible.

Servo-on signal accept timing on power-up

OFF

OFF

Control

power supply

Internal control

power supply

(L1C,L2C)


Related page • P.4-58... "Details of parameter"

10. Timing Chart

Preparation

When an Error (Alarm) Has Occurred (at Servo-ON Command)

Alarm



- **Caution** *1. t1 will be a shorter time of either the setup value of Pr4.38[Mechanical brake action at running setup] or elapsing time for the motor speed to fall below Pr4.39[Brake release speed setup].
 - t1 will be 0 when the motor is in stall regardless of the setup pf Pr4.37.
 - *2. When an alarm is generated, the dynamic brake operates according to Pr5.10 Sequence at alarm.
 - *3. Association of the series. Servo ON status output (SRV-ST) is a signal indicating that it has received the Servo-On input; please note that it is not an indication showing command input is possible.

When an Alarm Has Been Cleared (at Servo-ON Command)

		120 ms or longer *1	
	Alarm-clear input (A-CLR)	input coupler ON OFF OFF	
	Dynamic brake	engaged ↔ approx.2 ms release	d
A5I	Servo on status output(SRV-ST) *2	approx.25 ms ↓ ↓	
	Motor energization	not-energized approx.60 ms energized	
	External brake release output (BRK-OFF)	output Tr OFF (Break engage) output Tr Of (Break releas	
	Servo-Ready output (S-RDY)	output Tr OFF (not ready) (ready)	N N
	Servo-Alarm output (ALM)	output Tr OFF output Tr Off (alarm) (not alarm)	
	Position/Speed/ Torque command	100 ms or longer	enabled

Caution 🔅

*1. The alarm clear input recognition time can be changed in Pr5.16 Alarm clear input setup. *2. Asia: Only available on A5II series.

Servo ON status output (SRV-ST) is a signal indicating that it has received the Servo-On input; please note that it is not an indication showing command input is possible.


²⁻⁶² Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Preparation

2

Servo-ON/OFF Action While the Motor Is at Stall (Servo-Lock)

Remarks 🔅 To turn on/off the servo during normal operation, first stop the motor.



Caution 🔅

- *1 t1 depends on the setup value of Pr4.37 Setup of mechanical brake action at stalling. *2 The operation of dynamic brake during servo off depends on the setup value of Pr5.06 Sequence at servo off.
- *3. Servo-ON will not be activated until the motor speed falls below approx. 30 r/min.
- *4. A5II : Only available on A5II series. Servo ON status output (SRV-ST) is a signal indicating that it has received the Servo-On input; please note that it is not an indication showing command input is possible.

Connection


5

Preparation

Servo-ON/OFF


Servo-ON/OFF Action While the Motor Is in Motion

Remarks $\stackrel{*}{\longrightarrow}$ Timing at emergency stop or trip. Do not repeat this sequence.



Caution 🔅

- *1. t1 will be a shorter time of either the setup value of Pr4.38 "Mechanical brake action at running setup" or elapsing time for the motor speed to fall below Pr4.39 "Brake release speed setup".
- *2. Even though the SRV-ON signal is turned on again during the motor deceleration, Servo-ON will not be activated until the motor stops.
- *3. For the action of dynamic brake at alarm occurrence, refer to an explanation of Pr5.06, "Sequence at Servo-OFF" as well.
- *4. Servo-ON will not be activated until the motor speed falls below approx. 30 r/min.
- *5. For the motor energization during deceleration at Servo-OFF depends on the setup value of Pr.5.08, "Sequence at Servo-OFF".
- *6. ADDI: Only available on ADDI series. Servo ON status output (SRV-ST) is a signal indicating that it has received the Servo-On input; please note that it is not an indication showing command input is possible.



5

Preparation

11. Built-in Holding Brake

Outline


In the applications where the motor drives the vertical axis, this brake would be used to hold and prevent the work (moving load) from falling by gravity while the power to the servo is shut off.

Caution 🔅

Use this built-in brake for "Holding" purpose only, that is to hold the stalling status. Never use this for "Brake" purpose to stop the load in motion.

Connecting Example

The following shows the example when the brake is controlled by using the brake release output signal (BRK-OFF) of the driver.





1. The brake coil has no polarity.

- 2. Power supply for the brake to be provided by customer. Do not co-use the power supply for the brake and for the control signals (VDC).
- 3. Install a surge absorber as the above Fig. shows to suppress surge voltage generated by ON/OFF action of the relay (RY). When you use a diode, note that the time from the brake release to brake engagement is slower than that of the case of using a surge absorber.
- 4. For a surge absorber, refer to P.7-124, "Recommended Components" of Supplement.
- Recommended components are specified to measure the brake releasing time. Reactance of the cable varies depending on the cable length, and it might generate surge voltage.

Select a surge absorber so that relay coil voltage (max. rating : 30 V, 50 mA) and terminal voltage may not exceed the rating.

Output Timing of BRK-OFF Signal

- For the brake release timing at power-on, or braking timing at Servo-OFF/Servo-Alarm while the motor is in motion, refer to P.2-62, "Timing Chart".
- With the parameter, Pr4.38 (Setup of mechanical brake action while the motor is in motion), you can set up a time between when the motor enters to a free-run from energized status and when BRK-OFF signal turns off (brake will be engaged), when the Servo-OFF or alarm occurs while the motor is in motion.

Note

- 1. The lining sound of the brake (chattering and etc.) might be generated while running the motor with built-in brake, however this does not affect any functionality.
 - 2. Magnetic flux might be generated through the motor shaft while the brake coil is energized (brake is open). Pay an extra attention when magnetic sensors are used nearby the motor.

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 2-65

2 Preparation

11. Built-in Holding Brake

Specifications

Motor series	Motor output	Static friction torque N⋅m	Rotor inertia x 10 ⁻⁴ kg⋅m²	Engaging time ms	Releasing time ms	Exciting current DC A (at cool-off)	Releasing voltage	Permissible work (J) per one braking	Permissible total work x 10 ³ J	Permissible angular acceleration rad/s ²	
	50 W, 100 W	0.29 or less	0.002	35 or less	20 or less	0.3		39.2	4.9		
MSMD	200 W, 400 W	1.27 or less	0.018	50 or less	15 or less	0.36	DC1 V or more	137	44.1	30000	
	750 W	2.45 or less	0.075	70 or less	20 or less	0.42		196	147		
	50 W, 100 W	0.29 or less	0.002	35 or less	20 or less	0.3		39.2	4.9		
	200 W, 400 W	1.27 or less	0.018	50 or less	15 or less	0.36	DC1 V or more	137	44.1	30000	
	750 W(200 V)	2.45 or less	0.075	70 or less	20 or less	0.42		196	147		
	750 W(400 V)	2.5 or less			15 or less	0.7					
MSME	1.0 kW, 1.5 kW, 2.0 kW	7.8 or less	0.33	50 or less	15 or less (100)	0.81	DC2 V	392	490	10000	
	3.0 kW	11.8 or less		80 or less			or more			10000	
	4.0 kW, 5.0 kW	16.2 or less	1.35	110 or less	50 or less (130)	0.9		1470	2200		
	400 W, 600 W	2.5 or less		50 or less	15 or less	0.70		392	490		
	1.0 kW	4.9 or less	1.35	80 or less	70 or less (200)	0.59		588	780	10000	
	1.5 kW, 2.0 kW	13.7 or less		100 or less		0.79	DOON	1176	1500		
MDME	3.0 kW	16.2 or less		110 or less	(130)	0.9	DC2 V or more	1470	2200		
	4.0 kW, 5.0 kW	24.5 or less	4.7	80 or less	25 or less (200)	1.3		1372	2900	5440	
	7.5 kW	58.8 or less		150 or less	50 or less	1.4]			5000	
	11 kW, 15 kW	100 or less	7.1	300 or less	140 or less	1.08		2000	4000	3000	
	1.5 kW	7.8 or less	4.7	80 or less	35 or less	0.83	DOON	1372	2900		
MFME	2.5 kW	21.6 or less	8.75	150 or less	100 or loss	0.75	DC2 V or more	1470	1500	10000	
	4.5 kW	31.4 or less	0.75	150 01 1855	100 01 1855	0.75		1470	2200		
	0.9 kW	13.7 or less	1.35	100 or less	50 or less (130)	0.79		1176	1500	10000	
MGME	2.0 kW	24.5 or less		80 or less	25 or less (200)	1.3	DC2 V or more			5440	
	3.0 kW	58.8 or less	4.7	150 or less	50 or less (130)	1.4		1372	2900	5440	
	4.5 kW, 6.0 kW				50 or less					5000	
MHMD	200 W, 400 W	1.27 or less	0.018	50 or less	15 or less	0.36	DC1 V	137	44.1	30000	
	750 W	2.45 or less	0.075	70 or less	20 or less	0.42	or more	196	147	30000	
	1.0 kW	4.9 or less	1 25	80 or less	70 or less (200)	0.59		588	780	10000	
MHME	1.5 kW	13.7 or less	1.35	100 or less	50 or less (130)	0.79	DC2 V	1176	1500	10000	
	2.0 kW to 5.0 kW	24.5 or less	4.7	80 or less	25 or less (200)	1.3	or more	1372	2900	5440	
	7.5 kW	58.8 or less		150 or less	50 or less	1.4				5000	

• Excitation voltage is DC24 V±10 %.

 $\ensuremath{\cdot}$ Releasing time values represent the ones with DC-cutoff using a varistor.

- Values in () represent those measured by using a diode (V03C by Hitachi, Ltd.)
- Above values (except static friction torque, releasing voltage and excitation current) represent typical values.
- Backlash of the built-in holding brake is kept $\pm 1^{\circ}$ or smaller at ex-factory point.
- Service life of the number of acceleration/deceleration with the above permissible angular acceleration is more than 10 million times. (Life end is defined as when the brake backlash drastically changes.)
- ²⁻⁶⁶ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Z Preparation

12. Dynamic Brake

Outline

This driver (A to G-frame) is equipped with a dynamic brake for emergency stop. Pay a special attention to the followings.

The H-frame driver does not incorporate the dynamic brake.

Caution 🔅

1. Dynamic brake is only for emergency stop.


Do not start/stop the motor by turning on/off the Servo-ON signal (SRV-ON). Otherwise it may damage the dynamic brake circuit of the driver.

The Motor becomes a dynamo when driven externally and short circuit current occurred while dynamic brake is activated may cause smoking or fire.

- 2. Dynamic brake is a short-duration rating, and designed for only emergency stop. Allow approx. 10 minutes pause when the dynamic brake is activated during high-speed running. (F-frame(200 V), G-frame(200 V/400 V) built-in dynamic brake resistor is capable of handling up to 3 continuous halts at the rated revolutions with max. permissible inertia. When overheated under more critical operating conditions, the brake will blow out and should be replaced with a new one.)
- You can activate the dynamic brake in the following cases.
 - 1) When the main power is turned off
 - 2) At Servo-OFF
 - 3) When one of the protective function is activated.
 - 4) When over-travel inhibit input (NOT, POT) of connector X4 is activated In the above cases from 1) to 4), you can select either activation of the dynamic brake or making the motor free-run during deceleration or after the stop, with parameter. Note that when the control power is off, for A to F-frame driver, the dynamic brake will be kept actived, and for G and H-frame driver, the dynamic brake will be kept released.
- If the built-in dynamic brake resistor of the G-frame driver is insufficient, external dynamic brake resistors can be connected.
- For the H-frame driver, external dynamic brake resistors can be connected.
 Connections of the external dynamic brake resistors are the same as those of the G-frame driver. (The DB3 and DB4 terminals are not provided.)
- Use the following resistors as the external dynamic brake resistors. (To be prepared by user)

Driver **Resistance specifications per piece** Quantity of use Frame Voltage Resistance **Electric power** 400 W G, H 200 V 1.2 Ω 3 pcs. 400 V 400 W G, H 4.8 Ω 3 pcs. Dynamic Brake Characteristics (e.g. Motor MDME 15 kW 200 V) 80 torque (N·m) 70 Resistor 1.2 Ω 60 --- Resistor 2.4 Ω 50 40 Brake 30 20

2000



500


1000

Motor speed (r/min)

12. Dynamic Brake

Connections of external dynamic brake resistor (Example)


G-frame, 200 V



Do not make short circuit.

Connections of external dynamic brake resistor (Example)

G-frame, 400 V



Provide one dynamic brake resistor for each phase.

• When using an external dynamic brake, be sure to use the resistor.

Do not make short circuit.

· Do not connect anything.

Pin NC

Before Using the Product

2

3

4

5

Adjustment

12. Dynamic Brake

Condition setting chart

1) Setup of driving condition from deceleration to after stop by main power-off (Pr5.07)

Sequence at mai power-off (Pr5.07		Driving condition During deceleration After stalling				Contents of deviation counter
	value of Pr5.07		·			
ů ľ		DB		DΒ]	Clear
1		Free-run		DB]	Clear
2		DB		Free-run]	Clear
3 -		Free-run		Free-run]	Clear
4		DB		DB]	Hold
5		Free-run		DB]	Hold
6		DB		Free-run]	Hold
7		Free-run		Free-run]	Hold
8		Emergency stop		DB]	Clear
9		Emergency stop		Free-run]	Clear


Torque limit value at emergency stop will be that of Pr5.11 (Setup of torque at emergency stop) when the setup value is 8 or 9.

2) Setup of driving condition from deceleration to after stop by Servo-OFF (Pr5.06)

Sequenc Servo-OF		Driving condition During deceleration After stalling			Contents of deviation counter	
	Setup	value of Pr5.06				
	ŏ		- DB	<u> </u>	D B	Clear
	1		Free-run		D B	Clear
	2		DB		Free-run	Clear
	3		- Free-run	<u> </u>	Free-run	Clear
	4		- DB	<u> </u>	D B	Hold
	5		- Free-run		D B	Hold
	6		- DB	<u> </u>	Free-run	Hold
	7		Free-run	<u> </u>	Free-run	Hold
	8		Emergency stop	<u> </u>	D B	Clear
	9		Emergency stop	<u> </u>	Free-run	Clear

Torque limit value at emergency stop will be that of Pr5.11 (Setup of torque at emergency stop) when the setup value is 8 or 9.

3) Setup of driving condition from deceleration to after stop by activation of protective function (Pr5.10)




When setup value is within the range 4 and 7, the protection function that supports immediate stop acts according to operation A and the function that does not support acts according to operation B.

During deceleration to stop, the main power supply must be maintained.

When the protection function acts, content of deviation counter is cleared as the alarm is cleared.

4) Setup of driving condition from deceleration to after stop by validation of over-travel inhibit input (Pr5.05)



Torque limit value during deceleration will be that of Pr5.11 (Setup of torque at emergency stop) when the setup value is 2.

Changes will be validated after the control power is turned on.

3

13. Setup of Parameter and Mode

Outline / Setup / Connection

Outline of Parameter

This driver is equipped with various parameters to set up its characteristics and functions. This section describes the function and purpose of each parameter. Read and comprehend very well so that you can adjust this driver in optimum condition for your running requirements.

Setup of Parameter

- You can refer and set up the parameter with either one of the following.
- 1) front panel of the driver
- 2) combination of the setup support software, "PANATERM" and PC.

Note \rightarrow How to control the front panel, refer to P.2-86.

Setup with the PC


It is possible to connect your personal computer to connector X1 of MINAS A5 using a USB cable for personal computer connection. Downloading the setup support software "PANATERM" from our web site and installing it on your personal computer will allow you to perform the following easily.

• With the PANATERM, you can execute the followings.

- 1) Setup and storage of parameters, and writing to the memory (EEPROM).
- 2) Monitoring of I/O, pulse input and load factor.
- 3) Display of the present alarm and reference of the error history.
- 4) Data measurement of the wave-form graphic and bringing of the stored data.
- 5) Normal auto-gain tuning
- 6) Frequency characteristic measurement of the machine system.

Note Because no production software such as CD-ROM is available, download the setup support software from our web site and install it on your personal computer.

How to Connect



USB cable

On the driver, use commercially available USB mini-B connector.

The connector on the personal computer side should be in accordance with the specifications of the PC.

use after install to the PC.

When the cable does not have noise filter, attach a signal line noise filter (DV0P1460) to both ends of the cable.

 Related page ···
 • P.4-2 "Details of Parameter"

 • P.7-26 "Setup support software [PANATERM]"

The parameter No. is displayed in the form of PrX.YY (X: Classification, YY: No.).
For the details on the parameters, refer to P.4-4 "Details of parameter".

Parar	netr No.		Crown	page					
Class	No.*	Class name	Class name Group						
0	00 to 17	Basic setting	Parameter for Basic setting	P.2-74					
1	00 to 27	Gain adjustment	n adjustment Parameter for Gain adjustment						
2	00 to 23	Damping control	Parameter for Damping control	P.2-76					
3	00 to 29	Verocity/ Torque/ Full-closed control	Parameter for Verocity/ Torque/ Full-closed control	P.2-77					
4	00 to 44	I/F monitor setting	Parameter for I/F monitor setting	P.2-78					
5	00 to 35	Enhancing setting	Parameter for Enhancing setting	P.2-80					
	00 to 39								
6	A5II 00 to 57	Special setting	Parameter for Special setting	P.2-82					

* The Parameter No. consists of 2 digits. International Series.

• In this document, following symbols represent each mode.
--

Symbol	Control mode	Setup value of Pr0.01
Р	Position control	0
S	Velocity control	1
Т	Torque control	2
F	Full-Closed control	6
P/S	Position (1st)/Velocity (2nd) control	3 *
P/T	Position (1st)/Torque (2nd) control	4 *
S/T	Velocity (1st)/Torque (2nd) control	5 *

* When you select the combination mode of 3, 4 or 5, you can select either 1st or 2nd with control mode switching input (C-MODE).

When C-MODE is ON : 1st mode selection

When C-MODE is OFF : 2nd mode selection

Do not enter the command 10ms before/after the switching.

Connection

5

13. Setup of Parameter and Mode

List of Parameters

[Class 0] Basic setting

Para No		Title	Range		Default		Unit Turning		Control Mode				
Class	No.	inte	nunge	A,B -frame -	C D,E,F frame -frame	G,H -frame		power supply	Ρ	S	т	F	page
0	00	Rotational direction setup	0 to 1		1		-	0	0	0	0	\bigcirc	4-4
0	01	Control mode setup	0 to 6		0		-	0	0	0	0	0	4-4
0	02	Real-time auto-gain tuning setup	0 to 6		1		-		0	0	0	0	4-5
0	03	Selection of machine stiffness at real- time auto-gain tuning	0 to 31	13	3 1	1	-		0	0	0	0	4-6
0	04	Inertia ratio	0 to 10000		250		%		0	0	0	0	
	05		0 to 1		0							0	4-7
0	05	Selection of command pulse input	A5II 0 to 2		0		_	0	0			0	
0	06	Command pulse rotational direction setup	0 to 1		0		_	0	0			0	4-8
0	07	Command pulse input mode setup	0 to 3		1		-	0	0			0	+0
0	08	Command pulse counts per one motor revolution	0 to 220		10000		pulse	0	0			0	
0	09	1st numerator of electronic gear	0 to 230		0		-		0			\bigcirc	4-9
0	10	Denominator of electronic gear	0 to 230		10000		-		0			0	
0	11	Output pulse counts per one motor revolution	1 to 262144		2500		P/r	0	0	0	0	0	4-10
0	12	Reversal of pulse output logic	0 to 3		0		-	0	0	0	0	\bigcirc	
0	13	1st torque limit	0 to 500		500 *1		%		0	0	0	0	
0	14	Position deviation excess setup	0 to 227		100000	-	Command unit		0			\bigcirc	4-12
0	15	Absolute encoder setup	0 to 2		1		-	0	0	0	0	\bigcirc	
0	16	External regenerative resistor setup	0 to 3	3	0	3	-	0	0	0	0	0	
0	17	Load factor of external regenerative resistor selection	0 to 4		0		-	0	0	0	0	0	4-13

[Class 1] Gain adjustment

Parametr No.		Title	Range	D	efault	Unit	Turning on of	Related Control Mode				Detail
Class	No.	The	nange	A,B C -frame -fram	D,E,F G,H ne -frame -frame	-	power supply	Ρ	S	Т	F	page
1	00	1st gain of position loop	0 to 30000	480	320	0.1 /s*		0			0	
1	01	1st gain of velocity loop	1 to 32767	270	180	0.1 Hz*		0	0	0	0	4-14
1	02	1st time constant of velocity loop integration	1 to 10000	210	310	0.1 ms*		0	0	0	0	

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control • A5II represents setting range applied to A5II series.

*1 Default settings depend on the combination of driver and motor. Refer to P. 2-84 "Torque limit setting".

Caution ... The symbol "*" attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note i Parameter describes of this page is P.4-4 to P.4-14.

Para No		Title	Dongo	Def	ault	Unit	Turning on of			ated I Mo		Detail
Class	No.	Title	Range	A,B C -frame -frame	D,E,F G,H -frame -frame	Unit	power supply	Ρ	S	Т	F	page
1	03	1st filter of speed detection	0 to 5	()	-		0	0	0	0	4-14
1	04	1st time constant of torque filter	0 to 2500	84	126	0.01 ms		0	0	0	0	4-14
1	05	2nd gain of position loop	0 to 30000	570	380	0.1 /s*		0			\bigcirc	
1	06	2nd gain of velocity loop	1 to 32767	270	180	0.1 Hz*		0	0	0	0	
1	07	2nd time constant of velocity loop integration	1 to 10000	100	000	0.1 ms*		0	0	0	0	
1	08	2nd filter of speed detection	0 to 5	0)	-		0	0	0	\bigcirc	4-15
1	09	2nd time constant of torque filter	0 to 2500	84	126	0.01 ms*		0	0	0	0	4-15
1	10	Velocity feed forward gain	0 to 1000 A5I 0 to 2000	30	00	0.10 %*		0			0	
1	11	Velocity feed forward filter	0 to 6400	5	0	0.01 ms*		\bigcirc			\bigcirc	
1	12	Torque feed forward gain	0 to 1000 A5I 0 to 2000)	0.10%*		0	0		0	4-16
1	13	Torque feed forward filter	0 to 6400	()	0.01 ms*		0	0		\bigcirc	4-10
1	14	2nd gain setup	0 to 1	1		_		0	0	0	0	
1	15	Mode of position control switching	0 to 10	()	-		0			\bigcirc	
1	16	Delay time of position control switching	0 to 10000	5	0	0.1 ms*		0			0	4-17
1	17	Level of position control switching	0 to 20000	5	0	-		\bigcirc			\bigcirc	
1	18	Hysteresis at position control switching	0 to 20000	3	3	-		0			0	4-18
1	19	Position gain switching time	0 to 10000	3	3	0.1 ms*		0			\bigcirc	
1	20	Mode of velocity control switching	0 to 5	()	-			0			
1	21	Delay time of velocity control switching	0 to 10000	C)	0.1 ms*			0			4 10
1	22	Level of velocity control switching	0 to 20000	()	_			0			4-19
1	23	Hysteresis at velocity control switching	0 to 20000	()	-			0			
1	24	Mode of torque control switching	0 to 3	0)	-				0		
1	25	Delay time of torque control switching	0 to 10000	()	0.1 ms*				0		4 00
1	26	Level of torque control switching	0 to 20000	()	_				0		4-20
1	27	Hysteresis at torque control switching	0 to 20000	()	-				\bigcirc		

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control • A5II represents setting range applied to A5II series.

Caution ... The symbol " * " attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note 💮 P

Parameter describes of this page is P.4-14 to P.4-20.

1

Connection

4

7

Supplement

[Class 2] Damping control

Para N		Title	Range	Default	Unit	Turning on of	Co	Rela ntro	ated I Mo	de	Detail
Class	No.	The second se	nunge	A,B C D,E,F G,H -frame -frame -frame		power supply	Ρ	S	Т	F	page
2	00	Adaptive filter mode setup	0 to 4	- 0	_		0	0		0	
2	01	1st notch frequency	50 to 5000	5000	Hz		0	0	0	0	4.04
2	02	1st notch width selection	0 to 20	2	_		0	0	0	0	4-21
2	03	1st notch depth selection	0 to 99	0	_		0	0	0	0	
2	04	2nd notch frequency	50 to 5000	5000	Hz		0	0	0	0	
2	05	2nd notch width selection	0 to 20	2	_		0	0	0	0	
2	06	2nd notch depth selection	0 to 99	0	_		0	0	0	0	
2	07	3rd notch frequency	50 to 5000	5000	Hz		0	0	0	0	
2	08	3rd notch width selection	0 to 20	2	-		0	0	0	0	4-22
2	09	3rd notch depth selection	0 to 99	0	-		0	0	0	0	
2	10	4th notch frequency	50 to 5000	5000	Hz		0	0	0	0	
2	11	4th notch width selection	0 to 20	2	-		0	0	0	0	
2	12	4th notch depth selection	0 to 99	0	-		0	0	0	0	4-23
2	13	Selection of damping filter switching	0 to 3	0	-		0			0	4-23
2	14	1st damping frequency	0 to 2000	- 0	0.1 Hz*		0			0	
2	15	1st damping filter setup	0 to 1000	- 0	0.1 Hz*		0			0	
2	16	2nd damping frequency	0 to 2000	- 0	0.1 Hz*		0			0	4-24
2	17	2nd damping filter setup	0 to 1000 A5II 0 to 1500	- 0	0.1 Hz*		0			0	
2	18	3rd damping frequency	0 to 2000 A5II 0 to 3000	- 0	0.1 Hz*		0			0	

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control • A5II represents setting range applied to A5II series.

Caution The symbol "*" attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note Parameter describes of this page is P.4-21 to P.4-24.

Para N		Title	Range	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	The	nange	A,B C D,E,F G,H -frame -frame -frame	Onit	power supply	Ρ	S	Т	F	page
	10		0 to 1000		0 4 11 *						
2	19	3rd damping filter setup	A5I 0 to 1500	0	0.1 Hz*		0				
			0 to 2000		o / I I *						
2	20	4th damping frequency	абл 0 to 3000	0	0.1 Hz*		0				4-24
			0 to 1000		.						
2	21	4th damping filter setup	A5I 0 to 1500	0	0.1 Hz*		0				
		Positional command smoothing filter		_			0			0	4-25
2	22	First order filter time constant for position command	0 to 10000	0	0.1 ms*		0	0		0	4-26
		Positional command FIR filter					0			0	4-27
2	23	FIR filter time constant for position command	0 to 10000	00 0	0.1 ms*		0	0		0	4-28

[Class 3] Verocity/ Torque/ Full-closed control

Para No		Title	Range	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	The	nange	A,B C D,E,F G,H -frame -frame -frame	Unit	power supply	Р	s	т	F	page
3	00	Speed setup, Internal/External switching	0 to 3	0	-			0			4-29
3	01	Speed command rotational direction selection	0 to 1	0	-			0			4-29
3	02	Input gain of speed command	10 to 2000	500	(r/min)/ V			0	0		4-30
3	03	Reversal of speed command input	0 to 1	1	-			0			100
3	04	1st speed of speed setup	-20000 to 20000	0	r/min			0			
3	05	2nd speed of speed setup	-20000 to 20000	0	r/min			0			
3	06	3rd speed of speed setup	-20000 to 20000	0	r/min			0			
3	07	4th speed of speed setup	-20000 to 20000	0	r/min			0			
3	08	5th speed of speed setup	-20000 to 20000	0	r/min			0			4-31
3	09	6th speed of speed setup	-20000 to 20000	0	r/min			0			
3	10	7th speed of speed setup	-20000 to 20000	0	r/min			0			
3	11	8th speed of speed setup	-20000 to 20000	0	r/min			0			
3	12	Acceleration time setup	0 to 10000	0	ms/ (1000 r/min)			0			

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control • A5II represents setting range applied to A5II series.

The symbol "*" attached to "Unit". indicates that the digits of setting unit will change if the Caution 🔅 parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-24 to P.4-31.

1

Before Using the Products

2

Setup

7

Supplement

List of Parameters

Para No		Title	Range	Default	Unit	Turning on of			ated I Mo		Detail
Class	No.	The	nange	A,B C D,E,F G,H -frame -frame -frame	onit	power supply	Р	S	Т	F	page
3	13	Deceleration time setup	0 to 10000	0	ms/ (1000 r/min)			0			4-31
3	14	Sigmoid acceleration/ deceleration time setup	0 to 1000	0	ms			0			
3	15	Speed zero-clamp function selection	0 to 3	0	-			0	\bigcirc		4-32
3	16	Speed zero clamp level	10 to 20000	30	r/min			0	\bigcirc		
3	17	Selection of torque command	0 to 2	0	-				0		
3	18	Torque command direction selection	0 to 1	0	_				0		4-33
3	19	Input gain of torque command	10 to 100	30	0.1 V/ 100 %*				0		4-33
3	20	Input reversal of torque command	0 to 1	0	_				0		
3	21	Speed limit value 1	0 to 20000	0	r/min				0		
3	22	Speed limit value 2	0 to 20000	0	r/min				0		4-34
3	23	External scale selection	0 to 2	0	_	0				0	
3	24	Numerator of external scale division	0 to 220	0	_	0				0	
3	25	Denominator of external scale division	1 to 220	10000	_	0				0	4-35
3	26	Reversal of direction of external scale	0 to 1	0	-	0				0	4-55
3	27	External scale Z phase disconnection detection disable	0 to 1	0	_	0				0	
3	28	Hybrid deviation excess setup	1 to 227	16000	Command unit	0				0	4-36
3	29	Hybrid deviation clear setup	0 to 100	0	Revolution	0				\bigcirc	4-30

[Class 4] I/F monitor setting

	metr o.	Title	Range	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	The second se		A,B C D,E,F G,H -frame -frame -frame		power supply	Ρ	S	Т	F	page
4	00	SI1 input selection (Pin No.8)	0 to 00FFFFFFh	8553090	-	0	0	0	0	0	4-37
4	01	SI2 input selection (Pin No.9)	0 to 00FFFFFFh	8487297	-	0	0	0	0	0	
4	02	SI3 input selection (Pin No.26)	0 to 00FFFFFFh	9539850	-	0	0	0	0	0	
4	03	SI4 input selection (Pin No.27)	0 to 00FFFFFFh	394758	-	0	0	0	0	0	4-38
4	04	SI5 input selection (Pin No.28)	0 to 00FFFFFFh	4108	_	0	0	0	0	0	4-38
4	05	SI6 input selection (Pin No.29)	0 to 00FFFFFFh	197379	_	0	0	0	0	0	
4	06	SI7 input selection (Pin No.30)	0 to 00FFFFFFh	3847	_	0	0	0	0	0	

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control

Caution The symbol "*" attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-31 to P.4-38.

Para No		Title	Danga	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	Title	Range	A,B C D,E,F G,H -frame -frame -frame	Unit	power supply	Р	s	Т	F	page
4	07	SI8 input selection (Pin No.31)	0 to 00FFFFFFh	263172	-	0	0	0	0	0	
4	08	SI9 input selection (Pin No.32)	0 to 00FFFFFFh	328965	-	0	0	0	0	0	4-38
4	09	SI10 input selection (Pin No.33)	0 to 00FFFFFFh	3720	_	0	0	0	0	0	
4	10	SO1 output selection (Pin No.10, 11)	0 to 00FFFFFFh	197379	-	0	0	0	0	0	
4	11	SO2 output selection (Pin No.34, 35)	0 to 00FFFFFFh	131586	-	0	0	0	0	0	
4	12	SO3 output selection (Pin No.36, 37)	0 to 00FFFFFFh	65793	-	0	0	0	0	0	4 00
4	13	SO4 output selection (Pin No.38, 39)	0 to 00FFFFFFh	328964	-	0	0	0	0	0	4-39
4	14	SO5 output selection (Pin No.12)	0 to 00FFFFFFh	460551	-	0	0	0	0	0	
4	15	SO6 output selection (Pin No.40)	0 to 00FFFFFFh	394758	_	0	0	0	0	0	
4	16	Type of analog monitor 1	0 to 21	0	_		0	0	0	0	
4	17	Analog monitor 1 output gain	0 to 214748364	0	_		0	0	0	0	
4	18	Type of analog monitor 2	0 to 21	4	_		0	0	0	0	4-40
4	19	Analog monitor 2 output gain	0 to 214748364	0	_		0	0	0	0	
4	20	Type of digital monitor	0 to 3	0	_		0	0	0	0	
4	21	Analog monitor output setup	0 to 2	0	_		0	0	0	0	
4	22	Analog input 1 (AI1) offset setup	-5578 to 5578	0	0.366 mV		0	0	0	0	
4	23	Analog input 1 (AI1) filter	0 to 6400	0	0.01 ms*		0	0	0	0	
4	24	Analog input 1 (AI1) overvoltage setup	0 to 100	0	0.1 V*		0	0	0	0	4 40
4	25	Analog input 2 (AI2) offset setup	-342 to 342	0	5.86 mV		0	0	0	0	4-42
4	26	Analog input 2 (Al2) filter	0 to 6400	0	0.01 ms*		0	0	0	0	
4	27	Analog input 2 (Al2) overvoltage setup	0 to 100	0	0.1 V*		0	0	0	0	
4	28	Analog input 3 (AI3) offset setup	-342 to 342	0	5.86 mV		0	0	0	0	
4	29	Analog input 3 (AI3) filter	0 to 6400	0	0.01 ms*		0	0	0	0	
4	30	Analog input 3 (AI3) overvoltage setup	0 to 100	0	0.1 V*		0	0	0	0	
4	31	Positioning complete (In-position) range	0 to 262144	10	Command unit		0			0	4-43
4	32	Positioning complete (In-position) output setup	0 to 3	0	_		0			0	
4	33	INP hold time	0 to 30000	0	1 ms		\bigcirc			0	4-44

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control • A511 represents setting range applied to A511 series.

Caution ... The symbol " * " attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note 💮 Pa

Parameter describes of this page is P.4-38 to P.4-44.

1

Before Using the Products

2

Preparation

3

Connection

Setup

Supplement

Para No		Title	Range	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	me	nange	A,B C D,E,F G,H -frame -frame -frame		power supply	Ρ	S	т	F	page
4	34	Zero-speed	10 to 20000	50	r/min		0	0	0	0	4-44
4	35	Speed coincidence range	10 to 20000	50	r/min			0			4-44
4	36	At-speed (Speed arrival)	10 to 20000	1000	r/min			0	0		
4	37	Mechanical brake action at stalling setup	0 to 10000	0	1 ms		0	0	0	0	4-45
4	38	Mechanical brake action at running setup	0 to 10000	0	1 ms		0	0	0	0	
4	39	Brake release speed setup	30 to 3000	30	r/min	0	0	0	0	0	
4	40	Selection of alarm output 1	0 to 10	0	_		0	0	0	0	
4	41	Selection of alarm output 2	0 to 10	0	_		0	0	0	0	4-46
4	42	2nd Positioning complete (In-position) range	0 to 262144	10	Command unit		0			\bigcirc	

[Class 5] Enhancing setting

Para No		Title	Range	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	nue	nange	A,B C D,E,F G,H -frame -frame -frame	Onit	power supply	Ρ	s	т	F	page
5	00	2nd numerator of electronic gear	0 to 2 ³⁰	0	-		0			0	
5	01	3rd numerator of electronic gear	0 to 230	0	-		0			\bigcirc	
5	02	4th numerator of electronic gear	0 to 230	0	-		0			0	
_	00		0 to 262144								4-47
5	03	Denominator of pulse output division	<mark>А5I</mark> 0 to 1048576	0	-	0	0	0	0	0	
5	04	Over-travel inhibit input setup	0 to 2	1	-	0	0	0	0	0	
5	05	Sequence at over-travel inhibit	0 to 2	0	-	0	0	0	0	\bigcirc	
5	06	Sequence at Servo-Off	0 to 9	0	-		0	0	0	0	4-48
5	07	Sequence at main power OFF	0 to 9	0	-		0	0	0	0	4-40
5	08	LV trip selection at main power OFF	0 to 1	1	-		0	0	0	0	
5	09	Detection time of main power off	70 to 2000	70	1 ms	0	0	0	0	0	4-49
5	10	Sequence at alarm	0 to 7	0	-		0	0	0	0	
5	11	Torque setup for emergency stop	0 to 500	0	%		0	0	0	\bigcirc	4.50
5	12	Over-load level setup	0 to 500	0	%		0	0	0	0	4-50

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control • A5II represents setting range applied to A5II series.

Note ··· Parameter describes of this page is P.4-44 to P.4-50.

	metr o.	Title	Range	Default	Unit	Turning on of			ated I Mo		Detail
Class	No.	The	nange	A,B C D,E,F G,H -frame -frame -frame	Onit	power supply	Ρ	s	Т	F	page
5	13	Over-speed level setup	0 to 20000	0	r/min		0	0	0	\bigcirc	
5	14	Motor working range setup	0 to 1000	10	0.1 revolution*		0			0	4-50
5	15	I/F reading filter	0 to 3	0	_	0	0	0	0	0	
5	16	Alarm clear input setup	0 to 1	0	_	0	0	0	0	\bigcirc	
5	17	Counter clear input mode	0 to 4	3	_		0			0	
5	18	Invalidation of command pulse inhibit input	0 to 1	1	_		0			0	4-51
5	19	Command pulse inhibit input reading setup	0 to 4	0	_	0	0			0	
5	20	Position setup unit select	0 to 1	0	-	0	\circ			\bigcirc	
5	21	Selection of torque limit	0 to 6	1	-		\bigcirc	0		\bigcirc	4-52
5	22	2nd torque limit	0 to 500	500 *1	%		0	0		0	
5	23	Torque limit switching setup 1	0 to 4000	0	ms/100 %		0	0		\bigcirc	
5	24	Torque limit switching setup 2	0 to 4000	0	ms/100 %		0	0		0	
5	25	External input positive direction torque limit	0 to 500	500 ^{*1}	%		0	0		0	4-53
5	26	External input negative direction torque limit	0 to 500	500 *1	%		0	0		0	
5	27	Input gain of analog torque limit	10 to 100	30	0.1 V/ 100 %*		0	0		\bigcirc	
5	28	LED initial status	0 to 35	1	_	0	0	0	0	0	
5	29	RS232 baud rate setup	0 to 6	2	_	0	0	0	0	0	4-54
5	30	RS485 baud rate setup	0 to 6	2	_	0	0	0	0	0	
5	31	Axis address	0 to 127	1	_	0	0	0	0	0	
5	32	Command pulse input maximum setup	250 to 4000	4000	kpulse/s	0	0			0	
5	33	Pulse regenerative output limit setup	0 to 1	0	_	0	0	0	0	0	4-55
5	34	For manufactuer's use	_	4	_						
5	35	Front panel lock setup	0 to 1	0	_	0	0	0	0	0	

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control

• A5II represents setting range applied to A5II series.

*1 Default settings depend on the combination of driver and motor. Refer to P. 2-84 "Torque limit setting".

Caution The symbol " * " attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Preparation 3

1

Before Using the Products

2

Setup

6

7

Note 🔅 Parameter describes of this page is P.4-50 to P.4-55.

[Class 6] Special setting

Para No		Title	Panga	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	nue	Range	A,B C D,E,F G,H -frame -frame -frame	Unit	power supply	Ρ	s	Т	F	page
6	00	Analog torque feed forward conversion gain	0 to 100	0	0.1 V/ 100 %*		0	0		0	
6	02	Velocity deviation excess setup	0 to 20000	0	r/min		\circ				
6	04	JOG trial run command speed	0 to 500	300	r/min		0	0	0	0	4-56
6	05	Position 3rd gain valid time	0 to 10000	0	0.1 ms*		0			\bigcirc	
6	06	Position 3rd gain scale factor	50 to 1000	100	%		0			0	
6	07	Torque command additional value	-100 to 100	0	%		0	0		\bigcirc	
6	08	Positive direction torque compensation value	-100 to 100	0	%		0			0	
6	09	Negative direction torque compensation value	-100 to 100	0	%		0			0	4-57
6	10	Function expansion setup	0 to 63	0	_		0	0	0	0	
6	11	Current response setup	50 to 100	100	%		0	0	\bigcirc	\bigcirc	
6	13	Current response setup	0 to 10000	250	%		0	0	0	0	
6	14	Emergency stop time at alarm	0 to 1000	200	1 ms		0	0	0	0	
6	15	2nd over-speed level setup	0 to 20000	0	r/min		0	0	0	0	4-58
6	16	For manufacturer's use	-	0	-	0					
6	17	Front panel parameter writing selection	0 to 1	0	_	0	0	0	0	0	
6	18	Power-up wait time	0 to 100	0	0.1 s*	0	\circ	0	0	\bigcirc	
6	19	Encoder Z phase setup	0 to 32767	0	pulse	0	0	0	0	0	
6	20	Z-phase setup of external scale	0 to 400	0	μs	0				0	
6	21	Serial absolute external scale Z phase setup	0 to 2 ²⁸	0	pulse	0				0	4-59
6	22	A, B phase external scale pulse output method selection	0 to 1	0	_	0				0	
6	23	Disturbance torque compensating gain	-100 to 100	0	%		0	0			
6	24	Disturbance observer filter	0 to 2500	53	0.01 ms*		0	0			
6	27	Alarm latch time selection	0 to 10	5	S	0	0	0	0	0	4-60
6	31	Real time auto tuning estimation speed	0 to 3	1	-		0	0	\bigcirc	\bigcirc	
6	32	Real time auto tuning custom setup	-32768 to 32767	0	_		0	0	0	0	4-61

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control • A511 represents setting range applied to A511 series.

Caution ... The symbol "*" attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note in Parameter describes of this page is P.4-56 to P.4-61.

Para No		Title	Range	Default	Unit	Turning on of		Rela ntro			Detail
Class	No.	nue	-	A,B C D,E,F G,H -frame -frame -frame	onit	power supply	Р	s	т	F	page
6	33	For manufacturer's use	-	1000	-						-
6	34	Hybrid vibration suppression gain	0 to 30000	0	0.1 /s*					\bigcirc	4.00
6	35	Hybrid vibration suppression filter	0 to 6400	10	0.01 ms*					0	4-62
6	37	Oscillation detecting level	0 to 1000	0	0.1 %*		\bigcirc	0	0	\bigcirc	
6	38	Alarm mask setup	-32768 to 32767	4	_	0	0	0	0	0	
6	39	For manufactuer's use	-	0	_						
6	41	A5I Anti-vibration depth 1	0 to 1000	0	_		0			0	4-63
6	42	A5II Two-stage torque filter time constant	0 to 2500	0	0.01 ms		0	0	0	0	
6	43	A5II Two-stage torque filter Attenuation term	0 to 1000	0	-		0	0	0	0	
6	47	A511 Function expansion settings 2	0 to 15	0	_	0	\circ	\bigcirc	\bigcirc	\bigcirc	
6	48	A5I Adjust filter	0 to 2000	0	0.1 ms		0	0			
6	49	Adjust/Torque command Attenuation term	0 to 99	0	_		0				4-64
6	50	Viscous friction compensation gain	0 to 10000	0	0.1 %/ (10000 r/min)		0				
6	51	A5II Immediate cessation completion wait time	0 to 10000	0	ms		0	0	0	0	4-65
6	57	A5II Torque saturation anomaly detection time	0 to 5000	0	ms		0	0		0	4-03

• Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

• Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control

• A5I represents setting range applied to A5I series.

Caution 🔅

Note

The symbol "*" attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

parameter is set by using the setup support software PANATERM. Parameter describes of this page is P.4-62 to P.4-65. Before Using the Products

1

3

5

6

Z Preparation

13. Setup of Parameter and Mode

Setup of Torque Limit

Torque limit setup range is 0 to 300 and default is 300 except the combinations of the motor and the driver listed in the table below.

Frame	Model No.	Applicable motor	Max. value of torque limit	Frame	Model No.	Applicable motor	Max. value of torque limit
	MDDHT5540	MGME092G**	225		MGDHTC3B4	MGME602G**	272
D		MGME092S**	225			MGME602S**	272
D	MDDHT3420	MGME094G**	225			MDME752G**	265
		MGME094S**	225			MDME752S**	265
		MGME202G**	250			MHME752G**	265
	MFDHTA390	MGME202S**	250			MHME752S**	265
		MGME302G**	250	G		MGME604G**	272
	MFDHTB3A2	MGME302S**	250			MGME604S** 272 MDME754G** 267 MDME754S** 267	272
		MGME452G**	262				267
_		MGME452S**	262		MGDHTB4A2		267
F	MFDHT5440	MGME204G**	250			MHME754G**	267
		MGME204S**	250			MHME754S**	267
	MFDHTA464	MGME304G**	250	Н		MDMEC12G**	265
		MGME304S**	250			MDMEC12S**	265
		MGME454G**	263		MHDHTC3B4		253
		MGME454S**	263				253
						MDMEC14G**	265
						MDMEC14S**	265
					MHDHTB4A2	MDMEC54G**	253
							1

• The above limit applies to Pr0.13 (1st torque limit), Pr5.22 (2nd torque limit), Pr5.11 (Torque setup for emergency stop), Pr5.25 (External input positive direction torque limit) and Pr5.26(External input negative direction torque limit).

MDMEC54S**

253

Caution 🔅

When you change the motor model, above max. value may change as well. Check and reset the setup values of Pr0.13, Pr5.22, Pr5.11, Pr5.25 and Pr5.26.

2

Preparation

3

Connection

4

Setup


5

Cautions on Replacing the Motor

As stated previously, torque limit setup range might change when you replace the combination of the motor and the driver. Pay attention to the followings.


1. When the motor torque is limited,

When you replace the motor series or to the different wattage motor, you need to reset the torque limit setup because the rated toque of the motor is different from the previous motor. (see e.g.1)




2. When you want to obtain the max. motor torque,

You need to reset the torque limiting setup to the upper limit, because the upper limit value might be different from the previous motor. (see e.g.2)



Preparation

Relation between Electronic Gear and Position Resolution or Traveling Speed



Example of ball screw drive by servo motor

Here we take a ball screw drive as an example of machine.

A travel distance of a ball screw M [mm] corresponding to travel command P1 [P], can be described by the following formula (1) by making the lead of ball screw as L [mm]

 $M = P1 x (D/E) x (1/R) x L \dots (1)$

therefore, position resolution (travel distance ΔM per one command pulse) will be described by the formula (2)

 $\Delta M = (D/E) \times (1/R) \times L$ (2)

modifying the above formula (2), electronic gear ratio can be found in the formula (3).

Actual traveling velocity of ball screw, V[mm/s] can be described by the formula (4) and the motor rotational speed, N at that time can be described by the formula (5).

V = F x (D/E) x (1/R) x L(4)

 $N = F x (D/E) x 60 \dots (5)$

modifying the above formula (5), electronic gear ratio can be found in the formula (6).

 $D = (N \times E)/(F \times 60)$ (6)

Note

1) Make a position resolution, Δ M as approx. 1/5 to 1/10 of the machine positioning accuracy, $\Delta\epsilon$, considering a mechanical error.

- 2) Set up Pr0.09 and Pr0.10 to any values between 1 to 2³⁰.
- 3) The desired setting can be determined by selecting value of numerator and denominator of electronic gear. However, an excessively high division or multiplication ratio cannot guarantee the operation. The ratio should be in a range between 1/1000 and 1000. Excessively high multiplication ratio will cause Err27.2 (command pulse multiplication error protection) due to varying command pulse input or noises, even if the other settings are within the specified range.

4)	2 ⁿ	Decimal	2 ⁿ	Decimal
	2º	1	211	2048
	21	2	2 ¹²	4096
	2 ²	4	2 ¹³	8192
	2 ³	8	2 ¹⁴	16384
	2 ⁴	16	2 ¹⁵	32768
	2 ⁵	32	2 ¹⁶	65536
	2 ⁶	64	2 ¹⁷	131072
	27	128	2 ¹⁸	262144
	2 ⁸	256	2 ¹⁹	524288
	2 ⁹	512	2 ²⁰	1048576
	2 ¹⁰	1024		

	Electronic gear ratio $D = \frac{\Delta M \times E \times R}{L}$	$D = \frac{Pr0.09}{Pr0.10}$		
Lead of ball screw, L =10 mm Gear reduction ratio, R = 1 Position resolution, ΔM =0.005 mm Encoder, 17-bit (E= 2 ¹⁷ P/r)	$\frac{0.0005 \times 2^{17} \times 1}{10} = \frac{5 \times 2^{17}}{10 \times 10^4} = \frac{655360}{100000}$	Pr0.09 = 655360 Pr0.10 = 100000		
Lead of ball screw, L =20 mm Gear reduction ratio, R = 1 Position resolution, ΔM =0.0005 mm Encoder, 17-bit (E= 2 ¹⁷ P/r)	$\frac{0.00005 \times 2^{17} \times 1}{20} = 0.32768$ D < 1, hence use 120-bit.	"D = 1" is the condition for minimum resolution.		
Encoder : 20-bit (E = 2 ²⁰ P/r)	$\frac{0.00005 \times 2^{20} \times 1}{20} = \frac{5 \times 2^{20}}{20 \times 10^5} = \frac{5242880}{2000000}$	Pr0.09 = 5242880 Pr0.10 = 2000000		
	Motor rotational speed (r/min), $N = F \times \frac{D}{E} \times 60$			
Lead of ball screw, L =20 mm Gear reduction ratio, R = 1 Position resolution, $\Delta M = 0.0005$ mm Line driver pulse input, 500 kpps Encoder, 17-bit	$500000 \times \frac{1 \times 2^{15}}{10000} \times \frac{1}{2^{17}} \times 60$ $= 50 \times 60 \times \frac{1}{2^2} = 750$			
	Electronic gear ratio $D = \frac{N \times E}{F \times 60}$	$D = \frac{Pr0.09}{Pr0.10}$		
Ditto	$D = \frac{2000 \times 2^{17}}{500000 \times 60} = \frac{2000 \times 2^{17}}{30000000} = \frac{262144000}{30000000}$	Pr0.09 = 262144000 Pr0.10 = 30000000		
To make it to 2000 r/min.	Travel distance per command pulse (mm) (Position resolution) $\Delta M = \frac{D}{E} \times \frac{1}{R} \times L$	<u> </u>		
	$\frac{2^{15}}{3750} \times \frac{1}{2^{17}} \times \frac{1}{1} \times 20 = \frac{1}{3750} \times \frac{20}{2^2} = \frac{20}{3750 \times 4} = 0.00133 \text{ mm}$			

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble


7

Supplement

15. How to Use the Front Panel

Setup

Setup with the Front Panel




Note \rightarrow For connector X7, refer to P.2-60 "Wiring to the connector, X7".

Initial Status of the Front Panel Display (7 Segment LED)

Status

Front panel display shows the following after turning on the power of the driver.




Initial display of LED

(Determined by the setup of Parameter, Pr5.28 "Initial status of LED".)

Upon Occurrence of an Alarm

If a driver alarm is generated, the front panel display shows the following repeatedly.



Repeatedly(during continuous alarm)

Below shows possible cause of an alarm.

alarm No.	Alarm	Content
A0	Overload protection	Load factor is 85 % or more the protection level.
A1	Over-regeneration alarm	Regenerative load factor is 85 % or more the protection level.
A2	Battery alarm	Battery voltage is 3.2 V or lower.
A3	Fan alarm	Fan has stopped for 1 sec.
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.
A5	Encoder overheat alarm	The encoder detects overheat alarm.
A6	Oscillation detection alarm	Oscillation or vibration is detected.
A7	Lifetime detection alarm	The life expectancy of capacity or fan becomes shorter than the specified time.
A8	External scale error alarm	The external scale detects the alarm.
A9	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.

Before Using the Products

2

Connection

5


Setup

6


15. How to Use the Front Panel

Structure of Each Mode

Use each button on the touch panel to select the structure and switch the mode.



Note → You can change the flashing decimal point with , then shift the digit for data change "."
 Caution → On power-up, the monitor mode executed is displayed according to the setup of Pr5.28 LED initial status.



15. How to Use the Front Panel

Setup of front panel lock

Outline

To prevent operational error e.g. unintentional parameter modification, the front panel may be locked.

Once locked, operations on the panel are limited as follows:

Mode	Locked panel conditions
Monitor Mode	No limitation: all monitored data can be checked.
Parameter Set up Mode	No parameter can be changed but setting can be checked.
EEPROM Writing Mode	Cannot be run. (No display)
Auxiliary Function Mode	Cannot be run except for "Release of front panel lock". (No display)

How to operate

Related parameters

Parameter No.		Title	Function		
Class	No.	nue	Function		
5	35	Setup of front panel lock	Locks the operation attempted from the front panel.		

Lock and unlock can be made in one of two ways.

Procedure	Front panel	Setup support software PANATERM
Lock	(1) Set Pr5.35 "Front panel lock" to 1, a(2) Turn on power to the driver.(3) The front panel is locked.	nd writ the setting to EEPROM.
Unlock	 (1) Execute the auxiliary function mode, front panel lock release function. (2) Turn on power to the driver. (3) The front panel is unlocked. 	 (1) Set Pr5.35 "Front panel lock" to 0, and writ the setting to EEPROM. (2) Turn on power to the driver. (3) The front panel is unlocked.

2 Preparation

15. How to Use the Front Panel

Before Using the Products

Monitor Mode (SELECTION display)

To change the monitor display setting, select the display option to be changed from "**SELECTION** display", and press(\underline{S}) to change to "**EXECUTION** display". After completion of changing, press(\underline{S}) to return to the selection display,

	2
Monitor Mode SELECTION display	
Display example Description Pages to refer Display example Description Pages to refer	Prepa
Display example Description Pages to refer Display example Description Pages to refer Image: Description Positional command deviation Positional command P.2-94 (1) Display example Description Pages to refer	aration
Image: Constraint of the second state P.2-94 (2) Image: Constraint of the second state P.2-103 (12)	3
Image: displayed block with the speed Positional command speed P.2-94 (2) Image: displayed block with the speed Absolute external scale position P.2-104 (13)	
Understand Velocity control command P.2-94 (2) Understand P.2-94 (2) <t< td=""><td>Connec</td></t<>	Connec
Image: displayed black in the second seco	tion
Image: Second system P.2-95 (3) Image: Second system Encoder positional deviation [Encoder unit] P.2-104 (16)	4
Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3) Image: Command pulse sum P.2-95 (3)	ľ
Image: Constraint of the system P.2-95 (3) Image: Constraint of the system P.2-95 (3) Image: Constraint of the system P.2-105 (18) Image: Constraint of the system P.2-95 (3) Image: Constraint of the system P.2-105 (18) Image: Constraint of the system Image: Constraint of the system P.2-95 (3) Image: Constraint of the system P.2-105 (18) Image: Constraint of the system Image: Constraint of the system P.2-95 (3) Image: Constraint of the system P.2-105 (18) Image: Constraint of the system Image: Constraint of the system P.2-95 (3) Image: Constraint of the system P.2-105 (18) Image: Constraint of the system	Setu
Image: Control mode P.2-95 (4) Image: Control mode P.2-95 (4) Image: Control mode P.2-95 (4) Voltage across PN [V] P.2-105 (19)	D
Image: Observation Image:	_
Image: Analog input value P.2-97 (6) Image: Image: Analog input value Image: Image: Analog input value Image: Image: Image: Analog input value Image: Image	5
Image: Second state of the story of the	Adius
Image: display P.2-100 (8) Image: display Accumulated operation time P.2-106 (23)	tment
Image: Automatic motor factor P.2-101 (9) Image: Automatic motor recognizing function P.2-106 (24)	
Image: Second sector P.2-101 (9) Image: Second sector Temperature information P.2-106 (25)	6
Inertia ratio P.2-101 (9) Image: State structure P.2-107 (26)	When i
d ! 6. J r b Inertia ratio P.2-101 (9) Factor of no-motor running P.2-102 (10) Return to "Positional command deviation".>	n Trouble
Display shifts toward the arrowed direction by pressing () and reversed direction by pressing ().	
(Mode switch button)	7
Parameter Setup Mode SELECTION display	S
Note \rightarrow When you turn on the Product for the first time, display shows r \square . (at motor stall)	unplem

To change this display, change the setup of Pr5.28 (Initial status of LED).

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(1) Display of positional command deviation [command unit]

Displays positional deviation of the command unit in High order or Low order.



HHigh order

• To switch between Low order (L) and High order (H), press (

(2) Display of motor speed, positional command speed, velocity control command and torque command

Motor speed (r/min)

Displays the motor speed (r/min).

Positional command speed (r/min)


— Displays positional command speed (r/min).

Velocity control command (r/min)

Displays velocity control command (r/min).

• Torque command (%)


— Displays torque command (%).




Supplement

(5) Display of I/O Signal Status


Displays the control input and output signal to be connected to connector X4. Use this function to check if the wiring is correct or not.




• Shift the flashing decimal point with (



• Select In or Out by pressing (A) or (V) button.



• Select the Pin No. to be monitored by pressing $(\bigstar)(\checkmark)$.



*1 When input signal

When output signal

Active : Input signal photocoupler is ON. Inactive : Input signal photocoupler is OFF. Active : Output signal transistor is ON. Inactive : Output signal transistor is OFF.


Note

For detail of input/output signal, refer to P.3-32 "Inputs and outputs on connector X4" For detail of Error Code, refer to P.6-2 "Protective Function".

(6) Display of Analog Input Value

| Input signal

•Select the signal No. to be monitored by pressings (\bigstar)




Caution ···· Voltage exceeding ± 10 V can not be displayed correctly.



1

5

(7) Display of Error Factor and Reference of History



<List of error code No.> (ASI : Only available on ASI series.)

Error	code			Attribute	
Main	Sub	Protective function	History	Can be cleared	Immediate stop
11	0	Control power supply under- voltage protection		0	
12	0	Over-voltage protection	0	0	
10	0	Main power supply under-voltage protection (between P to N)		0	
13	1	Main power supply under-voltage protection (AC interception detection)		0	
14	0	Over-current protection	0		
14	1	IPM error protection	0		
15	0	Over-heat protection	0		0
16	0	Over-load protection	0	○*1	
10	1	A5II Torque saturation anomaly protection	0	0	
18	0	Over-regeneration load protection	0		0
10	1	Over-regeneration Tr error protection	0		
21	0	Encoder communication disconnect error protection	0		
21	1	Encoder communication error protection	0		
23	0	Encoder communication data error protection	0		
24	0	Position deviation excess protection	0	0	0
24	1	Velocity deviation excess protection	0	0	0
25	0	Hybrid deviation excess error protection	0		0
26	0	Over-speed protection	0	0	0
20	1	2nd over-speed protection	0	0	
27	0	Command pulse input frequency error protection	0	0	0
21	2	Command pulse multiplier error protection	0	0	0
28	0	Limit of pulse replay error protection	0	0	0
29	0	Deviation counter overflow protection	0	0	
30	0	Safety detection		0	
	0	IF overlaps allocation error 1 protection	0		
	1	IF overlaps allocation error 2 protection	0		
	2	IF input function number error 1 protection	0		
33	3	IF input function number error 2 protection	0		
- 33	4	IF output function number error 1 protection	0		
	5	IF output function number error 2 protection	0		
	6	CL fitting error protection	0		
	7	INH fitting error protection	0		

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

Error code				Attribute			
Main	Sub	Protective function	History	Can be cleared	Immediate stop		
34	0	Software limit protection	0	0			
36	0 to 2	EEPROM parameter error protection					
37	0 to 2	EEPROM check code error protection					
38	0	Over-travel inhibit input protection		0			
	0	Analog input1 excess protection	0	0	0		
39	1	Analog input2 excess protection	0	0	0		
	2	Analog input3 excess protection	0	0	0		
40	0	Absolute system down error protection	0	0			
41	0	Absolute counter over error protection	0				
42	0	Absolute over-speed error protection	0	0			
43	0	Initialization failure	0				
44	0	Absolute single turn counter error protection	0				
45	0	Absolute multi-turn counter error protection	0				
47	0	Absolute status error protection	0				
48	0	Encoder Z-phase error protection	0				
49	0	Encoder CS signal error protection	0				
50	0	External scale connection error protection					
50	1	External scale communication error protection	0				
	0	External scale status 0 error protection	0				
	1	External scale status 1 error protection	0				
F 4	2	External scale status 2 error protection	0				
51	3	External scale status 3 error protection	0				
	4	External scale status 4 error protection	0				
	5	External scale status 5 error protection	0				
	0	A-phase connection error protection	0				
55	1	B-phase connection error protection	0				
	2	Z-phase connection error protection					
87	0	Compulsory alarm input protection					
95							
Other I	number	Other error	0				

Note

History...The error will be stored in the error history.

Can be cleared...To cancel the error, use the alarm clear input (A-CLR).

If the alarm clear input is not effective, turn off power, remove the cause of the error and then turn on power again.

Immediate stop...Instantaneous controlled stop upon occurrence of an error. (Setting of "Pr.5.10 Sequence at alarm" is also required.)

Caution 🔅

- Certain alarms are not included in the history. For detailed information on alarms e.g. alarm numbers, refer to P.6-2.
 - 2) When one of the errors which are listed in error history occurs, this error and history o shows the same error No.

Before Using the Products

2

Preparation

3

Connection

4

Setup


5

∆djustment

6

When in Trouble

(8) Alarm Display



• To display the alarm occurrence condition, press A or V button.

r n 80	8
	\mathbf{v}
r n 89	-

alarm No.	Alarm	Content	Latched time *1
A0	Overload protection	Load factor is 85 % or more the protection level.	1 s to 10 s or ∞
A1	Over-regeneration alarm	Regenerative load factor is 85 % or more the protection level.	10 s or ∞
A2	Battery alarm	Battery voltage is 3.2 V or lower.	Fixed at ∞
A3	Fan alarm	Fan has stopped for 1 sec.	1 s to 10 s or ∞
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.	1 s to 10 s or ∞
A5	Encoder overheat alarm	The encoder detects overheat alarm.	1 s to 10 s or ∞
A6	Oscillation detection alarm	Oscillation or vibration is detected.	1 s to 10 s or ∞
A7	Lifetime detection alarm	Life expectancy of capacitor or fan is short.	Fixed at ∞
A8	External scale error alarm	The external scale detects the alarm.	1 s to 10 s or ∞
A9	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.	1 s to 10 s or ∞


*1 Alarms can be cleared by using the alarm clear. Because the all existing alarms are kept cleared while the alarm clear input (A-CLR) is kept ON, be sure to turn it OFF during normal operation. Either 1 s to 10 s or ∞ can be selected by using user parameter.

Exception: Battery alarm is fixed at ∞ because it is latched by the encoder.

Because the end of life alarm means that the life expectancy cannot be extended, the alarm is set at ∞.

5

Monitor Mode (EXECUTION display)




Displays the inertia ratio (%).

Value of Pr0.04 (Inertia Ratio) will be displayed as it is.

10) Display of the Factor of No-Motor Running

Displays the factor of no-motor running in number.



P......Position control

ETorque control

 ${\bf 5} \dots {\bf Velocity\ control} \qquad {\bf F} \dots {\bf Full-closed\ control}$


Control mode

• Explanation of factor No.

Factor	Factor	Related Control Mode		de	Content		
No.	1 40101	Ρ	S	Т	F		
flashing	Occurrence of error/alarm	0	0	0	0	An error is occurring, and an alarm is triggered.	
00	No particular factor	0	0	0	0	No factor is detected for No-motor run. The motor runs in normal case.	
01	Main power shutoff	0	0	\circ	0	The main power of the driver is not turned on.	
02	No entry of SRV-ON input	0	0	0	0	The Servo-ON input (SRV-ON) is not connected to COM	
03	Over-travel inhibition input is valid	0	0	0	0	 While Pr5.04 is 0 (Run-inhibition input is valid), Positive direction over-travel inhibition input (POT) is open and speed command is Positive direction. Negative direction over-travel inhibition input (NOT) is open and speed command is Negative direction. 	
04	Torque limit setup is small	0	0	0	0	Either one of the valid torque limit setup value of Pr0.13 (1st) or Pr5.22 (2nd) is set to 5 $\%$ or lower than the rating.	
05	Analog torque limit input is valid.	0	0		0	 While Pr5.21 is 0 (analog torque limit input accepted), Positive direction analog torque limit input (P-ATL) is negative voltage and speed command is Positive direction. Negative direction analog torque limit input (N-ATL) is positive voltage and speed command is Negative direction. 	
06	INH input is valid.	\circ			0	Pr5.18 is 0 (Command pulse inhibition input is valid.), and INH is open.	
07	Command pulse input frequency is low.	0			0	 The position command per each control cycle is 1 pulse or smaller due to, No correct entry of command pulse No correct connection to the input selected with Pr0.05. No matching to input status selected with Pr0.06 pr Pr0.07. 	
08	CL input is valid.	0			0	While Pr5.17 is 0 (Deviation counter clear at level), the deviation counter clear input (CL) is connected to COM–.	
09	ZEROSPD input is valid.		0	0		While Pr3.15 is 1 (Speed zero clamp is valid.), the speed zero clamp input (ZEROSPD) is open.	
10	External speed command is small.		0			While the analog speed command is selected, the analog speed command is smaller than 0.06[V].	
11	Internal speed command is 0.		0			While the internal speed command is selected, the internal speed command is set to lower than 30 [r/min]	
12	Torque command is small.			0		The analog torque command input (SPR or P-ATL) is smaller than 5 [%] of the rating.	
13	Speed limit is small.			0		 While Pr3.17 is 0 (speed is limited by 4th speed of internal spee Pr3.07, (4th speed of speed setup) is set to lower than 30 [r/min]. While Pr3.17 is 1 (speed is limited by SPR input), the analog speed limit input (SPR) is smaller than 0.06 [V]. 	
14	Other factor	0	0	0	0	The motor runs at 20 [r/min] or lower even though the factors from 1 to 13 are cleared, (the command is small, the load is heavy, the motor lock or hitting, driver/ motor fault etc.)	

Note

* Motor might run even though the other number than 0 is displayed. Refer to "6.In trouble".




8


Ь

(13) Display of absolute external scale position


- Displays the absolute position of serial absolute scale.
- If a serial incremental scale, displays the scale position relative to the power on position which is defined as 0.



• Select encoder or external scale by pressing (\blacktriangle) or (\checkmark) button.



(14) Display of No. of encoder/ external scale communication errors monitor




(15) Display of communication axis address





Displays the value set to Pr5.31 "Axis address".

(16) Display of encoder positional deviation [Encoder unit]




²⁻¹⁰⁴ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com





(This is not meter readings but only for reference.)



Adjustment

6


When in Trouble

7

Supplement


15. How to Use the Front Panel

Parameter Setup Mode



Note ·· After setting up parameters, return to SELECT mode, referring to structure of each mode (P.2-90).

[·] Each parameter has a limit in number of places for upper-shifting.



Caution 🔅

1. When writing error occurs, make writing again. If the writing error repeats many times, this might be a failure.

7


Supplement

- 2. Don't turn off the power during EEPROM writing. Incorrect data might be written. If this happens, set up all of parameters again, and re-write after checking the data.
- 3. When the error defined by Err11.0 "Under voltage protection of control power supply" occurs, <u>Error</u> is displayed indicating that no writing is made to EEPROM.

2 Preparation

15. How to Use the Front Panel

Auxiliary Function Mode (SELECTION display)




15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)

1) Alarm Clear Screen

This function releases the current alarm status.

Certain alarms will persist. If this is the case, refer to P.6-2 "When in Trouble - Protective Function".



Adjustment

Before Using the Products


2


Supplement

After alarm cleaning, return to SELECTION display, referring to structure of each mode (P.2-90).

(2) Analog inputs 1 to 3 automatic offset adjustment

This function automatically adjusts offset setting of analog input. Analog input 1 (Al1).....Pr4.22 (Analog input 1 (Al1) offset setup) Analog input 2 (Al2).....Pr4.25 (Analog input 2 (Al2) offset setup) Analog input 3 (Al3).....Pr4.28 (Analog input 1 (Al3) offset setup)





 After completion of the automatic offset adjustment, return to SELECTION display by referring to P.2-90 "Structure of Each Mode".

5

Auxiliary Function Mode (EXECUTION display)

(3) Motor trial run

You can make a trial run (JOG run) without connecting the Connector, Connector X4 to the host controller such as PLC.

Remarks 🔅

- Separate the motor from the load, detach the Connector, Connector X4 before the trial run.
- Bring the user parameter setups (especially Pr0.04 and Pr1.01 to 1.04) to defaults, to avoid oscillation or other failure.


Inspection Before Trial Run

(1) Inspection on wiring

- Miswiring ? (Especially power input and motor output)
- Short or grounded ?
- Loose connection ?


(2) Confirmation of power supply and voltage

Rated voltage ?



(6) Turn to Servo-OFF after finishing the trial run by pressing (\underline{S}) .

Procedure for Trial Run




Caution 🔅

- Before starting the trial run, set the gain-related parameters to appropriate values to avoid problems such as oscillation. If the load is removed, be sure to set Pr0.04 "Inertia Ratio" to 0.
- During the trial run, use the velocity control mode. Various settings including parameters should assure safe and positive operation under appropriate velocity control.
- If SRV-ON becomes valid during trial run, the display changes to <u>Error</u>, which is normal run through external command.
- **Note** After finished trial running, return to SELECTION display, referring to structure of each mode (P.2-90).
- ²⁻¹¹⁴ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

4) Clearing of Absolute Encoder

You can clear the multi-turn data of the absolute encoder.



Adjustment **6** When i

5

Before Using the Products


7

Note

 After clearing of absolute encoder finishes, return to SELECTION display, referring to structure of each mode (P.2-90).

(5) Initialization of parameter

Initialize the parameter.




Caution ☆ Parameter cannot be initialized when one of the following error occurs: Err11.0 "Under voltage protection of control power supply", EEPROM related errors (Err36.0, Err36.1, Err36.2, Err37.0, Err37.1 and Err37.2) - initialization will result in "Error" display.

Note • After initialization of parameter finishes, return to SELECTION display, referring to structure of each mode (P.2-90).

(6) Release of front panel lock

Release the front panel lock setting.



Note

· After release of front panel lock finishes, return to SELECTION display, referring to structure of each mode (P.2-90).

Before Using the Products

5

N	Ε	Ν	/	0	

2

Preparation

3

7

3. Connection

1. Outline of mode

Pos	ition Control Mode	3-2
Velo	ocity Control Mode	3-6
Toro	que Control Mode	3-9
Full	- -closed Control Mode	3-12
2 Con	stral Block Diagram	
	ntrol Block Diagram	
Pos	sition Control Mode	3-14
A5I	Two-degree-of-freedom control mode (Position control)	3-15
Velo	ocity Control Mode	3-16
A51	Two-degree-of-freedom control mode (Velocity control)	3-17
Toro	que Control Mode	3-18
Full	-closed Control Mode	3-19
3. Wiri	ing Diagram to the connector, X4	
Exa	Imple of control mode specific wiring	3-20
Cor	nnecting Example to Host Controller	3-22
4. Inpu	uts and outputs on connector X4	
-	rface Circuit (Input)	3-32
	rface Circuit (Output)	
	ut Signal and Pin No	
	put Signal and Pin No.	
5. IF IV	Ionitor Settings	
Hov	v to Assign Various I/O Functions to the I/F	3-52


1. Outline of mode

Position Control Mode

Outline

You can perform position control based on the positional command (pulse train) from the host controller.

This section describes the fundamental setup to be used for the position control.



Function

Caution 🔅

Note

(1) Process of command pulse input

The positional commands of the following 3 types (pulse train) are available.

- · 2-phase pulse
- Positive direction pulse/negative direction pulse
- Pulse train + sign

Set the pulse configuration and pulse counting method based on the specification and configuration of installation of the host controller.

The input terminals can accommodate the following 2 systems.

- Input 1 "PULSH1, PULSH2, SIGNH1, SIGNH2" line receiver input (4 Mpps)
- Input 2 "PULS1, PULS2, SIGN1, SIGN2" photocoupler input (500 kpps)

For line driver output, "Input 2" can also be used without changing the allowable input frequency.

Relevant parameters

Parameter No.	Title	Range	Function
Pr0.05	Selection of command pulse input	0 to 1 A5II 0 to 2	You can select either the photocoupler input or the exclusive input for line driver as the command pulse input. 0: Photocoupler input (PULS1, PULS2, SIGN1, SIGN2) 1: Exclusive input for line driver (PULSH1, PULSH2, SIGNH1, SIGNH2) 2: Photocoupler input (PULS1, PULS2, SIGN1, SIGN2) [250 kpps or less]
Pr0.06	Command pulse rotational direction setup	0 to 1	Sets the counting direction when command pulse is input.
Pr0.07	Command pulse input mode setup	0 to 3	Sets the counting method when command pulse is input.

As represents setting range applied to A5I series.

For details of these parameters, refer to P.4-7 and 8 "Details of parameter".

Related page • P.3-14 "Control Block Diagram"

• P.3-20 "Wiring Diagram to the connector, X4"

(2) Electronic gear function

This function multiplies the input pulse command from the host controller by the predetermined dividing or multiplying factor and applies the result to the position control section as the positional command. By using this function, desired motor rotations or movement distance per unit input command pulse can be set; or the command pulse frequency can be increased if the desired motor speed cannot be obtained due to limited pulse output capacity of the host controller.

Relevant parameters

Parameter No.	Title	Range	Function
Pr0.08	Command pulse counts per one motor revolution	0 to 1048576	Set the command pulses that causes single turn of the motor shaft.
Pr0.09	1st numerator of electronic gear	0 to 1073741824	Set the numerator of division/multiplication operation made according to the command pulse input.
Pr0.10	Denominator of electronic gear	1 to 1073741824	Set the Denominator of division/multiplication operation made according to the command pulse input.

Note

For details of these parameters, refer to P.4-9 "Details of parameter".

(3) Positional command filtering function

To make the positional command divided or multiplied by the electronic gear smooth, set the command filter.

Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr2.22	Positional command smoothing filter	0 to 10000	0.1 ms	Set up the time constant of the 1st delay filter in response to the positional command.
Pr2.23	Positional command FIR filter	0 to 10000	0.1 ms	Set up the time constant of the 1st delay filter in response to the positional command.

Note

For details of these parameters, refer to P.4-25 and 27 "Details of parameter".

2

5

(4) Pulse regeneration function

The information on the amount of movement can be sent to the host controller in the form of A- and B-phase pulses from the servo driver. When the output source is the encoder, Z-phase signal is output once per motor revolution; or if the feedback scale, the signal is output at absolute zero position. The output resolution, B-phase logic and output source (encoder or external scale) can be set with parameters.

Parameter No.	Title	Range	Unit	Function				
Pr0.11	Output pulse counts per one motor revolution	1 to 262144	P/r	You can set up the output pulse counts per one motor revolution for each OA and OB with the Pr0.11 setup.				
Pr0.12	Reversal of pulse output logic	0 to 3	_	You can set up the B-phase logic and the output source of the pulse output. With this parameter, you can reverse the phase relation between the A-phase pulse and the B-phase pulse by reversing the B-phase logic.				
Pr5.03	Denominator of pulse	0 to 262144	_	For application where the number of pulses per revolution is not an integer, this parameter can be set to a value other				
110.00	output division	A5I 0 to 1048576		than 0, and the dividing ratio can be set by setting numerator of division to Pr0.11 and denominator of division to Pr5.03.				
Pr5.33	Pulse regenerative output limit setup	0 to 1	_	Enable/disable detection of Err28.0 Pulse regenerative limit protection.				
Pr6.20	Z-phase setup of external scale	0 to 400	μs	Set up the Z phase regenerative width of feedback scale in unit of time.				
Pr6.21	Serial absolute external scale Z phase setup	0 to 268435456	pulse	Full-closed control using serial absolute feedback scale. When outputting pulses by using the feedback scale as the source of the output, set the Z phase output interval in units of A phase output pulses of the feedback scale (before multiplied by 4).				
Pr6.22	A, B phase external scale pulse output method selection	0 to 1	_	Select the pulse regeneration method of A, B and Z parallel feedback scale.				

Relevant parameters

* **A511** represents setting range applied to A51 series.

Note

For details of these parameters, refer to P.4-10, 12, 47, 55 and 59 "Details of parameter".

(5) Deviation counter clear function

The deviation counter clear input (CL) clears the counts of positional deviation counter at the position control to 0.

Relevant parameters

Parameter No.	Title	Range	Function
Pr5.17	Counter clear input mode	0 to 4	You can set up the clearing conditions of the counter clear input signal.

Note

For details of these parameters, refer to P.4-51 "Details of parameter".

(6) Positioning complete output (INP) function

The completion of positioning can be verified by the positioning complete output (INP). When the absolute value of the positional deviation counter at the position control is equal to or below the positioning complete range by the parameter, the output is ON. Presence and absence of positional command can be specified as one of judgment conditions.

Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr4.31	Positioning complete (In-position) range	0 to 262144	Command unit	Set up the timing of positional deviation at which the positioning complete signal (INP1) is output.
Pr4.32	Positioning complete (In-position) output setup	0 to 3		Select the condition to output the positioning complete signal (INP1).
Pr4.33	INP hold time	0 to 30000	1 ms	Set up the hold time when Pr4.32 Positioning complete output setup = 3.
Pr4.42	2nd Positioning complete (In-position) range	0 to 262144	Command unit	Set up the timing of positional deviation at which the positioning complete signal (INP2) is output.

* A5II represents setting range applied to A5II series.

Note

For details of these parameters, refer to P.4-43 and 46 "Details of parameter".

(7) Command pulse inhibition (INH) function

The command pulse input counting process can be forcibly terminated by using the command pulse inhibit input signal (INH). When INH input is ON, the servo driver ignores the command pulse, disabling pulse counting function.

The default setting of this inhibition function is disable. To use INH function, change the setting of Pr5.18 "Invalidation of command pulse prohibition input".

Relevant parameters

Parameter No.	Title	Range	Function
Pr5.18	Invalidation of command pulse inhibit input	0 to 1	Select command pulse inhibit input enable/disable.
Pr5.19	Command pulse inhibit input reading setup	0 to 4	Select command pulse inhibit input enable/disable signal reading period. When the status of several signals read during the predetermined reading period are same, update the signal status.

Note

For details of these parameters, refer to P.4-51 "Details of parameter".

3

6




1. Outline of mode

Velocity Control Mode

Outline

You can control the speed according to the analog speed command from the host controller or the speed command set in the servo driver.



Note

Only for position control type is not provided with analog input.

Function

(1) Velocity control by analog speed command

The analog speed command input voltage is converted to equivalent digital speed command. You can set the filter to eliminate noise or adjust the offset.

Parameter No.	Title	Range	Unit	Function
Pr3.00	Speed setup, Internal/ External switching	0 to 3	_	This driver is equipped with internal speed setup function so that you can control the speed with contact inputs only.
Pr3.01	Speed command rotational direction selection	0 to 1	_	Select the Positive/Negative direction specifying method.
Pr3.02	Input gain of speed command	10 to 2000	(r/min) /V	Based on the voltage applied to the analog speed command (SPR), set up the conversion gain to motor command speed.
Pr3.03	Reversal of speed command input	0 to 1	-	Specify the polarity of the voltage applied to the analog speed command (SPR).
Pr4.22	Analog input 1 (AI1) offset setup	–5578 to 5578	0.359 mV	Set up the offset correction value applied to the voltage fed to the analog input 1.
Pr4.23	Analog input 1 (Al1) filter	0 to 6400	0.01 ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 1.

Relevant parameters

Note

For details of these parameters, refer to P.4-29, 30 and 42 "Details of parameter". Only for position control type is not provided with analog input.

(2) Velocity control by internal speed command

You can control the speed by using the internal speed command set to the parameter. By using the internal speed command selections 1, 2, 3 (INTSPD1, 2, 3), you can select best appropriate one among up to 8 internal speed command settings. Default setting uses the analog speed command. To use the internal speed command, select it through Pr3.00 "Internal/external speed setup".

Relevant parameters

Parameter No.	Title	Range	Unit	Function			
Pr3.00	Speed setup, Internal/ External switching	0 to 3	_	This driver is equipped with internal speed setup function so that you can control the speed with contact inputs only.			
Pr3.01	Speed command rotational direction selection	0 to 1	_	Select the Positive/Negative direction specifying method.			
Pr3.04	1st speed of speed setup			Set up internal command speeds, 1st to 1st.			
Pr3.05	2nd speed of speed setup					:	Set up internal command speeds, 1st to 2nd.
Pr3.06	3rd speed of speed setup				Set up internal command speeds, 1st to 3rd.		
Pr3.07	4th speed of speed setup		r/min	Set up internal command speeds, 1st to 4th.			
Pr3.08	5th speed of speed setup	20000		Set up internal command speeds, 1st to 5th.			
Pr3.09	6th speed of speed setup			Set up internal command speeds, 1st to 6th.			
Pr3.10	7th speed of speed setup			Set up internal command speeds, 1st to 7th.			
Pr3.11	8th speed of speed setup			Set up internal command speeds, 1st to 8th.			

Note

For details of these parameters, refer to P.4-29, 30 and 31 "Details of parameter".

(3) Speed zero clamp (ZEROSPD) function

You can forcibly set the speed command to 0 by using the speed zero clamp input.

Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr3.15	Speed zero-clamp function selection	0 to 3	_	You can set up the function of the speed zero clamp input.
Pr3.16	Speed zero clamp level	0 to 1	r/min	elect the timing at which the position control is activated as the Pr3.15 Speed zero-clamp function selection is set to 2 or 3.

Note

For details of these parameters, refer to P.4-32 "Details of parameter".

(4) Attained speed output (AT-SPEED)

The signal AT-SPEED is output as the motor reaches the speed set to Pr4.36 "Attained speed".

Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr4.36	At-speed (Speed arrival)	10 to 20000	r/min	Set the detection timing of the speed arrival output (AT-SPEED).

Note

For details of these parameters, refer to P.4-45 "Details of parameter".

(5) Speed coincidence output (V-COIN)

This signal is output when the motor speed is equal to the speed specified by the speed command. The motor speed is judged to be coincident with the specified speed when the difference from the speed command before/after acceleration/deceleration is within the range specified by Pr4.35 "Speed coincident range".

Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr4.35	Speed coincidence range	10 to 20000	r/min	Set the speed coincidence (V-COIN) output detection timing.

Note

For details of these parameters, refer to P.4-44 "Details of parameter".

(6) Speed command acceleration/deceleration setting function

This function controls the speed by adding acceleration or deceleration instruction in the driver to the input speed command.

Using this function, you can use the soft start when inputting stepwise speed command or when using internal speed setup. You can also use S shaped acceleration/deceleration function to minimize shock due to change in speed.

Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr3.12	Acceleration time setup	0 to 10000	ms/ (1000 r/min)	Set up acceleration processing time in response to the speed command input.
Pr3.13	Deceleration time setup	0 to 10000	ms/ (1000 r/min)	Set up deceleration processing time in response to the speed command input.
Pr3.14	Sigmoid acceleration/ deceleration time setup	0 to 1000	ms	Set S-curve time for acceleration/ deceleration process when the speed command is applied.

Caution 🔅

When the position loop is external to the driver, do not use the acceleration/ deceleration time setting. Set these values to 0.

Note

For details of these parameters, refer to P.4-31 and 32 "Details of parameter".

5

1. Outline of mode

Connection

Torque Control Mode

Outline

The torque control is performed according to the torque command specified in the form of analog voltage. For controlling the torque, the speed limit input is required in addition to the torque command to maintain the motor speed within the speed limit.

With the A5 series, 3 torque control modes are available, each requires different torque command and speed limit as shown in the table below.

Pr3.17 (Selection of torque command)


Setup value		Torque command input	Velocity limit input
0	Selection of torque command 1	Analog input 1 ^{*1} (Al1, 16-bit resolution)	Parameter value (Pr3.21)
1	Selection of torque command 2	Analog input 2 (Al2, 12-bit resolution)	Analog input 1 (AI1, 16-bit resolution)
2	Selection of torque command 3	Analog input 1 *1 (AI1, 16-bit resolution)	Parameter value (Pr3.21, Pr3.22)

*1 For Pr0.01 Control mode setup = 5 (velocity/torque control), the torque command input is the analog input 2 (Al2, 12-bit resolution).

Note

For details of these parameters, refer to P.4-33 "Details of parameter".

<Selection of torque command 1, 3>



<Selection of torque command2>

	Analog torque command (Al2, ±10 V)	Process of analog torque command input	
Host controller	(AL, ±10 V) Speed limit input (AI1, ±10 V) ZEROSPD input AT-SPEED output V-COIN output	Process of speed limit input Speed zero clamp (ZEROSPD) function Attained speed output Speed coincidence output	Torque control section

Torque Control Mode

Function

(1) Process of analog torque command input

This process converts the analog torque command input (voltage) to the equivalent digital torque command having the same effect. You can set the filter or adjust the offset to eliminate noise.

Parameter No.	Title	Range	Unit	Function	
Pr3.18	Torque command direction	0 to 1	_	Select the direction positive/negative direction of torque command.	
Pr3.19	Input gain of torque command	10 to 100	0.1 V /100 %	Based on the voltage (V) applied to the analog torque command (TRQ R), set up the conversion gain to torque command (%).	
Pr3.20	Input reversal of torque command	0 to 1	_	Set up the polarity of the voltage applied to the analog torque command (TRQR).	
Pr4.22	Analog input 1 (Al1) offset setup	–5578 to 5578	0.359 mV	Set up the offset correction value applied to the voltage fed to the analog input 1.	
Pr4.23	Analog input 1 (AI1) filter	0 to 6400	0.01 ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 1.	

Relevant parameters <Selection of torque command 1, 3>

Relevant parameters <Selection of torque command 2>

Parameter No.	Title	Range	Unit	Function
Pr3.18	Torque command direction	0 to 1	-	Select the direction positive/negative direction of torque command.
Pr3.19	Input gain of torque command	10 to 100	0.1 V /100 %	Based on the voltage (V) applied to the analog torque command (TRQ R), set up the conversion gain to torque command (%).
Pr3.20	Input reversal of torque command	0 to 1	_	Set up the polarity of the voltage applied to the analog torque command (TRQR).
Pr4.25	Analog input 2 (Al2) offset setup	-342 to 342	5.86 mV	Set up the offset correction value applied to the voltage fed to the analog input 2.
Pr4.26	Analog input 2 (Al2) filter	0 to 6400	0.01 ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 2.

Note

For details of these parameters, refer to P.4-33 and 42 "Details of parameter".

4

7

Supplement

(2) Speed limit function

The speed limit is one of protective functions used during torque control.

This function regulates the motor speed so that it does not exceed the speed limit while the torque is controlled.

Caution 🔅

While the speed limit is used to control the motor, the torque command applied to the motor is not directly proportional to the analog torque command. Torque command should have the following result: the motor speed is equal to the speed limit.

Parameter No.	Title	Range	Unit	Function
Pr3.21	Speed limit value 1	0 to 20000	r/min	Set up the speed limit used for torque
Pr3.22	Speed limit value 2	0 to 20000	r/min	controlling.
Pr3.15	Speed zero-clamp function selection	0 to 3	_	You can set up the function of the speed zero clamp input.

Relevant parameters <Selection of torque command 1, 3>

• Relevar	nt parameters <sele< th=""><th>ection of to</th><th>rque co</th><th>mmand 2></th></sele<>	ection of to	rque co	mmand 2>

Parameter No.	Title	Range	Unit	Function
Pr3.02	Input gain of speed command	10 to 2000	(r/min) /V	Based on the voltage applied to the analog speed command (SPR), set up the conversion gain to motor command speed.
Pr4.22	Analog input 1 (AI1) offset setup	–5578 to 5578	0.359 mV	Set up the offset correction value applied to the voltage fed to the analog input 1.
Pr4.23	Analog input 1 (AI1) filter	0 to 6400	0.01 ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 1.
Pr3.15	Speed zero-clamp function selection	0 to 3	_	You can set up the function of the speed zero clamp input.

Note

For details of these parameters, refer to P.4-30, 32, 34 and 42 "Details of parameter".


1. Outline of mode

Connection

Full-closed Control Mode

Outline


In this full-closed control, you can make a position control by using a external scale mounted externally which detects the position directly and feeds it back. With this control, you can control without being affected by the positional variation due to the ball screw error or temperature and you can expect to achieve a very high precision positioning in sub-micron order.



We recommend the external scale division ratio of $\frac{1}{40} \leq$ External scale division ratio \leq 160

Cautions on Full-Closed Control

- (1) Enter the command pulses making the external scale as a reference. If the command pulses do not match to the external scale pulses, use the command division/ multiplication function (Pr0.09 to Pr0.10) and setup so that the command pulses after division/ multiplication is based on the external scale reference.
- (2) The A5 series supports the external scale of A- and B-phase output type and serial communication type. Initialize the parameters according to the following procedures and write to EEPROM and turn on power.
- (3) When using a scale of A- and B-phase output type, correctly connect it so that the rotating direction of the motor (CW/CCW) and Aphase and B-phase of the external scale have the following relationship.



<How to make an initial setup of parameters related to external scale >

- 1) Turn on the power after checking the wiring.
- 2) Check the values (initial) feedback pulse sum and external scale feedback pulse sum with the front panel.
- 3) Move the work and check the travel from the initial values of the above 2).
- 4) If the travel of the feedback pulse sum and the external scale feedback pulse sum are reversed in positive and negative, set up the reversal of external scale direction (Pr3.26) to 1.
- 5) Set up the external scale division ratio Pr3.24/Pr3.25 based on the design values.

External scale division ratio = $\frac{\text{Encoder resolution per motor revolution [pulse]}}{\text{External scale's resolution per motor revolution [pulse]}} = \frac{\text{Pr3.24}}{\text{Pr3.25}}$

If a wrong scale is applied, difference between the position calculated by using encoder feedback pulses and the position calculated by using external scale pulses as moving distance increases: larger difference will cause excessive deviation error protect.

 Note
 Only for position control type is not provided with connector X5.

 Related page ···
 • P.3-19 "Control Block Diagram"
 • P.3-21 "Wiring Diagram to the connector, X4"

 • P.3-32 "Inputs and outputs on connector X4"
 • P.4-35 "Details of parameter"

³⁻¹² Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

6

6) Set up appropriate value of hybrid deviation excess (Pr3.28) in command unit, in order to avoid the damage to the machine.

* A5-series driver calculates the difference between the encoder position and the external scale position as hybrid deviation, and is used to prevent the machine runaway or damage in case of the external scale breakdown or when the motor and the load is disconnected.
 If the hybrid deviation excess range is too wide, detection of the breakdown or the disconnection will be delayed and error detection effect will be lost. If this is too narrow, it may detect the normal

will be delayed and error detection effect will be lost. If this is too narrow, it may detect the norma distortion between the motor and the machine under normal operation as an error.

* When the external scale division ration is not correct, hybrid deviation excess error (Err25.0) may occur especially when the work travels long distance, even though the external scale and the motor position matches.

In this case, widen the hybrid deviation excess range by matching the external scale division ratio to the closest value.

Function

(1) Selection of external scale type

Select the type of external scale to be used.

Relevant parameters

Parameter No.	Title	Title Range Fun			
Pr3.23	External scale selection	0 to 2	Select the type of external scale.		
Pr3.26	Reversal of direction of external scale	0 to 1	Reverse the direction of external scale, feedback counter.		

Note

For details of these parameters, refer to P.4-34 and 35 "Details of parameter".

(2) Setup of external scale division ratio

Set up the division ratio of encoder resolution and external scale resolution.

Relevant parameters

F	Parameter No.	Title	Range	Function
	Pr3.24	Numerator of external scale division	0 to 220	Set up the numerator of the external scale dividing setup.
	Pr3.25	Denominator of external scale division	1 to 220	Set up the Denominator of the external scale dividing setup.

Note

For details of these parameters, refer to P.4-35 "Details of parameter".

(3) Setup of hybrid excessive deviation

This function detects the positional difference between the motor (encoder) and load (external scale) and enables the hybrid excessive deviation protection if the difference exceeds Pr3.28 "Hybrid excessive deviation setup".

Hybrid excessive deviation is mainly caused by feedback scale error, wrong connection and loose connection between the motor and load.


Relevant parameters


Parameter No.	Title	Range	Function
Pr3.28	Hybrid deviation excess setup	1 to 2 ²⁷	You can setup the permissible gap (hybrid deviation) between the present motor position and the present external scale position.
Pr3.29	Hybrid deviation clear setup	0 to 100	As the motor turns the number of revolutions set by this parameter, the hybrid deviation is cleared to 0.

Note

For details of these parameters, refer to P.4-36 "Details of parameter".

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 3-13






*1 Two-stage torque filter is only available at A5I Series.
*2 Setting of anti-vibration depth 1 is only available at A5II Series.


· P.3-22 "Connecting example to host controller"

• P.3-32 "Inputs and outputs on connector X4" • P.4-2 "List of Parameters"



Note Only for position control type is not provided with analog input. Related page … • P.3-21 "Wiring example of full-close control mode"


3-15



*1 Two-stage torque filter is only available at A5I Series.

 Note
 Only for position control type is not provided with analog input.

 Related page ··· P.3-20 "Wiring example of velocity control mode"



 Note
 Only for position control type is not provided with analog input.


 Related page ···
 • P.3-20 "Wiring example of velocity control mode"

Supplement



2. Control Block Diagram


Torque Control Mode



*1 Two-stage torque filter is only available at A5I Series.

 Note
 Only for position control type is not provided with analog input.

 Related page ··· P.3-21 "Wiring example of torque control mode"




3 Connection


3. Wiring Diagram to the connector, X4

Example of control mode specific wiring

Wiring Example of Position Control Mode




Wiring Example of Velocity Control Mode



³⁻²⁰ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Example of control mode specific wiring

Wiring Example of Torque Control Mode



5

Preparation

3


Connectior

3 Connection

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller


Connection between MINAS A5 and FP7-AFP7PP02T/L(2-axes) AFP7PP04T/L(4-axes) Panasonic devices SUNX.



Note

____ represents twisted pair wire.


Related page P.3-32 "Inputs and outputs on connector X4"



2

5


Connecting Example to Host Controller



Connection between MINAS A5 and FP2-PP2 AFP2430 Panasonic devices SUNX.

represents twisted pair wire.

Related page • P.3-32 "Inputs and outputs on connector X4"



Note

represents twisted pair wire.

Related page P.3-32 "Inputs and outputs on connector X4"

1

Before Using the Products

2

Preparation


3

Connection

When in Trouble


7

Supplement



Connection between MINAS A5 and F3YP22-0P/F3YP24-0P/F3YP28-0P Yokogawa Electric Corp.

• P.3-32 "Inputs and outputs on connector X4"



Connection between MINAS A5 and F3NC32-ON/F3NC34-ON Yokogawa Electric Corp.

P.3-32 "Inputs and outputs on connector X4"

Related page

When in Trouble

7

Supplement

5

Before Using the Products


2

Preparation

3

Connection

Connecting Example to Host Controller




* When connecting, please make sure to use twisted-pair cable.

Note

represents twisted pair wire.

Related page P.3-32 "Inputs and outputs on connector X4"




3

5

6

Connecting Example to Host Controller




Connection between MINAS A5 and QD75D1 Mitsubishi Electric Corp.

Note

Related page


represents twisted pair wire. • P.3-32 "Inputs and outputs on connector X4"




Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 3-3

4. Inputs and outputs on connector X4 Interface Circuit (Input)


Input Circuit







4. Inputs and outputs on connector X4 Interface Circuit (Output)

Output Circuit







4. Inputs and outputs on connector X4 Input Signal and Pin No.

Input Signals (common) and Their Functions

Pin	7	Title of signal	Power supply for control signal (+)	Related control mode	Р	S	Т	F
No.	1	Symbol	COM+	I/F circuit		_	-	
			+ of the external DC power supply (12 V to 24 V). power supply voltage of 12 V \pm 5 % to 24 V \pm 5 %					

Pin	11	41 Title of signal Power supply for control signal (–)		Related control mode	Р	S	Т	F
No.	41	Symbol	COM-	I/F circuit —				
			 of the external DC power supply (12 V to 24 V). ver capacity varies depending on a composition of I/C ended.) circuit. 0.5	A or n	nore	is	

Input Signals (Pulse Train) and Their Functions

You can select appropriate interface out of two kinds, depending on the command pulse specifications.

Pulse train interface exclusive for line driver

Pin	44	Title of signal	Command pulse input 1	Related control mode	Р	S	Т	F		
No.	45	Symbol	Pin No.44: PULSH1 Pin No.45: PULSH2	I/F circuit	PI2 P.3-33					
Pin	46	Title of signal	Command pulse sign input 1	Related control mode	Ρ	S	Т	F		
No.	47	Symbol	Pin No.46: SIGNH1 Pin No.47: SIGNH2	I/F circuit	Pl2] P.3·	-33			
	Input terminal for position command pulse. You can select by setting up Pr0.05 (Selection of									

- command pulse input) to 1. • This input becomes invalid at such control mode as velocity control or torque control, where
- I his input becomes invalid at such control mode as velocity control or torque control, where no position command is required.
- Permissible max. input frequency is 4 Mpps.
- You can select up to 6 command pulse input formats with Pr0.06 (Setup of command pulse rotational direction) and Pr0.07 (Setup of command pulse input mode).
 For details, refer to the table next page, "Command pulse input format".

Pulse train interface (supports both line driver and open collector)

	1	Title of signal	Command pulse input 2	Related control mode	P S T F
Pin No.	3 4	Symbol	Pin No.1: OPC1 Pin No.3: PULS1 Pin No.4: PULS2	I/F circuit	PI1 P.3-32
	2	Title of signal	Command pulse sign input 2	Related control mode	P S T F
Pin No.	5 6	Symbol	Pin No.2: OPC2 Pin No.5: SIGN1 Pin No.6: SIGN2	I/F circuit	PI1 P.3-32
		comman A51 Wh to • This inpu where no • Permissi collector • You can	ut becomes invalid at such control mode as the veloc p position command is required. ble max. input frequency is 500 kpps at line driver in	is recommentity control or put and 200 l	nded to set Pr0.05 torque control, <pps at="" open<="" td=""></pps>

For details, refer to the table next page, "Command pulse input format".

7

Related page ···· P.3-32 "Inputs and outputs on connector X4" • P.4-8 "Details of parameter" Before Using the Products

Connection

Adjustment

Setup

Pr0.06 setup value Command pulse rotational direction setup	Pr0.07 setup value Command pulse input mode setup	Command pulse format	Signal title	Positive direction command	Negative direction command
	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	A- <u>phase</u> B- <u>phase</u> t1 t1 B-phase advances to A by 90°.	t1 t1 t1 t1 t1 t1 B-phase delays from A by 90
0	1	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN	t4 t5 t6 t6 t6	14 t5 t6 t6
	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	A-phase B-phase t1 t1 B-phase delays from A by 90°.	ti ti ti ti ti ti B-phase advances to A by 90
1	1	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN		t4 t5 t6 t6 t6

• PULS and SIGN represents the outputs of pulse train in put circuit. Refer to the fig. of P.3-32, "Input Circuit".

• In case of negative direction pulse train + positive direction pulse train and pulse train + sign, pulse train will be cap tured at the rising edge

be cap tured at the rising edge.

• In case of 2-phase pulse, pulse train will be captured at each edge.

Permissible max. input frequency, and min. necessary time width of command pulse input signal.

Input I/E of D	Input I/F of PULS/SIGN signal			Min. necessary time width (µs)							
				t2	tз	t4	t5	t6			
Pulse train interface exclusive to line driver		4 Mpps	0.25	0.125	0.125	0.125	0.125	0.125			
Dulas train interface	Line driver interface	500 kpps	2	1	1	1	1	1			
Pulse train interface	Open collector interface	200 kpps	5	2.5	2.5	2.5	2.5	2.5			
	Open collector interface	200 kpps	5	2.5	2.5	2.5	2.5	2.5			

Input Signal and Pin No.

Control Input

Control signal having the desired function can be applied to any input pin of I/F connector. The logic can be changed.

Default assignment

		0			Default			Default	Setup		
				Applicable	parameter setting	Position/ Full-c	losed control	Verocity		Torque o	control
				parameter	(): decimal notation	Signal	Logic *1	Signal	Logic *1	Signal	Logic *1
Pin	8	Title of signal	SI1 input	Pr4.00	00828282h	NOT	b contact	NOT	b contact	NOT	h contact
No.	0	Symbol	SI1	F14.00	(8553090)	NOT	b-contact	NOT	b-contact	NOT	b-contact
Pin		Title of signal	SI2 input		00818181h						
No.	9	Symbol	SI2	Pr4.01	(8487297)	POT	b-contact	POT	b-contact	POT	b-contact
Pin		Title of signal	SI3 input		0091910Ah						
No.	26	Symbol	SI3	Pr4.02	(9539850)	VS-SEL1	a-contact	ZEROSPD	b-contact	ZEROSPD	b-contact
Pin		Title of signal	SI4 input		00060606h						
No.	27	Symbol	SI4	Pr4.03	(394758)	GAIN	a-contact	GAIN	a-contact	GAIN	a-contact
Pin		Title of signal	SI5 input		0000100Ch						
No.	28	Symbol	SI5	Pr4.04	(4108)	DIV1	a-contact	INTSPD3	a-contact	_	-
Pin		Title of signal	SI6 input		00030303h						
No.	29	Symbol	SI6	Pr4.05	(197379)	SRV-ON	a-contact	SRV-ON	a-contact	SRV-ON	a-contact
Pin		Title of signal	SI7 input		00000f07h						
No.	30	Symbol	SI7	Pr4.06	(3847)	CL	a-contact	INTSPD2	a-contact	—	-
Pin		Title of signal	SI8 input		00040404h						
No.	31	Symbol	SI8	Pr4.07	(263172)	A-CLR	a-contact	A-CLR	a-contact	A-CLR	a-contact
Pin		Title of signal	SI9 input		00050505h						
No.	32	Symbol	SI9	Pr4.08	(328965)	C-MODE	a-contact	C-MODE	a-contact	C-MODE	a-contact
Pin		Title of signal	SI10 input		00000E88h						
No.	33	Symbol	SI10	Pr4.09	(3720)	INH	b-contact	INTSPD1	a-contact	—	_
			ction depend						input".	L	1
No	ote	*1 Opera	tion of a-con	tact and b	o-contact:		0		·		
		a-co	ontact: Input	0					•	,	
		h o	Input ontact: Input		nnected to						
		D-C(nnected to						
		[—]: No f	unction assig	-				,		,	
Relate	d page 🔅	P.3-52									
Cau	tion 🔅	-	Precautions								
		-	please set d		• •					•	
			that is used t act, verify that						iy the d		input
		For the sa	ame reason a		-				ervo-on i	input (SR	V-ON)
		to a-conta		to b as at	of voult. 1	ot the	++ina!!!	not occor	0.001-1-	problem	
		when set	ting the input	to D-Conta	act, verity th	hat the se	tting will	not caus	e safety	problem.	

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com ³⁻³⁹

1

Before Using the Products

Setup

Function allocatable to control input

Title of signal	Servo-ON input	Related control mode	Р	S	Т	F						
Symbol	SRV-ON	29 (SI6)	I/F circuit	SI] P.3·	-32						
	This signal turns on/off the servo (motor).											

Title of signal	Positive direction over-travel	Positive direction over-travel inhibition input				S	Т	F
Symbol	POT	Default assignment	9 (SI2)	I/F circuit	SI] P.3-	-32	

- · Positive direction over-travel inhibit input.
- The operation with this input turned ON is set up in Pr5.04 "Setup of over-travel inhibit input".
- When using this input, set Pr5.04 "Setup of over-travel inhibit input" to a value other than 1 so that the input is OFF when the moving portion of the machine exceeds this signal range toward positive direction.

Title of signal	Negative direction over-trave	Related control mode	Ρ	S	Т	F		
Symbol	NOT	Default assignment	8 (SI1)	I/F circuit	SI] P.3-	32	

- Negative direction over-travel inhibit input.
- The operation with this input turned ON is set up in Pr5.04 "Setup of over-travel inhibit input".
- When using this function, set Pr5.04 "Setup of over-travel inhibit input" to a value other than 1 so that the input is OFF when the moving portion of the machine exceeds this signal range toward negative direction.

Title of signal	Deviation counter clear input			Related control mode	Ρ	S	Τ	F
Symbol	CL	Default assignment	30 (SI7)	I/F circuit	SI	P.3-	32	


- · Clears the positional deviation counter.
- Default setup clears the counter at the rising edge of the clear input, To change the setup, modify it in the Pr5.17 "Counter clear input mode".

<Signal width and clear timing>

Pr5.17	CL signal width	Deviation clear timing
1	500 μs or more	Continually clear the counter while the deviation counter
2	1 ms or more	clear input is ON. *1
3	100 µs or more	Only once clear the counter at OFF to ON edge of the
4	1 ms or more	deviation counter clear input signal. *1

*1 Deviation counter clear input ON/OFF = input photocoupler ON/OFF

Caution \Rightarrow This function can be assigned to only SI7. Allocation of this function to any other pin will cause an error.



ON

ON

Input Signal and Pin No.

Title of signal	Alarm clear input			Related control mode	Р	S	Т	F
Symbol	A-CLR	Default assignment	31 (SI8)	I/F circuit	SI] P.3·	-32	
	 Clears the alarm condition. This input cannot clear som For details, refer to P.6-2 W and P.7-25 "Display of Batter 	hen in Trouble "P	rotective function	n", P.2-100 "	(8) Ala	arm [Displa	ay"
Caution ··	When alarm clear input (A-C prevented.	LR) is kept enat	oled, all potentia	al alarms an	d waı	rning	s will	be

Title of signal	Command pulse inhibition in	put		Related control mode	P S	Т	F
Symbol	INH	Default assignment	33 (SI10)	I/F circuit	SI P.	3-32	
	 Ignores the positional comnWhen using this feature, se	tion of command	d pulse inhibi	ition inpu	t" to 0.		
Caution ··	This function can be assigned	Allocation of this	s function to	any oth	er pin	will	
	cause an error.						

Title of signal	Control mode switching inpu	t		Related control mode	Ρ	S	Т	F
Symbol] P.3·	-32	
	Selects a control mode.							
Caution ··	Caution 🔅 • This signal is required in all control modes. No setting will cause an error.							

• Do not input any command 10 ms before and after changing the control mode.

Title of signal	Electro	onic gear	(division/mu	Itiplication) swite	ching input 1	Related control mode	Ρ	S	Т	F
Symbol	DIV1			Default assignment	28 (SI5)	I/F circuit	SI	P.3-3	32	
Title of signal	signal Electronic gear (division/multiplication) switching input 2						Ρ	S	Т	F
Symbol	ymbol DIV2 Default assignment —						SI	P.3-	32	
Up to 4 numerators can be used for command dividing/multiplying by using DIV1 a CDIV1 and DIV2 vs numerator/denominator of selected command dividing/multiplying Selected command dividing/multiplying process										
	•	V1 and DI	/2 vs numerato	or/denominator of s	selected comm	and dividing/mu	ultiply	ing pr		
	•		/2 vs numerato	or/denominator of s	selected comm	and dividing/mu	ultiply ocess	ing pr		
	•	V1 and DI	/2 vs numerato	or/denominator of s Selected comma	selected comm	and dividing/mu nultiplying pro	ultiply ocess	ing pr		
	•	V1 and DIV DIV1	/2 vs numerato	or/denominator of s Selected comma Numerator	selected comm	and dividing/mu nultiplying pro Denominator	ultiply ocess	ing pr		

Title of signal	Damping control switching in	iput 1		Related control mode	Ρ	S	Т	F		
Symbol						P.3-	32			
Title of signal	Damping control switching in	iput 2		Related control mode	Ρ	S	Т	F		
Symbol						P.3-	32			
 Selects applicable frequency for damping control. Combination of damping control input changeover 1 and 2 (VS-SEL1, VS-SEL2) enables select of max. 4 options. 								les		
Į.	Note Also refer to P.4-23 "Pr2.13 [Damping filter switching selection]".									

Pr5.02


Pr0.10

Before Using the Products

2

Title of signal	Gain switching input	ain switching input				S	Т	F
Symbol	GAIN	Default assignment	27 (SI4)	I/F circuit	SI] P.3·	-32	
	 Select 1st or 2nd gain. 							

Title of signal	Torque limit	switching input			Related control mod	le P	S	Т	
Symbol	TL-SEL	De	efault assignment	_	I/F circuit] P.3-3	2	
	Select 1s	t or 2nd torque limit.							
	Pr5.21	Torque limit switching input (TL-SEL)	Torque limit switching setup (Pr5.23, Pr5.24)		direction ue limit		Negative direction Torque limit		
	0		Analog input			input *1			
	1	-	—	Pr0.13					
	2	-	—	Pr	0.13		Pr5.22		
	3	OFF ON			.13 .22				
	4		Analas input *1						
	5		Analog input *1						
	6	OFF	_	+	0.13 5.25		Pr5.22 Pr5.26		
	• Setup of When app selecting n	iy the torque limit value rate of change after lying Pr5.21 "Torque ew torque limit can be	torque limit switc e limit selection" = e changed.	hover 3, changi	ng rate of	torque	(slope	e) afte	
	Pr5.23 "To	When changing from the 1st torque limit to 2nd torque limit, the changing rate (slope) set at Pr5.23 "Torque limit selection setup 1" is applied; after changing from the 2nd torque limit to 1st torque limit, the changing rate (slope) set at Pr5.24 "Torque limit selection setup 2" is							
	difference i	e sign of the changin n value between the	1st and 2nd torque	limit.	-		_	-	
		orque limit selection s is instantaneous.	etup 1" and Pr5.24	"Torque lim	it selection	setup 2	" are s	et to	



Related page P.4-52 "Details of Parameter"

the selection is made by using the torque limit select input (TL-SEL).

Input Signal and Pin No.

Title of	Solaction 1 is	nput of internal con	mand spood		Related	P S T F		
signal		-	-		ontrol mode			
Symbol	INTSPD1	De	fault assignment 33	(SI10)	I/F circuit	SI P.3-32		
Title of signal	Selection 2 in	nput of internal con	nmand speed	сс	Related	P S T F		
Symbol	INTSPD2	De	fault assignment 30	(SI7)	I/F circuit	SI P.3-32		
Title of signal	Selection 3 in	nput of internal con	nmand speed	CC	Related	P S T F		
Symbol	INTSPD3	De	fault assignment 28		I/F circuit	SI P.3-32		
	Select one	of 8 internal comma	and speeds.					
		ship between Pr3.0	•	en internal a	and extern	nal sneed setun"		
		al command speed	-			•		
	Selection 1 ofSelection 2 ofSelection 3 ofPr3.00internal commandinternal commandinternal command							
	Pr3.00	internal command speed (INTSPD1)	internal command speed (INTSPD2)	internal co speed (IN		Selection of speed command		
		OFF	OFF		,	1st speed		
	1	ON	OFF	No eff		2nd speed		
		OFF	ON			3rd speed		
		ON	ON			4th speed		
		OFF	OFF	_	Ļ	1st speed		
		ON	OFF		t	2nd speed		
	2	OFF	ON	No eff	ect	3rd speed		
		ON	ON			Analog speed command		
		The same a	as Pr3.00=1	OFF	=	1st to 4th speed		
		OFF	OFF	ON		5th speed		
	3	ON	OFF	ON		6th speed		
		OFF	ON	ON		7th speed		
		ON	ON	ON	I	8th speed		
Caution ··		mand speed switchi	• ·	-		-		
	• •	are selected altern	•	•		•		
	•	internal command s	• •	-		e setting value and		
	acceleration	/deceleration setting	will cause unexpec	ted operation	1.			
	INTSPD1	open COM-	[INTSPD1 ope				
	INTSPD2	- : : :		INTSPD2 000				
		COM- 4th		INTSPD3 ope	en	COM-		
	Speed	2nd	3rd	Speed	4#6	7th 6th 5th		
	command [r/min]		1st	command [r/min]	1st 2nd 4th 3	ard 1st		
	Exa	ample 1) When Pr3.00=	1 or 2	Examp	le 2) When	Pr3.00=3		

Title of signal	Speed zero clamp input			Related control mode	Ρ	S	Т	F
Symbol	ZEROSPD	Default assignment	26 (SI3)	I/F circuit	SI] P.3-	32	

- Set the speed command to 0.
- When using, set Pr3.15 "Speed zero clamp function selection" to a value other than 0.

Title of signal	Speed command sign input	Related control mode	Р	S	Т	F				
Symbol	VC-SIGN	I/F circuit	SI] P.3-	32					
 Specify the sign of speed command input at velocity control. Refer to P.4-29 "Pr3.01 Speed command rotational direction selection" 										

1

3

Title of signal	Torque command sign	input		Related control mode	P S T	F							
Symbol	TC-SIGN	Default assignment	—	I/F circuit	SI P.3-32								
	Specify the sign of torque command input at torque control.												
	ON	Negative direction											
	OFF	Positive direction											
	Refer to P.4-33 "Pr3.18 Torque command direction selection"												

Title of signal	Forced alarm input	Related control mode	Р	S	Т	F						
Symbol	E-STOP	I/F circuit	SI] P.3·	-32							
	Generates Err87.0 "Forced alarm input error".											

Title of signal	Ine	rtia ratio switching input			Related control mode	Ρ	S	Т	F				
Symbol	J-S	EL	Default assignment	—	I/F circuit	SI] P.3	-32					
	•	Selects 1st inertia ratio or	2nd inertia ratio ac	cording to the	e inertia ratio se	elect i	nput	(J-SE	L).				
		Inertia ratio switching input (J-SEL)	Applicable ine	Applicable inertia ratio									
		OFF	1st Inertia ratio										
		ON	2nd Inertia ratio	o (Pr6.12)									
	Refer to P.4-57 "Pr6.10 Function expansion setup"												

Note \rightarrow Only for position control type is not provided with analog input.

Input Signals (Analog Command)

Pin	14	Title of signal	Al1 input	Correspondence function
No.	14	Symbol	All	SPR, TRQR, SPL
Pin	16	Title of signal	Al2 input	Correspondence function
No.			AI2	TRQR, P-ATL
Pin	18	Title of signal	Al3 input	Correspondence function
No.	TO	Symbol	AI3	N-ATL

Function allocatable to Input Signals (Analog Command)

	Dr 5 01	Positive direction	direction	Negat	ive di	rectio	n					
	 Specify the torque limit for each direction value by the analog voltage. 											
Symbol	N-ATL				I/F circuit	AI] P.3-	33				
Title of signal	Negative di	rection Torque limit	Related control mode	P	S	Т	F					
Symbol	P-ATL		I/F circuit	AI] P.3-	33						
Title of signal	Positive dire	ection Torque limit i	Related control mode	Ρ	S	Т	F					

(P-ATL)	(N-ATL)	Torque limit	Torque limit			
0 V to 10 V	-10 V to 0 V	P-ATL	N-ATL			
-	-	Set up through parameter. *1				
0 V to 10 V	0 V to 10 V	P-ATL	N-ATL			
0 V to 10 V	No effect	P-4	ATL .			
-	-	Setup by p	arameter *1			
	0 V to 10 V	- 0 V to 10 V 0 V to 10 V	O V to 10 V O V to 10 V P-ATL			

*1 When specifying the torque limit value through the parameter, refer to P.4-52 "Torque limit select function"

5

7

Note Only for position control type is not provided with analog input.

Title of signal	Speed comm	nand input			Related control mode	S T F
Symbol	SPR				I/F circuit AI	P.3-33
	The table internal au "Speed co command	below show nd external ommand inp I sign select	vs relationsl speed setup out inversion tion (VC-SIC	form of analog voltage. hip between the combinat o", Pr3.01 "Speed comma ", analog speed comman GN) and the motor rotatior I input voltage to the spee	nd direction selectio d (SPR) of I/F conne nal direction; and the	n", Pr3.03 ector and speec
	Pr3.00	Speed command sign selection (VC-SIGN)	Motor rotational direction			
			0	+Voltage (0 V to 10 V)	No effect	Positive direction
				-Voltage (-10 V to 0 V)	No effect	Negative direction
	0	0	1	+Voltage (0 V to 10 V)	No effect	Negative direction
	(2)*			-Voltage (-10 V to 0 V)	No effect	Positive direction
				+Voltage (0 V to 10 V) -Voltage (-10 V to 0 V)	OFF	Positive direction
		1	No effect	+Voltage (0 V to 10 V) -Voltage (-10 V to 0 V)	ON	Negative direction
	* When inter	nal comman	d speed sele	ect 1 and 2 are ON.		

Title of signal	Torque com	mand input	t		Related point Poin	S T F
Symbol	TRQR				I/F circuit AI	P.3-33
	When Pr3	3.17 "Torque	e command	form of analog voltage. selection" = 0, pin No.14 selection" = 1, pin No.16		
	Pr3.17	Pr3.18	Pr3.20	Torque command input (TRQR)	Torque command sign selection (TC-SIGN)	Motor rotational direction
		0	0	+Voltage (0 V to 10 V)	No effect	Positive direction
				-Voltage (-10 V to 0 V)	No effect	Negative direction
			1	+Voltage (0 V to 10 V)	No effect	Negative direction
	0		I	-Voltage (-10 V to 0 V)	No effect	Positive direction
				+Voltage (0 V to 10 V) -Voltage (-10 V to 0 V)	OFF	Positive direction
		1	No effect	+Voltage (0 V to 10 V) -Voltage (-10 V to 0 V)	ON	Negative direction

Title of signal	Speed limit input	Related control mode	Р	S	Т	F
Symbol	SPL	I/F circuit	AI] P.3-	-33	
	 When setting Pr3.17 "Torque command selection" to 1, input of analog voltage. 	the speed lir	nit va	lue ir	n the t	form

Note \therefore Only for position control type is not provided with analog input.

Output Signals (Common) and Their Functions

Control output signal of desired function can be assigned to I/F connector. Logic of the output pin cannot be changed.

					Default		Default Setup	
				Applicable parameter	parameter setting (): decimal	Position/ Full- closed control	Verocity control	Torque control
					notation	Signal	Signal	Signal
Pin	10	Title of signal	SO1 output		00030303h			
No.	11	Symbol	Pin No.10: SO1– Pin No.11: SO1+	Pr4.10	(197379)	BRK-OFF	BRK-OFF	BRK-OFF
Pin	34	Title of signal	SO2 output		00020202h			
No.	35	Symbol	Pin No.34: SO2– Pin No.35: SO2+	Pr4.11	(131586)	S-RDY	S-RDY	S-RDY
Pin	36	Title of signal	SO3 output		00010101h			
No.	No. 37	Symbol	Pin No.36: SO3– Pin No.37: SO3+	Pr4.12	(65793)	ALM	ALM	ALM
Pin	38	Title of signal	SO4 output	D 4 40	00050504h			
No.	39	Symbol	Pin No.38: SO4– Pin No.39: SO4+	Pr4.13	(328964)	INP	AT-SPEED	AT-SPEED
Pin	12	Title of signal	SO5 output	Pr4.14	00070707h	ZSP	ZSP	ZSP
No.		Symbol	SO5		(460551)	201	201	201
Pin	40	Title of signal	SO6 output	Pr4.15	00060606h	TLC	TLC	TLC
No.		Symbol	SO6		(394758)			0
		The fun	ction is changed by the	e setting of	f parameter.	For details, re	fer to P.4-39.	
		See "Fu	inctions assignable to c	control out	put" as shov	vn below.		
No	te 🔅	[—]: No fu	inction assigned					
		Related page	•• P.3-54					

Function allocatable to control input

Title of signal	Servo-Alarm output	Related control mode	Ρ	S	Т	F		
Symbol	ALM	I/F circuit	SO	_ P.	3-34			
	 This signal shows that the d Output transistor turns ON v 			s, and turns	OFF a	at ala	rm st	atus.

Title of signal	Servo-Ready output			Related control mode	Р	S	Т	F
Symbol	S-RDY	I/F circuit	SO	P.	3-34			
	 This signal shows that the c Output transistor turns ON v 	,		r are ON but	not a	at ala	rm sta	atus.

2

5

Setup

6

Title of signal	e of inal External brake release signal		Related control mode	Р	S	Т	F	
Symbol	BRK-OFF	I/F circuit	SC		3-34			
	Feeds out the timing signal which activates the holding brake of the motor.							
	Turns the output transistor ON at the release timing of the h							

Title of signal	Positioning complete			Related control mode	P S T F			
Symbol	INP	Default assignment	38, 39 (SO4)	I/F circuit	SO P.3-34			
Title of signal	Positioning complete 2			Related control mode	P S T F			
Symbol	INP2	Default assignment	—	I/F circuit	SO P.3-34			
	Outputs the positioning complete signal/positioning complete signal 2.							

• Turns ON the output transistor upon completion of positioning.

Title of signal	Speed arrival output			Related control mode	Р	S	Т	F
Symbol	AT-SPEED	Default assignment	38, 39 (SO4)	I/F circuit	SO	P.	3-34	

Outputs thespeed arrival signal.

• Turns ON the output transistor upon arrive of speed.

Title of signal				Related control mode	Ρ	S	Т	F
Symbol	TLC Default assignment 40 (SO6) I/F circu) P.	3-34	
	Outputs thetorque in-limit si							

• Turns ON the output transistor upon limit of torque.

Title of signal	Pof nal Zero-speed detection output signal		Related control mode	Ρ	S	Т	F	
Symbol	ZSP	I/F circuit	SC) P.	3-34			
	Outputs the zero-speed detection signal.							
	Turns ON the output transistor upon detection of Zero-speed.							

Title of signal	Speed coincidence output			Related control mode	Ρ	S	Т	F
Symbol	V-COIN	Default assignment	—	I/F circuit	SC) P.	3-34	
	Outputs the speed coincide							
	Turns ON the output transistor upon coincidence of speed.							

Title of signal	Title of signal Alarm output 1			Related control mode	Р	S	Т	F
Symbol							3-34	
	Outputs the warning output signal set to Pr4.40 "Warning output select 1".							

Turns ON the output transistor upon occurrence of warning condition.

Title of signal	Fitle of signal Alarm output 2			Related control mode	Ρ	S	Т	F	
Symbol	WARN2 Default assignment — I/F circuit SO P.3-3								
	 Outputs the warning output signal set to Pr4.41 "Warning output select 2". Turns ON the output transistor upon occurrence of warning condition. 								

• Sel	ection of alarm 1 o	output and 2 output			
Alarm No.	Alarm	Content	Pr6.27 *1	Pr4.40/ Pr4.41 *2	Pr6.38 Corresponding bit *3
A0	Overload protection	Load factor is 85 % or more the protection level.	0	1	bit7
A1	Over-regeneration alarm	Regenerative load factor is 85 % or more the protection level.	0	2	bit5
A2	Battery alarm	Battery voltage is 3.2 V or lower.	Fixed at no time limit.	3	bit0
A3	Fan alarm	Fan has stopped for 1 sec.*4	0	4	bit6
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.	0	5	bit4
A5	Encoder overheat alarm	The encoder detects overheat alarm.	0	6	bit3
A6	Oscillation detection alarm	Oscillation or vibration is detected.	0	7	bit9
A7	Lifetime detection alarm	The life expectancy of capacity or fan becomes shorter than the specified time.	Fixed at no time limit.	8	bit2
A8	External scale error alarm	The feedback scale detects the alarm.	0	9	bit8
A9	External scale communication alarm	The number of successive feedback scale communication errors exceeds the specified value.	0	10	bit10

*1 The "circle" means that a time in the range 1 s to 10 s or no time limit can be selected through Pr6.27 "Warning latching time". Note that the battery warning and the end of life warning have no time limit.

*2 Select the warning output signal 1 (WARN1) or warning output signal 2 (WARN2) through Pr4.40 "Warning output select 1" or Pr4.41 "Warning output select 2". When the set value is 0, all warnings are ORed before being output. Do not set to any value other than those specified in the table above.

- *3 A warning detection can be masked by Pr6.38 "Warning mask setup" Corresponding bits are shown in the table. Warning is masked with bit = 1.
- *4 The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal and no fan alarm is displayed.

Title of signal	Positional command ON/OFF	output	Related control mode	Ρ	S	Т	F					
Symbol	P-CMD	Default assignment —	I/F circuit	SC) P.	3-34						
	. Turne on output transister with positional command applied											

• Turns on output transistor with positional command applied.

Title of signal	Speed in-limit output			Related control mode	Р	S	Т	F
Symbol	V-LIMIT	Default assignment	—	I/F circuit	SO	P.	3-34	

Turns on output transistor when the speed is limited by torque controlling function.

Title of signal	Alarm attribute output			Related control mode	Р	S	Т	F
Symbol	ALM-ATB	Default assignment	—	I/F circuit	SC	P.	3-34	

• Turns on output transistor when an alarm that can be cleared generates.

Title of signal	Speed command ON/OFF out	put		Related control mode	Ρ	S T	F				
Symbol	V-CMD	Default assignment	—	I/F circuit	SO	P.3-34					
Turns on output transistor when the speed command is applied while the speed is controlled.											

Before Using the Products

2

Preparation

3

5

A5I	Only available on A5II series.							
Title of signal	Servo on status output			Related control mode	Ρ	S	Т	F
Symbol	SRV-ST	Default assignment	—	I/F circuit	SC) P.	3-34	
	Turns on output transistor will	hen servo is on.						

Output Signals (Pulse Train) and Their Functions

Pin	21	Title of signal	A-phase output	Related control mode	Ρ	S	Т	F
No.	22	Symbol	Pin No.21: OA+ Pin No.22: OA-	I/F circuit	PO1	P.:	3-34	
Pin	48	Title of signal	B-phase output	Related control mode	Ρ	S	Т	F
No.	49	Symbol	Pin No.48: OB+ Pin No.49: OB-	I/F circuit	PO1	P.:	3-34	
Pin	23	Title of signal	Z-phase output	Related control mode	Ρ	S	Т	F
No.	24	Symbol	Pin No.23: OZ+ Pin No.24: OZ-	I/F circuit	PO1	P.:	3-34	
	• Feeds out the divided encoder signal or feedback scale signal (A, B, Z-phase) in differential.							

(equivalent to RS422)

Ground for line driver of output circuit is connected to signal ground (GND) and is not insulated.
Max. output frequency is 4Mpps (after quadrupled)

Pin	19	Title of signal	Z-phase output	Related control mode	Ρ	S	Т	F
No.	19	Symbol	CZ	I/F circuit	PO2	2 P.	3-35	
		• Open co	llector output of Z-phase signal					
		• The emi	ter side of the transistor of the output circuit is connect	cted to the sig	gnal g	roun	d (Gl	ND)
		and is no	ot insulated.					


- When using the CZ signal, isolate it from external noise.
- Note that the logic of Z phase open collector output (CZ) is a reversal of the line driver output (OZ) logic.

Note

$\boldsymbol{\cdot}$ When the output source is the encoder

• If the encoder resolution $\times \frac{Pr0.11}{Pr5.03}$ is multiple of 4, Z-phase will be fed out synchronizing

with A-phase. In other case, the Z-phase width will be equal to the encoder resolution, and will not synchronize with A-phase because of narrower width than that of A-phase.



- In case of the 5-wire, 20-bit incremental encoder, the signal sequence might not follow the above fig. until the first Z-phase is fed out. When you use the pulse output as the control signal, rotate the motor one revolution or more to make sure that the Z-phase is fed out at least once before using.
- ³⁻⁵⁰ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Output Signals (Analog) and Their Functions

Pin	42	Title of signal	Torque monitor output	Related control mode	Ρ	S	Т	F
No.	42	Symbol	IM	I/F circuit	AO] P.3	-35	
			on of the output signal varies with the output of Pr4.18 put signal is identical to the analog monitor 2 on the f	, C		2 typ	e).	
			but setting, refer to P.4-40 "Details of parameter"					

Pin	43	Title of signal	Speed monitor output	Related control mode	Р	S	Т	F
No.	40	Symbol	SP	I/F circuit	AO] P.3	-35	
			on of the output signal varies with the output of Pr4.16	, e		1 typ	e).	
		 The out 	put signal is identical to the analog monitor 1 on the f	ront monitor.				
		 For outp 	out setting, refer to P.4-40 "Details of parameter"					

Output Signals (Others) and Their Functions

Pin	13, 15	Title of signal	Signal ground	Related control mode	Ρ	S	Т	F
No.	17, 25	Symbol	GND	I/F circuit		-	-	
		Signal gThis out	round out is insulated from the control signal power (COM–) inside of the	e driv	er.		

Pin	50	Title of signal	Frame ground	Related control mode	Ρ	S	Т	F
No.	50	Symbol	FG	I/F circuit		-	_	
This output is connected to the earth terminal inside of the driver.								

1

5

Connection

How to Assign Various I/O Functions to the I/F

Control Input Settings

Title of signal	Connector X4 Pin No.	Parameter No.
SI1 input selection	8	Pr4.00
SI2 input selection	9	Pr4.01
SI3 input selection	26	Pr4.02
SI4 input selection	27	Pr4.03
SI5 input selection	28	Pr4.04
SI6 input selection	29	Pr4.05
SI7 input selection	30	Pr4.06
SI8 input selection	31	Pr4.07
SI9 input selection	32	Pr4.08
SI10 input selection	33	Pr4.09

Title	Cumhol	Setu	p value
Title	Symbol	a-contact	b-contact
Invalid	_	00h	Do not setup.
Positive direction over-travel inhibition input	POT	01h	81h
Negative direction over-travel inhibition input	NOT	02h	82h
Servo-ON input *1	SRV-ON	03h	83h
Alarm clear input	A-CLR	04h	Do not setup.
Control mode switching input *2	C-MODE	05h	85h
Gain switching input	GAIN	06h	86h
Deviation counter clear input *3	CL	07h	Do not setup.
Command pulse inhibition input *4	INH	08h	88h
Torque limit switching input	TL-SEL	09h	89h
Damping control switching input 1	VS-SEL1	0Ah	8Ah
Damping control switching input 2	VS-SEL2	0Bh	8Bh
Electronic gear switching input 1	DIV1	0Ch	8Ch
Electronic gear switching input 2	DIV2	0Dh	8Dh
Selection 1 input of internal command speed	INTSPD1	0Eh	8Eh
Selection 2 input of internal command speed	INTSPD2	0Fh	8Fh
Selection 3 input of internal command speed	INTSPD3	10h	90h
Speed zero clamp input	ZEROSPD	11h	91h
Speed command sign input	VC-SIGN	12h	92h
Torque command sign input	TC-SIGN	13h	93h
Forced alarm input	E-STOP	14h	94h
Inertia ratio switching input	J-SEL	15h	95h

(e.g. 1) Parameter setting

00 82 82 82 h (Hexadecimal numbers)

- Position/ Full-closed Control (Negative direction over-travel inhibition input; b-contact)
- Velocity Control

- Torque Control

(Negative direction over-travel inhibition input; b-contact)

(Negative direction over-travel inhibition input; b-contact)

Convert to a decimal number


8553090 - Enter this value to the relevant parameter.

(e.g. 2) Parameter setting

0	0	* * *	≜ ≜h	(Hexadecimal numbers)	
			≜	Position/ Full-closed Control	(Damping control switching input 1; a-contact)
				Velocity Control	(Speed zero clamp input; b-contact)
				Torque Control	(Speed zero clamp input; b-contact)
,	Co	onver	t to a	decimal number	

Enter this value to the relevant parameter.

7



The front panel display is in decimal (six digits). For setting functions and parameters, hexadecimal and decimal numbers should be used respectively.

The expression of "00 \blacksquare ** \blacktriangle h" indicates that the number is hexadecimal.

The SI1 input (connector X4, pin No. 8) means that the negative direction over-travel inhibition input is set to b-contact as a factory default.

For using the device in the position or full-closed control mode, the negative direction over-travel inhibition input is set to b-contact by setting "8" and "2" in the seventh and eighth digits from the left respectively. The settings in the first to sixth digits from the left do not matter.

For the hexadecimal value "00000082h" or simply "82h", enter "130" (decimal) to the parameter Pr4.00.

To make multiple settings, enter the function number in the first eight digits from the left and then enter a parameter in a decimal number after converting it from a hexadecimal number. An example of this is shown in example 1 (the case on the left side).

Similarly, the SI3 input (connector X4, pin No. 26) has a function of damping control switching input 1 as a default when used in the position control mode.

Also, if the speed control is used, it is set to the function of speed zero clamp input. Therefore, in order to set it to the damping control switching input in the position control mode, enter the value of "10" (decimal) in the parameter Pr4.02 meaning the hexadecimal number "0Ah", or "Ah".

To change the speed zero clamp of pin No. 26 from b-contact to a-contact in the speed control mode, enter the decimal number of "4352" in the parameter Pr4.02 meaning the hexadecimal number of "00001100h", or "1100h".

Caution 🔅

• Do not setup to a value other than that specified in the table.

- Do not assign specific function to 2 or more signals. Duplicated assignment will cause Err33.0 I/F input multiple assignment error 1 or Err33.1 I/F input multiple assignment error 2.
- *1 Servo-on input signal (SRV-ON) must be used to enable servo-on.
- *2 When using control mode switching input (C-MODE), set the signal to all control modes. If the signal is set to only 1 or 2 control modes, Err33.2 I/F input function number error 1 or Err33.3 I/F input function number error 2 will be generated.
 - The control input pin set to invalid state does not affect any operation.
 - Function (servo-on input, alarm clear, etc.) to be used in multiple control modes must be assigned to the same pin with correct logical arrangement. Incorrect setting will cause Err33.0 I/F input multiple assignment error 1 or Err33.1 I/F input multiple assignment error 2.
- *3 Deviation counter clear input (CL) can be assigned only to SI7 input. Wrong assignment will cause Err33.6 Counter clear assignment error.
- *4 Command pulse inhibit input (INH) can be assigned only to SI10 input. Wrong assignment will cause Err33.7 Command pulse input inhibit input.

Note → Input circuit, refer to P.3-32 and function, refer to P.3-39 to P.3-44. Related page → P.4-37 to P.4-39

Control Output Settings

Title of signal	Connector X4 Pin No.	Parameter No.
SO1 output	10, 11	Pr4.10
SO2 output	34, 35	Pr4.11
SO3 output	36, 37	Pr4.12
SO4 output	38, 39	Pr4.13
SO5 output	12	Pr4.14
SO6 output	40	Pr4.15

These parameters shall be set by using hexadecimal numbers. Setting shall be made for each control mode as shown in examples below.

 $00 - - - - \blacktriangle$ h: Position/Full-closed control

- 00 --- * * --- h: Speed control

Set an appropriate function number in place of "■■", "**" and "▲▲". For the function number, see the table on the right.

Setup Title Symbol value 00h Invalid _ Servo alarm output ALM 01h 02h Servo-Ready output S-RDY BRK-OFF 03h External brake release signal 04h INP Positioning complete output 05h At-speed output AT-SPEED 06h Torque in-limit signal output TLC Zero-speed detection output signal ZSP 07h 08h Speed coincidence output V-COIN 09h Alarm output 1 WARN1 0Ah Alarm output 2 WARN2 0Bh Positional command ON/OFF output P-CMD 0Ch Positioning complete 2 INP2 V-LIMIT 0Dh Speed in-limit output 0Eh Alarm attribute output ALM-ATB 0Fh Speed command ON/OFF output V-CMD A5I SRV-ST Servo on status output 10h

* A5II : Only available on A5II series.

(External brake release signal)

(e.g. 1) Parameter setting

00 03 03 03 h (Hexadecimal numbers)

Position/ Full-closed Control (External brake release signal)
 Velocity Control (External brake release signal)

Targua Cantrol

— Torque Control

Convert to a decimal number

197379 - Enter this value to the relevant parameter.

(e.g. 2) Parameter setting

00 05 05 04 h (Hexadecimal numbers)

Î	Position/ Full-closed Contro	I (Positioning complete)
	Velocity Control	(Speed arrival output)
	——— Torque Control	(Speed zero clamp input; b-contact)

Convert to a decimal number

328964 - Enter this value to the relevant parameter.

- · Same function can be assigned to 2 or more output signals.
- · Control output pin set to invalid always has the output transistor turned OFF.
- Do not change the setup value shown in the table.

Caution 🔅 *1 Note that the setup values are displayed in decimal on the front panel.

Note

• Output circuit, refer to P.3-34, 35 and function, refer to P.3-47 to P.3-50. Related page : P.4-39

List of Parameters	4-2
[Class 0] Basic setting	4-4
[Class 1] Gain adjustment	4-14
[Class 2] Damping control	4-21
[Class 3] Velocity/ Torque/ Full-closed control	4-29
[Class 4] I/F monitor setting	4-37
[Class 5] Enhancing setting	4-47
[Class 6] Special setting	4-56
2.Trial Run (JOG run)	
Inspection Before Trial Run	4-66
	4 07

Trial Run by Connecting the Connector X44-67 Setup of Motor Rotational Speed and Input Pulse Frequency4-70 1

5



List of Parameters

· A parameter is designated as follows:

Pr<u>0</u>.00

Class — Parameter No.

- Definition of symbols under "Related mode" -
 - P: position control, S: velocity control,
- T: torque control, F: full closed control

Param	etr No.	Title					ted Co	ntrol	Mode	Detail	
Class	No.						S	Т	F	page	
	00	Rota	tional	direction se	tup	0	0	0	0		
	01	Cont	rol mo	de setup		0	0	0	0	4-4	_
	02		-time	setup		0	0	0	0	4-5	C C
	03		uto-gain Selection of machine stiffness				0	0	0	4-6	[Class 2] Damping control
	04	Inert	ia ratio			0	0	0	0		
	05			input selec	ction	0	_	_	0	4-7	am
ច	06		mand		lirection setup	0	_	_	0		pin
as	07	pulse	Э	input mode		0	_	_	0	4-8	0 D
0		Com	mand	pulse count							ön
μ.	08			tor revolution		0	_	_	-		tro
asi	09	1st n	umera	tor of electr	ronic gear	0	—	—	0	4-9	
C S	10	Dend	ominat	or of electro	onic gear	0	—	—	0		
[Class 0] Basic setting	11		out puls lution	e counts pe	er one motor	0	0	0	0	4-10	
	12	Reve	ersal of	f pulse outp	ut logic	0	0	0	0		
	13		orque l		-	0	0	0	0		
	14			viation exce	ess setup	0	_	_	0	4-12	
	15			ncoder setu		0	0	0	0		
	16				resistor setup	0	0	0	0		
	-				regenerative					4-13	
	17		tor sel			0	0	0	0		
	00			f a solition l							
	00			of position lo		0	-	-			
	01			of velocity lo		0	0	0	0		
	02	1st	integr		velocity loop	0	0	0	0	4-14	
	03		_	of speed de	tection	0	0	0	0		
	00		<u> </u>	-	torque filter	6	0	0	0		
	05			of position le		0		_	0		_
	05			of velocity lo	· · · · · · · · · · · · · · · · · · ·	6	0	0	0		
	00				velocity loop			0			SS
	07	2nd	integr		velocity loop	0	0	0	0		[Class 3] Velocity/ Iorque/ Fui
	08			of speed de	tection	0	0	0	0	4-15	\ €
<u></u>	09		<u> </u>		torque filter	0	0	0	0		- C
[Class 1] Gain au	10				gain	0	_	_	0		TV I
Ľ.	11	Velo	city fee	ed forward	filter	0	_	_	0		0
ດ ດ	12				gain	0	0	_	0		rqu
ain	13	Torq	ue fee	d forward	filter	0	0	_	0	4-16	Je/
		2nd	gain se	atun	intoi	$\overline{0}$	0	\cap	0	- 10	Ţ
ljus	15	Znu	gain sc	mode		0	_	_	0		-0
ljustment	16	Posi	tion	delay time		0	_		0	4-17	so
ent	17	conti		level		0	_	_	0		II-closed control
	18	swito	ching	hysteresis		0	_		0	4-18	ŝ
	10	Poei	tion as	in switching		0	_	_	0		lurd
	20	1 0 51	uon ya	mode	Juille	E	0	_	Ľ		
	20	Velo	city	delay time		+			-		
		conti	rol	level		-	\circ	_	-	4-19	
	22	swite	ching			-	0	-	-		
	23			hysteresis			0	_	-		
	24	Torq	ue	mode		-	-	0	-		
	25	conti		delay time		-	-	0	-	4-20	
	26	swite	ching	level		-	-	0	-		
	27			hysteresis		-	-	\bigcirc	-		

Parametr No. Related Control Mode Detail Title Class No. P S T F page 00 Adaptive filter mode setup \bigcirc 00 01 frequency 02 000 0 1st notch width selection 4-21 0000 03 depth selection 0000 04 frequency 05 2nd notch width selection 000 \bigcirc 06 depth selection 0000 07 0000 frequency 80 3rd notch 0000 4-22 width selection 09 depth selection 0 10 frequency 0 0 11 4th notch width selection 0 0 12 depth selection 4-23 Selection of damping filter switching 13 14 frequency 1st damping 15 filter setup \cap 16 2nd frequency 17 damping filter setup 4-24 18 3rd frequency damping 19 filter setup 0 20 4th frequency damping 21 filter setup Positional command smoothing filter 4-25 22 A5I First order filter time constant 0 0 4-26 for command Positional command FIR filter 4-27 23 A5I FIR filter time constant for command 4-28 00 Speed setup, Internal/External switching 4-29 01 rotational direction selection Speed 02 input gain 0 \bigcirc command 4-30 03 reversal input 0 04 1st 05 2nd 06 3rd 07 4th Speed setup 08 5th 4-31 09 6th 10 7th 8th 11 12 acceleration Time setup 13 deceleration Sigmoid acceleration/ deceleration 14 time setup 4-32 15 function selection Speed zero-clamp 16 level 17 selection 0 18 direction selection Torque 4-33 command 19 input gain 20 input reversal 21 1 Speed limit 22 value 2 4-34 23 selection 24 numerator of division 25 **External** \cap denominator of division scale 4-35 26 reversal of direction \cap Z phase disconnection 27 detection disable 28 excess setup Hybrid 4-36 deviation 29 clear setup

Note

Only for position control type is not provided with X2 (Communication connector), X3 (Safety function connector), X5 (External scale connector) and analog input.

List of Parameters

N	etr No.			Titl		Rela	ted Co	ontrol	Mode	Deta
Class	No.			Titl		Ρ	S	Т	F	page
	00		SI1	(Pir	ו No.8)	0	0	0	0	4-37
	01		SI2	(Pir	n No.9)	\bigcirc	0	0	0	
	02		SI3	(Pir	n No.26)	0	0	0	0	
	03		SI4		n No.27)	0	0	0	0	1
	04	Input	SI5		n No.28)	0	0	0	0	
	05	selection SI6 (Pin No.29)						0	0	4-38
	06		SI7		1 No.30)		0	0	0	
	07		SI8	(1 No.31)	0	0	0	0	
	07				n No.32)	0	0	0	0	
					n No.33)		0		0	
	09				,	0		0	-	
	10				n No.10, 11)	0	0	0	0	
	11				n No.34, 35)	0	0	0	0	
	12	Output		· ·	n No.36, 37)	0	0	0	0	4-39
	13	selectior			n No.38, 39)	0	0	0	0	
	14				n No.12)	0	0	0	0	
	15		SO	3 (Pir	n No.40)	0	0	0	0	
	16	Analog r	nonitor	- 1	type	0	\bigcirc	0	0	
ဂြ	17			<u> </u>	output gain	0	0	0	0	
as	18	Analaa	nonitor	<u> </u>	type	0	0	0	0	4-4
s 4	19	Analog n	nonitor	2	output gain	0	0	0	0	
N I	20	Type of o	digital r	nonit		0	0	0	0	1
т П	21	Analog n				0	0	0	0	
por	22				ffset setup	0	0	0	0	
[Class 4] I/F monitor setting	23	Analog i	nput 1		Iter	0	0	0	0	
rs	23	(AI1)			vervoltage setup	0	0	0	0	
ëtt	25			_	ffset setup	0	0	0	0	4-4
ing	25	Analog i	nput 2		Iter	0	0	0	0	
<u> </u>		(Al2)				-				
	27			_	vervoltage setup	0	0	0	0	
	28	Analog i	nput 3		ffset setup	0	0	0	0	
	29	(AI3)	iputo		ter	0	0	0	$ \circ $	
	30	< - /		0	vervoltage setup	0	0	0	0	
	31		<u>_</u>		e range	0	—	—	0	4-43
	32	(In-positi	on)		output setup	0	—	_	0	
	33	INP hold	time			0	—	—	0	
	34	Zero-spe	ed			0	\bigcirc	0	0	4-44
	35	Speed co	oincide	ence	range	-	\bigcirc	0	—	4-44
	36	At-speed	l (Spee	d ar	rival)	—	0	0	—	
	37	Mechani	cal	at s	talling setup	0	\bigcirc	0	0	4-4
	38	brake ac			unning setup	0	0	0	0	
	39				ion at running setup		0	0	0	
	40	Selection		1	server anning botup	0	0	0	0	
	40	alarm ou		2		0	0	0	0	4-46
				_	plete (In-position)			F	F	
	42	range	aoning			0	-	-	0	
						1	۱ <u>ــــــــــــــــــــــــــــــــــــ</u>	L		
_	00					0	-	-	0	
	00	2nd				1	I -	0		
	01		nerato	r of e	electronic gear	0	—	_		
			merato	r of e	electronic gear	0			0	
5	01	3rd nui 4th				<u> </u>	- - 0	- 0	0	4-4
[Cla:	01 02 03	3rd nui 4th Denomir	nator of	fpuls	e output division	0			0	4-4
[Class	01 02 03 04	3rd nur 4th Denomir Over-trav	nator of vel inhi	f puls bit in	e output division put setup	0 0 0	0	0	0	4-4
[Class 5]	01 02 03 04 05	3rd nur 4th Denomir Over-trav Sequenc	nator of vel inhi ce at ov	f puls bit in /er-tr	e output division put setup avel inhibit	0 0 0	0	0	0 0 0	4-4
[Class 5] En	01 02 03 04 05 06	3rd nur 4th Denomir Over-trav	nator of vel inhi ce at ov	f puls bit in /er-tr ervo-	e output division put setup avel inhibit Off	0 0 0 0	0 0 0	0 0 0	000000000000000000000000000000000000000	
[Class 5] Enha	01 02 03 04 05 06 07	3rdnur4thDenomirOver-travSequenceSequence	nator of vel inhi ce at ov ce at Se	f puls bit in /er-tr ervo- seq	e output division put setup avel inhibit Off uence	0 0 0 0	0 0 0	0 0 0	0 0 0 0	
[Class 5] Enhanci	01 02 03 04 05 06 07 08	3rd nur 4th Denomir Over-trav Sequenc	nator of vel inhi ce at ov ce at Se	f puls bit in /er-tr ervo- seq LV t	e output division put setup avel inhibit Off uence rip selection	0 0 0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	4-48
[Class 5] Enhancing	01 02 03 04 05 06 07	3rdnur4thDenomirDenomirOver-traviousSequenceSequenceMain povoOFF	nator of vel inhi ce at ov ce at Se wer	f puls bit in /er-tr ervo- seq LV t dete	e output division put setup avel inhibit Off uence	0 0 0 0 0 0 0 0	0 0 0 0 0	0 0 0 0 0	0 0 0 0 0 0	4-48
[Class 5] Enhancing se	01 02 03 04 05 06 07 08	3rdnur4thDenomirDenomirOver-transSequenceSequenceSequencemain power	nator of vel inhi ce at ov ce at Se wer	f puls bit in /er-tr ervo- seq LV t dete	e output division put setup avel inhibit Off uence rip selection	0 0 0 0 0 0	0 0 0 0	0 0 0 0	0 0 0 0	4-48
[Class 5] Enhancing setti	01 02 03 04 05 06 07 08 09	3rd 4thnunDenomir Over-trav SequenceSequenceSequencemain pov OFFSequence	nator of vel inhi ce at ov ce at Se wer wer	f puls bit in /er-tr ervo- seq LV t dete arm	e output division put setup avel inhibit Off uence rip selection	0 0 0 0 0 0 0 0	0 0 0 0 0	0 0 0 0 0	0 0 0 0 0 0	4-48
[Class 5] Enhancing setting	01 02 03 04 05 06 07 08 09 10	3rdnun4thDenomirDenomirOver-travitSequenceSequenceMain povOFFSequenceTorque set	nator of vel inhi ce at ov ce at Se wer ce at al etup fo	f puls bit in ver-tr ervo- seq LV t dete arm or em	e output division put setup avel inhibit Off uence rip selection ection time ergency stop	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0	0 0 0 0 0 0	0 0 0 0 0 0 0 0	4-48
[Class 5] Enhancing setting	01 02 03 04 05 06 07 08 09 10 11 12	3rdnun4thDenomirDenomirOver-trainSequenceSequenceMain povoOFFSequenceSequenceTorque sOver-load	nator of vel inhi ce at ov ce at Se wer ce at al etup fo d level	f puls bit in ver-tr ervo- seq LV t dete arm or em setu	e output division put setup avel inhibit Off uence rip selection ection time ergency stop		0 0 0 0 0 0 0 0 0	000000000000000000000000000000000000000	000000000000000000000000000000000000000	4-48
[Class 5] Enhancing setting	01 02 03 04 05 06 07 08 09 10 11	3rdnun4thDenomirDenomirOver-travitSequenceSequenceMain povOFFSequenceTorque set	nator of vel inhi ce at ov ce at Se wer ce at al etup fo d level eed lev	f puls bit in ver-tr ervo- seq LV t dete arm or em setu vel se	e output division put setup avel inhibit Off uence rip selection ection time ergency stop p tup	000000000000000000000000000000000000000			0 0 0 0 0 0 0 0 0 0	4-47 4-48 4-49

	etr No.	Title		ted Control Mode			1
Class	No.	The	Ρ	S	Т	F	page
	16	Alarm clear input setup	0	0	\bigcirc	\bigcirc	
	17	Counter clear input mode	0	-	—	\bigcirc	4-51
	18	Command pulse Invalidation	0	—	—	\bigcirc	4-31
	19	inhibit input reading setup	0	—	—	\bigcirc	
	20	Position setup unit select	0	—	—	\bigcirc	
[CI	21	Selection of torque limit	0	0	—	\bigcirc	4-52
[Class 5] Enhancing setting	22	2nd torque limit	0	\bigcirc	—	\bigcirc	
s 5	23	Torque limit switching 1	0	0	_	\bigcirc	
	24	setup 2	0	0	—	0	
inh	25	External positive direction torque limit	0	0	—	\bigcirc	4-53
an	26	input negative direction torque limit	0	0	—	0	
cin	27	Input gain of analog torque limit	0	0	—	\bigcirc	
s Bi	28	LED initial status	0	0	0	0	
sett	29	RS232	0	0	0	0	4-54
line	30	RS485 baud rate setup	0	0	0	0	
Q	31	Axis address	0	0	0	0	
	32	Command pulse input maximum setup	0			0	
	32 33		0	0	0	0	4-55
		Pulse regenerative output limit setup	\square	\square	\cup		4-55
	34	For manufacturer's use					
	35	Front panel lock setup	0	0	0	0	
	00	Analog torque feed forward					
	00	conversion gain	0	0	_	0	
	02	Velocity deviation excess setup	0	—	—	—	
	04	JOG trial run command speed	0	0	0	0	4-56
	05	valid time	0	_		0	
	06	Position 3rd gain scale factor	0	_	_	0	
	07	Torque command additional value	0	0	_	0	
		Positive direction torque	0				
	08	compensation		-	—	0	4-57
	09	Negative direction value	0	-	—	$^{\circ}$	
	10	Function expansion setup	0	0	0	0	
	11	Current response setup	0	0	0	0	
	13	2nd Inertia ratio	0	0	0	0	
	14	Emergency stop time at alarm	0	0	0	0	
	15	2nd over-speed level setup	0	0	0	0	4-58
	17	Front panel parameter writing selection	0	0	0	0	
_	18		0	0	0	0	
Cla	-	Power-up wait time	\square	\square	\cup		
SSE	19	Encoder Z phase setup	-	-	—	0	
6]	20	Z-phase setup of external scale	-	-	—	0	
S	21	Serial absolute external scale Z phase setup	-	-	—	0	4-59
pe	22	A, B phase external scale pulse	_	_		0	
cia		output method selection					
6] Special setting	23	Disturbance torque compensating gain	0	0	-	-	
ətti	24	Disturbance observer filter	0	0	-	-	
рŋ	27	Alarm latch time selection	0	0	0	0	4-60
	31	Real time estimation speed	0	0	0	0	
	32	auto tuning custom setup	0	0	0	0	4-61
	34	Hybrid vibration gain	_	-	-	\bigcirc	4-62
	35	suppression filter	_	_	_	\bigcirc	02
	37	Oscillation detection level	0	0	0	\bigcirc	
	38	Alarm mask setup	0	0	0	\bigcirc	
	20	For manufacturer's use					4 00
	39	A5I Anti-vibration depth 1	0			0	4-63
	41		_	0	0	0	
			\circ	$ \circ $	\sim		
	41	A51 Two-stage torque filter time constant	0	0	0	0	
	41 42	A5I Two-stage torque filter time constant A5I Two-stage torque filter attenuation term				0	
	41 42 43 47	A511 Two-stage torque filter time constant A511 Two-stage torque filter attenuation term A511 Function expansion setup 2	0 0	0	0	-	
	41 42 43 47 48	A51 Two-stage torque filter time constant A51 Two-stage torque filter attenuation term A51 Function expansion setup 2 A51 Adjust filter	000000000000000000000000000000000000000	0	0	-	4-64
	41 42 43 47 48 49	A51 Two-stage torque filter time constant A51 Two-stage torque filter attenuation term A51 Function expansion setup 2 A51 Adjust filter A51 Adjust/Torque command attenuation term	0 0 0	0	0	-	4-64
	41 42 43 47 48	A51 Two-stage torque filter time constant A51 Two-stage torque filter attenuation term A51 Function expansion setup 2 A51 Adjust filter	0 0 0	0	0	-	4-64

A5II : Only available on A5II series.

Preparation

4

Setup

Adjustment

5

6 When

When in Trouble

[Class 0] Basic setting

	1								Defaul Relate
• 0 . 00	Rotatio	nal direction set	up			ange	Unit	Default	control r
					0	to 1		1	PS
	0: Motor side si 1: Motor side sh	e relationship betw turns CW in response haft end) turns CCW in res haft end) sitive direction (CCW)	onse to po	ositive dire	ction co	ommand	(CW whe	n viewed fro	m load
		I	Default	(CW)					
	Setup value	Command directi		tor rotation direction	-	Positive d drive inhil		Negative d drive inhib	
	0	Positive direction	n	CW		Vali	id	_	
		Negative directio	n	CCW		_		Valio	ł
	[1]	Positive direction		CCW		Vali	id		
		Negative directio	n	CW		_		Valio	k
)1 *		I mode setup set up the control	mode to b	_	J	to 6	_	0	PS
	Setup value				-	•		bination moder the 1st or 1	
	[0]	1st mode 2 Position	2st mode					g input (C-M	
	1	Velocity	_	- v	Vhen C·	-MODE is	s open, th	ne 1st mode	will be
	2	Torque	_		elected				
	3 *1	Position	Velocity		vhen C∙ e selec'		s shorted	, the 2nd me	ode wil
	4 *1	Position	Torque	-			mands 1	0 ms befor	e/after
	5*1	Velocity	Torque		witching				
	6	Full-closed	_	C-MODE			close		
	Note	••••••		O-WODE	ope				pen
	Two-de	egree-of-freedom	control ca	n	1st	$\rightarrow \leftarrow$	— 2nd	\ ←	1st
		ected with Pr6.47.							
	For de	tails, refer to Pr6.4	47 (P.4-64).	1	10 ms or lo	onger	10 ms or lo	nger
				S	he wav etting o	eform ab f C-MOD	ove show E input is	vs when logic a-contact. V d short is rev	Vhen

• Only for position control type is not provided with X2 (Communication connector), X3 (Safety function connector), X5 (External scale connector) and analog input.

Related page • P.3-32... "Inputs and outputs on connector X4"

[Class 0] Basic setting

				Range	Unit	Default	Related			
Pr0.02	Real-ti	me auto-gain tun	ing setup	0 to 6	_	1	P S T			
	You can	set up the action r	node of the real-tim	e auto-gain tun	ina.					
	Setup	-		-	•					
	value	Mode	Varying degree of load inertia in motion							
	0	Invalid	Real-time auto-gain tuning function is disabled. Basic mode. Do not use unbalanced load, friction compensation of							
	[1]	Standard	gain switching.							
	2	Positioning *1	Main application is positioning. It is recommended to use this mode on equipment without unbalanced horizontal axis, ball screw driving equipment with low friction, etc.							
	3	Vertical axis *2	With additional features to the positioning mode - use this mode to positively and effectively compensate for unbalanced load to the vertical axis or minimize variations in setting time.							
	4	Friction compensation *3	With additional features to the vertical axis mode - use this mode to positively and effectively reduce positioning setting time when the belt driving axis has high friction.							
	5	Load characteristic measurement	Estimate the load characteristics without changing current parameter setting. This mode requires use of the setup support software.							
	6	Customize *4	Functions of real-time auto-gain tuning can be customized to meet the requirements of the specific application by combining desired functions according to the Pr6.32 "Real-time auto-gain tuning custom setting".							
A5I	Pr6 Two-de	.32.	n control mode:	ecific control m standard type		to descripti	on in			
A5I	Two-de	.32. egree-of-freedon -degree-of-freedor		standard type er to Pr6.47 (P.4	9	to descripti	on in			
A5I	Two-de	.32. egree-of-freedon -degree-of-freedor	n control mode: so n control mode, refe the real-time auto-g	standard type er to Pr6.47 (P.4	9 1-64).		on in			
A5I	Two-de For Two Set up th	.32. egree-of-freedon -degree-of-freedor he action mode of	n control mode: s n control mode, refe the real-time auto-g Varyin Real-time auto-gain	standard type er to Pr6.47 (P.4 ain tuning. ng degree of loa tuning function is	e I-64). d inertia in i	motion				
A5I	Two-de For Two Set up th Setup value	.32. egree-of-freedon -degree-of-freedor he action mode of Mode	n control mode: s n control mode, refe the real-time auto-g Varyin Real-time auto-gain Stability-first mode. I	standard type er to Pr6.47 (P.4 ain tuning. ng degree of loa tuning function is Do not use unbal	e I-64). d inertia in i	motion				
A5I	Two-de For Two Set up th Setup value 0, 6	.32. egree-of-freedom -degree-of-freedom he action mode of Mode Invalid Standard Quick response	n control mode: s n control mode, refe the real-time auto-g Varyin Real-time auto-gain Stability-first mode. I compensation or gai Positioning-first mode	standard type er to Pr6.47 (P.4 ain tuning. Ing degree of loa tuning function is Do not use unbal n switching de. Use this mod	e I-64). d inertia in i disabled. anced load c de for equip	motion compensatio ment with h	n, friction			
A5I	Two-de For Two Set up th Setup value 0, 6 [1]	.32. egree-of-freedom -degree-of-freedom he action mode of Mode Invalid Standard	n control mode: s n control mode, refe the real-time auto-g Varyin Real-time auto-gain Stability-first mode. I compensation or gai	standard type er to Pr6.47 (P.4 ain tuning. Ing degree of loa tuning function is Do not use unbal n switching de. Use this mod screw driving an atures provided of mpensate unbal	e I-64). d inertia in r disabled. anced load c de for equip d without un with the Quid anced load,	motion compensation ment with h balanced loa ck response	n, friction norizontal ad. mode 1,			
A5I	Two-de For Two Set up th Setup value 0, 6 [1] 2	.32. egree-of-freedom -degree-of-freedom he action mode of Mode Invalid Standard Quick response mode 1 Quick response	n control mode: s n control mode, refe the real-time auto-g Varyin Real-time auto-gain Stability-first mode. I compensation or gai Positioning-first mod axis, low friction ball In addition to the fea use this mode to co reduce variation in p In addition to the fea use this mode to sh high friction.	standard type er to Pr6.47 (P.4 ain tuning. ng degree of loa tuning function is Do not use unbal n switching de. Use this mod screw driving an atures provided w mpensate unbala ositioning settling atures provided w	e I-64). d inertia in r d disabled. anced load c de for equip d without un with the Quid anced load, g time. with the Quid settling tim	motion compensation ment with h balanced loa ck response to apply thir ck response e when the	n, friction ad. mode 1, d gain to mode 2, load has			
A5I	Two-de For Two Set up th Setup value 0, 6 [1] 2 3	.32. egree-of-freedom -degree-of-freedom he action mode of Mode Invalid Standard Quick response mode 1 Quick response mode 2 Quick response	n control mode: s n control mode, refe the real-time auto-g Varyin Real-time auto-gain Stability-first mode. I compensation or gai Positioning-first mod axis, low friction ball In addition to the fea use this mode to co reduce variation in p In addition to the fea use this mode to sh	standard type er to Pr6.47 (P.4 ain tuning. ng degree of loa tuning function is Do not use unbalant n switching de. Use this mod screw driving an atures provided with ositioning settling atures provided without orten positioning acteristics without	d inertia in i disabled. anced load of de for equip d without un with the Quid anced load, g time. with the Quid settling tim	motion compensation ment with h balanced loa ck response to apply thir ck response e when the g basic gain	n, friction orizontal ad. mode 1, d gain to mode 2, load has n setting			
	Two-de For Two Set up th 0, 6 [1] 2 3 4 5 *1 Velo Forv	.32. egree-of-freedom -degree-of-freedom he action mode of Mode Invalid Standard Quick response mode 1 Quick response mode 2 Quick response mode 3 *1 Load characteristic measurement city control is the s ward torque compe	n control mode: s n control mode, refet the real-time auto-g Varyin Real-time auto-gain Stability-first mode. I compensation or gai Positioning-first mod axis, low friction ball In addition to the fea use this mode to co reduce variation in p In addition to the fea use this mode to sh high friction. Estimate load char or friction compens	standard type er to Pr6.47 (P.4 ain tuning. ng degree of loa tuning function is Do not use unbal n switching de. Use this mod screw driving an atures provided w mpensate unbal ositioning settling atures provided w orten positioning acteristics without ation setting wit response mode 09 Backward t	d inertia in 1 d inertia in 1 d isabled. anced load c de for equip d without un with the Quid anced load, g time. with the Quid settling tim but changing h the help of e 2. Value o orque com	motion compensation ment with h balanced loa ck response to apply thir ck response e when the g basic gain of the setup f parameter pensation v	n, friction norizontal ad. mode 1, d gain to mode 2, load has n setting o support rs, Pr6.08 /alue and			
A5II	Two-de For Two Set up th 0, 6 [1] 2 3 4 5 *1 Velo Forv Pr6.4	.32. egree-of-freedom -degree-of-freedom he action mode of Mode Invalid Standard Quick response mode 1 Quick response mode 2 Quick response mode 3 *1 Load characteristic measurement city control is the s ward torque compe- 50 Viscous friction	n control mode: s n control mode, refet the real-time auto-g Varyin Real-time auto-gain Stability-first mode. I compensation or gai Positioning-first mod axis, low friction ball In addition to the fea use this mode to co reduce variation in p In addition to the fea use this mode to sh high friction. Estimate load char or friction compens software. ame as in the quick ensation value, Pr6.	standard type er to Pr6.47 (P.4 ain tuning. ng degree of loa tuning function is Do not use unbal n switching de. Use this mod screw driving an atures provided of mpensate unbala ositioning settling atures provided of norten positioning cacteristics witho ation setting wit response mode 09 Backward to will be updated	e I-64). d inertia in r disabled. anced load of d without un with the Quid anced load, g time. with the Quid anced load, g time. with the Quid settling tim but changing h the help of e 2. Value of orque comp but not refle	motion compensation ment with h balanced loa ck response to apply thir ck response e when the g basic gain of the setup f parameter pensation v	n, friction ad. mode 1, d gain to mode 2, load has n setting o support rs, Pr6.08 /alue and			

Related page • P.3-32... "Inputs and outputs on connector X4"

Setup

2

Preparation

3

Connection


Default: []

A5I

Two-degree-of-freedom control mode: synchronous type

For Two-degree-of-freedom control mode, refer to Pr6.47 (P.4-64). Set up the action mode of the real-time auto-gain tuning.

Setup value	Mode	Varying degree of load inertia in motion
0, 6	Invalid	Real-time auto-gain tuning function is disabled.
[1]	Synchronous	Synchronous control mode. Do not use this mode for unbalanced load or friction compensate. Use this mode first when maintaining command response filter, then switch to another mode as necessary.
2	Synchronous friction compensation	With dynamic friction compensation/viscous friction compensation in addition to those of synchronous mode. Use this mode when the load has a large friction.
3	Stiffness setting	Use this mode when modifying gain filter setting according to stiffness table without making inertia ratio assumption, unbalanced load compensation or friction compensation. When handling a load with larger inertia variations, first estimate inertia in an appropriate mode, e.g. sync mode, and then switch to this mode.
4	Load characteristics update	Use this mode when applying only inertia ratio, dynamic friction compensation and viscous friction compensation among load characteristics while holding gain filter setting.
5	Load characteristic measurement	Estimate load characteristics without changing basic gain setting or friction compensation setting with the help of the setup support software.



[•] For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power. Related page … • P.3-32... "Inputs and outputs on connector X4"

[Class 0] Basic setting

	Pr0.04	Inertia ratio	Range	Unit	Default	Related control mode					
	P10.04		0 to 10000	%	250 *	PSTF					
	Set 1st inertia ratio. You can set up the ratio of the load inertia against the rotor (of the motor) inertia.										
	Pr0.04 = (load inertia/ rotor inertia) × 100 [%]										
		The inertia ratio will be estimated at all time while the result will be saved to EEPROM every 30 m		e auto-gai	n tuning is v	alid, and					
Caution :: If the inertia ratio is correctly set, the setup unit of Pr1.01 and Pr1.06 becomes (Hz). We the inertia ratio of Pr0.04 is larger than the actual, the setup unit of the velocity loop becomes larger, and when the inertia ratio of Pr0.04 is smaller than the actual, the setup of the velocity loop gain becomes smaller.											

			Range	Unit	Default	Related control mod			
Pr0.05 *	Selection of	of command pulse input	0 to 1		0	P F			
			A5I 0 to 2	_					
You can select either the photocoupler input or the exclusive input for line driver as the command pulse input.									
	Setup value		Content						
	[0]	Photocoupler input (PULS1, PULS2	, SIGN1, SIGN2)					
	1	Exclusive input for line driver (PULS	SH1, PULSH2, S	IGNH1, SIG	NH2)				
	A5I 2	Photocoupler inputs (PULS1, PULS2, SIGN1, SIGN2) [250 kpps or less]							
		vailable on A5II series.							

Default: []

1

Preparation

5

7

Note

· Parameters which default values have a suffix of " * " will be automatically set up during real time auto-gain tuning. When you change manually, invalidate the real-time auto-gain tuning first then set, referring to P.5-8, "Release of Automatic Gain Adjusting Function" of Adjustment.

[Class 0] Basic setting

D-0 00 *	0					Range)	Unit	De	əfault	Rela	
Pr0.06 *	Com	mand pulse ro	tational dire	ectio	n setup	0 to 1		_		0	Р	
D-0 07 *	0					Range	,	Unit	De	efault	Rela	ate I m
Pr0.07 *	Com	mand pulse ir	iput mode s	setup		0 to 3		_		1	Р	
		an set up the ro input format.	otational dire	ectior	n against th	ne comm	nand pu	ulse inj	out, and	d the c	omma	เท
Comman Pulses ar	d pulse e coun	shows combination input mode se ited at edges in command puls	tup. dicated by th						n setup	and P	r0.07	
Pr0.06 setu Command rotatio direction	p value pulse nal	Pr0.07 setup value Command pulse input mode setup	Comman pulse forn		Signal title		e direct nmand	ion	-	ive dire ommane		
· . ·		0 or 2	90° phase difference 2-phase pulse (A + B-phase)		PULS SIGN	A- <u>phase</u> B- <u>phase</u> ti B-phase adv			t1 t1 t1 t1 t1 t1 t1 t1 B-phase d		 A by 90°	
[0]		[1]	Positive direc pulse trai + Negative dire pulse trai	n ection	PULS SIGN	t2	↦		t2 t2			-
		3	pulse train + Signal		PULS SIGN	t4	• t5 "H"	t6 t		L"	⊢ t6	
		0 or 2	90° phas differenc 2-phase pu (A + B-pha	e ılse	PULS SIGN	t1 A-phase B-phase→ t1 B-phase dela	t1 t1 t1 t1 avs from A	. . by 90°.	t1 t1 t1 3-phase ac	t1 t1 t1 t1 t1	 A by 90°	
1		1	Positive direc pulse trai + Negative dire pulse trai	n ection	PULS SIGN	F	+ t2					
		3	pulse trai + Signal	in	PULS SIGN	t4 t6	*↔ t5 "L"	 t6 t		H"	⊢ t6	
• Permis	sible n	nax. input frequ	iency, and n	nin. r	ecessary t	time wid	th of co	omman	d puls	e input	signa	ıl.
			Pern	nissible max	x. I			time w	-	-		
Input I/F of PULS/SIGN signal					ut frequency	y t1	t2	tз	t4	t5	t6	
Pulse trai	n interfa	ace exclusive to I			4 Mpps	0.25	0.125	0.125	0.125	0.125	0.125	_
Pulse trai	n interfa	ace Line driver Open collect	interface		500 kpps 200 kpps	2	1 2.5	1 2.5	1 2.5	1 2.5	1 2.5	-
Make the rising/falling time of the command pu							mallor		•	•		

Note

 A parameter is designated as follows: Class <u>Pro.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

Related page P.3-32... "Inputs and outputs on connector X4"

[Class 0] Basic setting

Default: []

Pr0.08 *	Command pulse counts per one motor	Range	Unit	Default	Related control mode					
F10.00	revolution	0 to 1048576	pulse	10000	P					
Set the command pulses that causes single turn of the motor shaft. When this setting is 0, Pr0.09 1st numerator of electronic gear and Pr0.10 Denominator of electronic gear become valid.										

Pr0.09	1 at numerator of electronic goar	Range	Unit	Default	control mod	de
Pr0.09 1st numerator of electronic gear		0 to 2 ³⁰	—	0	P	F
	Set the numerator of division/multiplication opering	eration made ac	cording to	the comma	nd pulse	

This setup is enabled when Pr0.08 command pulse counts per one motor revolution = 0.

Pr0.10	Denominator of electronic gear	Range	Unit	Default	Relate control m	
P10.10	Denominator of electronic gear	1 to 2 ³⁰	—	10000	P	F
	Set the Denominator of division/multiplication pulse input. This setup is enabled when Pr0.08 command			Ū		d

<Interrelationship between Pr0.08, Pr0.09 and Pr0.10 during Position control>

Pr0.08	Pr0.09	Pr0.10	Command d	livision/multiplicatior	n operation	
			Command pulse input	Encoder resolution	Positional command	
1 to 1048576	_	_		[Pr0.08 setup value]		
110 1040370	(Not effect)	(Not effect)	* Regardless of setup of Pr0.09 and Pr0.10, operation is processed according to setup valu Pr0.08.			
			Command pulse input	Encoder resolution	Positional command	
	0	0 to 1073741824		[Pr0.10 setup value]		
0			* When both Pr0.08 and Pr0.09 are set to 0, th operation is processed according to setup value Pr0.10.			
0			Command		Positional	
			pulse input	[Pr0.09 setting]	command	
	1 to 1073741824	1 to 1073741824		[Pr0.10 setting]		
			* When setup value of Pr0.08 is 0, and Pr0.09≠0 this operation is processed according to setup value of Pr0.09 and Pr0.10.			

<Interrelationship between Pr0.08, Pr0.09 and Pr0.10 during full closed control>

2

6

[Class 0] Basic setting

Default: []


Pr0.08	Pr0.09	Pr0.10	Command division/multiplication operation
(Invelid)	0	1 to 1073741824	Command pulse input 1 * If Pr0.09 is 0 during full closed controlling, the process as shown above is performed with both numerator and denominator set to 1.
(Invalid)	1 to 1073741824	1 to 1073741824	Command pulse input [Pr0.09 setting] [Pr0.10 setting] * When setup value of Pr0.09≠0, this operation is processed according to setup value of Pr0.09 and Pr0.10.

Caution :: The desired setting can be determined by selecting value of numerator and denominator of electronic gear. However, an excessively high division or multiplication ratio cannot guarantee the operation. The ratio should be in a range between 1/1000 and 1000.

Excessively high multiplication ratio will cause Err27.2 (command pulse multiplication error protection) due to varying command pulse input or noises, even if the other settings are within the specified range.

During full closed controlling, do not change command division and multiplication ratio. Otherwise, Err25.0 (Hybrid over deviation alarm) will be generated.

Pr0.11 *	Output pulse counts	Range	Unit	Default	Related control mode				
	per one motor revolution	0 to 262144	P/r	2500	PSTF				
You can set up the output pulse counts per one motor revolution for each OA and OB with the Pr0.11 setup.									
Caution 🔅 For details of setup, refer to description in Pr5.03.									



[Class 0] Basic setting

	De							
Pr5.03 *	Denominator of	of pulse output o	division	Range	Unit	Default	Control III	
110.00				0 to 2621	44 —	0	PST	
		barameter to a va merator and Pr5. counts per one retup value / Pr5. of Pr0.11 Output	alue other tha 03 as the de revolution 03 setup valu pulse count	n 0; and th nominator. ue) × Encoc	e dividing ratio	$\frac{1}{4}$	et by using	
	Pr0.11	Pr5.03		Pulse re	producing pr	ocess		
			When the o	utput sour	ce is encode	r		
			Encod	-			utput pulse	
				ack pulse	[Pr0.11 setup v		ulse]	
			[pulse]]	Encoder reso	olution	-	
		[0] V		etup value. ber of pulses ne number of	above process is of reproduced p pulses set in Pr(evolution is equa	ulse output ().11. The res	OA and solution of	
	1 to 262144		Externa [pulse]	utput soun	ce is externa		out pulse se] ►	
		1 to 262144	or external s [pulse] * If Pr5.03 is based on se When the o	not equal to etup value of utput sour	[Pr0.11 setup v [Pr5.03 setup v 0, then the abov Pr0.11 and Pr5.0 rce is encode uced pulses (O/	value] [puls value] e process is 03. r	s performed	
		абл 1 to 1048576	 The number of reproduced pulses (OA, OB) per one motor revolution is not an integer. Note that when the number of pulses per one motor revolution is not an integer, Z-phase output is not synchronized with that of A-phase, reducing pulse width. The pulse output resolution per one revolution cannot become higher than the encoder resolution. When output source is external scale Setting: numerator (Pr0.11 setting) ≦ denominator (Pr.5.03 setting). No multiplication 					

7

 A parameter is designated as follows: Class <u>Pr0.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when Note you turn on the control power. Related page … • P.2-84... "Setup of Torque Limit" • P.3-32... "Inputs and outputs on connector X4" • P.6-2... "Protective Function"

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 4-11

[Class 0] Basic setting

								Default: [
Pr0.12 *	Boyor	eal of pul	se output	logic	Range	Unit	Default	Related control mod		
F10.12	never	sai oi pui	se output	logic	0 to 3	-	0	PSTF		
	parame pulse by	ter, you ca y reversing	an reverse the B-pha	e logic and the c the phase relation se logic. Encoder	between the A or external scal	A-phase pu e can be s	lse and the elected as t	e B-phase the output		
	source for full-closed control. The encoder is selected as the source if not for full-closed control.									
	Pr0.12	B-phase logic	Output source	CCW dire rotatio		C	W direction rotation			
	[0]	Non-	Encoder	A-phase		A-phase				
	2	reversal	External scale	B-phase		B-phase				
	1	Dovoraal	Encoder	A-phase		A-phase				
	3	Reversal	External scale	B-phase		B-phase				
Caution 🔅	 Setup value 2 and 3 are valid only for full-closed control. Setting must be 0 or 1 if not for full-closed control. The selection of the output source of Z-phase is held concurrently. Setup value 0 and 1 are Z-phase output of encoder. Setup value 2 and 3 are Z-phase output of external scale. 									

	Pr0.13	1st torque limit	Range	Unit	Default	Related control mode				
	PI0.13		0 to 500	%	500	P S T F				
	You can set up the limit value of the motor output torque.									
Note i For details of torque limit value, refer to P.2-84.										

Pr0.14	Position deviation excess actum	Range	Unit	Default	Rela control	
Pr0.14	Position deviation excess setup	0 to 134217728	Command unit	100000	P	F
	 Set excess range of positional deviation by th Setup unit can be changed to encoder unit the If the unit is changed, set up with the encoder the external scale pulse counts at the full-close Err24.0 (Error detection of position deviation external scale) 	rough Pr5.20 (p r pulse counts a sed control.	osition set t the posit	tup unit selection control a	nd wi	th
Note i For description of "command unit" and "encoder unit", refer to P.4-52 "Pr5.20".						

Pr0.15 *	Abaaluta a	ncoder setup	Range	Unit	Default	Related control mode
FI0.15	Absolute e	neodel setup	0 to 2	—	1	P S T F
	You can set up the using method of 17-bit absolute encoder.					
	Setup value		Function			
	0	Use as an absolute encoder.				
	[1]	Use as an incremental encoder.				
	2	Use as an absolute encoder, but igr	nore the multi-turn	counter ov	ver.	
Caution 🔅	This paramet	ter will be invalidated when 5-wire	, 20-bit increme	ntal encod	der is used.	

[Class 0] Basic setting

					Default: []
	_	Range	Unit	Default	Related control mode
Pr0.16 *	External regenerative resistor setup	0 to 3	—	A,B,G,H-frame: 3 C,D,E,F-frame: 0	PSTF
	With this parameter, you can select either to driver, or to separate this built-in regenerative resistor (between B1 and B2 of Connector XE of Connector XC in case of D-frame(400 V) a block in case of F to H-frame).	resistor and ext 3 in case of A to	ernally ins D-frame,	stall the rege between B1	nerative and B2

A, B, G and H-frame driver is not provided with built-in resister.

	Setup value	Regenerative resistor to be used	Function
	[0] (C to F-frame)	Built-in resistor	Regenerative processing circuit will be activated and regenerative resistor overload protection will be triggered according to the built-in resistor (approx. 1 % duty).
	1	External resistor	The driver trips due to regenerative overload protection (Err18.0), when regenerative processing circuit is activated and its active ratio exceeds 10 %.
	2	External resistor	Regenerative processing circuit is activated, but no regenerative over-load protection is triggered.
	[3] (A, B, G, H-frame)	No resistor	Both regenerative processing circuit and regenerative protection are not activated, and built-in capacitor handles all regenerative power.
Remarks 🔅	resistor. Otherwise, the reg	generative res	ch as thermal fuse when you use the external regenerative istor might be heated up abnormally and result in burnout, dation of regenerative over-load protection.
Caution 🔅	touch the external	regenerative r	nerative resistor, never to set up other value than 0. Don't resistor. ets very hot, and might cause burning.

Pr0.17 *	Load facto	r of external regenerative	Range	Unit	Default	Related control mode	
F10.17	resistor se	lection	0 to 4	_	0	P S T F	
When selecting the external regenerative resistor ($Pr0.16 = 1, 2$), select the computing method of load factor of regenerative resistor.							
	Setup value		Function				
	[0] Regenerative load factor is 100 % when duty factor of external regenerative resistor is 10 %.						
	1 to 4	For manufacturer's use (do not setup)					
1 to 4 For manufacturer's use (do not setup)							

2

1

Before Using the Products

5

6

• A parameter is designated as follows: Class Pro.00 Parameter No.

• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

Related page • P.2-12... "System Configuration and Wiring" • P.3-32... "Inputs and outputs on connector X4"

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 4-13



[Class 1] Gain adjustment

D 4 00		Range	Unit	Default	Related control mode
Pr1.00	1st gain of position loop	0 to 30000	0.1 /s	A,B,C-frame: 480 D to H-frame: 320	P F
	You can determine the response of the positio Higher the gain of position loop you set, faster Note that too high setup may cause oscillation	the positioning		can obtain.	

D#1.01	1 at gain of valuatity loop	Range	Unit		Related control mode
Pr1.01	1st gain of velocity loop	1 to 32767	0.1 Hz	A,B,C-frame: 270 D to H-frame: 180	P S T F
	You can determine the response of the velocity In order to increase the response of overall ser you need higher setup of this velocity loop gain oscillation.	rvo system by se	0 0	•	

Caution 🔅 When the inertia ratio of Pr0.04 is set correctly, the setup unit of Pr1.01 becomes (Hz).

	1st time constant of velocity loop	Range	Unit	Default	Related control mode	
Pr1.02	integration	1 to 10000	0.1 ms	A,B,C-frame: 210 D to H-frame: 310	P S T F	
	You can set up the integration time constant of	f velocity loop.				
	Smaller the setup, faster you can dog-in devia	tion at stall to 0.				
	The integration will be maintained by setting to "9999".					
	The integration effect will be lost by setting to	'10000".				

Pr1.03	1st filter of speed detection	Range	Unit	Default	Related control mode
	ist litter of speed detection	0 to 5	—	0	PSTF
	You can set up the time constant of the low parsteps. Higher the setup, larger the time constant you motor noise, however, response becomes slow operation.	can obtain so th	nat you ca	n decrease t	he
Pr1.04	1st time constant of torque filter	Range	Unit	Default	Related control mode

Pr1.04	1st time constant of torque filter	0 to 2500	0.01 ms	A,B,C-frame: 84 D to H-frame: 126	ΡS	Т	F
	You can set up the time constant of the 1st del portion. You might expect suppression of oscill	,		•	d		

Caution 🔅	To Panasonic MINAS users: A4 and higher series
	CAUTION: Parameter settings shown in this manual may differ from those applied to your
	product (s).
Note	• For parameters which No. have a suffix of " * ", changed contents will be validated when
	you turn on the control power.
Related page 🔅	P.3-32 "Inputs and outputs on connector X4"

[Class 1] Gain adjustment

D 4 05		Range	Unit	Default	Related control mode
Pr1.05	2nd gain of position loop	0 to 30000	0.1 /s	A,B,C-frame: 570 D to H-frame: 380	P F
5 4 9 9		Range	Unit	Default	Related control mode
Pr1.06	2nd gain of velocity loop	1 to 32767	0.1 Hz	A,B,C-frame: 270 D to H-frame: 180	P S T F
Pr1.07	2nd time constant of velocity loop	Range	Unit	Default	Related control mode
	integration	1 to 10000	0.1 ms	10000	PSTF
Dr1 00	2nd filter of speed detection	Range	Unit	Default	Related control mode
Pr1.08		0 to 5	—	0	PSTF
D-1 00		Range	Unit	Default	Related control mode
Pr1.09	2nd time constant of torque filter	0 to 2500	0.01 ms	A,B,C-frame: 84 D to H-frame: 126	PSTF
	Position loop, velocity loop, speed detection pairs of gain or time constant (1st and 2nd).	filter and torque	e comma	nd filter have	e their 2
Related page :: For details of switching the 1st and the 2nd gain or the time constant, refer to P.5- Switching Function" of Adjustment. The function and the content of each parameter is as same as that of the 1st gain a constant.					

		Range	Unit	Default	Relate control m	
Pr1.10	Velocity feed forward gain	0 to 1000	0.1 %	300	P	Ц
		A5I 0 to 2000	0.1 %			
	Multiply the velocity control command calc command by the ratio of this parameter and a from the positional control process.		•	•		
* Asi represents setting range applied to A5I series.						

Pr1.11	Velocity feed forward filter	Range	Unit	Default	Related control mode					
F11.11	velocity leed forward litter	0 to 6400	0.01 ms	50	P F					
Set the time constant of 1st delay filter which affects the input of velocity feed forward. <usage example="" feed="" forward="" of="" velocity=""></usage> The velocity feed forward will become effective as the velocity feed forward gain is gradually increased with the velocity feed forward filter set at approx. 50 (0.5 ms). The positional deviation during operation at a constant velocity is reduced as shown in the equation below in proportion to the value of velocity feed forward gain.										
	Positional deviation [unit of command] = command speed [unit of command/s] / positional loop gain [1 /s] × (100 - velocity feed forward gain [%]) / 100									

Adjustment

1

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

6

7

 A parameter is designated as follows: Class <u>Pro</u> <u>o</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power. Related page P.3-32... "Inputs and outputs on connector X4"

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

[Class 1] Gain adjustment

Default: []

		Range	Unit	Default	F	Relat	
Pr1.12		0 to 1000		0			
		A5I 0 to 2000	0.1 %		F	3	F

- Multiply the torque command calculated according to the velocity control command by the ratio of this parameter and add the result to the torque command resulting from the velocity control process.
- Positional deviation at a constant acceleration/deceleration can be minimized close to 0 by increasing the torque forward gain. This means that positional deviation can be maintained at near 0 over entire operation range while driving in trapezoidal speed pattern under ideal condition where disturbance torque is not active.
 - * A5I represents setting range applied to A5I series.

Pr1.13	Torque feed forward filter	Range	Unit	Default	Related control mode				
F11.13	Torque leed forward litter	0 to 6400	0.01 ms	0	P S F				
 Set up the time constant of 1st delay filter which affects the input of torque feed forward. The torque feed forward will become effective as the torque feed forward gain is gradually increased with the torque feed forward filter is set at approx. 50 (0.5 ms). 									
<usage example="" feed="" forward="" of="" torque=""></usage>									

- To use the torque feed forward, correctly set the inertia ratio. Use the value that was determined at the start of the real time auto tuning, or set the inertia ratio that can be calculated from the machine specification to Pr0.04 Inertia ratio.
- The torque feed forward will become effective as the torque feed forward gain is gradually increased with the torque feed forward filter is set at approx. 50 (0.5 ms).
- Positional deviation at a constant acceleration/deceleration can be minimized close to 0 by increasing the torque forward gain. This means that positional deviation can be maintained at near 0 over entire operation range while driving in trapezoidal speed pattern under ideal condition where disturbance torque is not active .

Caution 🔅 Zero positional deviation is impossible in actual situation because of disturbance torque. As with the velocity feed forward, large torque feed forward filter time constant decreases the operating noise but increases positional deviation at acceleration change point.

Pr1.14	2nd gain se	atun	Range	Unit	Default	Related control mod			
FI1.14	2nu gain se	eup	0 to 1	—	1	PSTF			
	Arrange this function.	range this parameter when performing optimum adjustment by using the gain swit nction.							
	Setup value	Gain s	election/switch	ing					
	0	1st gain is fixed at a value. By u the velocity loop operation from GAIN input photocoupler OFF GAIN input photocoupler ON * The above description appl a-contact. ON/OFF of photo	PI to P. \rightarrow PI operation \rightarrow P operation ies when the log	gical setti	ng of GAIN				
	[1]	Enable gain switching of 1st gain (Pr1.00-Pr1.04) and 2nd gain (Pr1.0 Pr1.09).							
Related page 🤹	For switching Adjustment.	g condition of the 1st and the 2nd	l, refer to P.5-31	Gain S	witching Fur	nction" of			

[Class 1] Gain adjustment

-	_		Range	Unit	Default	Related
Pr1.1	5 Mode of p	position control switching	0 to 10	_	0	P
	Set up the t	triggering condition of gain switchin	g for position co	ntrol.		
Setup value	Switching condition	Gain s	witching condition	n		
[0]	Fixed to 1st gain	Fixed to the 1st gain (Pr1.00 to Pr1.04)	•			
1	Fixed to 2nd gain	Fixed to the 2nd gain (Pr1.05 to Pr1.09).			
2	With gain switching input	 1st gain when the gain switching input 2nd gain when the gain switching input * If no input signal is allocated to the gain 	ut (GAIN) is connec			ed.
3	Torque command is large	 Shift to the 2nd gain when the absol hysteresis) (%) previously with the 1s Return to the 1st gain when the absolu - hysteresis) (%) previously during de 	t gain. te value of the torq	ue comman		
5	Speed command is large	 Valid for position and full-closed contr Shift to the 2nd gain when the absol hysteresis) (r/min) previously with the Return to the 1st gain when the absolu - hysteresis) (r/min) previously during 	ute value of the sp 1st gain. Ite value of the spec	ed command		
6	Position deviation is large	 Valid for position and full-closed contri- Shift to the 2nd gain when the absolut hysteresis) (pulse) previously with the Return to the 1st gain when the absolut (level - hysteresis) (pulse) previously * Unit of level and hysteresis (pulse) is and external scale resolution for full-or 	te value of the pos e 1st gain. Iute value of the p over delay time wi s set as the encod	ositional dev th the 2nd g	viation was ko ain.	ept below
7	Position command exists	 Valid for position and full-closed control Shift to the 2nd gain when the position Return to the 1st gain when the positime with the 2nd gain. 	nal command was i		-	-
8	Not in positioning complete	 Valid for position and full-closed control Shift to the 2nd gain when the position Return to the 1st gain when the position during delay time with the 2nd gain. 	ning was not compl		-	-
9	Actual speed is large	 Valid for position and full-closed controls Shift to the 2nd gain when the absolysteresis (r/min) previously with the Return to the 1st gain when the absolysteresis (r/min) previously during of 	olute value of the 1st gain. ute value of the ac	tual speed v		
10	Position command exists + Actual speed	 Valid for position and full-closed contra- Shift to the 2nd gain when the position Return to the 1st gain when the positime and the absolute value of actual previously with the 2nd gain. 	nal command was i ositional command	l was kept	at 0 during 1	the delay

Pr1.16	Delay time of position control switching	Range	Unit	Default	Related control mode			
		0 to 10000	0.1 ms	50	P F			
For position controlling : When shifting from the 2nd gain to the 1st gain with Pr1.15 Position								

For position controlling : When shifting from the 2nd gain to the 1st gain with Pr1.15 Position control switching mode set at 3, 5, 6, 7, 8, 9 or 10, set up the delay time from trigger detection to the switching operation.

Note

• A parameter is designated as follows: Class Pro.00 Parameter No.

• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

6

5

7

Related page …

P.3-32... "Inputs and outputs on connector X4"

[Class 1] Gain adjustment

Pr1.17	Level of position control switching	Range	Unit	Default	Related control mode
P11.17	Level of position control switching	0 to 20000	Mode- dependent	50	P F
	For position controlling: Set up triggering level is set at 3, 5, 6, 9 or 10. Unit of setting varies with switching mode.		osition cor	ntrol switchi	ing mode
Caution 🔅	Set the level equal to or higher than the hyster	esis.			

Pr1.18	Hysteresis at position control switching	Range	Unit	Default	Related control mode				
F11.10	Hystelesis at position control switching	0 to 20000	Mode- dependent	33	Ρ		F		
For position controlling: Set up triggering hysteresis when Pr1.15 Position control switching mode is set at 3, 5, 6, 9 or 10. Unit of setting varies with switching mode.									
Caution 🔅	When level < hysteresis, the hysteresis is inter	mally adjusted s	o that it is	equal to lev	el.				

Pr1.19	Position goin owitabing time	Range	Unit	Default	Related control mode			
F11.19	Position gain switching time	0 to 10000	0.1 ms	33	P F			
	For position controlling: If the difference betwe 2nd gain of poison loop is large, the increasin this parameter. The position loop gain will increase over the tir	ng rate of position	•	•				
Caution ···	 <position gain="" switching="" time=""></position> When using position control and full-closed control, gain of position loop rapidly changes causing torque change and vibration. By adjusting Pr1.19 Position gain switching time increasing rate of the poison loop gain can be decreased and vibration level can be reduced Setting of this parameter does not affect the gain switching time when the gain of position loop is switched to lower level (gain is switched immediately). 							
	Example: 1st (Pr1.00) > 2nd (Pr1.05)							
	1st (Pr1.00) switch	on gain hing time (ms)		_				
Result of switching 1st 2nd 1st								

Note → A parameter is designated as follows: Class Pro. 00 Parameter No.
 For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.
 Related page → P.3-32... "Inputs and outputs on connector X4"

⁴⁻¹⁸ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

[Class 1] Gain adjustment

Pr1.20	Mode of ve	logity control owitch	ina	Range	Unit	Default	Related control mo	
r1.20	Mode of ve	Mode of velocity control switching			_	0	S	
	For velocity of	ontrolling: Set the con	dition to trig	gger gain switch	ing.			
	Setup value	Switching condition	Gain switching condition					
	[0]	Fixed to the 1st gain.	Fixed to the 1st gain (Pr1.00 to Pr1.04).					
	1	Fixed to the 2nd gain.	Fixed to the 2nd gain (Pr1.05 to Pr1.09).					
	2	Gain switching input	 1st gain when the gain switching input (GAIN) is open. 2nd gain when the gain switching input (GAIN) is connected to COM–. * If no input signal is allocated to the gain switching input (GAIN) the 1st gain is fixed. 				ected to	
	3	Torque command	 Shift to the 2nd gain when the absolute value of the torque command exceeded (level + hysteresis) (%) previously with the 1st gain. Return to the 1st gain when the absolute value of the torque command was kept below (level - hysteresis) (%) previously during delay time with the 2nd gain. 			usly with e torque		
	4	Speed command variation is larger.	 Shift to the command previously Return to comman (10 r/min/ 	during velocity cor ne 2nd gain when I variations exceed y with the 1st gain. the 1st gain wher d variations was s) during delay tim ain is fixed while th	the absolu ed (level + n the absolu kept below e previously	hysteresis) (10 ute value of th w (level - hys y with the 2nd y	o r/min/s) e speed steresis) gain.	

Pr1.2	Delay time of velocity control switching	Range	Unit	Default	Related control mode
F11.2	0 to 10	0 to 10000	0.1 ms	0	S
	For velocity controlling: When shifting from th control switching mode set at 3, 4 or 5, set switching operation.	•	•		-

Pr1.22	Level of velocity control switching	Range	Unit	Default	Related control mode		
Pr1.22			Mode- dependent	0	S		
For velocity controlling: Set up triggering level when Pr1.20 Velocity control gain switch mode is set at 3, 4 or 5.							
Caution 🔅							
	Set the level equal to or higher than the hyster	esis.					

Pr1.23	Hystoresis at valuaity control switching		Unit	Default	cor	Related control mode		
Pr1.25	Hysteresis at velocity control switching	0 to 20000	Mode- dependent	0		S		
	For velocity controlling: Set up triggering he switching mode is set at 3, 4 or 5.	ysteresis when	Pr1.20 V	elocity con	trol	ga	in	
Caution 🔅	Unit of setting varies with switching mode. When level < hysteresis, the hysteresis is internally adjusted so that it is equal to level.							
Note	• A parameter is designated as follows: Class	Pr0.00 Paramoto	r No					

Note A parameter is designated as follows: Class <u>Parameter No.</u>
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
 Related page :
 P.3-32... "Inputs and outputs on connector X4"

Connection

5

[Class 1] Gain adjustment

Pr1.24	Mode of to	rauo control owitchin		Range	Unit	Default	Related control me
F11.24	Mode of to	rque control switchin	ig	0 to 3	—	0	T
	For torque co	ontrolling: Set the cond	lition to trigg	ger gain switchir	ıg.		
	Setup value	Switching condition	Gain switching condition				
	[0]	Fixed to the 1st gain.	. Fixed to the 1st gain (Pr1.00 to Pr1.04).				
	1	Fixed to the 2nd gain.	n. Fixed to the 2nd gain (Pr1.05 to Pr1.09).				
	2	Gain switching input	 1st gain when the gain switching input (GAIN) is open. 2nd gain when the gain switching input (GAIN) is connected t COM–. * If no input signal is allocated to the gain switching input (GAIN the 1st gain is fixed. 				nected to
	3	Torque command	 Shift to the 2nd gain when the absolute value of the to command exceeded (level + hysteresis) (%) previously the 1st gain. Return to the 1st gain when the absolute value of the to command was kept below (level - hysteresis) (%) previously during delay time with the 2nd gain. 				usly with ne torque

Dr1	Pr1.25	Delay time of torque control switching	Range	Unit	Default	Related control mode
FII	.25		0 to 10000	0.1 ms	0	T
		For torque controlling : When shifting from the control switching mode set at 3, set up the del operation.	•	•		

Dr1 26	1.26 Level of torque control switching	Range	Unit	Default	Related control mod	le		
F11.20	Level of torque control switching	0 to 20000	Mode- dependent	0	T			
For torque controlling: Set up triggering level when Pr1.24 Torque control gain switching mode is set at 3. Unit varies depending on the setup of mode of control switching.								
Caution 🔅 Set the level equal to or higher than the hysteresis.								

Dr1	Pr1.27	Hysteresis at torque control switching	Range	Unit	Default	Related control mode			
FII.	.21		0 to 20000	Mode- dependent	0	T			
	For torque controlling: Set up triggering hysteresis when Pr1.24 Torque control gain switching mode is set at 3. Unit of setting varies with switching mode.								
Cautio	n 🔅	When level < hysteresis, the hysteresis is internally adjusted so that it is equal to level.							

 A parameter is designated as follows: Class <u>Pro.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

Related page P.3-32... "Inputs and outputs on connector X4"

[Class 2] Damping control

				5			Default Relate
Pr2.00	Adaptive fi	Iter mode setup		Range	Unit	Default	control m
				0 to 4	—	0	P S
		esonance frequency er estimation.	to be estir	nated by the a	daptive fi	lter and sp	ecify th
	Setup value			Content			
	[0]	Adaptive filter: invalid	current value.				ld the
	1	Adaptive filter: 1 filter is valid	One adaptive filter is enabled. Parameters related to the 3 notch filter will be updated based on adaptive performance				
	2	Adaptive filter: 2 filters are valid Two adaptive filters are enabled. Parameters related to 3rd and 4th notch filters will be updated based on adapt performance.					
	3	Resonance frequency measurement mode	can be che	ne resonance freq ocked with PANAT n notch filter hold t	ERM. Para	meters relate	
	4	Clear result of adaptation		s related to the 3r nd results of adap			-
	A5I 5	adaptationdisabled and results of adaptive operation are clearHigh-precisionTwo adaptive filters are enabled. Parameters relatadaptive filterand 4th notch filters will be updated basedresults of adaptive performance. Use of this setuprecommended when using 2 adaptive filters.			ated based o f this setup v	n the	
	A5II 6	For manufacturer's use	or manufacturer's PANATERM's fit gain function used internally.				

 Pr2.01
 1st notch frequency
 Related control mode

 50 to 5000
 Hz
 5000
 P S T F

 Set the center frequency of the 1st notch filter.

Caution 🔅 The notch filter function will be invalidated by setting up this parameter to "5000".

	Pr2.02	1st notch width selection	Range	Unit	Default	Related control mode
	F12.02		0 to 20	—	2	P S T F
		Set the width of notch at the center frequency	of the 1st notch	filter.		
Caution 🔅 Higher the setup, larger the notch width you can obtain. Use with default setup in norm operation.						

Pr2.03	1st notch depth selection	Range	Unit	Default	Related control mode			
P12.03		0 to 99	_	0	P S T F			
Set the depth of notch at the center frequency of the 1st notch filter.								
Caution 🔅	Caution 🔅 Higher the setup, shallower the notch depth and smaller the phase delay you can obtain.							

Pr2.04	2nd notch frequency	Range	Unit	Default	Related control mode			
F12.04		50 to 5000	Hz	5000	PSTF			
Set the center frequency of the 2nd notch filter.								
Caution The notch filter function will be invalidated by setting up this parameter to "5000".								

[Class 2] Damping control

Pr2.05	2nd notch width selection	Range	Unit	Default		lelate trol m	ed node
P12.05		0 to 20	—	2	Ρ	sт	' F
Caution	Set the width of notch at the center frequency Higher the setup, larger the notch width you can c			p in normal o	pera	atior	۱.

	Pr2.06	2nd notch depth selection	Range	Unit	Default	Related control mode		
			0 to 99	—	0	PSTF		
	Set the depth of notch at the center frequency of the 2nd notch filter.							
	Caution 🔅 Higher the setup, shallower the notch depth and smaller the phase delay you can obtain.							

Pr2.07	3rd notch frequency	Range	Unit	Default	Re	lated
P12.07	Sid noten nequency	50 to 5000	Hz	5000	PS	TF
Caution 🔅	Notch frequency is automatically set to the 1st results in no resonance point is found, the frequency is	, ,	estimated	l by the adapt	ive fil	ter.

Pr2.08	3rd notch width selection	Range	Unit	Default	Related control mode
F12.00	Sid holen width selection	0 to 20	—	2	PSTF
Caution ···	Set the width of notch at the center frequency Higher the setup, larger the notch width you can c When the applicable filter function is used, par	btain. Use with d	efault setu	•	peration.

Pr2.09	3rd notch depth selection	Range	Unit	Default	Related control mode
P12.09		0 to 99	—	0	P S T F
Caution 🔅	Set the depth of notch at the center frequency Higher the setup, shallower the notch depth ar When the applicable filter function is used, par	nd smaller the pl	nase delay		otain.

Pr2.10	4th notch frequency	Range	Unit	Default		Relate	
P12.10	4th hoten frequency	50 to 5000	Hz	5000	Ρ	ST	F
Caution ··*	Notch frequency is automatically set to the 2nd res The notch filter function will be invalidated by s	•	•	,	otive	filte	r.

Pr2.11	4th notch width selection	Range	Unit	Default	Related control mode
F12.11	411 Hotell width selection	0 to 20	—	2	PSTF
Caution 🔅	Set the width of notch at the center frequency Higher the setup, larger the notch width you can c When the applicable filter function is used, par	btain. Use with d	efault setu	•	peration.

Note
 A parameter is designated as follows: Class Problem: Orgen Parameter No.
 For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.
 P.3-32... "Inputs and outputs on connector X4"

[Class 2] Damping control

					Default: []
Pr2.12	4th notch depth selection	Range	Unit	Default	Related control mode
P12.12		0 to 99	—	0	P S T F
Caution ··;•	Set the depth of notch at the center frequency Higher the setup, shallower the notch depth ar When the applicable filter function is used, par	nd smaller the pl	nase delag		otain.
		_			Related

Pr2.13	Selection	of damping	filtor ewite	hing		Range	Unit D	efault	Relat control
F12.15	Selection		III.CI SWILL	inng		0 to 3	_	0	P
	• When setu	up value is 0	Up to 2 filte	ers can be ı	used	ping control. I simultaneou ternal input(s)	-	nd/or V	S-SEL2
	Setup value	VS-SEL2	VS-SEL1	1st dampi	ng	2nd damping	3rd damping	4th da	mping
	[0]	_	_	0		0			
	1	—		0			0		
	1	_	0			0		()
				0					
	2	\frown	0		_	0	0		
	-	0	0				0)
						l eline etiene)
	• With setup	value 3: Se	lect the filte	r with comn	nanc	direction.			
	Setup value	Position o direc	tion	1st dampi	ng	2nd damping	3rd damping	4th da	mping
	3	Positive		0			0		
	Ŭ	Negative	direction			0			D
	shown belowWhen theWhen setu	w (only 1 fun setup value	ction can be is 0, only 1s	e used at th t damping i	e sa s en	,			
	 shown below When the When seture 	w (only 1 fun setup value	ction can be is 0, only 1s	e used at th t damping i he filter with	e sa s en n ext	ame time). abled.	(VS-SEL1 a	nd/or V	S-SEL2
	shown belowWhen theWhen setu	w (only 1 fun setup value Ip value is 1 d	iction can be is 0, only 1s or 2: Select t	e used at th t damping i he filter with	e sa s en n ext	ame time). habled. ternal input(s)	(VS-SEL1 a	nd/or V	S-SEL2
	shown belov • When the • When setu • When setu value [0]	w (only 1 fun setup value p value is 1 d VS-SEL2	iction can be is 0, only 1s or 2: Select t	e used at th t damping i he filter with 1st damp	e sa s en n ext	ame time). habled. ternal input(s)	(VS-SEL1 a	nd/or V	S-SEL2
	 shown below When the When seture Setup value 	w (only 1 fun setup value p value is 1 d VS-SEL2	iction can be is 0, only 1s or 2: Select t VS-SEL1	e used at th t damping i he filter with 1st damp	e sa s en n ext	ame time). habled. ternal input(s)	(VS-SEL1 a	nd/or V	S-SEL2
	shown belov • When the • When setu • When setu value [0]	w (only 1 fun setup value p value is 1 d VS-SEL2	iction can be is 0, only 1s or 2: Select t VS-SEL1 — OFF	e used at th t damping i he filter with 1st damp	e sa s en n ext	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	nd/or V	S-SEL2
	shown belov • When the • When setu • When setu value [0] 1	w (only 1 fun setup value ip value is 1 d VS-SEL2 — — — —	ction can be is 0, only 1s or 2: Select 1 - OFF ON OFF ON	e used at th t damping i he filter with 1st damp	e sa s en n ext	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	nd/or V	S-SEL2
	shown belov • When the • When setu • When setu value [0]	w (only 1 fun setup value p value is 1 d VS-SEL2 — — — — — — — OFF OFF ON	ction can be is 0, only 1s or 2: Select t VS-SEL1 — OFF ON OFF ON OFF	e used at th t damping i he filter with 1st damp	e sa s en n ext	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	nd/or V	S-SEL2
	shown belov • When the • When setu • When setu value [0] 1	w (only 1 fun setup value p value is 1 o VS-SEL2 — — — — — — — OFF OFF	ction can be is 0, only 1s or 2: Select 1 - OFF ON OFF ON	e used at th t damping i he filter with 1st damp	e sa s en n ext	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	nd/or V	S-SEL2
	shown belov • When the • When setur Value [0] 1 2	w (only 1 fun setup value p value is 1 d VS-SEL2 — — — — — — — OFF OFF ON	or 2: Select 1 	e used at the t damping is the filter with 1st damp	e sa s en n ext	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	nd/or V	S-SEL2
	shown belov • When the • When setur Value [0] 1 2	w (only 1 fun setup value p value is 1 d VS-SEL2 — — — — — — — — — — — — — — — — — — —	or 2: Select 1 	e used at the t damping i he filter with 1st damp 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	e sa s en n ext iing	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	and/or Va	S-SEL2
	shown belov • When the • When setur [0] 1 2 • With setup value Setup value	w (only 1 fun setup value p value is 1 d VS-SEL2 — — — — — — — — — — — — — — — — — — —	ction can be is 0, only 1s or 2: Select 1 	e used at the t damping i he filter with 1st damp 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	e sa s en n ext iing	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	and/or Va	S-SEL2
	shown belov • When the • When setur [0] 1 2 • With setur Setur Setur	w (only 1 fun setup value p value is 1 d VS-SEL2 — — — — — — — — — — — — — — — — — — —	ction can be is 0, only 1s or 2: Select 1 - OFF ON OFF ON OFF ON lect the filter command ction	e used at the t damping i he filter with 1st damp 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	e sa s en n ext iing	ame time). habled. ternal input(s) 2nd damping	(VS-SEL1 a	and/or Va	S-SEL2
	shown belov • When the • When setue [0] 1 2 • With setue Setup value 3 • Switching pulses/0.16 When the o	w (only 1 fun setup value p value is 1 d VS-SEL2 — — — — — — — — — — — — — — — — — — —	ction can be is 0, only 1s or 2: Select 1 – OFF ON OFF ON OFF ON lect the filter command ction direction e direction	e used at the t damping is the filter with 1st damp O O O O O O O O O O O O O O O O O O O	e sa s en n ext bing nanc bing	ame time). habled. ternal input(s) 2nd damping 	(VS-SEL1 al	and/or Va	S-SEL2 amping
	shown belov • When the • When setur [0] 1 2 • With setur Setur value 3 • Switching pulses/0.16 When the opulses are	w (only 1 fun setup value p value is 1 o VS-SEL2 — — — — — — — — — — — — — — — — — — —	ction can be is 0, only 1s or 2: Select 1 – OFF ON OFF ON OFF ON lect the filter command ction direction e direction on trols will be changed from ency is incre lter at that time	e used at the t damping is the filter with 1st damp 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	e sa s en n ext bing nanc bing posit bled epres	ame time). habled. ternal input(s) 2nd damping 	(VS-SEL1 al	g 4th d	S-SEL2 amping
	shown belov • When the • When setur [0] 1 2 • With setur Setur value 3 • Switching pulses/0.16 When the opulses are filter subtrace	w (only 1 fun setup value p value is 1 o VS-SEL2 — — — — — — — — — — — — — — — — — — —	ction can be is 0, only 1s or 2: Select 1 OFF ON OFF ON OFF ON Iect the filter command ction direction e direction ontrols will be a changed from ler at that timus ue of position	e used at the t damping is the filter with 1st damp 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	e sa s en n ext ing nanc ing ne ris posit bled ter fil	ame time). habled. ternal input(s) 2nd damping 	(VS-SEL1 al	and/or V 4th d 4th d 4th d 4th d 4th d 5 5 6 7 7 7 7 7 7 7 7 7 7	S-SEL2 amping amping amping humber large, a and befor that sin

Before Using the Products

5

[Class 2] Damping control

		Range	Unit	Default	Relat control	
Pr2.14	1st damping frequency	0 to 2000	0.1 Hz	0	Р	F
		A5II 0 to 3000	0.1112	0		
		Range	Unit	Default	Relat control	
Pr2.16	2nd damping frequency	0 to 2000	0.1 Hz	0	Р	F
		A5II 0 to 3000	0.1 HZ	0		
		Range	Unit	Default	Relat control	
Pr2.18	3rd damping frequency	0 to 2000	0.1 Hz	0	Р	F
		A5II 0 to 3000	0.1 HZ	0		
		Range	Unit	Default	Relat control	
Pr2.20	4th damping frequency	0 to 2000	0.1 Hz	0	Р	F
		A5I 0 to 3000	0.1 HZ	U		
	You can set up the 1st to 4th damping f vibration at the load edge. The driver measures vibration at load edg			ntrol which a	suppre	SS
	The setup frequency is 1.0 to 200 $0[H_7]$	Saturn of 0 to 0 hoos	moo involi	d		

The setup frequency is 1.0 to 200.0[Hz]. Setup of 0 to 9 becomes invalid. Effective frequency range for A5 II series is 1.0 Hz to 300.0 Hz.

* A5I represents setting range applied to A5I series.

Related page 🔅 Refer to P.5-34, "Suppression of Machine Resonance" as well before using this parameter.

		Range	Unit	Default	Related control mode
Pr2.15	1st damping filter setup	0 to 1000	0.1 Hz	0	P F
		A5I 0 to 1500	0.1112	0	
		Range	Unit	Default	Related control mode
Pr2.17	2nd damping filter setup	0 to 1000	0.1 Hz	0	P F
		A5I 0 to 1500	0.1 HZ	0	
		Range	Unit	Default	Related control mode
Pr2.19	3rd damping filter setup	0 to 1000	0.1 Hz	0	P F
		A5I 0 to 1500	0.1112	0	
		Range	Unit	Default	Related control mode
Pr2.21	4th damping filter setup	0 to 1000	0.1 Hz	0	P F
		A5I 0 to 1500	0.1112	U	
	If torque saturation occurs with damping free	equency (1st- 4th)	enabled,	decrease t	he setup
	value, or if the operation is slow, increase it.	,			·

* A5I represents setting range applied to A5I series.


Caution The maximum setup value is internally limited to the corresponding damping frequency or 2000 - damping frequency, whichever is smaller.

However, with A5I series, the upper setup value is internally limited to the corresponding damping frequency or (3000 - damping frequency), whichever the lower.

Related page 🔅 Refer to P.5-38, "Damping control" as well before using this parameter.

Note · A parameter is designated as follows: Class <u>Pr0.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
 Related page · P.3-32... "Inputs and outputs on connector X4"

[Class 2] Damping control



Before Using the Products

2


[Class 2] Damping control

A5II					Data
Pr2.22	Command smoothing filter	Range 0 to 10000	Unit 0.1 ms	Default 0	P S
	 [Position control mode] With previous control (Pr6.47 bit0 = 0) Set the time constant of the 1st delay filter in In the two-degree-of-freedom control mode (Time constant of the command response filter The maximum value is limited by 2000 (= 20) 	response to the Pr6.47 bit0 = 1) er	1		
	 [Speed control mode] With previous control (Pr6.47 bit0 = 0) This setting is ignored. In the two-degree-of-freedom control mode (Time constant of the command response filte The maximum value is limited by 640 (= 64.0 	er			
elated page 🔅	For Two-degree-of-freedom control mode, ref		-64).		
	 [Full-closed control mode] Always set the time constant of the 1st delay * The value of the parameter is not limited but attenuation term in Pr6.49 [Set attenuation term 	the value to be	applied to	driver is lim	nited. Se
	 When a square wave command for the targe of the 1st delay filter as shown in the figure b 	t speed Vc is ap	-		-
	Speed Positional command before [r/min] Vc Vc Positional command Vc Positional command Vcx0.632 *1 Positional comm Vcx0.368 *1 Positional comm	after filter and smoothing ms]	Filter swi	me *2	
	 *1 Actual filter time constant (setup value × 0.1 ms) constant below 100 ms and the maximum relative *2 Switching of Pr2.22 Positional command smoothin with the number of command pulses/0.166 ms is positioning complete is being output. If the filter time constant is decreased and positior of plusses are accumulated in the filter (the area e of positional command after filter" integrated over discharged at a higher rate, causing the motor to speed higher than the command speed for a short *3 Even if Pr2.22 Positional command smoothing f switching as described in *2 occurs during this delivered. 	error of 0.2 % for a g filter is performed is changed from 0 hing complete rang equivalent of "value r the time), at the p return to the prev time. filter is changed, i	time consta d on the risir to a value e is increas of positiona time of swit vious positionation t is not app	ant 20 ms or n ng edge of the other than 0 ed, and a ma al command fi ching, these on - the motor	nore. command while the ny numbe ter - value bulses are runs at a tely. If the

A parameter is designated as follows: Class <u>119.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

Related page • P.3-32... "Inputs and outputs on connector X4"

[Class 2] Damping control



5

∆djustment

Connection

• A parameter is designated as follows: Class Pro.00 Parameter No. Note • For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power. Related page … • P.3-32... "Inputs and outputs on connector X4"

[Class 2] Damping control

A5I						
Pr2.23	Command FIR filter	Range	Unit	Default	Rela control	ated I mod
112120		0 to 10000	0.1 ms	0	P S	F
telated page	[Position control mode / Full-closed control • Set up the time constant of FIR filter in respo [Speed control mode] • With previous control (Pr6.47 bit0 = 0) This setting is ignored. • In the two-degree-of-freedom control mode (frime constant of the command response filter The maximum value is limited by 640 (= 64.0) For Two-degree-of-freedom control mode, refe • When a square wave command for the target of the 1st delay filter as shown in the figure be Speed [r/min] Vc Positional command before filter Positional command after filter (Pr2.23 × 0.1 ms)*1 *1 The actual average travel time (setup value × 0.1 ms × 1 time constant below 10 ms and the maximum relati *2 When changing Pr2.23 Command FIR filter, stop wait time has elapsed. The filter switching wait time setup time is 10 ms, and setup value × 0.1 ms × 1 changed while the command pulse is being input,	I mode] nse to the comr Pr6.47 bit0 = 1) r ms).* r to Pr6.47 (P.4- t speed Vc is ap elow. Filter waiti ms) has the maxive error of 1.6 % f the command pul- me is the setup va- .05 when the setup	-64). oplied, set r switching ng time *2 Time imum absolu for a time col se and wait alue × 0.1 m p time is 10	up the time ute error of 0. nstant 10 ms until the filter ns + 0.25 ms ms or more. I	2 ms fc or more switch f Pr2.22	or a e. iing the 3 is

Note
 A parameter is designated as follows: Class Problem: Orgen Parameter No.
 For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.
 P.3-32... "Inputs and outputs on connector X4"

[Class 3] Velocity/ Torque/ Full-closed control

								Defau	
r3.00	Speed or	tup, Internal/Exter	nal ewitching	Rar	nge	Unit	Default	Relat control r	
5.00	Speed 30		nai switching	0 to	53	—	0	S	
		is equipped with int t inputs only.	ernal speed se	tup funct	tion so tha	t you ca	an control th	ne spee	
	Setup valu	e	Spe	ed setup	method				
	[0]	Analog speed co	mmand (SPR)						
	1	Internal speed co	mmand 1st to 4th	n speed (Pr3.04 to P	r3.07)			
	2	Internal speed co Analog speed co		d speed (Pr3.04 to P	r3.06),			
	3	Internal speed co		n speed (Pr3.04 to P	r3.11)			
		ship between Pr3.0 ommand speed sele Selection 1 of internal command speed (INTSPD1)		3, and s of and in		nmand 3 of Imand	-	cted>	
		OFF	OFF		peed (1st spe	ed	
	1	ON			No effec	-+	2nd sp	eed	
	1	OFF ON			NO ellec	JL	3rd spe	eed	
		ON	ON				4th spe	eed	
		OFF	OFF				1st spe		
		ON	OFF		Nie offen		2nd sp		
	2	OFF	ON		No effec	Ct	3rd spe		
		ON	ON				Analog s comma		
		The same a	as Pr3.00=1		OFF		1st to 4th		
		OFF	OFF		ON		5th spe	eed	
	3	ON	OFF		ON		6th spe	ed	
		OFF	ON		ON		7th spe	eed	
		ON	ON		ON		8th spe	ed	
	that single simultaned	open COM- 4th 2nd	selected alternative ternal comman	ately. If 2 d speed tting will INTS INTS Sp	2 or more may be a cause une SPD1 oper SPD2 oper SPD3 oper eed mand		signals are htly selected	selected, who	
	[r/min]				min]	Ist		<u>1st</u>	
	Ex	ample 1) When Pr3.00=	1 or 2		Example	e 2) Whe	en Pr3.00=3		

	Pr3.01	Speed command rotational direction			Range		Unit Defau		control mode				
		selection			0 to 1		—	0			S		
Select the Positive/Negative direction specifying method.													
		Setup valueSelect speed command sign (1st to 8th speed)Speed command direction (VC-SIGN)		ction	Position command direction								
		[0]	+	No effect		F	Positive direction						
		[0]	-	No e	effect	N	egative dir	ection					
		1	Sign has no effect.	0	FF	F	Positive dire	ection					
		I	Sign has no effect.	C	DN	N	egative dir	ection					

2


Preparation

5

7

Supplement

[Class 3] Velocity/ Torque/ Full-closed control




Pr3.03	Reversal of speed command input		Range	Unit	Default	Related control mode				
P13.03	neversal o	i speed com	nanu input	0 to 1	—	1	S			
	Specify the polarity of the voltage applied to the analog speed command (SPR).									
	Setup value Motor rotating direction									
	0 Non-reversal "+Voltage" → "Positive direction", "-Voltage" → "Negative dire						ction"			
	[1]	Reversal "+Voltage" → "Negative direction", "–Voltage" → "Positive direction"								
Note 🔅	Default of this parameter is 1, and the motor turns to CW with (+) signal, this has compatibility to existing MINAS series driver.									
Caution 🔅	When you compose the servo drive system with this driver set to velocity control mode and external positioning unit, the motor might perform an abnormal action if the polarity of the speed command signal from the unit and the polarity of this parameter setup does not match.									

Note	 A parameter is designated as follows: Class Provide Parameter No.
	• For parameters which No. have a suffix of " * ", changed contents will be validated when
	you turn on the control power.
	 Only for position control type is not provided with analog input.

Related page • P.3-32... "Inputs and outputs on connector X4"

[Class 3]	Velocity/ T	orque/ F	Full-closed	control
-----------	-------------	----------	-------------	---------

Pr3.04	1st speed of speed setup	Range	Unit	Default	Related control mode
P13.04	ist speed of speed setup	-20000 to 20000	r/min	0	S
D#2.05	and encod of encod actum	Range	Unit	Default	Related control mod
Pr3.05	2nd speed of speed setup	-20000 to 20000	r/min	0	S
Pr3.06	2rd aroad of aroad actur	Range	Unit	Default	Related control mod
F13.00	3rd speed of speed setup	-20000 to 20000	r/min	0	S
D#2.07	4th speed of speed setup	Range	Unit	Default	Related control mod
Pr3.07		-20000 to 20000	r/min	0	S
D-0.00	5th speed of speed setup	Range	Unit	Default	Related control mod
Pr3.08		-20000 to 20000	r/min	0	S
Pr3.09	6th speed of speed setup	Range	Unit	Default	Related control mod
P13.09	on speed of speed setup	-20000 to 20000	r/min	0	S
Pr3.10	7th around of around actum	Range	Unit	Default	Related control mod
F13.10	7th speed of speed setup	-20000 to 20000	r/min	0	S
Pr3.11	9th aroad of aroad actur	Range	Unit	Default	Related control mod
FIJ.11	8th speed of speed setup	-20000 to 20000	r/min	0	S
	Set up internal command speeds, 1st to 8t	h.			



command after acceleration/deceleration, result is "acceleration" and if the reverse direction, the result is "deceleration".

Note · A parameter is designated as follows: Class Pro. 00 Parameter No.

• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

P.3-32... "Inputs and outputs on connector X4"

4

Setup

Before Using the Products

2

[Class 3] Velocity/ Torque/ Full-closed control

Default: [] Related control mode Range Unit Default Sigmoid acceleration/ deceleration time Pr3.14 setup 0 to 1000 0 S ms Set S-curve time for acceleration/deceleration process when the speed command is applied. According to Pr3.12 Acceleration time setup and Pr3.13 Deceleration time setup, set up sigmoid time with time width centering the inflection point of acceleration/deceleration. ts Speed command after Speed acceleration/deceleration [r/min] process Target speed (Vc) $ta = Vc/1000 \times Pr3.12 \times 1 ms$ $td = Vc/1000 \times Pr3.13 \times 1 ms$ ts ts $ts = Pr3.14 \times 1 ms$ * Use with the setup of ta/2 > ts, td/2 > tsTime ta td

Pr3.15	Spood Tora	alown function coloction	Range	Unit	Default	Related control mo	
P13.15	Speed zero	o-clamp function selection	0 to 3	—	0	S T	
	You can set u	up the function of the speed zero	clamp input.				
	Setup value	Function	of ZEROSPD (P	in-26)			
	[0]	Invalid: Speed zero-clamp input is ig	gnored.				
	1	Speed command is forced to 0 when the speed zero clamp (ZEROSPD) input signal is turned ON *1.					
2 Speed command is forced to 0 when the speed zero clamp (ZEROSPD) is turned ON ^{*1} . And when the actual motor speed drops to Pr3.16 Speed level or below, the position control is selected and servo lock is activated a The fundamental operations except for this function (switching to the posit are identical to those when setup value is 1.					16 Speed zer activated at the	o clamp is point.	
		When the speed zero clamp (ZEROSPD) input signal is ON ^{*1} and speed command is below Pr3.16 Speed zero clamp level –10 r/min, then the position control is selected and servo lock is activated at that point.					

Pr3.16	Speed zero clamp level	Range	Unit	Default	Related control mode
P13.10	Speed zero clamp level	10 to 20000	r/min	30	ST
	Select the timing at which the position control function selection is set to 2 or 3. If $Pr3.15 = 3$, then hysteresis of 10 r/min is pro-			5 Speed ze	ro-clamp

Note

- A parameter is designated as follows: Class Pro.00 Parameter No.
- For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.
- Related page P.3-32... "Inputs and outputs on connector X4"

[Class 3] Velocity/ Torque/ Full-closed control

Pr3.17	Soloction of	ftorque command	Range	Unit	Default	Related control mod
FI3.17	Selection of torque command		0 to 2	—	0	T
	You can selec	t the input of the torque comma	nd and the speed	d limit.		
	Setup value	Torque command input	Velocity lir			
	[0]	Analog input 1 ^{*1} (Al1, 16-bit resolution)	5 1			
	1	Analog input 2 (Al2, 12-bit resolution)	Analog i (Al1, 16-bit r	•		
	2	Analog input 1 ^{*1} (AI1, 16-bit resolution)	Parameter value (Pr3.21, Pr3.22)			

Pr3.18	Torque cor	nmand direction selection	Range	Unit	Default	Related control mode		
PI3.10	10.10 Torque command direction selection			—	0	T		
	Select the direction positive/negative direction of torque command.							
	Setup value	Designation						
	[0]	Specify the direction with the sign of torque command. Example: Torque command input (+) for positive direction, (–) for negative direction						
	1	Specify the direction with torque command sign (TC-SIGN). OFF: Positive direction, ON: Negative direction						

Pr3.19	Input gain of torque command	Range	Unit	Default	Related control mode
P13.19	input gain of torque command	10 to 100	0.1 V/100 %	30	T
	Based on the voltage (V) applied to the ar conversion gain to torque command (%).	nalog torque co	ommand ((TRQR), se	t up the
	 Unit of the setup value is [0.1 V/100 %] and set up input voltage necessary to produce the rated torque. Default setup of 30 represents 3 V/100 %. 				0 V und input

Pr3.20		col of torau	acommand	Range	Unit	Default	Related control mode	
F13.20	input revei	rsal of torque	commanu	0 to 1	—	0	T	
Set up the polarity of the voltage applied to the analog torque command (TRQR).								
	Setup value		Direction of motor output torque					
	[0]	Non-reversal "+Voltage" \rightarrow "Positive direction", "–Voltage" \rightarrow "Negative direction"						
	1	Reversal "+Voltage" → "Negative direction", "–Voltage" → "Positive direction"						

Before Using the Products

2

Adjustment

[Class 3] Velocity/ Torque/ Full-closed control

Pr3.21	Speed limit value 1	Range	Unit	Default	Related control mode	
	0 to 20000 r/min 0					
	Set up the speed limit used for torque controll	ina				
	During the torque controlling, the speed set by	•	value can	not ha avce	hahad	
	When $Pr3.17 = 2$, the speed limit is applied up	•				
	V V DED PG 17 = 7 THE SDEED II THE IS ADDIED UP	on receivina pos	silive airec	lion comma	and.	

Pr3.22	Sneed li	Speed limit value 2			F	lange	Unit	Default	Related control mod
F13.22	Speed in				0 to	20000	r/min	0	T
	Speed limit value of negative direction command when $Pr3.17 = 2$.								
Pr3.17	Pr3.21	Pr3.22	Pr3.15	Speed zero ((ZEROSP			g torque d direction	Speed lim	nit value
		0		No effect	t			Pr3.21 set	up value
0	0 to 20000	No effect	1 to 3	OFF	No effect		No effect		up value
			1 10 3	ON				0	
	0 to 20000	0 to 20000	0	No effec	. +	Positive direction		Pr3.21 set	up value
	0 10 20000	0 10 20000	U	NO ellec	<i>.</i> L	Negative	e direction	Pr3.22 set	up value
2	0 to 20000	0 to 20000	1 to 3	OFF		Positive	direction	Pr3.21 set	up value
	0 10 20000	0 10 20000	1103			Negative	e direction	Pr3.22 set	up value
	0 to 20000	0 to 20000	1 to 3	ON	ON No effect		0		

Pr3.23 *	Extorn	al scale selection		Range	Unit	Default	Related control mode
P13.23	Extern			0 to 2	—	0	F
	Select th	ne type of external scale.					
	Setup value	External scale type		Compatible sca		oatible eed	
	[0]	A,B phase output type *1	External se	cale of A, B phase		Mpps adrupled)	
	1	Serial communication type (incremental version) *1	-	le Co., Ltd. R85, SL700, SL7	to 400	to 400 Mpps	
	2	Serial communication type (absolute version) *1		ST771A, ST773A le Co., Ltd.	to 400) Mpps	
*1 Connect the external scale so that it increments the count as the motor shaft turns positive direction, and decrements as the shaft turns negative direction. If this connection arrangement is impossible due to installation condition, etc., use the count reverse function of Pr3.26 Reversal of direction of external scale.							
Caution 🔅							he serial

Note	• A parameter is designated as follows: Class Pro.00	Parameter No.

• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

[Class 3] Velocity/ Torque/ Full-closed control

						Default: []
	Set	Numerator of external scale division	Range	Unit	Default	Related control mode
Pr3.24 *		Numerator of external scale division	0 to 1048576	—	0	F
		Set up the numerator of the external scale divi When setup value = 0, encoder resolution is u	•	or of the d	ivision.	

Pr3.25 *	Denominator of external scale division	Range	Unit	Default		ated I mode	
F13.25	Denominator of external scale division	1 to 1048576	_	10000		F	
	• Check the number of encoder feedback pluse external scale pulses per one motor revoluti scale division (Pr3.24) and the denominator the expression shown below.	on, and then se	t up the n	umerator o	f exter	mal	
	With Pr3.24 set at 0, the encoder resolution i	s automatically ι	used as ni	umerator.			
Example: When ball screw pitch is 10 mm, scale 0.1 _m/pulse, encoder resolution 20 bits							
(1048576 pulses);							

Pr3.24 1048576	Encoder resolution per one motor revolution [pulse]
Pr3.25 100000	External scale resolution per one motor revolution [pulse]

Caution If this ratio is wrong, the difference between the position calculated based on the encoder pulses and the position calculated based on the external scale pulses becomes large over a long travel distance and will activate the excess hybrid deviation error protection.

Pr3.26 *	Povorcal o	f direction of external scale	Range	Unit	Default		Relat ntrol r		
F13.20	neversar u		0 to 1	—	0			F	
Reverse the direction of external scale, feedback counter.									
	Setup value Content								
	[0]	Count value of external scale can b	be used as it is.						
1 Sign (positive/negative) of count value of external scale should be inverted.									
Note Sor setting method of this parameter, refer to P.3-12 Full closed control mode.									

Pr3.27 *	External so	External scale Z phase disconnection		Unit	Default	Related control mode
P13.27	detection d	lisable	0 to 1	_	0	F
	Enable/disab is used.	le Z-phase disconnection detection	on when A, B ph	ase outpu	it type exter	nal scale
	Setup value	Content				
	[0]	Valid				
	1	Invalid				

Before Using the Products

2

Preparation

5

Note

A parameter is designated as follows: Class <u>Pr0.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when

Related page ↔ • P.3-32... "Inputs and outputs on connector X4" • P.6-2 "Protective Function"

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

[Class 3] Velocity/ Torque/ Full-closed control

					Default: [
Pr3.28 *	Hybrid deviation excess setup	Range	Unit	Default	Related control mode
F13.20	hybrid deviation excess setup	1 to 134217728	Command unit	16000	F
	You can setup the permissible gap (hybrid data and the present external scale position.	eviation) betwee	en the pre	esent motor	position
Pr3.29 *	Hybrid doviation about actum	Range	Unit	Default	Related control mode
P13.29 *	Hybrid deviation clear setup	0 to 100	Revolution	0	F
Caution 🔅	As the motor turns the number of revolutions cleared to 0. No clearing is made with setup va < Hybrid deviation clear feature> As the motor reaches the number of revolution clear the hybrid deviation to 0. This feature a where hybrid deviation accumulate due to slipp Hybrid deviation value (command unit) (absolute value) Pr3.28 (Hybrid deviation excess setup) Pr3.29 (Hybrid deviation clear set Note: Revolution in the hybrid deviation clear set To use the hybrid deviation clear, be sure to s appropriate value. If the setup value is too str deviation excess setup, abnormal operation cannot be protected.	alue 0. Ins set by Pr3.29 allows the motor page, etc. Excess (Hybrid de up is counted by u set Pr3.29 Hybr nall with respect	P Hybrid d r to be us s hybrid dev Pr3.29 eviation clea No. of n sing encod id deviatio	eviation clea ed in an ap viation error ar setup) notor revolution ler feedback pon clear setu lue of Pr3.2	ar setup, plication ons [rev] pulses. up to the 8 Hybrid

Note
 A parameter is designated as follows: Class Problem: Orgen Parameter No.
 For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.
 P.3-32... "Inputs and outputs on connector X4"

[Class 4] I/F monitor setting

	1					
Pr4.00 *	SI1 input selection	Range	Unit	Default	Related control mo	
P14.00	Sit input selection	0 to 00FFFFFFh		00828282h (8553090)	P S T	
	Assign functions to SI1 inputs. These parameters are presented in hexadecided Hexadecimal presentation is followed by a sp $0 \ 0 \ - \ - \ - \ + \ + \ + \ + \ + \ + \ +$	pecific control mod ol				
	For the function number see the table below.	Logical setup is a	also a functi	on number	:	
	Title Symbol Setup value					
	-	• • • • • •	a-contact	b-conta		
	Invalid	-	00h	Do not se		
	Positive direction over-travel inhibition input	POT	01h	81h		
	Negative direction over-travel inhibition input	NOT	02h	82h		
	Servo-ON input *1	SRV-ON	03h	83h		
	Alarm clear input	A-CLR	04h	Do not se		
	Control mode switching input *2	C-MODE	05h	85h		
	Gain switching input	GAIN	06h	86h		
	Deviation counter clear input *3	CL	07h	Do not se	etup.	
	Command pulse inhibition input *4		08h	88h		
	Torque limit switching input	TL-SEL VS-SEL1	09h	89h		
	Damping control switching input 1	VS-SEL1 VS-SEL2	0Ah	8Ah		
	Damping control switching input 2	DIV1	0Bh	8Bh		
	Electronic gear switching input 1 Electronic gear switching input 2	DIV1 DIV2	0Ch 0Dh	8Ch 8Dh		
	Selection 1 input of internal command speed	INTSPD1	0Eh	8Eh		
	Selection 2 input of internal command speed	INTSPD1	0En 0Fh	8Fh		
	Selection 2 input of internal command speed	INTSPD3	10h	90h		
	Speed zero clamp input	ZEROSPD	11h	91h		
	Speed command sign input	VC-SIGN	12h	92h		
	Torque command sign input	TC-SIGN	13h	93h		
	Forced alarm input	E-STOP	14h	94h		
	Inertia ratio switching input	J-SEL	15h	95h		
Note 🔅	For input pin assignment with default setting, Related page P.3-52 <example change="" of=""> To change the default setting "Negative of modes) for b-contact to for a-contact, set the * For easier setting, use the setup support setting</example>	direction over-tra e input to 000202	ivel inhabit 02h.		t" (in all	
Caution 🔅	 Do not setup to a value other than that specific Do not assign specific function to 2 or meterr33.0 I/F input multiple assignment error 1 *1 Servo-on input signal (SRV-ON) must be used to *2 When using control mode switching input (C-Moset to only 1 or 2 control modes, Err33.2 I/F inpunumber error 2 will be generated. The control input pin set to invalid state does n Function (servo-on input, alarm clear, etc.) to the same pin with correct logical arrangement assignment error 1 or Err33.1 I/F input multiple *3 Deviation counter clear input (CL) can be assigned. 	ore signals. Dupl or Err33.1 I/F inp o enable servo-on. DDE), set the signal out function number ot affect any operation be used in multiple of t. Incorrect setting we assignment error 2.	to all control error 1 or Err on. control modes vill cause Erro	assignmen modes. If the 33.3 I/F inpu s must be as 33.0 I/F inpu	t error 2. e signal is it function ssigned to it multiple	
	 Err33.6 Counter clear assignment error. *4 Command pulse inhibit input (INH) can be ass Err33.7 Command pulse input inhibit input. *5 Note that the front panel indicates parameter values. 			assignment	will cause	

2

Preparation

1

3

5

7

Supplement

[Class 4] I/F monitor setting

	SI2 input selection	Range	Unit	Default	Related control mode
Pr4.01 *	SI2 input selection	0 to 00FFFFFh	_	00818181h (8487297)	P S T F
		Range	Unit	Default	Related control mode
Pr4.02 *	SI3 input selection	0 to 00FFFFFFh	_	0091910Ah (9539850)	P S T F
	SI4 input selection	Range	Unit	Default	Related control mode
Pr4.03 *		0 to 00FFFFFFh	_	00060606h (394758)	P S T F
	SI5 input selection	Range	Unit	Default	Related control mode
Pr4.04 *		0 to 00FFFFFFh	_	0000100Ch (4108)	P S T F
		Range	Unit	Default	Related control mode
Pr4.05 *	SI6 input selection	0 to 00FFFFFFh	_	00030303h (197379)	P S T F
Pr4.06 *		Range	Unit	Default	Related control mode
	SI7 input selection	0 to 00FFFFFFh	_	00000f07h (3847)	P S T F


Caution \therefore Deviation counter clear (CL) can be set up only with this parameter. If any other parameter is used for this purpose, Err33.6 Counter clear assignment error will be issued.

D 4 07 *	SI8 input selection	Range	Unit	Default	Related control mode		
Pr4.07 *	SI8 input selection	0 to 00FFFFFFh	_	00040404h (263172)	P S T F		
	SI9 input selection	Range	Unit	Default	Related control mode		
Pr4.08 *		0 to 00FFFFFFh	_	00050505h (328965)	P S T F		
	SI10 input selection	Range	Unit	Default	Related control mode		
Pr4.09 *		0 to 00FFFFFFh	—	00000E88h (3720)	P S T F		
	Assign functions to SI2 to SI10 inputs.						
	These parameters are presented in hexadecimals.						

Setup procedure is the same as described for Pr4.00.

Note \rightarrow For input pin assignment with default setting, also refer to P.3-39 Control input.

Caution ··· Command pulse inhibition input (INH) can be setup only with this parameter. If any other parameter is used for this purpose, Err33.7 INH assignment error will be issued.



• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

Related page • P.3-32... "Inputs and outputs on connector X4" • P.6-2 "Protective Function"

			Range	Unit	Default	Related control mod	
Pr4.10 *	SO1 out	put selection	0 to 00FFFFFFh	-	00030303h (197379)	PSTF	
	Assign fur	nctions to SO1 outputs.					
	These par	rameters are presented in hexadecir	nals. *1				
	Hexadecii	mal presentation is followed by a spe	ecific control mo	de desian	ation.		
		- * * h : position/full-closed contro		Ũ			
		* – – h : velocity control					
		– – – h : torque control					
		* with the function number.					
	•	nction number see the table below. I	ogical setun is	also a fun	ction number		
						•	
	Setup value	Title	Symbol	Note			
	00h	Invalid		•	t pin assignm		
	01h	Servo alarm output	ALM	 default setting, also refer to P.3-47 Output signals (common and their functions. 			
	02h	Servo-Ready output	S-RDY				
	03h	External brake release signal	BRK-OFF				
	04h	Positioning complete output	INP	Related page	·: P.3-54		
	05h	At-speed output	AT-SPEED				
	06h	Torque in-limit signal output		•	e of changes		
	07h	Zero-speed detection output signal	ZSP		ge the default	•	
	08h	Speed coincidence output	V-COIN	"Externa	l brake releas	se signal	
	09h	Alarm output 1	WARN1	(in all mo	odes) to "Alar	m output	
	0Ah	Alarm output 2	WARN2	1", set th	e input to 00	090909h	
	0Bh	Positional command ON/OFF output	P-CMD	* For ear	sier setting, u	ise the	
	0Ch	Positioning complete 2	INP2		upport softwa		
	0Dh	Speed in-limit output	V-LIMIT	PANAT			
	0Eh	Alarm attribute output	ALM-ATB	FANAI			
	0Fh	Speed command ON/OFF output Servo on status output	V-CMD SRV-ST				
aution 🔅	Same fu Control c Do not c A511 : On	nction can be assigned to 2 or more butput pin set to invalid always has the hange the setup value shown in the ly available on A5II series.	output signals. he output transis table.				
		hat the setup values are displayed in			71.		
			Range	Unit	Default	Related control mod	
Dr4 11 *	502 Aut	nut selection		1	0000000		

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

7

Supplement

	000 entruit este ation	Range	Unit	Default	control mode			
Pr4.11 *	SO2 output selection	0 to 00FFFFFFh	_	00020202h (131586)	PSTF			
		Range	Unit	Default	Related control mode			
Pr4.12 *	SO3 output selection	0 to 00FFFFFFh	_	00010101h (65793)	P S T F			
	SO4 output selection	Range	Unit	Default	Related control mode			
Pr4.13 *		0 to 00FFFFFFh	_	00050504h (328964)	P S T F			
	SO5 output selection	Range	Unit	Default	Related control mode			
Pr4.14 *		0 to 00FFFFFFh	_	00070707h (460551)	P S T F			
		Range	Unit	Default	Related control mode			
Pr4.15 *	SO6 output selection	0 to 00FFFFFFh	—	00060606h (394758)	P S T F			
	Assign functions to SO2 to SO6 outputs.							
	These parameters are presented in hexadecir	nals.						
	Setup procedure is the same as described for Pr4.10.							

[Class 4] I/F monitor setting

					Default: []	
Pr4.16	Type of analog monitor 1	Range	Unit	Default	Related control mode	
P14.10		0 to 21	—	0	P S T F	
Select the type of monitor for analog monitor 1. *See the table shown on the next page.						

Pr4.17	4.17 Analog monitor 1 output gain	Range	Unit	Default	Relat control r		
P14.17	Analog monitor Toutput gain	0 to 214748364	[Monitor unit in Pr4.16] / V	0	PS	۶Т	F
	Set up the output gain of analog monitor 1. For Pr4.16 = 0 Motor speed, 1 V is output at th	ne motor speed	[r/min] = P	r4.17 setup [,]	valu	е.	

	Dr/ 19	4.18 Type of analog monitor 2	Range	Unit	Default	Related control mode		
	F14.10		0 to 21	—	4	PSTF		
Select the type of monitor for analog monitor 2. *See the table shown on the next page.								

Pr4.1	Analog monitor 2 output gain	Range	Unit	Default	Related control mode
P14.1		0 to 214748364	[Monitor unit in Pr4.16] / V	0	PSTF
	Set up the output gain of analog monitor 2. For Pr4.18 = 4 Torque command, 1 V is outpu	t at the torque com	mand [%]	= Pr4.19 set	up value.

Pr4.20	Type of digi	Type of digital monitor	Range	Unit	Default	Related control mo
F14.20	Type of dig		0 to 3	—	0	P S T
	Select type o	f the digital monitor.				
	Setup value Type of monitor Digital s L output L L	Digital signal output				
		Type of monitor	L output		H output	
	[0]	Positioning complete condition	Not completed		Completed	
	1	Positional command	Without commar	id N	With command	
	2	Alarm	Not generated		Generated	
	3	Gain selected	1st gain	(in	2nd gain cluding 3rd gai	n)

Note
 A parameter is designated as follows: Class Projeto:00 Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
 Only for position control type is not provided with analog input.
 Only for position control type is not provided with digital monitor output.
 Related page
 P.3-32... "Inputs and outputs on connector X4"


⁴⁻⁴⁰ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

[Class 4] I/F monitor setting


Pr4.16/Pr4.18	Type of monitor	Unit	Output gain for setting Pr4.17/Pr4.19 = 0
0	Motor speed	r/min	500
1	Positional command speed *3	r/min	500
2	Internal positional command speed *3	r/min	500
3	Velocity control command	r/min	500
4	Torque command	%	33
5	Command positional deviation *4	pulse (Command unit)	3000
6	Encoder positional deviation *4	pulse (Encoder unit)	3000
7	Full-closed deviation *4	pulse (External scale unit)	3000
8	Hybrid deviation	pulse (Command unit)	3000
9	Voltage across PN	V	80
10	Regenerative load factor	%	33
11	Overload factor	%	33
12	Positive direction torque limit	%	33
13	Negative direction torque limit	%	33
14	Speed limit value	r/min	500
15	Inertia ratio	%	500
16	Analog input 1 *2	V	1
17	Analog input 2 *2	V	1
18	Analog input 3 *2	V	1
19	Encoder temperature *5	°C	10
20	Driver temperature	°C	10
21	Encoder single-turn data *1	pulse (Encoder unit)	110000

*1 The encoder rotation data CCW is always positive value regardless of Pr0.00 Rotational direction setup. The direction of other monitor data basically follows Pr0.00 Rotational direction setup.

- *2 Analog inputs 1, 2 and 3 always output terminal voltage regardless of usage of analog input function. Only for position control type is not provided with analog inputs.
- *3 For the command pulse input, the speed before the command filter (smoothing, FIR filter) is defined as positional command speed and speed after filter is defined as internal command speed.



*4 Command positional deviation is the deviation with respect to the command pulse input and the encoder positional deviation/ full-closed positional deviation is the deviation at the input section of the positional control, as described in the figure below.



Positional command deviation (command unit)

*5 Temperature information from the encoder includes value only when it is a 20-bit incremental encoder. Otherwise, the value is always 0.

[Class 4] I/F monitor setting

Default: []

Dr4 01	21 Analog monitor output setup		Rang	ge	Unit	De	əfault	Re	ault: [elated ol mode
Pr4.21	Analog mo	nitor output setup	0 to	2	—		0	P S	S T F
	Select output format of the analog monitor.								
	Setup value	Outp	ut format						
	[0]	Signed data output	–10 V to 10 V	1					
	1	Absolute value data output	0 V to 10 V						
	2	Data output with offset	0 V to 10 V (5	5 V at ce	enter)				
							1		

	Pr4.22 Analog input 1 (Al1) offset setup	Range	Unit	Default	Related control mode	
	F14.22	Pr4.22 Analog input 1 (Al1) offset setup	-5578 to 5578	0.359 mV	0	P S T F
Γ						

Set up the offset correction value applied to the voltage fed to the analog input 1.

Pr4.23	Analog input 1 (Al1) filter	Range	Unit	Default	Related control mod	le
F14.23		0 to 6400	0.01 ms	0	PST	=
	Set up the time constant of 1st delay filter the applied to the analog input 1.	at determines th	e lag time	e behind the	voltage	

	Pr4.24	Analog input 1 (Al1) overvoltage setup	Range	Unit	Default	Relate control m	
			0 to 100	0.1 V	0	P S T	F
		Set up the excessive level of the input volt associated with offset.	age of analog	input 1 b	y using the	voltage	e

Pr4.25	Analog input 2 (Al2) offset setup	Range	Unit Default		Related control mode					
		-342 to 342	5.86 mV	0	PSTF					
Set up the offset correction value applied to the voltage fed to the analog input 2.										

Pr4.26	Analog input 2 (Al2) filter	Range	Unit	Default	Related control mode				
F14.20		0 to 6400	0.01 ms	0	P S T F				
Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 2.									

Pr4.27	Analog input 2 (Al2) overvoltage setup	Range	Unit	Default		lelate trol m	
P14.27	Analog input 2 (Ai2) overvoltage setup	0 to 100	0.1 V	0	Ρ	ST	F
	Set up the excessive level of the input volt associated with offset.	age of analog	input 2 b	y using the	vo	tag	e

Pr4.28	Analog input 3 (Al3) offset setup	Range	Unit	Default	Related control mode		
F14.20	Analog input 5 (Als) onset setup	-342 to 342	5.86 mV	0	PSTF		
Set up the offset correction value applied to the voltage fed to the analog input 3.							
Note 🔶	• A parameter is designated as follows: Class						

• Only for position control type is not provided with analog input.

Related page • P.3-32... "Inputs and outputs on connector X4"

[Class 4] I/F monitor setting

Default: []

Pr4.29	Analog input 3 (AI3) filter	Range	Unit	Default	Related control mode
F14.23		0 to 6400	0.01 ms	0	PSTF
	Set up the time constant of 1st delay filter that applied to the analog input 3.	at determines th	ie lag time	e behind the	voltage

Dr/1 30	Pr4.30 Analog input 3 (Al3) overvoltage setup		Unit	Default	Related control mode
F14.30	Analog input 5 (Als) overvoltage setup	0 to 100	0.1 V	0	P S T F
	Set up the excessive level of the input volt associated with offset.	age of analog	input 3 b	y using the	voltage

Pr4.31	Positioning complete (In-position) range	Range	Unit	Default	cor	Relate	d ode
P14.31	Positioning complete (in-position) range	0 to 262144	Command unit	10	Ρ		F
	Set up the timing of positional deviation at which	the positioning c	omplete si	ignal (INP1) i	s oi	utput	-
Caution 🔅	The command unit is used as the default unit but can be replaced by the encoder unit by using Pr5.20. Positioning unit selection. Note that when the encoder unit is used, unit of Pr0.14 Positional deviation excess setup is also changed.						
Note 🔸	For description of "command unit" and "encode	er unit", refer to	P.4-52 "Pr	5.20".			

	Deait	sitioning complete (In-position)						
Pr4.32	output setup		0 to 3	_	0	Р	F	
	Select	the co	ndition to output the positioning c	omplete signal (INP1).			
	Setup	value	Action of po	sitioning comple	ete signal			
	[0)]	The signal will turn on when the pos complete range)	sitional deviation is	smaller th	an Pr4.31 (Po	sitioning	
	A5I	1 6	The signal will turn on when there is smaller than Pr4.31 (Positioning comp	•	and and the	e positional de	viation is	
	A5I	2 7	The signal will turn on when there is n ON and the positional deviation is small				signal is	
		3	The signal will turn on when there is n smaller than Pr4.31 (Positioning com	blete range). Then	holds "ON"	status until the	e next	
	A5I	8	position command is entered.Subsequently, ON state is maintained until Pr4.33 INP hold time has elapsed. After the hold time, INP output will be turned ON/OFF according to the coming positional command or condition of the positional deviation.					
	A5I	4, 9	When the positioning judgment delay time set by Pr4.33 INP hold time passes after transi- tion from "with position command" to "without position command", positioning complete judgment sequence starts. If there is no position command and the positional deviation is smaller than Pr4.31 Positioning complete (in position) range, the signal will turn on.					
	АБП	5, 10	When the positioning judgment delay time set by Pr4.33 INP hold time passes after tra- tion from "with position command" to "without position command", and within positioni					
Caution ··	positio comma	on com and filte	sence of position command can nmand filter when the setup va er when the setup value is 6-10. vailable on A5II series.		-			
Note 💮	 Only 	for po	er is designated as follows: Class _ sition control type is not provided uts and outputs on connector X4"					

Before Using the Products

2

5

6

[Class 4] I/F monitor setting


Default: []

_	Default: []							
Pr4.33	INP hold ti	ma	Range	Unit	Default	Related control mod		
P14.33		lile	0 to 30000	1 ms	0	P F		
	Set up the ho	old time when Pr4.32 Positioning	complete output	setup = 3.				
	Setup value	State of positioning complete signal						
	[0]	The hold time is maintained definitely, keeping ON state until the next positional command is received. ON state is maintained for setup time (ms) but switched to OFF state as the positional command is received during hold time.						
	1 to 30000							

Pr4.34	Zero-speed	Range	Unit	Default	Related control mode
F14.34	Zeio-speed	10 to 20000	r/min	50	P S T F
	You can set up the timing to feed out the zero rotational speed [r/min]. The zero-speed detection signal (ZSP) will be setup of this parameter, Pr4.34.	•			,
	 The setup of Pr4.34 is valid for both Positive and Negative direction regardless of the motor rotating direction. There is hysteresis of 10 [r/min]. 	(Pr4.34+10) r/min			
		ZSP	ive direction ON	- (Pr4.34–1 1	0) r/min

D=4.05			Range	Unit	Default	Related control mode
Pr4.35	Speed coincidence range		10 to 20000	r/min	50	S T
	Speed	COIN) wher smaller that peed commar coceleration/de occess	n the difference n the speed spe nd after	Pr4.35 *1 (Speed co	his paramet	er.
	Speed coincidence output ON OF V-COIN ON OF *1 Because the speed coincidence detection range is as shown be Speed coincidence output Speed coincidence output	ce detection elow. OFF → ON t	timing (Pr4.35 –	vith 10 r/m 10) r/min	-	- s, actual

[Class 4] I/F monitor setting



Pr4.37	Mechanical brake action at stalling setup	Range	Unit	Default	Related control mode
F14.J7	Mechanical brake action at staning setup	0 to 10000	1 ms	0	P S T F
	You can set up the time from when the brake r motor is de-energized (Servo-free), when the mo	• •	,		
	• Set up to prevent a micro-travel/ drop of the motor (work) due to the action delay	SRV-ON	ON	С)FF
	time (tb) of the brake After setting up Pr4.37 ≥ tb , 	BRK-OFF	release	tb h	old
	then compose the sequence so as the driver turns to Servo-OFF after the brake	actual brake	ke _release	h	old
	is actually activated.	motor energization	energized	no en Pr4.37	n- ergized
				↓	

nical brake action at running setup n set up time from when detecting the xternal brake release signal (BRK-OF he motor in motion. up to prevent the brake deterioration to the motor running.			gnal (SRV-ON) tor turns to se	•
xternal brake release signal (BRK-OF he motor in motion. up to prevent the brake deterioration	F) turns off, wl	hile the mo	tor turns to se	•
• • •	SRV-ON			
5			OFF	
At Servo-OFF during the motor is running, tb of the right fig. will be a shorter one of either Pr4.38 setup time actual	BRK-OFF	release	hold	1
	actual brake ^e	energized	tb non- energize	d
w Pr4.39 setup speed.	motor energization		Pr4.39 setup spee	d.
r	he lapse till the motor speed falls	he lapse till the motor speed falls v Pr4.39 setup speed.	ne lapse till the motor speed falls	ne lapse till the motor speed falls v Pr4.39 setup speed. motor

• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

1

Before Using the Products

2

Preparation

3

Connection

4

5

7

[Class 4] I/F monitor setting

					Default: []	
Dr4 20	A.39 Brake release speed setup	Range	Unit	Default	Related control mode	
P14.39		30 to 3000	r/min	30	P S T F	
	Set up the speed timing of brake output checking during operation.					

Pr4.40	Selection of alarm output 1	Range 0 to 10	Unit —	Default 0	Relatedcontrol modePSTF
Pr4.41	Selection of alarm output 2	Range 0 to 10	Unit	Default 0	PSTF

Select the type of alarm issued as the alarm output 1 or 2.

Setup value	Alarm	Content				
[0]	_	ORed output of all alarms.				
1	Overload protection	Load factor is 85 % or more the protection level.				
2	Over-regeneration alarm	Regenerative load factor is 85 % or more the protection level.				
3	Battery alarm	Battery voltage is 3.2 V or lower.				
4	Fan alarm	Fan has stopped for 1 sec. *1				
5	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.				
6	Encoder overheat alarm	The encoder detects overheat alarm.				
7	Oscillation detection alarm	Oscillation or vibration is detected.				
8	Lifetime detection alarm	Life expectancy of capacitor or fan becomes short.				
9	External scale error alarm	The external scale detects the alarm.				
10	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.				

*1 The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal.

Related page … For detailed description of alarm types, refer to P.3-49.

Pr4.42	2nd Positioning complete (In-position)	Range	Unit	Default	Related control mode					
F14.42	range	0 to 262144	Command unit	10	P F					
	The INP2 turns ON whenever the positional of parameter, without being affected by Pr4.32 F absence of positional command is not related	Positioning com	olete outp							
Caution 🔅	The command unit is used as the default unit using Pr5.20. Positioning unit selection. Note Pr0.14 Positional deviation excess setup is also	e that when the	-		-					
Note 🔅	For description of "command unit" and "encode	For description of "command unit" and "encoder unit", refer to P.4-52 "Pr5.20".								

 A parameter is designated as follows: Class <u>Pro</u> <u>o</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

• P.3-32... "Inputs and outputs on connector X4"

[Class 5] Enhancing setting

						Default: []
В	r5.00	2nd numerator of electronic gear	Range	Unit	Default	Related control mode
FI	15.00	2nd numerator of electronic gear	0 to 2 ³⁰	_	0	P F
	r5.01	2rd numerator of electronic goor	Range	Unit	Default	Related control mode
F	15.01	3rd numerator of electronic gear	0 to 2 ³⁰	—	0	P F
	F 02	Ath numerator of electropic coor	Range	Unit	Default	Related control mode
	Pr5.02	4th numerator of electronic gear	0 to 2 ³⁰	—	0	P F
		Set the 2nd to 4th numerator of division/mu command pulse input. This setup is enabled when Pr0.08 command full closed controlling. When the setting value is 0 for positioning numerator. When the setting value is 0 for full closed controlling	pulse counts po	er one mo	otor revolutio	on = 0 or set as a

	Pr5.03 *		Range	Unit	Default	Related control mode
		Denominator of pulse output division	0 to 262144	_	0	PSTE
			A5II 0 to 1048576			
		For details, refer to P.4-11.				

* A5II represents setting range applied to A5II series.

	Pr5.04 *	Over travel	inhibit input setup	Range	Unit	Default	Related control mode			
	P15.04	Over-travel		0 to 2	—	1	P S T F			
	Set up the operation of the run-inhibition (POT, NOT) inputs.									
	Setup value Operation									
$0 \qquad \begin{array}{c} \text{POT} \rightarrow \text{Inhibit positive direction travel} \\ \text{NOT} \rightarrow \text{Inhibit negative direction travel} \end{array}$										
	[1] Disable POT, NOT									
	2 POT or NOT input activates Err38.0 Run-inhibition input protection.									

Seque	nce at o	ver-travel inhihit	Range	Unit	Default	Related control mode
ocque			0 to 2	—	0	PSTF
applicati	ion of the	over-travel inhibition (POT	, NOT).	ng decele	eration and s	stop after
Pr5.04	Pr5.05	During deceleration	After stallin	g	Deviation counter content	
	[0]	Dynamic brake action			Hold	
0	1	Torque command=0 towards inhibited direction			Hold	
2		Emergency stop	Command=0 towards inhibited direction		Clears before/ after deceleration	
	When P applicati <details Pr5.04</details 	When Pr5.04 Ov application of the <details b="" of="" pr5.0<=""> Pr5.04 Pr5.05 [0] 0 1</details>	application of the over-travel inhibition (POT <details (sequence="" at="" of="" over-travel)<="" pr5.05="" td=""> Pr5.04 Pr5.05 During deceleration 0 1 Dynamic brake action 0 1</details>	Sequence at over-travel inhibit 0 to 2 When Pr5.04 Over-travel inhibition = 0, specify the status duri application of the over-travel inhibition (POT, NOT). <details (sequence="" at="" inhibit)="" of="" over-travel="" pr5.05=""> Pr5.04 Pr5.05 During deceleration After stallin 0 1 1 Torque command=0 towards inhibited direction 2 Emergency stop</details>	Sequence at over-travel inhibit 0 to 2 0 to 2 - When Pr5.04 Over-travel inhibition = 0, specify the status during deceleration of the over-travel inhibition (POT, NOT). <details (sequence="" at="" inhibit)="" of="" over-travel="" pr5.05=""> Pr5.04 Pr5.05 During deceleration After stalling 0 1 1 Torque command=0 towards inhibited direction 2 Emergency stop</details>	Sequence at over-travel inhibit 0 to 2 0 0 to 2 - 0 When Pr5.04 Over-travel inhibition = 0, specify the status during deceleration and s application of the over-travel inhibition (POT, NOT). - <details (sequence="" at="" inhibit)="" of="" over-travel="" pr5.05=""> - Deviation of content of the over-travel inhibit) Pr5.04 Pr5.05 During deceleration After stalling Deviation of content of towards inhibited direction 0 1 Torque command=0 towards inhibited direction Torque command=0 towards inhibited direction Hold 0 1 Torque command=0 towards inhibited direction Command=0 towards inhibited direction Hold</details>

Note

 A parameter is designated as follows: Class <u>Pro.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

Related page … • P.3-32... "Inputs and outputs on connector X4" • P.6-2 "Protective Function" 5

6

[Class 5] Enhancing setting

	T			Danca	1 10:4	Defeuilt	Default: Related	
Pr5.06	Seque	nce at Servo-Off		Range 0 to 9	Unit	Default 0	PST	
	Specify	the status during deceleration a	and afte		vo-off.	0		
	Setup value	During deceleration *3		After stalling		Positional d external deviati	scale	
	[0]	Dynamic Brake (DB) action	Dyn	amic Brake (DB) a	action	Clear	*4	
	1	Free-run (DB OFF)	Dyn	amic Brake (DB) a	action	Clear	*4	
	2	Dynamic Brake (DB) action		Free-run (DB OFI	=)	Clear	*4	
	3	Free-run (DB OFF)		Free-run (DB OFI	=)	Clear	*4	
	4	Dynamic Brake (DB) action	Dyn	amic Brake (DB) a	action	Hold	*2	
	5	Free-run (DB OFF)	Dyn	amic Brake (DB) a	action	Hold	*2	
	6	Dynamic Brake (DB) action		Free-run (DB OFI	=)	Hold	*2	
	7	Free-run (DB OFF)		Free-run (DB OFI	=)	Hold	*2	
	8	Emergency stop *1	Dyn	amic Brake (DB) a	action	Clear *4		
	9	Emergency stop *1		Free-run (DB OFI	=)	Clear *4		
	The f *2 If the devia serve oper posit *3 Dece moto	 *1 Emergency stop refers to a controlled immediate stop with servo-on. The torque command value is limited during this process by Pr5.11 Emergency stop torque setup. *2 If the positional command is kept applied or the motor is kept running with servo-off condition, positional deviation is accumulated, causing Err24.0 Excess positional deviation protection to be issued. If the servo is turned ON while the position or external scale is significantly deviating, the motor may rapidly operate to reduce the deviation to 0. Remember these requirements if you want to maintain the positional deviation/external scale deviation. *3 Deceleration period is the time required for the running motor to speed down to 30 r/min. Once the motor speed drops below 30 r/min, it is treated as in stop state regardless of its speed. *4 Positional deviation/external scale deviation is always cleared to 0. 						
Caution 🔅		ror occurs during servo-off, foll off during servo-off, follow Pr5.0		•			power is	
Related page 👾		o P.2-63, "Timing Chart"-Ser tion as well.	vo-ON	/OFF action w	hile the	motor is at	stall" o	

Pr5.07	Sequence at main power OFF	Range	Unit	Default	Related control mode			
P13.07	Sequence at main power OFF	0 to 9	_	0	PSTF			
	Specify the status during deceleration after main power interrupt or after stoppage. The relationship between the setup value of Pr5.06 and the operation and process at deviation counters is the same as that for Pr5.07 (sequence at main power OFF).							
Caution 🔅	If an error occurs with the main power supplied to the operation. When the main power supply is turned of undervoltage error occurs if Pr5.08 LV trip operation follows Pr5.10 Sequence at alarm.	f with servo-or	i state, E	rr13.1 Mair	n power			

Note	• A parameter is designated as follows: Class Pro. 00 Parameter No.
------	---

• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

[Class 5] Enhancing setting

Default: [] Related control mode Range Unit Default Pr5.08 LV trip selection at main power OFF 0 to 1 PSTF 1 You can select whether or not to activate Err13.1 (Main power under-voltage protection) function while the main power shutoff continues for the setup of Pr5.09 (Main power-OFF detection time). Setup value Action of main power low voltage protection When the main power is shut off during Servo-ON, Err13.1 will not be triggered and 0 the driver turns to Servo-OFF. The driver returns to Servo-ON again after the main power resumption. When the main power is shut off during Servo-ON, the driver will trip due to Err13.1 [1] (Main power low voltage protection). Caution 🔅 This parameter is invalid when Pr5.09 (Detection time of main power OFF)=2000. Err13.1 (Main power under-voltage protection) is triggered when setup of Pr5.09 is long and P-N voltage of the main converter falls below the specified value before detecting the main power shutoff, regardless of the Pr5.08 setup.

Pr5.09 *	Detection time of main power off	Range	Unit	Default	Related control mode
P15.09	Detection time of main power of	70 to 2000	1 ms	70	PSTF
	You can set up the time to detect the shutoff wh The main power off detection is invalid when y	•		shut off con	inuously.

D.c 10	0			Range	Unit	Default	Related control mo
Pr5.10	Sequence at alarm			0 to 7	_	0	P S T
	Specify	the status during deceleration a	and afte	r stop, after occ	urrence	of alarm.	
	Setup value	During deceleration *3		After stalling		Positional de external s deviation	scale
	[0]	Dynamic Brake (DB) action	Dyn	amic Brake (DB) a	action	Hold *	1
	1	Free-run (DB OFF)	Dyn	amic Brake (DB) a	action	Hold *	1
	2	Dynamic Brake (DB) action		Free-run (DB OFF	=)	Hold *	1
	3	Free-run (DB OFF)		Free-run (DB OFF	=)	Hold *	1
	4	Action A: Emergency stop Action B: DB action *2	Dyn	amic Brake (DB) a	action	Hold *	1
	5	Action A: Emergency stop Action B: DB OFF *2	Dyn	amic Brake (DB) a	action	Hold *	1
	6	Action A: Emergency stop Action B: DB action *2		Free-run (DB OFF	-)	Hold *	1
	7	Action A: Emergency stop Action B: DB OFF *2		Free-run (DB OFF	-)	Hold *	1
	clear *2 Actio setup an al	tional deviation/external scale de red when the alarm is cancelled. on of A/B: When an alarm requiring o value in the table is set within the larm not requiring emergency stop free-running.	g emerge e range 4	ency stop occurs, 4 to 7, causing en	the action	n A is selected stop of operati	when the on. Wher
		eleration period is the time required	d for the	runnina motor to s	speed dov	wn to 30 r/min.	

Deceleration period is the time required for the running motor to speed down to 30 r/min.

2

Preparation

Connection

5

6

[Class 5] Enhancing setting

						Defau	ult:[]
р,	r5.11	Torque setup for emergency stop	Range	Unit	Default	Rela control	
FI	15.11	Torque setup for enlergency stop	0 to 500	%	0	PS	TF
No	-	Set up the torque limit at emergency stop. When setup value is 0, the torque limit for norr	nal operation is	applied.			

Pr5.12	Over-load level setup	Range	Unit	Default	Related control mode			
P13.12	Over-load level setup	0 to 500	%	0	P S T F			
• You can set up the over-load level. The overload level becomes 115[%] by setting up this to								

0. · Use this with 0 setup in normal operation. Set up other value only when you need to lower

the over-load level.

• The setup value of this parameter is limited by 115[%] of the motor rating.

	Pr5.13	Over-speed level setup	Range	Default		Related control mode			
			0 to 20000	r/min	0	P	S	Т	F
	. If the motor speed exceeds this setup value, Err26.0. Over-speed protection occurs								

 If the motor speed exceeds this setup value, Err26.0 Over-speed protection occurs. • The over-speed level becomes 1.2 times of the motor max. speed by setting up this to 0.

Pr5.14	Motor working range setup	Range	Unit	Default	Related control mode		
P15.14	Motor working range setup	0 to 1000	0.1 revolution	10	PSTF		
	 You can set up the movable range of the mot When the motor movement exceeds the set will be triggered. 	•		•	-		

Pr5.15 * I/F read	I/E reading	filter	Range	Unit	Default	Related control mode
P15.15	#F reading	lillei	0 to 3	—	0	PSTF
:	Select reading	g period of the control input signa	al.			
	Setup value	Reading period of the signal.				
	[0]	0.166 ms				
	1	0.333 ms				
	2	1 ms				
	3	1.666 ms				

 A parameter is designated as follows: Class <u>Pro.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

• P.3-32... "Inputs and outputs on connector X4" • P.6-2 "Protective Function" Related page …

[Class 5] Enhancing setting

			Range	Unit	Default	Default: []		
Pr5.16 *	Pr5.16 * Alarm clear input setup		0 to 1	-	0	P S T F		
Select alarm clear input (A-CLR) recognition time.								
Setup value Recognition tim			time					
	[0] 120 ms							
	1	To Pr5.15 IF read	ing filter					
Pr5.17	Countar al	or input mode	Range	Unit	Default	Related control mode		
P15.17	Counter Cie	ear input mode	0 to 4	_	3	P F		
	You can set u	up the clearing conditions of the c	ounter clear	input signal.				

Clear condition
Invalid
Clear at a level (no reading filter)
Clear at a level (with reading filter)
Clear at an edge (no reading filter)
Clear at an edge (with reading filter)

Note For signal width/timing requiring the deviation counter input, refer to P.3-40.

Pr5.18	Invalidation of command pulse inhibit		Range	Unit	Default	Related control mode	
FIJ.10	input		0 to 1	—	1	P F	
Select command pulse inhibit input enable/disable.							
	Setup value	INH input					
	0	Valid					
	[1]	Invalid					

	Pr5.19 *	Command	pulse inhibit input reading	Range	Unit	Default	Rela control	
	FIJ.19	setup		0 to 4	—	0	P	F
		Select commissions	0.1					
	Setup value Signal reading period							
		[0]	0.166 ms					
		1	0.333 ms					
		2	1 ms					
		3	1.666 ms					
		4	0.166 ms (no check for mu	ltiple coincidence)				
C	aution 🔅	noise but	decreases r	respon	ise			

Ν	ote	•

 A parameter is designated as follows: Class <u>Pr0.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

Related page • P.3-32... "Inputs and outputs on connector X4" • P.6-2 "Protective Function"

1

Before Using the Products

2

Preparation

3

Connection

[Class 5] Enhancing setting

Pr5.20 *	Position setup unit select	tun unit select	Range	Unit	Default	Related control mode	
F13.20	FOSITION SE		0 to 1	_	0	P F	
	Specify the u deviation.	unit to determine the range of p	ositioning comp	lete and	excessive p	ositional	
	Setup value	Unit					
	[0]	Command unit					
	1	Encoder unit					
Note 💮	The command unit defines 1 command pulse from the higher level device as setting value 1, while the encoder unit defines 1 encoder pulse as setting value 1. When the electronic gear ratio set by using the command division and multiplication function (electronic gear) is R, the following relationship is obtained.						
	Command	unit × R = encoder unit					
	For example,	if 20-bit encoder is used with the	e default setting,				
	$R = \frac{2^{20}}{10000}$, then, command unit × $\frac{2^{20}}{10000}$	= encoder unit.				

Pr5.21	Soloction	f torque limit	Range		Unit	Default	Re	lated	
P13.21	Selection		0	to 6	—	1	P S	F	
	You can set u	up the torque limiting method.							
	Setup value	Positive direction			Negative	direction			
	0	P-ATL (0 V to 10 V)	0 V) N-ATL (-10 V to 0 V)						
	[1]	1st to	1st torque limit (Pr0.13)						
	2	1st torque limit (Pr0.13)	.13) 2nd torque limit (Pr5.22)						
	3	TL-SEL OFF → 1st torque limit (Pr0.13)							
	0	TL-SEL ON → 2nd	torque l	limit (Pr5.2	2)				
	4	P-ATL (0 V to 10 V)			N-ATL (0	V to 10 V)			
	5	P-/	ATL (0 \	/ to 10 V)					
		TL-SEL OFF							
		1st torque limit (Pr0.13)		2	2nd torque	limit (Pr5.22)			
	6	TL-SEL ON							
		External input positive direction to limit (Pr5.25)				torqu	е		

Pr5.22	2nd torgue limit	Range	Unit	Default	Related control mode			
P15.22		0 to 500	%	500	P S F			
You can set up the 2nd limit value of the motor output torque. The value of parameter is limited to the maximum torque of the applicable motor.								
Note i For details of torque limit value, refer to P.2-84.								

Note • A parameter is designated as follows: Class Pr0.00
 Parameter No.
 • For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
 • P.2-84 "Setup of Torque Limit" • P.3-32... "Inputs and outputs on connector X4" • P.6-2 "Protective Function"

⁴⁻⁵² Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

[Class 5] Enhancing setting

Pr5.23	Torque limit switching setup 1	Range	Unit	Default		Relate	ed node
F15.25		0 to 4000	ms/100 %	0	P	s	F
	Specify the rate of change (slope) from 1st to 2	2nd during torqu	ue limit swit	tching.			

Pr5.24	Torque limit switching setup 2	Range	Unit	Default		Relate	
F15.24		0 to 4000	ms/100 %	0	Ρ	S	F
	Specify the rate of change (slope) from 2nd to	1st during torqu	e limit swi	tching.			

Pr5.25	External input positive direction	Range	Unit	Default	Related control mode				
P15.25	torque limit	0 to 500	%	500	P S F				
	Set up positive direction torque limit upon receiving TL-SEL with Pr5.21 Selection of torque limit set at 6. The value of parameter is limited to the maximum torque of the applicable motor.								
Note 🔅	For details of torque limit value, refer to P.2-84								

Pr5.26	External input negative direction	Range	Unit	Default	Related control mode
P15.20	torque limit	0 to 500	%	500	P S F
	Set up negative direction torque limit upon red limit set at 6. The value of parameter is limited to the maxim	C C			of torque
Note 🔅	For details of torque limit value, refer to P.2-84				
		Range	Unit	Default	Related

Pr5.27	Input gain of analog torque limit	Range	Unit	Default	control mode	
P15.27		10 to 100	0.1 V/100 %	30	P S F	
	From the voltage [V] applied to the analog tor gain to torque limit [%].	que limit input (l	P-ATL, N-/	ATL), set co	nversion	

6

7

Note	• A parameter is designated as follows: Class Pro. 00 Parameter No.						
• For parameters which No. have a suffix of " * ", changed contents will be validated when							
	you turn on the control power.						
Related page …	• P.2-84 "Setup of Torque Limit" • P.3-32 "Inputs and outputs on connector X4" • P.6-2 "Protective Function"						

2

Preparation

3

Connection

5

Adjustment

[Class 5] Enhancing setting

Dr5	.28 *	LED initial status			Range	Unit	Default _c	Relate ontrol n	
FIJ.	.20				0 to 35	—	1 F	r s 1	
		You can select the t initial status after po		of data to be displayed on.	on the fron	t panel LED (7 segment) at	the	
	Power -ON								
Setup value		Content	Setup value	Content	Setup		Content		
		Content nal command deviation	Setup value 12		value		Content	r unit]	
value		nal command deviation	value	Content	value	Encoder positiona			
value 0	Positior Motor s	nal command deviation	value 12	Content Error factor and reference of	history 24	Encoder positiona External scale dev	I deviation [Encode		
value 0 [1]	Positior Motor s Positior	nal command deviation	value 12 13	Content Error factor and reference of Alarm Display	history 24 25	Encoder positiona External scale dev	I deviation [Encoder viation [External scal [Command unit]		
value 0 [1] 2	Position Motor s Position Velocity	nal command deviation peed nal command speed	value 12 13 14	Content Error factor and reference of Alarm Display Regenerative load factor	history 24 25 26	Encoder positiona External scale dev Hybrid deviation	I deviation [Encoder viation [External scal [Command unit] PN [V]		
value 0 [1] 2 3	Position Motor s Position Velocity Torque	nal command deviation peed nal command speed v control command	value 12 13 14 15	Content Error factor and reference of Alarm Display Regenerative load factor Over-load factor	value history 24 25 26 27 27	Encoder positiona External scale dev Hybrid deviation Voltage across F	I deviation [Encoder riation [External scal [Command unit] PN [V]		
value 0 [1] 2 3 4	Position Motor s Position Velocity Torque Feedba	nal command deviation peed nal command speed control command command	value 12 13 14 15 16	Content Error factor and reference of Alarm Display Regenerative load factor Over-load factor Inertia ratio	value history 24 25 26 27 28 29 29	Encoder positiona External scale dev Hybrid deviation Voltage across F Software version	I deviation [Encoder viation [External scal [Command unit] PN [V] n nber		
value 0 [1] 2 3 4 5	Position Motor s Position Velocity Torque Feedba Comma	al command deviation peed nal command speed control command command ack pulse sum	value 12 13 14 15 16 17	Content Error factor and reference of Alarm Display Regenerative load factor Over-load factor Inertia ratio Factor of no-motor running	value history 24 25 26 27 28 29 29	Encoder positiona External scale dev Hybrid deviation Voltage across F Software version Driver serial num	I deviation [Encoder viation [External scal [Command unit] PN [V] n nber nber		
0 [1] 2 3 4 5 6	Position Motor s Position Velocity Torque Feedba Comma	anal command deviation peed nal command speed control command command ack pulse sum and pulse sum scale feedback pulse sum	value 12 13 14 15 16 17 18	Content Error factor and reference of Alarm Display Regenerative load factor Over-load factor Inertia ratio Factor of no-motor running No. of changes in I/O signa	value history 24 25 26 27 28 29 30 31 31	Encoder positiona External scale dev Hybrid deviation Voltage across F Software versior Driver serial num Motor serial num Accumulated op	I deviation [Encoder viation [External scal [Command unit] PN [V] n nber nber	le unit]	
value 0 [1] 2 3 4 5 6 8	Positior Motor s Positior Velocity Torque Feedba Comma External Control	anal command deviation peed nal command speed control command command ack pulse sum and pulse sum scale feedback pulse sum	value 12 13 14 15 16 17 18 20	Content Error factor and reference of Alarm Display Regenerative load factor Over-load factor Inertia ratio Factor of no-motor running No. of changes in I/O signa Absolute encoder data	value history 24 25 26 27 28 29 30 31 32 ale 33	Encoder positiona External scale dev Hybrid deviation Voltage across F Software versior Driver serial num Motor serial num Accumulated op	I deviation [Encoder viation [External scal [Command unit] PN [V] n nber nber eration time recognizing function	le unit]	

	Pr5.29 *	Baud rate setup of	Range	Unit	Default	Related control mode
		RS232 communication	0 to 6	—	2	PSTF
		You can set up the communication speed of R	S232.			
	Note 🔶	For baud rate setup value, refer to RS485 setu	ıp.			

Pr5.30 *	Baud rate setup of		Range	Unit	Default	Related control mode		
F13.30	RS485 com	munication	0 to 6	—	2	P S T F		
	You can set u	p the communication speed of R	S485.					
	Setup value	Baud rate	Setup value	B	aud rate			
	0	2400 bps	4	3	8400 bps			
	1	4800 bps	5	5	7600 bps			
	[2]	9600 bps	6	11	5200 bps			
	3	19200 bps						
	Baud rate erro	r is ±0.5 % for 2400 to 38400 bps, a	and ±2 % for 576	00 to 11520	0 bps.			

Note • Only for position control type is not provided with X2 (Communication connector).

[Class 5] Enhancing setting

					Default: []			
Pr5.31 *	Axis address	Range	Unit	Default	Related control mode			
P15.51		0 to 127	—	1	P S T F			
During communication with the host (e.g. PC) to control multiple shafts, the shaft being accessed by the host should be identified. Note When using RS232/RS485, the maximum valid value is 31.								

	Pr5.32 *	Command pulse input maximum setup		Range	Unit	Default	Rela control			
	P15.32 *		iput maximum setup	250 to 4000	k pulse/s	4000	P	F		
			timber of pulses to be us the setup value × 1.2,		• •					
	Caution 🔅	received pulse is hig detected. By selecting a value	The number of input pulses received by the driver is always checked. If the frequency of the received pulse is higher than the upper limit of the setting, input pulses are not accurately detected. By selecting a value lower than 1000, a digital filter of the specification shown below is enabled against the command pulse input.							
		Pr5.32 setting range	Digital filter	• With A5 II serie		,				
		250 to 499	200 ns 2-time reading	setting of Pr5.3 2-time reading		•		5		
		500 to 999	100 ns 2-time reading	C						
		1000 or more	No reading (thru)	regardless of Pr5.32 setting.						

Pr5.33 *	Pulse regenerative output limit setup	Range	Unit	Default	Related control mo	
P15.55		0 to 1	—	0	P S T	F
	Enable/disable detection of Err28.0 Pulse	Setup value	Content			
	regenerative limit protection.	[0]		Invalid		
		1		Valid		

Pr5.34	For manufacturer's use	Range	Unit	Default	Related control mode
P15.54		_	_	4	
	Fixed to 4.				

Pr5.35 *	Front panel lock setup	Range	Unit	Default	Relate control m	
P15.55		0 to 1	-	0	P S T	F
Lock the operation on the front panel. Setup value Content						1
		[0]	No limit on the front panel operation			
		1	Lock the operation on the front panel			

Note

- A parameter is designated as follows: Class <u>Pro</u> <u>o</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when
- For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
 Related page ...
 P.3-32... "Inputs and outputs on connector X4"

1

Setup

6

[Class 6] Special setting

Pr6.00	Analog torque feed forward conversion	Range	Unit	Default	Re conti	elated ol mo			
F10.00	gain	0 to 100	0.1 V/100 %	0	P	S	F		
	 Set the input gain of analog torque feed forward. 0 to 9 are invalid. 								

Pr6.02	Velocity deviation excess setup	Range	Unit	Default	Related control mode
F10.02		0 to 20000	r/min	0	P
	When the speed deviation (difference betweer speed) exceeds this value, Err24.1 Speed ove This protection is not detected when the setup	r deviation prote			ual

Pr6.04	JOG trial run command speed	Range	Unit	Default	Related control mode			
F10.04	JOG that full command speed	0 to 500	r/min	300	PSTF			
Set up the command speed used for JOG trial run (velocity control).								
Related page 🔅	Before using, refer to P.4-66 Preparation Trial Run.							

Pr6.05	Position 3rd gain valid time	Range	Unit	Default	Relat control r	
F10.05		0 to 10000	0.1 ms	0	P	F
	 Set up the time at which 3rd gain becomes value When not using this parameter, set Pr6.05 to This is valid for only position control/full-close 	0 and Pr6.06 to	100.			

Pr6.06	Position 3rd gain scale factor	Range	Unit	Default		elated rol mo	
P10.00		50 to 1000	%	100	Ρ		F
	 Set up the 3rd gain by a multiplying factor of 3rd gain = 1st gain × Pr6.06/100 	the 1st gain:					

Note

 A parameter is designated as follows: Class <u>Pro.00</u> Parameter No.
 For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.

Related page … • P.3-32... "Inputs and outputs on connector X4" • P.6-2 "Protective Function"

[Class 6] Special setting

Pr6.07	Torque command additional value	Range	Unit	Default	Related control mode
P10.07		-100 to 100	%	0	P S F
	 Set up the offset load compensation value control mode except for the torque control mode Update this parameter when the vertical axis 	ode.		•	

Pr6.08	Positive direction torque compensation	Range	Unit	Default	Related control mode			
F10.00	value	-100 to 100	%	0	P F			
 Set up the dynamic friction compensation value to be added to the torque command when forward positional command is fed. 								
• Update this parameter when the friction compensation mode for real time auto-tuning is valid.								

Pr6.09	Negative direction torque compensation	Range	Unit	Default		elated ol mode		
F10.09	value	-100 to 100	%	0	Ρ	F		
 Set up the dynamic friction compensation value to be added to the torque command when negative direction positional command is fed. 								
 Update this parameter when the friction compensation mode for real time auto-tuning is valid. 								

			Range	Unit	Default	Related control mod
Pr6.10	Function e	expansion setup	0 to 63	_	0	PST
			A5I 0 to 2047			
	Set up the fu	unction in unit of bit.				
		Function	Setup value			
		Function	[0]		1	
	bit 0	Speed observer	Invalid		Valid	
	bit 1	Disturbance observer	Invalid		Valid	
	bit 2	Disturbance observer operation	Always valid	Valid only when 1st gain		1st gain
		setup			is selected	d.
	bit 3	Inertia ratio switching	Invalid		Valid	

	bit 2	Disturbance observer operation setup	Always valid	Valid only when 1st gai is selected.
	bit 3	Inertia ratio switching	Invalid	Valid
	bit 4	Current response improvement	Invalid	Valid
	bit 5	Analog torque FF	Invalid	Valid
A5II	bit 6	Speed FF selection	Previous specifications	High-precision type
A5II	bit 7	Not used	Fixed	l to 0.
A5II	bit 8	Not used	Fixed	l to 0.
A5II	bit 9	For manufacturer's use	Fixed	l to 0.
A5I	bit 10	Positional deviation of falling prevention function during alarm	Invalid (hold)	Valid (clear)
*	1.00			

* bit 0 = LSB

* A5II : Only available on A5II series.

Related page

A parameter is designated as follows: Class <u>Pr0.00</u> Parameter No.
For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
P.3-32... "Inputs and outputs on connector X4"

5

[Class 6] Special setting

					De	fau	lt: []
Pr6.11	11 Current response setup	Range	Unit	Default	F cont	trol		e
P10.11		50 to 100	%	100	Ρ	S	TF	:
Fine tune the current response with respect to default setup (100 %).								

Pr6.13	2nd Inertia ratio	Range	Unit	Default	Related control mode				
		0 to 10000	%	250	P S T F				
Set 2nd inertia ratio. You can set up the ratio of the load inertia against the rotor (of the motor) inertia.									
Pr6.13 = (load inertia/ rotor inertia) × 100 [%]									

Caution 🔅 If the inertia ratio is correctly set, the setup unit of Pr1.01 and Pr1.06 becomes (Hz). When the inertia ratio of Pr0.04 is larger than the actual, the setup unit of the velocity loop gain becomes larger, and when the inertia ratio of Pr0.04 is smaller than the actual, the setup unit of the velocity loop gain becomes smaller.

Pr6.14	Emergency stop time at alarm	Range	Unit	Default	Related control mode
P10.14		0 to 1000	1 ms	200	PSTF
	Set up the time allowed to complete emerger time puts the system in alarm state. When setup value is 0, immediate stop is disa				C

Pr6.15	2nd over-speed level setup	Range	Unit	Default	Related control mode
P10.15	zna over-speed level setup	0 to 20000	r/min	0	PSTF
	When the motor speed exceeds this setup tin activated. The over-speed level becomes 1.2 times of the			·	

Pr6.17 *	Eront papa	I parameter writing selection	Range	Unit	Default	Related control mode		
-10.17	From pane	i parameter writing selection	0 to 1	—	0	P S T F		
Specify the EEPROM writing procedure when parameter is edited form the front panel.								
	Setup value	Writing						
	[0]	Do not write to EEPROM at the same time						
	1	Write to EEPROM at the same time						

Pr6.18 *	Power-up wait time	Range	Unit	Default	Related control mode
F10.10	Power-up wait time	0 to 100	0.1s	0	P S T F
	Set up the standard initialization time (1.5 s + o For example, when setup value is 10, then 1.5 s +	, ,	•		

Note

• A parameter is designated as follows: Class Pro.00 Parameter No.

• For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

Related page … • P.2-109 "EEPROM Writing Mode" • P.3-32... "Inputs and outputs on connector X4"

[Class 6] Special setting

					Defa	ault:	[]	
Pr6.19 *	Encoder Z phase setup	Range	Unit	Default	Rel	lated		
PI0.19		0 to 32767	pulse	0	P S	T	F	
If the number of output pulses per one motor revolution after division of pulse output is not an integer, fine adjust the width of encoder Z phase.								

Pr6.20 *	Z-phase setup of external scale	Range	Unit	Default	Related control mode					
F10.20		0 to 400	μs	0	F					
	Set up the Z phase regenerative width of external scale in unit of time. Even if the width of Z phase signal cannot be detected because the width equivalent of the travel distance from the external scale is too short, the Z phase signal will be output for at least the period set to									

Pr6.21 *	Serial absolute exter	nal scale Z phase	Range	Unit	Default	Related control mod
F10.21	setup		0 to 2 ²⁸	pulse	0	F
	Full-closed control using external scale as the sc output pulses of the ext	ource of the output, set	the Z phase out			•
	Setup value	Setup value Content				
	[0]	Output Z phase only at	absolute 0 positio	n of extern	al scale.	
	After the power is fed to the driver, the Z phase, as it crosses the zero a the absolute position of external scale, is output in synchronous with the A phase. Subsequently, the Z phase is output at the A phase output pulse intervals set to this parameter.				with the	

A, B phase external scale pulse output		Range	Unit	Default	Rela control			
method se	lection	0 to 1	—	0		F		
Select the pulse regeneration method of A, B and Z parallel external scale.								
Setup value	Regenerating method							
[0]	Directly output the signals from A, E	3 and Z parallel ex	ternal scale	es.				
1	Output A and B phase signals recovered from A, B and Z parallel external scales. Z-phase is output directly.							
	method se Select the pu Setup value	method selection Select the pulse regeneration method of A, B a Setup value Reg [0] Directly output the signals from A, E 1 Output A and B phase signals recovered	method selection 0 to 1 Select the pulse regeneration method of A, B and Z parallel ex Setup value Regenerating method [0] Directly output the signals from A, B and Z parallel ex 1 Output A and B phase signals recovered from A, B and	A, D phase external source pulse output A and Z A and Z method selection 0 to 1 - Select the pulse regeneration method of A, B and Z parallel external scale Regenerating method [0] Directly output the signals from A, B and Z parallel external scale 1 Output A and B phase signals recovered from A, B and Z parallel	A, D phase external source pulse output Integer Integer method selection 0 to 1 - 0 Select the pulse regeneration method of A, B and Z parallel external scale. Setup value Regenerating method [0] Directly output the signals from A, B and Z parallel external scales. 1 Output A and B phase signals recovered from A, B and Z parallel external scales.	A, B phase external scale pulse output method selection Hange Onit Default control method selection 0 to 1 - 0 <td< th=""></td<>		

Pr6.23	Disturbance torque compensating gain	Range	Unit	Default	Related control mode				
Pro.25 Disturbance forque compensating gain		-100 to 100	%	0	PS				
 Set up -100 % to 100 % compensating gain against disturbance torque. After setting up Pr6.24, increase Pr6.23. The disturbance suppressing capability increases by increasing the gain, but it is associated with increasing volume of operation noise. This means that well balanced setup can be obtained by adjusting Pr6.24 and Pr6.23. 									

• A parameter is designated as follows: Class Pro. 00 Parameter No.

2

5

[Class 6] Special setting

Default: []

Pr6.24 Disturbance observer filter 0 to 2500 0.01 ms 53 P S	D=0.04	Disturbance sheeven filter	Range	Unit Default	Related control mode		
	Pr6.24	Disturbance observer filter	0 to 2500	0.01 ms	53	P S	

Set up the filter time constant according to the disturbance torque compensation.
First, set up Pr6.24 to a larger value and check the operation with Pr6.23 Disturbance torque compensating gain set to a low value, and then gradually decrease the setup value of Pr6.24. A low filter setup value assures disturbance torque estimation with small delay and effectively suppresses effects of disturbance. However, this results in larger operation noise. Well balanced setup is required.

Pr6.27 *	Alarm latch time selection	Range	Unit	Default	Related control mode
P10.27 *		0 to 10	—	5	PSTF

Set up the latch time.

Setup value	Cont	ent
0	Latch time	: infinite
1		1 [s]
2		2 [s]
3		3 [s]
4] [4 [s]
[5]	Latab tima	5 [s]
6	Latch time	6 [s]
7		7 [s]
8		8 [s]
9		9 [s]
10		10 [s]

Pr6.31 Real time auto tuning estimation speed Range Unit Default Related control mode 0 to 3 - 1 P S T F						
Pro.51 Real time auto tuning estimation speed $0 \text{ to } 3 - 1 \text{ P S T F}$	Dr6 21	Real time outo tuning actimation around	Range	Unit	Default control mode	
	P10.31	Real time auto tuning estimation speed	0 to 3	—	1	P S T F

Set up the load characteristics estimation speed with the real time auto tuning being valid. A higher setup value assures faster response to a change in load characteristics but increases variations in disturbance estimation. Result of estimation is saved to EEPROM every 30 minutes.

Setup value	Setup value Mode Description			
0	No change	Stop estimation of load characteristics.		
[1] Almost constant Response to changes in load charact		Response to changes in load characteristics in every minute.		
2	Slower change	Response to changes in load characteristics in every second.		
3 *	Faster change	Obtain best suitable estimation in response to changes in load characteristics.		

* If the automatic oscillation detection is enabled by the support software PANATERM, the setup value 3 is used.

Note

- A parameter is designated as follows: Class Pro. 00 Parameter No.
- For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.
- The setup support software PANATERM can be downloaded from our web site.
- Related page P.3-32... "Inputs and outputs on connector X4"

[Class 6] Special setting

	Dool time	auto tunina -		Range	Unit	Default	Relate control m	
Pr6.32	neal time	e auto tuning c	usion setup	-32768 to 32767	_	0	P S T	
A5I	the automa	atic adjusting fu	nction as shown	ito tuning is set to the one below. The below. The below is set (A5II series		,	,.	
	Bit	Content		Description	,,			
		Contoint	Enable/disable t	he load characteristics est	imation fu	action		
			Setup value	Function				
			[0]	Disable				
			1	Enable				
	1 to 0	Load char- acteristics estimation *	cannot be cha the estimated the estimated * To enable the	aracteristics estimation is anged even if the inertia value. When the torque value, it is cleared to 0 (in load characteristics me ning estimation speed to	ratio is upo compensa valid). asuremen	dated acc ition is up t, set Pr6	cording to odated by 6.31 Real	
			,	be made based on result 0.04 Inertia ratio.	of the load	d characte	eristics	
			Setup value	Function				
	3 to 2	Inertia ratio	[0]	Use the current setup				
	3102	update	1 l	Update by the estimated v	alue.			
			measurement	e inertia ratio update, set t) to 1 (enable). The iner ettings are made valid.				
				date to be made accord	ing to th	e resulta		
			Pr6.08 positive negative directio	estimation of Pr6.07 Torqu direction torque compo- n torque compensation va Function	ensation v Ilue.	value an	nal value, d Pr6.09	
			Pr6.08 positive negative directio	e direction torque componenter torque compensation variables of the second seco	ensation lue. Comp	value an ensation	nal value, d Pr6.09 setup	
			Pr6.08 positive negative directio Setup value [0]	e direction torque component torque component of the second	ensation Ilue. Comp Pr6.07	value an	nal value, d Pr6.09 setup	
		Torque	Pr6.08 positive negative directio Setup value [0]	e direction torque comp in torque compensation va Function Use current setup	ensation Ilue. Comp Pr6.07	value an ensation Pr6.08	nal value, d Pr6.09 setup Pr6.09	
	6 to 4	Torque compensation	Pr6.08 positive negative directio Setup value [0] 1 Dis	e direction torque component on torque compensation variation Function Use current setup sable torque compensation Vertical axis mode Friction compensation (low)	ensation lue. Comp Pr6.07 n 0 clear	ensation Pr6.08 0 clear	nal value, d Pr6.09 setup Pr6.09 0 clear	
	6 to 4		Pr6.08 positive negative directio Setup value [0] 1 Dis 2	e direction torque componentorque compensation vantorque compensation vantorque compensation vantorque compensation vertical axis mode vertical axis mode Friction compensation (low) Friction compensation (middle)	ensation v lue. Pr6.07 n 0 clear Update	ensation Pr6.08 0 clear 0 clear	nal value, d Pr6.09 Pr6.09 0 clear 0 clear	
	6 to 4		Pr6.08 positive negative direction Setup value [0] 1 Dis 2 3 4 5	e direction torque componentorque compensation value compensation value compensation value compensation vertical axis mode vertical axis mode Friction compensation (low) Friction compensation (middle) Friction compensation (high)	ensation v llue. Pr6.07 n 0 clear Update Update Update Update	ensation Pr6.08 0 clear 0 clear Low Middle High	nal value, d Pr6.09 Pr6.09 0 clear 0 clear Low Middle High	
	6 to 4		Pr6.08 positive negative direction Setup value [0] 1 Dis 2 3 4 4 5 * To enable the	e direction torque comp in torque compensation value Function Use current setup sable torque compensation Vertical axis mode Friction compensation (low) Friction compensation (middle) Friction compensation (high) torque compensation (se to 1 (enable). It is not	ensation v llue. Pr6.07 n 0 clear Update Update Update t to 2-5), s	Pr6.08 O clear O clear Low Middle High Set Bits 3-	nal value, d Pr6.09 Pr6.09 0 clear 0 clear Low Middle High -2 (Inertia	
	6 to 4		Pr6.08 positive negative direction Setup value [0] 1 Dis 2 3 4 4 5 * To enable the ratio update) torque compe Enable/disable the	e direction torque comp in torque compensation value Function Use current setup sable torque compensation Vertical axis mode Friction compensation (low) Friction compensation (middle) Friction compensation (high) torque compensation (se to 1 (enable). It is not	ensation v lue. Pr6.07 n 0 clear Update Update Update Update t to 2-5), s cossible to	Pr6.08 O clear O clear Low Middle High set Bits 3- o update	nal value, d Pr6.09 Pr6.09 0 clear 0 clear Low Middle High -2 (Inertia only the	
	6 to 4		Pr6.08 positive negative direction Setup value [0] 1 Dis 2 3 4 5 * To enable the ratio update) torque compe Enable/disable the Real time auto tu	e direction torque componentorque compensation value compensation value compensation value compensation vertical axis mode vertical axis mode Friction compensation (low) Friction compensation (middle) Friction compensation (high) torque compensation (set to 1 (enable). It is not posation.	ensation v lue. Pr6.07 n 0 clear Update Update Update Update t to 2-5), s cossible to	Pr6.08 O clear O clear Low Middle High set Bits 3- o update	nal value, d Pr6.09 Pr6.09 0 clear 0 clear Low Middle High -2 (Inertia only the	
			Pr6.08 positive negative direction Setup value [0] 1 Dis 2 3 4 4 5 * To enable the ratio update) torque compe Enable/disable the	e direction torque componentorque compensation variation variation variation variation variation variation vertical axis mode vertical axis mode vertical axis mode Friction compensation (low) Friction compensation (middle) Friction compensation (high) torque compensation (set to 1 (enable). It is not possible in the basic gain setup to be uning mechanical stiffness	ensation v lue. Pr6.07 n 0 clear Update Update Update Update t to 2-5), s cossible to	Pr6.08 O clear O clear Low Middle High set Bits 3- o update	nal value, d Pr6.09 Pr6.09 0 clear 0 clear Low Middle High -2 (Inertia only the	
	6 to 4	compensation	Pr6.08 positive negative direction Setup value [0] 1 Dis 2 3 4 5 * To enable the ratio update) torque compe Enable/disable the Real time auto to Setup value	e direction torque compensation variation torque compensation variation variation variation variation vertical axis mode vertical axis mode vertical axis mode Friction compensation (low) Friction compensation (middle) Friction compensation (high) torque compensation (set to 1 (enable). It is not insation.	ensation v lue. Pr6.07 n 0 clear Update Update Update Update t to 2-5), s cossible to	Pr6.08 O clear O clear Low Middle High set Bits 3- o update	nal value, d Pr6.09 Pr6.09 0 clear 0 clear Low Middle High -2 (Inertia only the	

1 Before Using the Products

Preparation

Setup

[Class 6] Special setting

					Default: [i 1
			Enable/disable	the change of parameter that is norm	ally set at a fixed value.	
			Setup value	Function		
		Fixed	[0]	Use the current setup.		
	8	parameter	1	Set to a fixed value.		
		setup	* To set this	setting to a value other than 0, set	Bits 3-2 (Inertia ratio	
				1 (enable). Inertia ratio is enabled/c		
			of Bits 1 an	d 0 (load characteristics measureme	ent).	
			Select the gai	n switching related parameter to be	used when the real	
			time auto tuni	ng is enabled.		
			Setup value	Function		
		Gain	[0]	Use the current setup.		
	10 to 9 switching setup	•	1	Disable gain switching.		
		setup	2	Enable gain switching.		
				setting to a value other than 0, set		
			. ,	1 (enable). Inertia ratio is enabled/c		
			of Bits 1 an	d 0 (load characteristics measureme	ent).	
Caution 🔅	This parameter should be setup bit by bit. To prevent setting error, use of the setup support software is recommended when editing parameter. Do not change this parameter while the motor is running. Updated parameters will be effective when the motor stops after the result of load characteristics measurement is confirmed.					
	Setup procedure of bitwise parameter> When setting parameter to a value other than 0, calculate the setup value of Pr6.32 in the following procedure. 1) Identify the LSB of the setup. Example: LSB of the torque compensation function is 4. 2) Multiply the setup value by power of 2 (LSB). Example: To set the torque compensation function to friction compensation (middle): 2 ⁴ × 4 = 64. 3) Perform steps 1) and 2) for every setups, sum up the values which are to be Pr6.32 setup value.					
	,	: Load charac torque compe fixed parame	teristics mea ensation = fric ter = set to a f	surement = enable, inertia rat tion compensation (middle), stiff fixed value, gain switching setup $2^7 \times 1 + 2^8 \times 1 + 2^9 \times 2 = 1477$	io update = enable, ness setup = enable,	

Pr6.34	Hybrid vibration suppression gain	Range	Unit	Default	Rel contro	lated ol mo	
F10.34	Hybrid vibration suppression gain	0 to 30000	0.1 /s	0			F
	Set up the hybrid vibration suppression gain for First set it to the value identical to that of poiso		•	tune as nec	essa	ry.	

Pr6.35	Hybrid vibration suppression filter	Range	Unit			ited mode
P10.35	Hybrid vibration suppression inter	0 to 6400	0.01 ms	10		F
	Set up the time constant of the hybrid vibration suppression filter for full-closed controlling. While driving under full-closed control, gradually increase the setup value and check changes in the response.					
Note	 A parameter is designated as follows: Class _ For parameters which No. have a suffix or you turn on the control power. P.3-32 "Inputs and outputs on connector X4" 	Pr0.00 Paramete f " * ", changed	r No. contents v	will be valida	ated w	hen

Default: []

detection of the alarm condition.

[Class 6] Special setting

Pr6.37	Oscillation detecting level	Range	Unit	Default	Related control mode
P10.37	Oscillation detecting level	0 to 1000	0.1 %	0	PSTF
Pro.s/ Oscillation detecting level 0 to 1000 0.1 % 0 P S T I Set up the oscillation detecting level. If the effective value of the torque vibration, which is calculated from the motor vibration, is the set value, or higher, in this case oscillation detection warning will be issued. If the setting value is 0, then oscillation detection warning is disabled.					

Pr6.38 *	Alarm mask setup	Range	Unit	Default	control mo			
P10.30	Alaliii illask setup	-32768 to 32767	—	4	P S T	F		
Set up the alarm detection mask. Placing 1 to the corresponding bit position disables								

 Pr6.39
 For manufacturer's use
 Range
 Unit
 Default
 Related control mode

 0

A5I	Only available on A5II series.						
Dr6 /1	Anti-vibration depth 1	Range	Unit	Default	Related control mode		
Pr6.41	And-vibration depth 1	0 to 1000	—	0			
Set the anti-vibration depth of 1st damping function.							

A5II	Only available on A5II series.		-			
Pr6.42	Two-stage torque filter time constant	Range	Unit	Default	Related control mode	
F10.42	Two-stage torque litter time constant	0 to 2500	0.01 ms	0	PSTF	
Set the time constant of the filter according to the torque command. The setup value 0 disables filter. Regardless of gain selecting state, this setting always remains valid.						

A	5I	Only available on A5II series.									
Pr6.43		Two-stage torque filter attenuation term	Range	Unit	Default	Related control mode					
P10 .	.43	Two-stage torque litter attenuation term	0 to 1000	—	0	P S T F					
	Set the attenuation term of 2-stage torque filter.										

Related page …

A parameter is designated as follows: Class Pro. O Parameter No.
For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
P.3-32... "Inputs and outputs on connector X4"

Before Using the Products

5

[Class 6] Special setting

A5I	Only av	vailable on A5II series.							
Pr6.47 *	Eupotia	n expension esttinge 2	Range Unit		Default	Related control mo			
F10.4/*	Functio	on expansion settings 2	0 to 15		0	P S T			
Set up the function in unit of bit.									
		Function		Setup va	alue				
		Function	0		1				
	bit 0	Two-degree-of-freedom control mode	Invalid		Valid				
	bit 1	For manufacturer's use		Fixed to 0					
	bit 2	Encoder/external scale communication error judgment setting	Compatible v previous sett		Relax error/ alarm judgment.				
			Standard ty	be	Synchronous type				
	bit 3 Auto tuning selection *1 • The least significant bit is represente • For bit3 (two-degree-of-freedom co time auto tuning select): this is many when bit0 is at 1 (valid).					trol real			

A5I	Only available on A5II series.										
Pr6.48	Adjust filter	Range	Unit	Default	Related control mode						
P10.40		0 to 2000	0.1 ms	0	P S						
Set time constant of adjustment filter for two-degree-of-freedom control (position and speed).											

A5II	Only available on A5II series.									
Pr6.49	Adjust/Torg	le command attenuation term	Range	Unit	Default	Related control mode				
F10.45	Aujustriorqu		0 to 99	—	0	P				
	Set attenuation term of the command filter and adjustment filter for two-degree-of-freedom control (position and speed). Decimal notation: 1st digit sets command filter and 2nd digit sets adjustment filter.									
	value of digit		Content							
	0 to 4	Without attenuation term (function	Without attenuation term (functions as 1st filter).							
	5 to 9	The 2nd filter (attenuation term ζ is 1.0, 0.86, 0.71, 0.50 and 0.35, in that order).								
	Example: To set command filter $\zeta = 1.0$, adjustment filter 1 _ = 0.71: Setup value = 75 1st digit = 5 ($\zeta = 1.0$), 2nd digit = 7 ($\zeta = 0.71$) Pr2.22 Command smoothing filter is applied as time constant of command filter.									

A5II	Only available on A5II series.									
D 0 50		Range	Unit	Default	Related control mode					
Pr6.50	Viscous friction compensation gain	0 to 10000	0.1 %/ (10000 r/min)	0	P					
	Command velocity is multiplied by this setting and the result is added to the torque command as compensation value. The unit is [Rated torque 0.1 %/(10000 r/min)].									
 Note → A parameter is designated as follows: Class Pr0.00 Parameter No. For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power. P.3-32 "Inputs and outputs on connector X4" 										

[Class 6] Special setting

A5II	Only available on A5II series.									
Pr6.51	Immediate cessation completion wait time	Range	Unit	Default	Related control mode					
P10.51	inimediate cessation completion wait time	0 to 10000	ms	0	PSTF					
When immediate stop alarm is occurs, turn off brake release output (BRK-OFF) and set the time during which the current flows through the motor. Setting resolution is 2 ms. For example: when the setup value is 11, the time required for processing is 12 ms.										

A5I	Only available o	on A5II series.							
Pr6.57	Torque saturation	an anomaly day	lastion (limo	Ra	nge	Unit	Default	Related control mode
P10.57	Torque saturation			line	0 to	0 to 5000 ms		0	P S F
	Set torque saturat When torque saturat protection occurs. When the setup va • For example, if longer than 5 sec • During torque co • During immediat Torque Torque limit —•	ration still conti alue is 0, this fu setting is 5000 c. ntrolling, this fu e stop alarm, th	inues af inction is), Err16. nction is	ter th s disa .1 wil s disa	e prese bled an I genera bled an	d no alai ate whei d Err16. ⁻	rm will ger n torque s 1 will not g	nerate. saturation c generate.	ontinues
	Torque controlling signal output (TLC)	OFF	ON	0	FF		ON	OFF	Time
	Servo-Alarm outp (ALM)			not	Alarm			Err16.1 oc	curs
		Pr6.57 setu	ıp value (ms) or	less l	Pr6.57 set	up value (m	is)	
	has setu	ondition Pr6.57 16.1 will nt is	cc th	ontinues f an Pr6.57	ue saturati for a period 7 setup va 1 generate	d longer lue,			

Note

Related page …

A parameter is designated as follows: Class <u>Pro</u>.oo Parameter No.
For parameters which No. have a suffix of "*", changed contents will be validated when you turn on the control power.
P.3-32... "Inputs and outputs on connector X4"

1

Before Using the Products

2

Preparation

3

Connection

4

Setup



2.Trial Run (JOG run)


Inspection Before Trial Run

(1) Inspection on wiring

- · Miswiring ? (Especially power input and motor output)
- · Short or grounded ?
- Loose connection ?

(2) Confirmation of power supply and voltage

Rated voltage ?



(6) Turn to Servo-OFF after finishing the trial run by pressing (\underline{S}) .

• Details of wiring, refer to P.2-12... "Overall Wiring"

The figure above shows connections on velocity, position, torque and full-closed mode driver.
Only for position control type is not provided with X2 (Communication connector), X3 (Safety function connector), X5 (External scale connector).


2.Trial Run (JOG run)

Trial Run by Connecting the Connector X4

Trial Run (JOG run) at Position Control Mode

- (1) Connect the Connector X4.
- (2) Enter the power (DC12 V to 24 V) to control signal (COM+, COM-)
- (3) Enter the power to the driver.
- (4) Confirm the default values of parameters.
- (5) Match to the output format of the host controller with Pr0.07 (Command pulse input mode setup).
- (6) Write to EEPROM and turn off/on the power (of the driver).
- (7) Connect the Servo-ON input (SRV-ON) and COM– (Connector X4, Pin-41) to bring the driver to Servo-ON status and energize the motor.
- (8) Enter low frequency from the host controller to run the motor at low speed.
- (9) Check the motor rotational speed at monitor mode whether, rotational speed is as per the setup or not, and the motor stops by stopping the command (pulse) or not.
- (10) If the motor does not run correctly, refer to P.2-102, "Display of Factor for No-Motor Running" of Preparation.

Wiring Diagram



• Parameter

Pr No.	Title	Setup value
0.01	Control mode setup	0
5.04	Over-travel inhibit input setup	1
0.05	Selection of command pulse input	0/1
0.07	Command pulse input mode setup	1
5.18	Invalidation of command pulse inhibit input	1
5.17	Counter clear input mode	2

Input signal status

No.	Title of signal	Monitor display
0	Servo-ON	+A

2

Preparation

5

4-67

Trial Run by Connecting the Connector X4


Trial Run (JOG run) at Velocity Control Mode

- 1) Connect the Connector X4.
- 2) Enter the power (DC12 V to 24 V) to control signal (COM+, COM-)
- 3) Enter the power to the driver.
- 4) Confirm the default values of parameters.
- 5) Connect the Servo-ON input (SRV-ON, Connector X4, Pin-29) and COM– (Connector X4, Pin-14) to turn to Servo-ON and energize the motor.
- 6) Close the speed zero clamp input (ZEROSPD) and apply DC voltage between velocity command input, SPR (Connector X4, Pin-14) and GND (Connector X4, Pin-15), and gradually increase from 0 V to confirm the motor runs.
- 7) Confirm the motor rotational speed in monitor mode.
 - Whether the rotational speed is per the setup or not.
 - · Whether the motor stops with zero command or not.
- 8) If the motor does rotate at a micro speed with command voltage of 0.
- 9) When you want to change the rotational speed and direction, set up the following parameters again.

Pr3.00: Speed setup, Internal/External switching	Refer to P.4-29, 30 "Param-
Pr3.01: Speed command rotational direction selection	– eter Setup" (Parameters for
Pr3.03: Reversal of speed command input _	Velocity/Torque Control)

10)If the motor does not run correctly, refer to P.2-102, "Display of Factor for No-Motor Running" of Preparation.

Wiring Diagram



Run with ZEROSPD switch close, and Stop with open

In case of bi-directional operation (Positive/Negative), provide a bipolar power supply, or use with Pr3.15 = 3. In case of one-directional operation

Parameter

Pr No.	Title	Setup value
0.01	Control mode setup	1
5.04	Over-travel inhibit input setup	1
3.15	Speed zero-clamp function selection	1
3.00	Speed setup, Internal/External switching	
3.01	Speed command rotational direction selection	
3.02	Input gain of speed command	Set up as
3.03	Reversal of speed command input required	
4.22	Analog input 1 (AI1) offset setup	
4.23	Analog input 1 (Al1) filter	

Input signal status

No.	Title of signal	Monitor display
0	Servo-ON	+A
5	Speed zero clamp	—

Note \Rightarrow • Only for position control type is not provided with analog input.

Trial Run by Connecting the Connector X4


Trial Run (JOG run) at Torque Control Mode

- 1) Connect the Connector X4.
- 2) Enter the power (DC12 V to 24 V) to control signal (COM+, COM-)
- 3) Enter the power to the driver.
- 4) Confirm the default values of parameters.
- 5) Set a lower value to Pr3.07 (4th speed of speed setup).
- 6) Energize the motor by connecting the Servo-ON input (SRV-ON, Connector X4, Pin-29) and COM– (Pin-41 of Connector X4) to turn to Servo-ON status.
- 7) Confirm that the motor runs as per the setup of Pr3.07 by applying DC voltage (positive/negative) between the torque command input (Pin-14 of Connector X4) and GND (Pin-15 of Connector X4).
- 8) If you want to change the torque magnitude, direction and velocity limit value against the command voltage, set up the following parameters.

Pr3.19: Input gain of torque command Pr3.20: Input reversal of torque command Pr3.21: Speed limit value 1

- Refer to P.4-33, 34, "Parameter Setup" - (Parameters for Velocity/Torque Control)
- 9) If the motor does not run correctly, refer to P.2-102, "Display of factor for No-motor running" of Preparation.

Wiring Diagram



For bi-directional running (Positive/Negative), provide a bipolar power supply.

In case of one way running

Parameter

Pr No.	Title	Setup value	
0.01	Control mode setup	2	
5.04	Over-travel inhibit input setup	1	
3.15	Speed zero-clamp function selection	0	
3.17	Selection of torque command	0	
3.19	Input gain of torque command	Set up as	
3.20	Input reversal of torque command	required	
3.21	Speed limit value 1 lower value		

Input signal status

No.	Title of signal	Monitor display
0	Servo-ON	+A
5	Speed zero clamp	—

• Only for position control type is not provided with analog input. Note

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

2.Trial Run (JOG run)

Setup of Motor Rotational Speed and Input Pulse Frequency


Input pulse frequency	Motor rotational speed	Pr0.08		
(pps)	(r/min)	17-bit	20-bit	
2 M	3000	2 ¹⁷ 40000	2 ²⁰ 40000	
500 K	3000	2 ¹⁷ 10000	2 ²⁰ 10000	
250 K	3000	2 ¹⁷ 5000	2 ²⁰ 5000	
100 K	3000	2 ¹⁷ 2000	2 ²⁰ 2000	
500 K	1500	2 ¹⁷ 20000	2 ²⁰ 20000	

Note

When setting Pr0.08, and encoder resolution is automatically set up as numerators. For full closed controlling, setting of Pr0.08 is ignored and settings of Pr0.09 and Pr0.10 are always applied.


Caution 🔅

- Max. input pulse frequency varies depending on input terminals.
 - The desired setting can be determined by selecting value of numerator and denominator of electronic gear. However, an excessively high division or multiplication ratio cannot guarantee the operation. The ratio should be in a range between 1/1000 and 1000. Excessively high multiplication ratio will cause Err27.2 (command pulse multiplication error protection) due to varying command pulse input or noises, even if the other settings are within the specified range.



When setting the command division and multiplication ratio as numerator/denominator, express it as Pr0.09/Pr0.10 with Pr0.08 = 0. For full closed controlling, setting of Pr0.08 is ignored and settings of Pr0.09 and Pr0.10 are always applied.
e.g.) When you want to rotate the motor by 60° with the load of total reduction ratio of 18/365.

	Encoder	
	17-bit	20-bit
Pr0.09 Pr0.10	<u>5840</u> 108	<u>5840</u> 67500
Command pulse	To rotate the output shaft by 60°, enter the command of 8192 (2 ¹³) pulses from the host controller.	To rotate the output shaft by 60°, enter the command of 10000 pulses from the host controller.
How to determine parameter	$ \frac{365}{18} \times \frac{1 \times 2^{17}}{2^{13}} \times \frac{60^{\circ}}{360^{\circ}} \\ = \frac{5840}{108} $	$ \frac{365}{18} \times \frac{1 \times 2^{20}}{10000} \times \frac{60^{\circ}}{360^{\circ}} \\ = \frac{5840}{67500} $



* Refer to P.2-86 "Setup of command division and multiplication ratio (electronic gear ratio)" of Supplement.

4-70 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Before Using the Products

2

3

Connection

Setup

5

7


5. Adjustment

1. Gain Adjustment Outline	5.0
2. Real-Time Auto-Gain Tuning	
Basic	5-4
A5II Two-degree-of-freedom control mode	Standard type5-10
A51 Two-degree-of-freedom control mode	Synchronous type5-17
3. Adaptive filter Adaptive filter	5-24
4. Manual Gain Tuning (Basic)	
Outline	
Adjustment in Position Control Mode	
Adjustment in Velocity Control Mode	
Adjustment in Torque Control Mode	
Adjustment in Full-Closed Control Mode	
Gain Switching Function	
Suppression of Machine Resonance	
5. Manual Gain Tuning (Application)	
Damping Control	5-38
Feed forward function	5-41
Instantaneous Speed Observer	5-44
Disturbance observer	
3rd gain switching function	5-48
Friction torque compensation	5-50
Inertia ratio switching function	5-52
Hybrid vibration damping function	5-54
Two-degree-of-freedom control mode	(Position control)5-55
A5II Two-degree-of-freedom control mode	(Velocity control)5-57
A5II Two-stage torque filter	5-58
6. About Homing Operation	
Caution on Homing Operation	5-60
Homing with Hit & Stop	5-61
Press & Hold Control	5-62


Purpose

It is required for the servo driver to run the motor in least time delay and as faithful as possible against the commands from the host controller. You can make a gain adjustment so that you can run the motor as closely as possible to the commands and obtain the optimum performance of the machine.

<e.g. : Ball screw>



Procedures



Note For safety operation, first adjust the gain by referring to P.6-20 Setup of gain pre-adjustment protection.

⁵⁻² Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

1. Gain Adjustment

Outline

Туре

	Function		Explanation	Pages to refer
	Re	eal-time auto-gain tuning	Estimates the load inertia of the machine in real time, and automatically sets up the optimum gain corresponding to this result.	P.5-4
Automatic adjustment	Абл Two-degree-of-freedom control mode *1		In the two-degree-of-freedom control mode, command response and servo rigidity can be independently set with improved responsiveness. This mode has enhanced position and speed control functions.	P.5-10
atic 1ent	Adaptive filter		Reduces the resonance vibration point by automatically setting up the notch filter coefficient which removes the resonance component from the torque com- mand while estimating the resonance frequency from the vibrating component which appears in the motor speed in actual operating condition.	P.5-24
	Ma	anual gain tuning (basic)	Execute the manual adjustment or fine-tuning when real-time auto-gain tuning cannot be activated due to the limitation of operation or load condition, or when you want to obtain an optimum response and stability under these conditions.	P.5-27
			Adjustment in position control mode	P.5-28
		Basic procedure	Adjustment in velocity control mode	P.5-29
		Basic procedure	Adjustment in torque control mode	P.5-29
			Adjustment in full-closed control mode	P.5-30
		Gain switching func- tion	You can expect to reduce vibration at stopping and settling time and to improve command compliance by switching the gains by internal data or external signals.	P.5-31
		Suppression of ma- chine resonance	When the machine stiffness is low, vibration or noise may be generated due to the distorted axis, hence you cannot set the higher gain. You can suppress the resonance with two kinds of filter.	P.5-34
	Manual gain tuning (application)		You can obtain the higher performance while you are not satisfied with the performance obtained with the basic adjustment, using the following application functions.	
Manu		Damping control	Function which reduces vibration by removing the vibration frequency compo- nent while the front end of the machine vibrates.	P.5-38
Manual adjustment		Feed forward function	Velocity feed forward function improves responsiveness during position control and full closed control. Torque feed forward improves the response of velocity control system.	P.5-41
ment		Instantaneous speed observer	Function which obtains both high response and reduction of vibration at stop- ping by estimating the motor speed with the load model, and hence improves the accuracy of speed detection.	P.5-44
		Disturbance observer	Function which uses estimated disturbance torque to reduce effects of the disturbance torque and to reduce vibration.	P.5-46
		3rd gain switching function	By using this function in addition to the normal gain switching function, the gain can be changed at the moment of stop to further shorten the positioning time.	P.5-48
		Friction torque compensation	Offset load compensation and dynamic friction compensation are used to reduce effects of mechanical friction.	P.5-50
		Inertia ratio switching function	This function can be used when selectable 2 inertia ratios are provided.	P.5-52
		Hybrid vibration damping function	This function, when used in full closed control mode, prevents vibration resulting from torsion on motor and load.	P.5-54
		A51 Two-degree-of-freedom control mode *1	In the two-degree-of-freedom control mode, command response and servo rigidity can be independently set with improved responsiveness. This mode has enhanced position and speed control functions.	P.5-55
		A5II Two-stage torque filter *1	In addition to 1st and 2nd torque filters (Pr1.04 and Pr1.09), another torque filter can be set.	P.5-58

Caution 🔅

*1 Two-degree-of-freedom control mode and 2-stage torque filter are available only with A5I (A5IIE) series and not with A5 and A5E.

Remarks 🔅

• Pay extra attention to safety, when oscillation (abnormal noise and vibration) occurs, shut off the main power, or turn to Servo-OFF.

1

Preparation

3

Connection

4

Setup

Adjustment

5

6 Wh

When in Trouble


7

Supplement

Basic

Outline

The system estimates the load characteristics in real time, and automatically performs basic gain setting and friction compensation by referring to stiffness parameter.



Applicable Range

Real time auto-gain tuning is applicable to all control modes.

	Real-time auto-tuning condition
Control Mode	Specific real-time auto-tuning mode is selected according to the currently active control mode. For details, refer to the description of Pr0.02 Real-time auto-tuning setup.
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Caution

Real-time auto-gain tuning may not be executed properly under the conditions described in the table below. Under these conditions, change the load condition or operation pattern, or start manual gain tuning (see P.5-27).

	Conditions which obstruct real-time auto-gain tuning action
 Load inertia • The load is too small or large compared to the rotor inertia. (times or more than 20 times). • The load inertia changes too quickly. 	
Load • The machine stiffness is extremely low. • Nonlinear characteristics such as backlash exist.	
Action pattern	 The motor is running continuously at low speed of (100 [r/min] or lower. Acceleration/deceleration is slow (2000 [r/min] per 1[s] or low). Acceleration/deceleration torque is smaller than unbalanced weighted/ viscous friction torque. When the speed condition of 100 [r/min] or more and acceleration/ deceleration condition of 2000 [r/min] per 1 [s] are not maintained for 50 [ms].

How to Operate

- 1) Bring the motor to stall (Servo-OFF).
- 2) Set up Pr0.02 (Setup of real-time auto-gain tuning mode) to 1-6. Default is set to 1.

Setup value	Real-time auto-gain tuning	
0	Invalid	
1	Standard	
2	Positioning *1	
3	Vertical axis *2	
4	Friction compensation *3	
5	Load characteristic measurement	
6	Customize *4	

- *1 Velocity and torque controls are the same as in the standard mode.
- *2 Torque control is the same as in the standard mode.
- *3 Velocity control is the same as in the vertical axis mode. Torque control is the same as in the standard mode.
- ^{*}4 Certain function(s) is not available in a specific control mode. Refer to description in Pr6.32.

Control parameter is automatically set according to Pr0.03 Real-time auto-tuning stiffness setup. For details, see P.5-6 and 5-7.

3) Turn on servo, and start the machine.

Estimation of load characteristics starts.

4) When the load characteristics are determined, Pr0.04 Inertia ratio is updated. In a specific mode, the following parameters are changed:

Pr6.07 Torque command additional value

Pr6.08 Positive direction torque compensation value

Pr6.09 Negative direction torque compensation value

Load characteristics estimation speed can be set by Pr6.31 Real time auto tuning estimation speed.

5) When value of Pr0.03 Real-time auto-tuning stiffness setup is increased, the motor responsiveness will be improved.

Determine the most appropriate stiffness in relation to the positioning setup time and vibration condition.

6) To save the result to memory, write the data to EEPROM.

Caution 🔅 If power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

Note • While the auto-tuning is valid, parameters that are to be automatically adjusted cannot be changed.

Related page … • P.2-109 "EEPROM Writing Mode" • P.4-5..., 4-60, 4-61 "Details of parameter"

Before Using the Products

2

Preparation

3

Connection

6

When in Trouble

Parameters set/changed by real-time auto-gain tuning

Parameters which are updated

The real-time auto-tuning function updates the following parameters according to Pr0.02 Real-time auto-tuning setup and Pr6.32 Real-time auto-tuning custom setup and by using the load characteristic estimate values.

Class	No.	Title	Function
0	04	Inertia ratio	Updates this parameter when the real-time auto- tuning inertia ratio update is enabled.
6	07	Torque command additional value	Update this parameter when the vertical axis mode for real time auto-tuning is valid.
6	08	Positive direction torque compensation value	Update this parameter when the friction compensation mode for real time auto-tuning is valid.
6	09	Negative direction torque compensation value	Update this parameter when the friction compensation mode for real time auto-tuning is valid.

• Parameters which are updated to setup value corresponding to stiffness setup The real-time auto-tuning function updates the following basic gain setup parameters according to Pr0.03 Real-time auto-tuning stiffness setup.

Class	No.	Title	Function
1	00	1st gain of position loop	
1	01	1st gain of velocity loop	
1	02	1st time constant of velocity loop integration	When stiffness setup is valid, updates the
1	04	1st time constant of torque filter	parameter based on the setup value.
1	05	2nd gain of position loop	Refer to P.5-9 Basic gain parameter setup table.
1	06	2nd gain of velocity loop	
1	07	2nd time constant of velocity loop integration	
1	09	2nd time constant of torque filter	

Parameters which are set to fixed value

Real-time auto-tuning function sets the following parameters to the fixed value.

Class	No.	Title	Setup value when fixed parameter setup is valid.
1	03	1st filter of speed detection	0
1	08	2nd filter of speed detection	0
1	10	Velocity feed forward gain	300 (30 %)
1	11	Velocity feed forward filter	50 (0.5 ms)
1	12	Torque feed forward gain	0
1	13	Torque feed forward filter	0

Related page • P.4-7 "Pr0.04" • P.4-14... "Pr1.00..." • P.4-57 "Pr6.07..."

$\boldsymbol{\cdot}$ Parameters which are set in response to gain switching setup

The real-time auto-tuning function sets the following parameters as the gain is switched.

Class	No.	Title	Function
1	14	2nd gain setup	Sets to 1 if the current setting is not maintained.
1	15	Mode of position control switching	Sets to 10 to enable the gain switching. Sets to 0 to disable the gain switching.
1	16	Delay time of position control switching	Sets to 50 if the current setting is not maintained.
1	17	Level of position control switching	maintaineo.
1	18	Hysteresis at position control switching	Sets to 33 if the current setting is not
1	19	Position gain switching time	maintained.
1	20	Mode of velocity control switching	
1	21	Delay time of velocity control switching	
1	22	Level of velocity control switching	
1	23	Hysteresis at velocity control switching	Sets to 0 if the current setting is not maintained.
1	24	Mode of torque control switching	
1	25	Delay time of torque control switching	
1	26	Level of torque control switching	
1	27	Hysteresis at torque control switching	

Parameters which are always set to invalid.

The following settings are always set to invalid when Pr0.02 Real-time auto-tuning setup is not 0.

Class	No.	Title	Function
6	10	Function expansion setup	Instantaneous speed observer function enable bit (bit 0), disturbance observer function enable bit (bit 1) and inertia ratio switching function enable bit (bit 3) are internally disabled.
6	13	2nd Inertia ratio	
6	23	Disturbance torque compensating gain	Parameter setup can be changed, but disturbance observer is disabled.
6	24	Disturbance observer filter	

4

1

Before Using the Products

2

Preparation

3

Connection

5

6

Caution

- Immediately after the first servo-on upon start up; or after increasing Pr0.03 Real-time auto-tuning stiffness setup, abnormal sound or oscillation may be generated until the load characteristics estimation is stabilized. If such abnormality lasts or repeats for 3 or more reciprocating operations, take the following countermeasures.
 Lower the setup of Pr0.03 (Selection of machine stiffness at real-time auto-gain
 - tuning).
 - 2) Set Pr0.02 Real-time auto-tuning setup to 0 to disable the real-time auto-tuning.
 - 3) Set Pr0.04 Inertial ratio to the calculational value of the equipment and set Pr6.07 Torque command addition value, Pr6.08 Positive direction compensation value and Pr6.09 Negative direction compensation value to 0.
- (2) When abnormal noise and oscillation occur, Pr0.04 (Inertia ratio) or Pr6.07 (Torque command additional value), Pr6.08(Positive direction torque compensation value), Pr6.09(Negative direction torque compensation value) might have changed to extreme values. Take the same measures as the above in these cases.
- (3) Among the results of real-time auto-gain tuning, Pr0.04 (Inertia ratio) and Pr6.07 (Torque command additional value), Pr6.08(Positive direction torque compensation value), Pr6.09(Negative direction torque compensation value) will be written to EE-PROM every 30 minutes. When you turn on the power again, the auto-gain tuning will be executed using the latest data as initial values.
- (4) Because the control gain is updated while the motor stops, changed setting value of Pr0.03 "Real-time auto-tuning stiffness setup" may not be reflected if the motor cannot stop due to excessively low gain or application of a command that directs the motor to turn in the same direction continuously. If the changed stiffness setting value is reflected after motor stops, it may generate abnormal sound or oscillate.

After changing stiffness, stop the motor and check to see that the new stiffness setting is made effective.

Invalidation of Real-Time Auto-Gain Tuning

You can stop the automatic calculation of Pr0.04 (Inertial ratio) and invalidate the realtime auto-gain tuning by setting up Pr0.02 (Real-time auto-gain tuning setup) to 0. Since the estimation result of Pr0.04 "Inertia ratio" remains, and if this parameter becomes clearly abnormal value, manually set to the appropriate value which is obtained from suitable formula or calculation.

Caution If power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

Basic gain parameter setup table

	1st gain				2nd	gain			
	Pr1.00	Pr1.01	Pr1.02	Pr1.04 *2	Pr1.05	Pr1.06	Pr1.07 *4	Pr1.09 *2	A4
Stiffness	Gain of position loop [0.1 /s]	Gain of velocity loop [0.1 Hz]	Time constant of velocity loop integration [0.1 ms]	Time constant of torque filter [0.01 ms]	Gain of position loop [0.1 /s]	Gain of velocity loop [0.1 Hz]	Time constant of velocity loop integration [0.1 ms]	Time constant of torque filter [0.01 ms]	Series Stiffness setup (reference) *1
0	20	15	3700	1500	25	15	10000	1500	—
1	25	20	2800	1100	30	20	10000	1100	—
2	30	25	2200	900	40	25	10000	900	—
3	40	30	1900	800	45	30	10000	800	_
4	45	35	1600	600	55	35	10000	600	_
5	55	45	1200	500	70	45	10000	500	_
6	75	60	900	400	95	60	10000	400	_
7	95	75	700	300	120	75	10000	300	_
8	115	90	600	300	140	90	10000	300	0
9	140	110	500	200	175	110	10000	200	_
10	175	140	400	200	220	140	10000	200	_
11 *3	320	180	310	126	380	180	10000	126	1
12	390	220	250	103	460	220	10000	103	2
13 *3	480	270	210	84	570	270	10000	84	3
14	630	350	160	65	730	350	10000	65	4
15	720	400	140	57	840	400	10000	57	5
16	900	500	120	45	1050	500	10000	45	6
17	1080	600	110	38	1260	600	10000	38	7
18	1350	750	90	30	1570	750	10000	30	8
19	1620	900	80	25	1880	900	10000	25	9
20	2060	1150	70	20	2410	1150	10000	20	10
21	2510	1400	60	16	2930	1400	10000	16	11
22	3050	1700	50	13	3560	1700	10000	13	12
23	3770	2100	40	11	4400	2100	10000	11	13
24	4490	2500	40	9	5240	2500	10000	9	14
25	5000	2800	35	8	5900	2800	10000	8	_
26	5600	3100	30	7	6500	3100	10000	7	15
27	6100	3400	30	7	7100	3400	10000	7	_
28	6600	3700	25	6	7700	3700	10000	6	_
29	7200	4000	25	6	8400	4000	10000	6	_
30	8100	4500	20	5	9400	4500	10000	5	_
31	9000	5000	20	5	10500	5000	10000	5	_

*1 Stiffness setting of A4 series refers to the setup value (0-15) of A4 series parameter Pr22 Real-time auto-tuning machine stiffness selection.

*2 When 17-bit absolute encoder, limited by the minimum value 10.

*3 Default stiffness setting: 13 for frames A, B and C, 11 for frames D, E, F, G and H.

*4 In the vertical axis mode or friction compensation mode (Pr0.02 = 3, 4), Pr1.07 keeps 9999 (hold) until load characteristics estimation completes.

Note

• For details of parameters, refer to P.4-14... "Details of parameter".

· Download the A4 series manual from the web site

1

Before Using the Products

2

Preparation

Setup

2. Real-Time Auto-Gain Tuning

Adjustment

A5I Two-degree-of-freedom control mode – Standard type

Outline

In this auto-tuning mode, two-degree-of-freedom control is available in addition to realtime auto tuning basic function.

The standard type is a mode that is suitable for positioning, and the 3rd gain switching and viscous friction compensation are enabled.

The two-degree-of-freedom control mode, standard type, can be used by setting Pr6.47 Function expansion setup 2 to bit 0 = 1 and bit 3 = 0.

Applicable Range

	Real-time auto-tuning condition		
Control Mode Real-time auto-tuning, two-degree-of-freedom control mode, standard ty can be applied for position control and speed control.			
Others	 Should be in servo-on condition. Input signals, such as deviation counter clear and command input inhibit, and parameters, except for controls such as torque limit setup, are correctly set, assuming that the motor can run smoothly. 		

Caution

Real-time auto-gain tuning may not be executed properly under the conditions described below.

Under these conditions, change the load conditions or operation patterns, or start manual gain tuning (refer to P.5-27 and subsequent).

	Conditions which obstruct real-time auto-gain tuning
Load inertia	 Load is small or large compared with the rotor inertia (less than 3 times or more than 20 times). The load inertia changes.
Load	 The machine stiffness is extremely low. Nonlinear characteristics such as backlash exist.
Action pattern	 The motor is running continuously at low speed of 100 [r/min] or lower. Acceleration/deceleration is slow (2000 [r/min/1[s] or low). Acceleration/deceleration torque is smaller than unbalanced weighted/ viscous torque. When speed condition of 100 [r/min] or more and acceleration/decelera- tion condition of 2000 [r/min]/1[s] are not maintained for 50 [ms].

A511 Two-degree-of-freedom control mode – Standard type

How to Operate

- 1) Bring the motor to stall (Servo-off).
- 2) Set up Pr0.02 (Setup of real-time auto-gain tuning mode) to other than 0, 6.

•	、	
Setup value	Real-time auto-gain tuning	Explanation
0, 6	Invalid	Real-time auto-gain tuning function is disabled.
1	Standard response mode	Stability-first mode. Do not use unbalanced load compensation, friction compensation or gain switching.
2	Quick response mode 1	Positioning-first mode. Use this mode for equipment with horizontal axis, low friction ball screw driving and without unbalanced load.
3	Quick response mode 2	In addition to the features provided with the Quick response mode 1, use this mode to compensate unbalanced load, to apply third gain to reduce variation in positioning settling time.
4	Quick response mode 3 ^{*1}	In addition to the features provided with the Quick response mode 2, use this mode to shorten positioning settling time when the load has high friction.
5	Load characteristic measurement	Estimate load characteristics without changing basic gain setting or friction compensation setting with the help of the setup support software.
	L	

Control parameter is automatically set according to Pr0.03 Real-time auto-tuning stiffness setup.

[Example of real-time auto-tuning setup]

1) When performing adjustment focusing on settling time by using PTP control.

It is recommended to use quick response mode (Pr0.02 = 2-4). When friction has large effect, use quick response mode 3 (Pr0.02 = 4).

The 3rd gain of quick response mode 2 and 3 (Pr0.02 = 3-4) should be doubled for a short time to damp vibration during settling.

If Pr0.03 (stiffness setting) is too high, it may cause oscillation during settling time. Observe the settled waveform.

2) When locus accuracy is necessary in CP control of machine e.g. processing machine, use the standard mode (Pr0.02 = 1) or quick response mode 1 (Pr0.02 = 2) if higher accuracy is required.

When 2 or more axes must be synchronized together, coordinate the stiffness setting (Pr0.03) so that Pr2.22 (command smoothing filter) of all axes have the same value.

*1 Velocity control is the same as in the quick response mode 2. Value of parameters, Pr6.08 Forward torque compensation value, Pr6.09 Backward torque compensation value and Pr6.50 Viscous friction compensation gain will be updated but not reflected on operation. Setup

A5II Two-degree-of-freedom control mode – Standard type

- 3) When the servo is tuned on, input the action command.
- As the load characteristics are correctly estimated, Pr0.04 Inertia ratio will be updated. In a specific mode, the following parameters are changed.
 - Pr6.07 Torque command additional value
 - Pr6.08 Positive direction torque compensation value
 - Pr6.09 Negative direction torque compensation value
 - Pr6.50 Viscous friction compensation gain
 - Load characteristics estimation speed can be set by Pr6.31 Real time auto tuning estimation speed.
- 5) When value of Pr0.03 Real-time auto-tuning stiffness setup is increased, the motor responsiveness will be improved.

Determine the most appropriate stiffness in relation to the positioning setup time and vibration condition.

- 6) To save the result to memory, write the date to EEPROM.
- **Caution** if power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

Note
While the auto-tuning is valid, parameters that are to be automatically adjusted cannot be changed.

Related page : P.2-109 "EEPROM Writing Mode" • P.4-6, 4-60 "Details of parameter"

A5II Two-degree-of-freedom control mode – Standard type

Parameters set/changed by real-time auto-gain tuning

Parameters which are updated

The real-time auto-tuning function updates the following parameters according to Pr0.02 Real-time auto-tuning setup by using the load characteristic estimate values.

Class	No.	Title	Function
0	04	Inertia ratio	Updates this parameter when the real-time auto-tuning is enabled ($Pr0.02 = 1 \text{ to } 4$).
6	07	Torque command additional value	Updates this parameter when the real-time auto-tuning is in the quick response mode 2, 3 ($Pr0.02 = 3, 4$).
6	08	Positive direction torque compen- sation value	Updates this parameter when the real-time
6	09	Negative direction torque compen- sation value	auto-tuning is in the quick response mode 3 $(Pr0.02 = 4)$.
6	50	Viscous friction compensation gain	

• Parameters which are updated to setup value corresponding to stiffness setup The real-time auto-tuning function updates the following basic gain setup parameters according to Pr0.03 Real-time auto-tuning stiffness setup.

Class	No.	Title	Function	
1	00	1st gain of position loop		
1	01	1st gain of velocity loop		
1	02	1st time constant of velocity loop integration	When real-time auto-tuning is valid (Pr0.02	
1	04	1st time constant of torque filter	= 1 to 4), updates the setup value according to the stiffness.	
1	05	2nd gain of position loop	Refer to P.5-9 Basic gain parameter setup	
1	06	2nd gain of velocity loop	table.	
1	07	2nd time constant of velocity loop integration	-	
1	09	2nd time constant of torque filter		
2	22	Command smoothing filter	When real-time auto-tuning is valid (Pr0.02	
6	48	Adjust filter	 = 1 to 4), updates the setup value according to the stiffness. * For velocity control, primary filter is fixed. 	

Parameters which are set to fixed value

Real-time auto-tuning function sets the following parameters to fixed value.

Class	No.	Title	Setup value
1	03	1st filter of speed detection	0
1	08	2nd filter of speed detection	0
1	10	Velocity feed forward gain	1000 (100 %)
1	11	Velocity feed forward filter	0
1	12	Torque feed forward gain	1000 (100 %)
1	13	Torque feed forward filter	0
6	10	Function expansion setup 2	bit4=1
6	49	Adjust/Torque command attenuation term	15

Parameters which are set in respons to gain switching setup

The real-time auto-tuning function sets the following parameters as the gain is switched.

Class	No.	Title	Function
1	14	2nd gain setup	Sets to 1 if real-time auto-tuning is valid $(Pr0.02 = 1 \text{ to } 4).$
1	15	Mode of position control switching	Sets to 0 when in standard response mode ($Pr0.02 = 1$); or to 7 when in quick response mode 1 to 3 ($Pr0.02 = 2$ to 4).
1	16	Delay time of position control switching	Sets to 10 if real-time auto-tuning is valid $(Pr0.02 = 1 \text{ to } 4).$
1	17	Level of position control switching	Sets to 0 if real-time auto-tuning is valid
1	18	Hysteresis at position control switching	(Pr0.02 = 1 to 4).
1	19	Position gain switching time	Sets to 10 if real-time auto-tuning is valid (Pr0.02 = 1 to 4).
1	20	Mode of velocity control switching	Sets to 0 if real-time auto-tuning is valid
1	21	Delay time of velocity control switching	(Pr0.02 = 1 to 4).
1	22	Level of velocity control switching	Sets to 10 if real-time auto-tuning is valid $(Pr0.02 = 1 \text{ to } 4).$
1	23	Hysteresis at velocity control switching	Sets to 0 if real-time auto-tuning is valid
1	24	Mode of torque control switching	(Pr0.02 = 1 to 4).
1	25	Delay time of torque control switching	Sets to 10 if real-time auto-tuning is valid $(Pr0.02 = 1 \text{ to } 4).$
1	26	Level of torque control switching	Sets to 0 if real-time auto-tuning is valid
1	27	Hysteresis at torque control switching	(Pr0.02 = 1 to 4).
6	05	Position 3rd gain valid time	Sets to 0 (invalid) when in standard response mode or high speed response mode 1 (Pr $0.02 = 1, 2$). When in high speed response mode 2 or 3 (Pr $0.02 = 3, 4$), sets to Pr 2.22×20 (max. value is limited to 10000).
6	06	Position 3rd gain scale factor	When in standard mode or high speed response mode 1, (Pr $0.02 = 1, 2$), sets to 100 (100 %). When in high speed response mode 2 or 3, (Pr $0.02 = 3, 4$), sets to 200 (200 %).

Parameters which are always set to invalid

The following settings are always set to invalid when Pr0.02 Real-time auto-tuning setup is not 0.

Class	No.	Title	Function	
6	10	Function expansion setup	Instantaneous speed observer function enable bit (bit 0), disturbance observer function enable bit (bit 1) and inertia ratio switching function enable bit (bit 3) are internally disabled.	
6	13	2nd Inertia ratio	Parameter setup can be changed, but inertia ration switching function is disabled.	
6	23	Disturbance torque compensating gain	Parameter setup can be changed, but disturbance	
6	24	Disturbance observer filter	compensation function is disabled.	

Related page • P.4-16... "Pr1.14..." • P.4-57... "Pr6.10..."

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

7

A5II Two-degree-of-freedom control mode – Standard type

Caution

- (1) Immediately after the first servo-on upon start up; or after increasing Pr0.03 Real-time auto-tuning stiffness setup, abnormal sound or oscillation may be generated until the load characteristics estimation is stabilized. If such abnormality lasts or repeats for 3 or more reciprocating operations, take the following countermeasures.
 - 1) Lower the setup of Pr0.03 (Selection of machine stiffness at real-time auto-gain tuning).
 - 2) Set Pr0.02 Real-time auto-tuning setup to 0 to disable the real-time auto-tuning.
 - Set Pr0.04 Inertial ratio to the calculational value of the equipment and set Pr6.07 (Torque command addition value), Pr6.08 (Positive direction compensation value), Pr6.09 (Negative direction compensation value) and Pr6.50 (Viscous friction compensation gain) to 0.
- (2) When abnormal noise and oscillation occur, Pr0.04 (Inertia ratio) or Pr6.07 (Torque command additional value), Pr6.08 (Positive direction torque compensation value), Pr6.09 (Negative direction compensation value), Pr6.50 (Viscous friction compensation gain) might have changed extreme value. Take the same measures as the above in these cases.
- (3) Among the results of real-time auto-gain tuning, Pr0.04 (Inertia ratio) and Pr6.07 (Torque command additional value), Pr6.08 (Positive direction torque compensation value), Pr6.09 (Negative direction compensation value), Pr6.50 (Viscous friction compensation gain) will be written to EE-PROM every 30 minutes. When you turn on the power again, the auto-gain tuning will be executed using the latest data as initial values.
- (4) Because the control gain is updated while the motor stops, changed setting value of Pr0.03 "Real-time auto-tuning stiffness setup" may not be reflected if the motor cannot stop due to excessively low gain or application of a command that directs the motor to turn in the same direction continuously. If the changed stiffness setting value is reflected after motor stops, it may generate abnormal sound or oscillate.

After changing stiffness, stop the motor and check to see that the new stiffness setting is made effective.

Invalidation of Real-Time Auto-Gain Tuning

You can stop the automatic calculation of Pr0.04 (Inertial ratio) and invalidate the realtime auto-gain tuning by setting up Pr0.02 (Real-time auto-gain tuning setup) to 0. Because the estimation result of Pr0.04 Inertia ratio is recorded, if this parameter becomes abnormal value, manually set to the appropriate value which is obtained from suitable formula or calculation.

Caution 🔅

If power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

A5II Two-degree-of-freedom control mode – Standard type

Basic gain parameter setup table

		1st gain/	2nd gain		Command	l response	Adjustment filter
	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 ^{*1} Pr1.09 ^{*1}	Pr2	2.22	Pr6.48*2
Stiffness	Position		Velocity loop			ne [0.1 ms]	Time
	loop [0.1 /s]	Velocity loop [0.1 Hz]	integration [0.1 ms]	Torque [0.01 ms]	Standard response mode	Quick response mode 1 to 3	constant [0.1 ms]
0	20	15	3700	1500	1919	764	155
1	25	20	2800	1100	1487	595	115
2	30	25	2200	900	1214	486	94
3	40	30	1900	800	960	384	84
4	45	35	1600	600	838	335	64
5	55	45	1200	500	668	267	54
6	75	60	900	400	496	198	44
7	95	75	700	300	394	158	34
8	115	90	600	300	327	131	34
9	140	110	500	200	268	107	24
10	175	140	400	200	212	85	23
11	320	180	310	126	139	55	16
12	390	220	250	103	113	45	13
13	480	270	210	84	92	37	11
14	630	350	160	65	71	28	9
15	720	400	140	57	62	25	8
16	900	500	120	45	50	20	7
17	1080	600	110	38	41	17	6
18	1350	750	90	30	33	13	5
19	1620	900	80	25	28	11	5
20	2060	1150	70	20	22	9	4
21	2510	1400	60	16	18	7	4
22	3050	1700	50	13	15	6	3
23	3770	2100	40	11	12	5	3
24	4490	2500	40	9	10	4	3
25	5000	2800	35	8	9	4	2
26	5600	3100	30	7	8	3	2
27	6100	3400	30	7	7	3	2
28	6600	3700	25	6	7	3	2
29	7200	4000	25	6	6	2	2
30	8100	4500	20	5	6	2	2
31	9000	5000	20	5	5	2	2

*1 When 17-bit absolute encoder, limited by the minimum value 10.

*2 The value of Pr6.48 Adjustment filter has additional value 1 for B to G frames.

Note • For details of parameters, refer to P.4-14 "Details of parameter".

2

5

7

Adjustment

2. Real-Time Auto-Gain Tuning

A5I Two-degree-of-freedom control mode – Synchronous type

Outline

In this auto-tuning mode, two-degree-of-freedom control is available in addition to realtime auto tuning basic function.

The synchronous type is a mode suitable for locus control of multi axes such as multijoint robot. It is different from other types in individual setting of command response and invalidation of unbalanced load (mass) compensation.

The two-degree-of-freedom control mode, standard type, can be used by setting Pr6.47 Function expansion setup 2 to bit 0 = 1 and bit 3 = 0.

Applicable Range

	Real-time auto-tuning condition	
Control Mode	Real-time auto-tuning, two-degree-of-freedom control mode, synchronous typ, can be applied for only position control mode.	
Others	 Should be in servo-on condition. Input signals, such as deviation counter clear and command input inhibit, and parameters, except for controls such as torque limit setup, are correctly set, assuming that the motor can run smoothly. 	

Caution

Real-time auto-gain tuning may not be executed properly under the conditions described below.

Under these conditions, change the load conditions or operation patterns, or start manual gain tuning (refer to P.5-27 and subsequent).

	Conditions which obstruct real-time auto-gain tuning
Load inertia	 Load is small or large compared with the rotor inertia (less than 3 times or more than 20 times). The load inertia changes.
Load	The machine stiffness is extremely low.Nonlinear characteristics such as backlash exist.
Action pattern	 The motor is running continuously at low speed of 100 [r/min] or lower. Acceleration/deceleration is slow (2000 [r/min/1[s] or low). Acceleration/deceleration torque is smaller than unbalanced weighted/ viscous torque. When speed condition of 100 [r/min] or more and acceleration/deceleration/d

A5II Two-degree-of-freedom control mode – Synchronous type

How to Operate

- 1) Bring the motor to stall (Servo-off).
- 2) Set up Pr0.02 (Setup of real-time auto-gain tuning mode) to other than 0, 6.

Setup value	Real-time auto-gain tuning	Explanation
0, 6	Invalid	Real-time auto-gain tuning function is disabled.
1	Synchronous	Synchronous control mode. Do not use this mode for unbalanced load or friction compensate. Use this mode first when maintaining command response filter, then switch to another mode as necessary.
2	Synchronous friction compensation	With dynamic friction compensation/viscous friction compensation in addition to those of synchronous mode. Use this mode when the load has a large friction.
3	Stiffness setting	Use this mode when modifying gain filter setting according to stiffness table without making inertia ratio assumption, unbalanced load compensation or friction compensation. When handling a load with larger inertia variations, first estimate inertia in an appropriate mode, e.g. sync mode, and then switch to this mode.
4	Load characteristics update	Use this mode when applying only inertia ratio, dynamic friction compensation and viscous friction compensation among load characteristics while holding gain filter setting.
5	Load characteristic measurement	Estimate load characteristics without changing basic gain setting or friction compensation setting with the help of the setup support software.

Control parameter is automatically set according to Pr0.03 Real-time auto-tuning stiffness setup.

[Example of real-time auto-tuning setup]

When using this function for the first time with multijoint robot, set initial stiffness to a lower value in accordance with the load capacity in the synchronous friction compensation mode (Pr0.02 = 2), and incline the arm by 45 degrees, and then estimate the load characteristics with short distance reciprocating running (1-2 rotations of motor shaft).

To see effects of quadrant switching due to friction compensation, try Pr0.02 = 1.

To perform only load characteristics estimation, use the load characteristic update mode Pr0.02 = 4.

Because the inertia ratio and resonance characteristic of multijoint robot vary with orientation, disable the auto-tuning (Pr2.00 = 0) after estimation of load characteristics. In the load characteristic measurement mode (Pr0.02 = 5), the load characteristic tic change due to arm orientation can be observed without affecting operation.

When adjusting during operation, enter the stiffness setup mode (Pr0.02 = 3). While holding load characteristic compensation, change the stiffness setting and check locus accuracy and positioning performance.

Note

• While the auto-tuning is valid, parameters that are to be automatically adjusted cannot be changed.

Related page ···· P.4-5, 4-6 "Details of parameter"

5

2. Real-Time Auto-Gain Tuning

A5II Two-degree-of-freedom control mode – Synchronous type

- 3) When the servo is tuned on, input the action command.
- As the load characteristics are correctly estimated, Pr0.04 Inertia ratio will be updated. In a specific mode, the following parameters are changed.
 - Pr6.07 Torque command additional value
 - Pr6.08 Positive direction torque compensation value
 - Pr6.09 Negative direction torque compensation value
 - Pr6.50 Viscous friction compensation gain
 - Load characteristics estimation speed can be set by Pr6.31 Real time auto tuning estimation speed.
- 5) When value of Pr0.03 Real-time auto-tuning stiffness setup is increased, the motor responsiveness will be improved.

Determine the most appropriate stiffness in relation to the positioning setup time and vibration condition.

6) To save the result to memory, write the date to EEPROM.

Caution 🔅

If power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

Note

• While the auto-tuning is valid, parameters that are to be automatically adjusted cannot be changed.

Related page 🔅 • P.2-109 "EEPROM Writing Mode" • P.4-6, 4-57, 4-60, 4-64 "Details of parameter"

A51 Two-degree-of-freedom control mode – Synchronous type

Parameters set/changed by real-time auto-gain tuning

Parameters which are updated

The real-time auto-tuning function updates the following parameters according to Pr0.02 Real-time auto-tuning setup by using the load characteristic estimate values.

Class	No.	Title	Function
0	04	Inertia ratio	In the synchronous mode ($Pr0.02 = 1$), synchronous friction compensation mode ($Pr0.02 = 2$) and load characteristic update mode ($Pr0.02 = 4$), this parameter will be updated.
6	08	Positive direction torque compen- sation value	In the synchronous friction compensation
6	09	Negative direction torque compen- sation value	mode ($Pr0.02 = 2$) and load characteristic update mode ($Pr0.02 = 4$), this parameter will be updated.
6	50	Viscous friction compensation gain	will be updated.

• Parameters which are updated to setup value corresponding to stiffness setup The real-time auto-tuning function updates the following basic gain setup parameters according to Pr0.03 Real-time auto-tuning stiffness setup.

Class	No.	Title	Function	
1	00	1st gain of position loop		
1	01	1st gain of velocity loop		
1	02	1st time constant of velocity loop integration	When real-time auto-tuning is valid (Pr0.02	
1	04	1st time constant of torque filter	= 1-4), updates the setup value according to the stiffness.	
1	05	2nd gain of position loop	Refer to P.5-9 Basic gain parameter setup	
1	06	2nd gain of velocity loop	table.	
1	07	2nd time constant of velocity loop integration		
1	09	2nd time constant of torque filter		
6	48	Adjust filter	In the synchronous mode, synchronous friction compensation mode and stiffness setup mode ($Pr0.02 = 1-3$), the setting will be updated according to stiffness.	

Parameters which are set to fixed value

The real-time auto-tuning function sets the following parameters to fixed values or uses the current setup values.

Class	No.	Title	Setup value when fixed parameter setup is valid.
1	03	1st filter of speed detection	0
1	08	2nd filter of speed detection	0
1	10	Velocity feed forward gain	1000 (100 %)
1	11	Velocity feed forward filter	0
1	12	Torque feed forward gain	1000 (100 %)
1	13	Torque feed forward filter	0
2	22	Command smoothing filter	Holds the current setup value. *1
6	07	Torque command additional value	0
6	10	Function expansion setup	bit4=1
6	49	Adjust/Torque command attenuation term	Tens digit set as 1 and ones digit is kept as is.

*1 If noise generates, change the setting to appropriate value (e.g. 3 ms = setup value: 30).

· Parameters which are set in respons to gain switching setup

The real-time auto-tuning function sets the following parameters according to Pr0.02 Real-time auto-tuning setup, or uses current setup values.

Class	No.	Title	Function
1	14	2nd gain setup	In the synchronous mode, synchronous friction compensation mode or stiffness setup mode (Pr0.02 = 1 to 3), sets to 1.
1	15	Mode of position control switching	In the synchronous mode, synchronous friction compensation mode or stiffness setup mode (Pr0.02 = 1 to 3), sets to 0.
1	16	Delay time of position control switching	In the synchronous mode, synchronous friction compensation mode or stiffness setup mode (Pr0.02 = 1 to 3), sets to 10.
1	17	Level of position control switching	In the synchronous mode, synchronous
1	18	Hysteresis at position control switching	friction compensation mode or stiffness setup mode (Pr0.02 = 1 to 3), sets to 0.
1	19	Position gain switching time	In the synchronous mode, synchronous friction compensation mode or stiffness setup mode (Pr0.02 = 1 to 3), sets to 10.
1	20	Mode of velocity control switching	
1	21	Delay time of velocity control switching	
1	22	Level of velocity control switching	
1	23	Hysteresis at velocity control switching	Sets to 0 if real-time auto-tuning is valid
1	24	Mode of torque control switching	(Pr0.02 = 1 to 4).
1	25	Delay time of torque control switching	
1	26	Level of torque control switching	
1	27	Hysteresis at torque control switching	
6	05	Position 3rd gain valid time	When the real-time auto-tuning remains
6	06	Position 3rd gain scale factor	valid (Pr0.02 = 1 to 4), uses the current setup value.

Parameters which are always set to invalid

The following settings are always set to invalid when Pr0.02 Real-time auto-tuning setup is not 0. Note that setup values of parameters remain unchanged.

Class	No.	Title	tle Function					
6	10	Function expansion setup	Instantaneous speed observer function enable bit (bit 0), disturbance observer function enable bit (bit 1) and inertia ratio switching function enable bit (bit 3) are internally disabled.					
6	13	2nd Inertia ratio	Parameter setup can be changed, but inertia ration switching function is disabled.					
6	compensating gain		Parameter setup can be changed, but disturbance					
6			 compensation function is disabled. 					

1

3

A5II Two-degree-of-freedom control mode – Synchronous type

Caution

- Immediately after the first servo-on upon start up; or after increasing Pr0.03 Real-time auto-tuning stiffness setup, abnormal sound or oscillation may be generated until the load characteristics estimation is stabilized. If such abnormality lasts or repeats for 3 or more reciprocating operations, take the following countermeasures.
 1) Lower the setup of Pr0.03 (Selection of machine stiffness at real-time auto-gain
 - 1) Lower the setup of Pr0.03 (Selection of machine stiffness at real-time auto-gain tuning).
 - 2) Set Pr0.02 Real-time auto-tuning setup to 0 to disable the real-time auto-tuning.
 - Set Pr0.04 Inertial ratio to the calculational value of the equipment and set Pr6.07 (Torque command addition value), Pr6.08 (Positive direction compensation value), Pr6.09 (Negative direction compensation value) and Pr6.50 (Viscous friction compensation gain) to 0.
- (2) When abnormal noise and oscillation occur, Pr0.04 (Inertia ratio) or Pr6.07 (Torque command additional value), Pr6.08 (Positive direction torque compensation value), Pr6.09 (Negative direction compensation value), Pr6.50 (Viscous friction compensation gain) might have changed extreme value. Take the same measures as the above in these cases.
- (3) Among the results of real-time auto-gain tuning, Pr0.04 (Inertia ratio) and Pr6.07 (Torque command additional value), Pr6.08 (Positive direction torque compensation value), Pr6.09 (Negative direction compensation value), Pr6.50 (Viscous friction compensation gain) will be written to EE-PROM every 30 minutes. When you turn on the power again, the auto-gain tuning will be executed using the latest data as initial values.
- (4) Because the control gain is updated while the motor stops, changed setting value of Pr0.03 "Real-time auto-tuning stiffness setup" may not be reflected if the motor cannot stop due to excessively low gain or application of a command that directs the motor to turn in the same direction continuously. If the changed stiffness setting value is reflected after motor stops, it may generate abnormal sound or oscillate.

After changing stiffness, stop the motor and check to see that the new stiffness setting is made effective.

Invalidation of Real-Time Auto-Gain Tuning

You can stop the automatic calculation of Pr0.04 (Inertial ratio) and invalidate the realtime auto-gain tuning by setting up Pr0.02 (Real-time auto-gain tuning setup) to 0. Because the estimation result of Pr0.04 Inertia ratio is recorded, if this parameter becomes abnormal value, manually set to the appropriate value which is obtained from suitable formula or calculation.

Caution 🔅

If power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

A511 Two-degree-of-freedom control mode – Synchronous type

Basic gain parameter setup table

		Adjustment filter			
Stiffness	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 ^{*1} Pr1.09 ^{*1}	Pr6.48*2
	Position loop	Velocity loop	Velocity loop integration	Torque	Time constant
	[0.1 /s]	[0.1 Hz]	[0.1 ms]	[0.01 ms]	[0.1 ms]
0	20	15	3700	1500	155
1	25	20	2800	1100	115
2	30	25	2200	900	94
3	40	30	1900	800	84
4	45	35	1600	600	64
5	55	45	1200	500	54
6	75	60	900	400	44
7	95	75	700	300	34
8	115	90	600	300	34
9	140	110	500	200	24
10	175	140	400	200	23
11	320	180	310	126	16
12	390	220	250	103	13
13	480	270	210	84	11
14	630	350	160	65	9
15	720	400	140	57	8
16	900	500	120	45	7
17	1080	600	110	38	6
18	1350	750	90	30	5
19	1620	900	80	25	5
20	2060	1150	70	20	4
21	2510	1400	60	16	4
22	3050	1700	50	13	3
23	3770	2100	40	11	3
24	4490	2500	40	9	3
25	5000	2800	35	8	2
26	5600	3100	30	7	2
27	6100	3400	30	7	2
28	6600	3700	25	6	2
29	7200	4000	25	6	2
30	8100	4500	20	5	2
31	9000	5000	20	5	2

*1 When 17-bit absolute encoder, limited by the minimum value 10.

*2 The value of Pr6.48 Adjustment filter has additional value 1 for B to G frames.

• For details of parameters, refer to P.4-14 "Details of parameter".

1

Preparation

Setup


3. Adaptive filter

Adjustment

Adaptive filter

Outline

Estimates the resonance frequency out of vibration component presented in the motor speed in motion, then removes the resonance component from the torque command by setting up the notch filter coefficient automatically, hence reduces the resonance vibration.



Applicable Range

This function works under the following condition.

	Conditions under which the Adaptive filter is activated						
Control Mode	Applies to other control modes than torque control.						
Others	 Should be servo-on status. Elements other than control parameters, such as deviation counter clear command inhibit and torque limit are appropriately set, enabling the motor to run normally. 						

Caution

In the following condition, normal operation may not be expected - manually set the notch filter to prevent resonance.

	Conditions which obstruct adaptive filter action
Resonance point	 Resonance frequency is lower than 3 times. Resonance peak is low, or control gain is low where the motor speed is not affected by this. Multiple resonance of 3 or more points exist.
Load	 Motor speed variation with high harmonic component is generated due to non-linear factors such as backlash.
Command pattern	 Acceleration/deceleration is rapid such as 30000[r/min] per 1[s].

How to Operate

Enter the action command with Pr2.00 Adaptive filter mode set to a value other than 0. If the resonance point affects the motor speed, parameters of 3rd notch filter and/or 4th notch filters are automatically set according to the number of adaptive filters.

Set the operation of the adaptive filter to the following parameter.

Class	No.	Title	Setup value	Function	
		D Adaptive filter mode setup	0	[Adaptive filter: invalid] The adaptive filter is disabled. Parameters related to the 3rd and 4th notch filter hold the current value.	
			•	1	[Adaptive filter: 1 filter is valid] One adaptive filter is enabled. Parameters related to the 3rd notch filter will be updated based on adaptive performance.
				2	[Adaptive filter: 2 filters are valid] Two adaptive filters are enabled. Parameters related to the 3rd and 4th notch filters will be updated based on adaptive performance.
2	00			3	[Resonance frequency measurement mode] Measure the resonance frequency. Result of measurement can be checked with PANATERM. Parameters related to the 3rd and 4th notch filter hold the current value.
				4	[Clear result of adaptation] Parameters related to the 3rd and 4th notch filter are disabled and results of adaptive operation are cleared.
			<mark>абіі</mark> 5	[High-precision adaptive filter] Two adaptive filters are enabled. Parameters related to the 3rd and 4th notch filters will be updated based on the results of adaptive performance. Use of this setup value is recommended when using 2 adaptive filters.	
			<mark>А51</mark> 6	[For manufacturer's use] PANATERM's fit gain function used internally. Do not use this setup value in the normal condition.	

A5II : Only available on A5II series.

At the same time, the following parameters are automatically set.

Class	No.	Title	Function		
2	07 3rd notch frequency		In no resonance point is found, the frequency is set to 5000.		
2	08 3rd notch width selection		Automotically act when the adaptive filter is active		
2	09	3rd notch depth selection	Automatically set when the adaptive filter is active.		
2	10	4th notch frequency	Notch frequency is automatically set to the 2nd resonance frequency estimated by the adaptive filter. In no resonance point is found, the frequency is set to 5000.		
2	11	4th notch width selection	Automotically act when a adaptive filtere are active		
2 12		4th notch depth selection	Automatically set when 2 adaptive filters are active.		

Related page • P.4-21... "Details of parameter"

3

Setup

6

Caution

- (1) Immediately after the first servo-on at start up; or after increasing stiffness setting with the real-time auto-tuning enabled, abnormal sound or oscillation may be generated until the adaptive filter stabilizes. If such abnormality lasts or repeats for 3 or more reciprocating operations, take the following countermeasures.
 - 1) Write the parameters which have given the normal operation into EEPROM.
 - 2) Lower the setup of Pr0.03 (Selection of machine stiffness at real-time auto-gain tuning).
 - 3) Invalidate the adaptive filter by setting up Pr2.00 (Setup of adaptive filter mode) to0. (Reset of inertia calculation and adaptive action)
 - 4) Set up the notch filter manually.
- (2) Abnormal sound or oscillation may excessively change the setup value of 3rd and 4th notch filters. If such change occurs, disable the adaptive filter as described in step 3) above, change setup value of Pr2.07 3rd notch frequency and Pr2.10 4th notch frequency to 5000 (disable), and then enable the adaptive filter again.
- (3) The 3rd filters (Pr2.07-Pr2.09) and 4th notch filters (Pr2.10-Pr2.12) are written to EE-PROM every 30 minutes. Upon power up, these data are used as default values during adaptive process.

Adjustment

4. Manual Gain Tuning (Basic)

Outline


As explained previously, MINAS-A5 series features the automatic gain tuning function, however, there might be some cases where this automatic gain tuning cannot be adjusted properly depending on the limitation on load conditions. Or you might need to readjust the tuning to obtain the optimum response or stability corresponding to each load. Here we explain this manual gain tuning method by each control mode and function.

Before Making a Manual Adjustment

By monitoring waveforms using the waveform graphic function of the setup support software PANATERM installed on the PC or by measuring the analog voltage waveform with the help of the monitor function, accurate adjustment can be positively, quickly and easily done when compared with that performed on the front panel.


1. Analog monitor output

You can measure the actual motor speed, commanded speed, torque and deviation pulses by analog voltage level by using an oscilloscope. Set up the types of the signals or the output voltage level with Pr4.16 (Selection of speed monitor) and Pr4.21 (Selection of torque monitor).



2. Waveform graphic function of the PANATERM

You can display the command to the motor, motor movement (speed, torque command and deviation pulses) as a waveform graphic on PC display. Refer to P.7-26, "Outline of the Setup Support Software, PANATERM" of Supplement.



Caution 🔅 Please download the Setup support software "PANATERM" from our web site and use after install to the PC.

Related page … • P.4-40, 4-42... "Details of parameter" • P.7-26 "Outline of Setup support software "PANATERM"

4. Manual Gain Tuning (Basic)

Adjustment in Position Control Mode

Position control of MINAS-A5 series is described in Block diagram of P.3-14. Make adjustment in position control per the following procedures.

Parameter No. (Pr □□)	Title of parameter	Standard value
1.00	1st gain of position loop	270
1.01	1st gain of velocity loop	150
1.02	1st time constant of velocity loop integration	370
1.03	1st filter of velocity detection	0
1.04	1.04 1st time constant of torque filter time	
1.10	1.10 Velocity feed forward	
1.11	1.11 Time constant of feed forward filter	
1.05	2nd gain of position loop	270
1.06	2nd gain of velocity loop	150
1.07	2nd time constant of velocity loop integration	370
1.08	2nd filter of speed detection	0
1.09	2nd time constant of torque filter	152
2.01	2.01 1st notch frequency	
2.02	1st notch width selection	2

(1) Set up the following parameters to the values of the table below.

Parameter No. (Pr □□)	Title of parameter	Standard value
0.04	Inertia ratio	100
0.02	Setup of real time auto-gain tuning mode	0
2.00	Adaptive filter setup mode	0
2.14	1st damping frequency	0
2.15	Setup of 1st damping filter	0
2.16	2nd damping frequency	0
2.17	Setup of 2nd damping filter	0
1.14	2nd gain setup	0
1.15	Mode of position control switching	0
1.16	Delay time of position control switching delay	0
1.17	Level of position control switching	0
1.18	Hysteresis at position control switching	0
1.19	Position gain switching time	0
2.22	Positional command smoothing filter	1
2.23	Positional command FIR filter	0

(2) Enter the inertia ratio of Pr0.04. Measure the ratio or setup the calculated value.

(3) Make adjustment using the standard values below.

Order	Parameter No. (Pr□□)	Title	Standard value	How to adjust	
1	Pr1.01	1st gain of velocity loop	300	Increase the value within the range where no abnormal noise and no vibration occur. If they occur, lower the value.	
2	Pr1.04	1st time constant of torque filter	50	When vibration occurs by changing Pr1.01, change this value. Setup so as to make Pr1.01 x Pr1.04 becomes smaller than 10000. If you want to suppress vibration at stopping, setup larger value to Pr1.04 and smaller value to Pr1.01. If you experience too large vibration right before stopping, lower than value of Pr1.04.	
3	Pr1.00	1st gain of position loop	500	Adjust this observing the positioning time. Larger the setup, faster the positioning time you can obtain, but too large setup may cause oscillation.	
4	Pr1.02	1st time constant of velocity loop integration	250	Setup this value within the range where no problem occurs. If you setup smaller value, you can obtain a shorter positioning time, but too small value may cause oscillation. If you setup too large value, deviation pulses do not converge and will be remained. Increase the value within the range where no abnormal noise occurs.	
5	Pr1.10	Velocity feed forward gain	300	Too large setup may result in overshoot or chattering of position complete signal, hence does not shorten the settling time. If the command pulse is not even, you can improve by setting up Pr1.11 (Feed forward filter) to larger value.	

Related page "Details of parameter" • P.3-14... "Control Block Diagram"

Preparation

7

Adjustment

4. Manual Gain Tuning (Basic)

Adjustment in Velocity Control Mode

Velocity control of MINAS-A5 series is described in Block Diagram of P.3-16 of Velocity Control Mode.

Adjustment in velocity control is almost same as that in position control described in "Adjustment in Position Control Mode", and make adjustments of parameters per the procedures except the gain setup of position loop gain (Pr1.00, Pr1.05) and the setup of velocity feed forward gain (Pr1.10).



4. Manual Gain Tuning (Basic)

Adjustment in Torque Control Mode

Torque control of MINAS-A5 series is described in P.3-18, "Block Diagram" of Torque Control Mode.

This torque control is based on velocity control while making Pr3.21 [Speed limit value 1], Pr3.22 [Speed limit value 2] or SPL input as a speed limit. Here we explain the setup of speed limiting value.

Setup of speed limiting value

The torque command selection (Pr3.17) specifies the setup method. Pr3.17 = 0 Set up by using speed limit value 1 (Pr3.21) Pr3.17 = 1 Set up by using analog input (SPL) Pr3.17 = 2 For positive direction, set up by using the speed limit value 1 (Pr3.21) For negative direction, set up by using the speed limit value 2 (Pr3.22)

- When the motor speed approaches to the speed limiting value, torque control following the analog torque command shifts to velocity control based on the speed limiting value.
- In order to stabilize the movement under the speed limiting, you are required to set up the parameters according to the above-mentioned "Adjustment in Velocity Control Mode".
- When the speed limiting value is too low or the velocity loop gain is too low, or when the time constant of the velocity loop integration is 10000 (invalid), the input to the torque limiting portion of the above fig. becomes small and the output torque may not be generated as the analog torque command.
- When not using the speed limit but using only torque command, disable the torque filter and notch filter, and set speed limit value to the maximum speed and set velocity loop gain to a value as high as possible.

4. Manual Gain Tuning (Basic)

Adjustment in Full-Closed Control Mode

Full-closed control of MINAS-A5 series is described in Block diagram of P.3-19 of Full-Closed Control.

Adjustment in full-closed control is almost same as that in position control described in P.5-28 "Adjustment in Position Control Mode", and make adjustments of parameters per the procedures except cautions of P.3-12, "Outline of Full-Closed Control" (difference of command unit and difference of electronic gear).

Here we explain the setup of feedback scale ratio and hybrid deviation excess of fullclosed control.

1) Setup of external scale ratio

Setup the external scale ratio using the numerator of external scale division (Pr3.24) and denominator of external scale division (Pr3.25).

• Check the encoder feedback pulse counts per one motor revolution and the external scale pulse counts per one motor revolution, then set up the numerator of external scale division (Pr3.24), and denominator of external scale division (Pr3.25) so that the following formula can be established.

Pr3.24 Number of encoder feedback pulses per motor rotation

- Pr3.25 Number of external scale pulses per motor rotation
- If this ratio is incorrect, a gap between the position calculated from the encoder feedback pulse counts and that of calculated from the external scale pulse counts will be enlarged and hybrid deviation excess (Err25.0) will be triggered when the work or load travels a long distance.
- When you set up Pr3.24 to 0, the encoder feedback pulse counts will be automatically set up.

2) Setup of hybrid deviation excess

Set up the minimum value of hybrid deviation excess (Pr3.28) within the range where the gap between the motor (encoder) position and the load (feedback scale) position will be considered to be an excess.

• Note that the hybrid deviation excess (Err25.0) may be generated under other conditions than the above 1), such as reversed connection of the external scale or loose connection of the motor and the load.

Caution

- (1) Enter the command pulses based on the feedback scale reference.
- (2) The feedback scales to used for full-closed control are as follows.
 - When A- and B-phase parallel, or serial scale,
 - ABS ST770A, ST770AL, AT573A series by Mitsutoyo Corp.
 - SR77, SR87, SL700, SL710 by Magnescale Co., Ltd.
- (3) To prevent the runaway and damage of the machine due to the setup of the feedback scale, setup the hybrid deviation excess (Pr3.28) to the appropriate value, in the unit of feedback scale resolution.
- (4) We recommend the external scale as $1/40 \le \text{external scale ratio} \le 160$.

Even within this range, if you setup the external scale ratio to smaller value than 50/position loop gain (Pr1.00 and 1.05), you may not be able to control by one pulse unit. If you set up too large external scale ratio, you may expect larger noise in movement.

Note · Only for position control type is not provided with X5 (For external scale connector).

Preparation

3

Connection

4

5

6

When in Trouble


upplement

4. Manual Gain Tuning (Basic)

Gain Switching Function

By selecting appropriate gain based on internal data or external signal, the following effects can be obtained.

- Decrease the gain at the time of stoppage (servo lock) to reduce vibration.
- Increase the gain at the time of stoppage (setting) to shorten the settling time.
- · Increase the gain during operation to improve command compliance.
- Based on condition of the equipment, change the gain with external signal.



Suppress the vibration by lowering the gain.

<Example>

Following is the example when you want to reduce the noise at motor in stall (Servo-Lock), by setting up to lower gain after the motor stops.

Make adjustment referring to the basic gain parameter setup table (P.5-9) as well.

Parameter No. (Pr□□)	Title of parameter	Execute manual gain-tuning without gain switching	 →	Set up the same value as Pr1.05 to 1.09 (2nd gain) to Pr1.00 to 1.04 (1st gain)	•	Set up Pr1.14 to 1.19 (Gain switching condition)	→	Adjust Pr1.01 and 1.04 at stopping (1st gain)
1.00	1st gain of position loop	630						
1.01	1st gain of velocity loop	350						270
1.02	1st time constant of velocity integration	160						
1.03	1st filter of velocity detection	0						
1.04	1st time constant of torque filter	65						84
1.10	Velocity feed forward	300						
1.11	Filter of velocity feed forward	50						
1.05	2nd gain of position loop			630				
1.06	2nd gain of velocity loop			350				
1.07	2nd time constant of velocity integration			160				
1.08	2nd filter of velocity detection			0				
1.09	2nd time constant of torque filter time			65				
1.14	Action setup of 2nd gain	0				1		
1.15	1st mode of control switching					7		
1.16	1st delay time of control switching					30		
1.17	1st level of control switching					0		
1.18	1st hysteresis of control switching					0		
1.19	Switching time of position gain					0		
0.04	Inertia ration	 Enter the known value from load calculation Measure the inertia ratio by executing nor mal auto-gain tuning Default is 250 						

Related page P.4-7... "Details of parameter"

Gain Switching Function

Setup of Gain Switching Condition

• Positing control mode, Full-closed control mode (O: Corresponding parameter is valid, -: invalid)

Set	up of gain switching condition		Setup parameters at position control, full-closed control			
D.4.45	Switching condition to 2nd gain		Delay time *1	Level	Hysteresis *2	
Pr1.15			Pr1.16	Pr1.17	Pr1.18	
0	Fixed to 1st gain		-	-	_	
1	Fixed to 2nd gain		-	-	_	
2	Gain switching input		-	-	_	
3	Torque command	Α	0	○ [%]	○[%]	
4	Invalid (Fixed to 1st gain)		-	-	_	
5	Speed command	С	0	○ [r/min]	○ [r/min]	
6	Position deviation	D	0	⊖ ^{∗3} [pulse]	⊖ [∗] ³ [pulse]	
7	Position command exists.	Е	0	-	_	
8	Not in positioning complete	F	0	-	-	
9	Speed	С	0	○ [r/min]	○ [r/min]	
10	Command exists + velocity	G	0	○ [r/min] *₅	○ [r/min] *5	

Velocity control mode


Setup of gain switching condition			Setup parameters at velocity control mode			
D 4 00	Switching condition to 2nd gain		Delay time *1	Level	Hysteresis *2	
Pr1.20			Pr1.16, 1.21	Pr1.17, 1.22	Pr1.18, 1.23	
0	Fixed to 1st gain		-	-	-	
1	Fixed to 2nd gain		_	-	_	
2	Gain switching input		_	-	_	
3	Torque command	Α	0	[%]	[%]	
4	Variation of speed command is large.	в	_	○*4 [10(r/min)/s]	○ ^{*4} [10(r/min)/s]	
5	Speed command	С	0	O [r/min]	○ [r/min]	


Torque control mode

Setup of gain switching condition			Setup parameters at torque control mode		
Pr1.24	Switching condition to 2nd gain	Fig.	Delay time *1	Level	Hysteresis *2
			Pr1.16, 1.25	Pr1.17, 1.26	Pr1.18, 1.27
0	Fixed to 1st gain		-	-	-
1	Fixed to 2nd gain		-	-	-
2	Gain switching input, GAIN ON		-	-	-
3	Variation of torque command is large.	A	0	○ [%]	○ [%]

*1 Delay time (Pr1.16, 1.12 and 1.25) will be valid only when returning from 2nd to 1st gain.

- *2 Hysteresis (Pr1.18, 1.23 and 1.27) is defined as the fig. below shows.
- *3 Designate with either the encoder resolution or the external scale resolution depending on the control mode.
- *4 When you make it a condition that there is speed variation of 10 r/min in 1s, set up the value to 1.
- *5 When Pr1.15=10, the meanings of delay time, level and hysteresis are different from the normal. (refer to Fig. G)





1

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

7

Supplement

4. Manual Gain Tuning (Basic)

Suppression of Machine Resonance

In case of a low machine stiffness, you cannot set up a higher gain because vibration and noise occur due to oscillation caused by axis distortion or other causes. By suppressing the resonance peak at the notch filter, higher gain can be obtained or the level of vibration can be lowered.

1. Torque command filter (Pr1.04 and Pr1.09)

Sets up the filter time constant so as to damp the frequency at vicinity of resonance frequency. You can obtain the cut off frequency of the torque command filter in the following formula.

Cut off frequency (Hz) fc = 1 / $(2\pi x \text{ parameter setup value } x 0.00001)$

2. Notch filter (Pr2.00, 2.07 to Pr2.12)

Adaptive filter

MINASA-5 series feature the adaptive filter. With this filter you can control vibration of the load which resonance points vary by machine by machine and normal notch filter or torque filter cannot respond. Enter the action command with Pr2.00 Adaptive filter mode set to a value other than 0.

If the resonance point affects the motor speed, parameters of 3rd notch filter and/ or 4th notch filters are automatically set according to the number of adaptive filters.


Pr2.00	Adaptive filter mode	1: Adaptive filter is valid
F12.00		2: 2 adaptive filters are valid.
Pr2.07	and notab fraguanay	In no resonance point is found, the frequency is set to
F12.07	3rd notch frequency	5000.
Pr2.08	3rd notch width selection	Automatically set when the adaptive filter is active.
Pr2.09	3rd notch depth selection	Automatically set when the adaptive litter is active.
	4th notch frequency	Notch frequency is automatically set to the 2nd
Pr2.10		resonance frequency estimated by the adaptive filter.
Pr2.10		In no resonance point is found, the frequency is set to
		5000.
Pr2.11	4th notch width selection	Automatically set when 2 adaptive filters are active.
Pr2.12	4th notch depth selection	Automatically set when 2 adaptive litters are active.

• Notch filter (Pr2.01 to 2.12)

MINASA-5 series feature 4 normal notch filters. You can adjust frequency and width and depth.

1st notch frequency	Set the center frequency of the 1st notch filter. *1
1st notch width selection	Set the width of notch at the center frequency of the 1st
	notch filter.
1st notch denth selection	Set the depth of notch at the center frequency of the
	1st notch filter.
2nd notch frequency	Set the center frequency of the 2nd notch filter. *1
and notch width coloction	Set the width of notch at the center frequency of the
	2nd notch filter.
2nd notch depth selection	Set the depth of notch at the center frequency of the
	2nd notch filter.
3rd notch frequency	Set the center frequency of the 3rd notch filter. *1
3rd notch width selection	Set the width of notch at the center frequency of the 3rd
	notch filter.
3rd notch depth selection	Set the depth of notch at the center frequency of the
	3rd notch filter.
4th notch frequency	Set the center frequency of the 4th notch filter. *1
4th notab width coloction	Set the width of notch at the center frequency of the 4th
4th holon width selection	notch filter.
4th notab donth coloction	Set the depth of notch at the center frequency of the
4th notch depth selection	4th notch filter.
	1st notch width selection 1st notch depth selection 2nd notch frequency 2nd notch width selection 2nd notch depth selection 3rd notch frequency 3rd notch width selection 3rd notch depth selection

*1 The notch filter function will be invalidated by setting up this parameter to "5000".



7

Supplement


Suppression of Machine Resonance

Notch width and depth

The width of the notch filter is the ratio of the width of -3dB attenuation frequency band with respect to the notch frequency at its center when depth is 0, and the value is as shown in the table below.

The notch filter depth indicates I:O ratio where the input at the center frequency is completely shut with setup value 0 but fully received with setup value 100. The table below shows this value in dB on the right.

	Band width/ce	nter frequency				
Notch width	A4 series (reference) A5,A5II series		Notch depth	I/O ratio	[dB]	
0	0.41	0.5	0	0	_∞	
1	0.56	0.59	1	0.01	-40	
2	0.71	0.71	2	0.02	-34	
3	0.86	0.84	3	0.03	-30.5	
4	1.01	1	4	0.04	-28	
5	—	1.19	5	0.05	-26	
6	—	1.41	6	0.06	-24.4	
7	—	1.68	7	0.07	-23.1	
8	—	2	8	0.08	-21.9	
9	—	2.38	9	0.09	-20.9	
10	—	2.83	10	0.1	-20	
11	—	3.36	15	0.15	-16.5	
12	—	4	20	0.2	-14	
13	—	4.76	25	0.25	-12	
14	—	5.66	30	0.3	-10.5	
15	—	6.73	35	0.35	-9.1	
16	—	8	40	0.4	-8	
17	—	9.51	45	0.45	-6.9	
18	_	11.31	50	0.5	-6	
19	—	13.45	60	0.6	-4.4	
20	—	16	70	0.7	-3.1	
			80	0.8	-1.9	
			90	0.9	-0.9	
			100	1	0	



5-36 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Preparation

4

7

4. Manual Gain Tuning (Basic)

Suppression of Machine Resonance

How to Check the Resonance Frequency of the Machine (1) Start up the Setup Support Software, "PANATERM" and bring the frequency characteristics measurement screen. (2) Set up the parameters and measurement conditions. (Following values are standard.) • Set up Pr1.01 (1st gain of velocity loop) to 25 or so. (to lower the gain and make it easy to identify the resonance frequency) • Set up the amplitude to 50 (r/min) or so. (not to saturate the torque) • Make the offset to 100 (r/min) or so. (to increase the speed detecting data and to avoid the measurement error in the vicinity of speed-zero) • Polarity is made positive direction with "+" and negative direction with "-". • Setup the sampling rate to 0. (setup range to be 0 to 7.) (3) Execute the frequency characteristic analysis. Remarks 🔅 Make sure that the revolution does not exceed the travel limit before the measurement. Standard revolutions are, Offset $(r/min) \times 0.017 \times (sampling rate +1)$ Larger the offset, better measurement result you can obtain, however, revolutions may be increased. Set up Pr2.00 (Setup of adaptive filter mode) to 0 while you make measurement. Note • When you set a larger value of offset than the amplitude setup and make the motor run to the one direction at all time, you can obtain a better measurement result. Set up a smaller sampling rate when you measure a high frequency band, and a larger sampling rate when you measure a low frequency band in order to obtain a better measurement result. • When you set a larger amplitude, you can obtain a better measurement result, but noise will be larger. Start a measurement from 50 [r/min] and gradually increase it. **Relation of Gain Adjustment and Machine Stiffness** In order to enhance the machine stiffness,

(1) Install the base of the machine firmly, and assemble them without looseness.

- (2) Use a coupling designed exclusively for servo application with high stiffness.
- (3) Use a wider timing belt. Belt tension to be within the permissible load to the motor shaft.
- (4) Use a gear reducer with small backlash.
 - Inherent vibration (resonance frequency) of the machine system has a large effect to the gain adjustment of the servo.

You cannot setup a higher response of the servo system to the machine with a low resonance frequency (machine stiffness is low).

Note


Please download the Setup support software "PANATERM" from our web site and use after install to the PC.

Related page P.7-26 "Outline of Setup support software "PANATERM"

Damping Control

Outline

This function reduces the vibration at the top or on whole of the equipment by removing the vibration frequency components specified by the positional command. Up to 2 among 4 frequency settings can be used at the same time.



Applicable Range

This function can only be applicable when the following conditions are satisfied.

	Conditions under which the damping control is activated
Control mode	 Control mode to be either or both position control or/and full-closed control. Pr0.01 = 0 : Position control Pr0.01 = 3 : 1st control mode of position and velocity control Pr0.01 = 4 : 1st control mode of position control and torque control Pr0.01 = 6 : Full-closed control

Caution


This function does not work properly or no effect is obtained under the following conditions.

	Conditions which obstruct the damping control effect
Load	 Vibration is triggered by other factors than command (such as disturbance). Ratio of resonance frequency and anti-resonance frequency is large. Vibration frequency is out of the range of 1.0-200.0 [Hz].

How to Use

(1) Setup of damping frequency (1st: Pr2.14, 2nd: Pr2.16, 3rd: Pr2.18, 4th: Pr2.20)) Measure the vibration frequency of the front edge of the machine. When you use such instrument as laser displacement meter, and can directly measure the load end vibration, read out the vibration frequency from the measured waveform and enter the correct value to the damping frequency parameter.

If no suitable measuring instrument is available, use our setup support software "PANATERM" that can graphically display the position deviated waveform as shown in the figure below. Determine the frequency (Hz) of the residual vibration and set the damping frequency.




(2) Setup of damping filter (1st: Pr2.15, 2nd: Pr2.17, 3rd: Pr2.19, 4th: Pr2.21)) First, set up 0.

You can reduce the settling time by setting up larger value, however, the torque ripple increases at the command changing point as the right fig. shows. Setup within the range where no torque saturation occurs under the actual condition. If torque saturation occurs, damping control effect will be lost.

Caution 🔅

Setting range of the damping filter should be limited as follows: 10.0 Hz – damping frequency \leq damping filter setting \leq damping frequency



2

How to Use

(3) Setup of damping filter switching selection (Pr2.13)

You can switch the 1st or the 2nd damping filter depending on the vibration condition of the machine.

Pr2.13	VS-SEL2	VS-SEL1	1st damping	2nd damping	3rd damping	4th damping
0	—	—	0	0		
4	—	OFF	0		0	
I	_	ON		0		0
	OFF	OFF	0			
2	OFF	ON		0		
2	ON	OFF			0	
	ON	ON				0
Pr2.13	Position of direct		1st damping	2nd damping	3rd damping	4th damping
3	Positive	direction	0		0	
3	Negative direction			0		0

A5I

However, when two-degree-of-freedom control mode is enabled, this function is limited as shown below (only 1 function can be used at the same time).

Pr2.13	VS-SEL2	VS-SEL1	1st damping	2nd damping	3rd damping	4th damping
0	_	_	0			
4	_	OFF	0			
I	—	ON		0		
	OFF	OFF	0			
	OFF	ON		0		
2	ON	OFF			0	
	ON	ON				0
Pr2.13	Position command direction		1st damping	2nd damping	3rd damping	4th damping

3

With A5I series, damping control is limited to only 1st, but Pr6.41 Anti-vibration depth 1 can also be set, regardless of availability of the two-degree-of-freedom control mode.

 \bigcirc

 \bigcirc

Caution 🔅

Damping control is switched over on the rising edge of the command while the positioning complete is being output and the number of command pulses/0.166 ms changes from 0 to non-0 state.

If higher damping frequency is selected or damping is disabled and positioning complete range is wide, and if the pulse (the area of the pulse = value of position command before filter minus value of position command after filter, integrated with respect to time) remains in the filter at the rising edge of the command, the pulse is rapidly discharged immediately after damping change. This causes the motor to run at a rate higher than the commanded speed for a while to return to the predetermined position.

Positive direction

Negative direction

Feed forward function

Outline

5

When position control or full closed control is used, positional deviation can be further reduced when compared with deviation where control is made only by feedback, and response is also improved, by calculating the velocity control command necessary for operation based on the internal positional command, and by adding velocity feed forward to the speed command calculated by comparison with position feedback.

The response time of the velocity control system is also improved by calculating torque command necessary for operation based on the velocity control command and by adding torque feed forward calculated by comparison with velocity feedback to the torque command.

Related Parameter

Class	No.	Title	Function
1	10	Velocity feed forward gain	Multiply the velocity control command calculated according to the internal positional command by the ratio of this parameter and add the result to the speed command resulting from the positional control process.
1	11	Velocity feed forward filter	Set the time constant of 1st delay filter which affects the input of velocity feed forward.
1	12	Torque feed forward gain	Multiply the torque command calculated according to the velocity control command by the ratio of this parameter and add the result to the torque command resulting from the velocity control process.
1	13	Torque feed forward filter	Set up the time constant of 1st delay filter which affects the input of torque feed forward.
6	0	Analog torque feed forward conversion gain	Set the input gain of analog torque feed forward. 0 to 9 are invalid.
6	10	Function expansion setup	Set up the function in unit of bit. bit5 0: Analog torque feed forward is invalid. 1: Analog torque feed forward is Valid. * bit 0 = LSB

For A5 series, the velocity feed forward and torque feed forward can be used.


7

5-41

Usage example of velocity feed forward

The velocity feed forward will become effective as the velocity feed forward gain is gradually increased with the velocity feed forward filter set at approx. 50 (0.5 ms). The positional deviation during operation at a constant velocity is reduced as shown in the equation below in proportion to the value of velocity feed forward gain.

Positional deviation [unit of command] = command speed [unit of command/s] / positional loop gain [1/s] × (100 - velocity feed forward gain [%]) / 100



With the gain set at 100 %, calculatory positional deviation is 0, but significant overshoot occurs during acceleration/deceleration.


If the updating cycle of the positional command input is longer than the driver control cycle, or the pulse frequency varies, the operating noise may increase while the velocity feed forward is active. If this is the case, use positional command filter (1st delay or FIR smoothing), or increase the velocity forward filter setup value.

Usage example of torque feed forward

• To use the torque feed forward, correctly set the inertia ratio.

Use the value that was determined at the start of the real time auto tuning, or set the inertia ratio that can be calculated from the machine specification to Pr0.04 Inertia ratio.

- The torque feed forward will become effective as the torque feed forward gain is gradually increased with the torque feed forward filter is set at approx. 50 (0.5 ms).
- Positional deviation at a constant acceleration/deceleration can be minimized close to 0 by increasing the torque forward gain. This means that positional deviation can be maintained at near 0 over entire operation range while driving in trapezoidal speed pattern under ideal condition where disturbance torque is not active .



Zero positional deviation is impossible in actual situation because of disturbance torque. As with the velocity feed forward, large torque feed forward filter time constant decreases the operating noise but increases positional deviation at acceleration change point.

Usage example of analog torque feed forward


Setting bit 5 place of Pr6.10 Function expansion setup to 1 enables the analog torque feed forward. When the analog input 3 is used by another function (e.g. analog torque limit), the function becomes invalid.

The voltage (V) applied to the analog input 3 is converted to the torque via Pr6.00 Analog torque feed forward conversion gain setup and added to the torque command (%): in CCW direction if it is positive voltage or in CW direction if negative.

The voltage (V) applied to the analog input 3 is converted to the motor torque command (%) through the process as shown in the graph below.

The slope represents when Pr6.00 = 30. The slope changes as the setup value changes.

Torque command (%) = $100 \times \text{input voltage}$ (V) / (Pr6.00 setup value $\times 0.1$)



6 When in Trouble

7

2

Connection


4

Setup

Instantaneous Speed Observer

Outline

This function enables both realization of high response and reduction of vibration at stopping, by estimating the motor speed using a load model, hence improving the accuracy of the speed detection.



Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the instantaneous speed observer is activated
Control mode	 Control mode to be either or both position control or/and velocity control. Pr0.01 = 0 : Position control Pr0.01 = 1 : Velocity control
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly. Real-time auto-tuning should be disabled. (Pr0.02=0)

Caution

This function does not work properly or no effect is obtained under the following conditions.

	Conditions which obstruct instantaneous speed observer action
Load	 Gap between the estimated total load inertia (motor + load) and actual machine is large. e.g.) Large resonance point exists in frequency band of 300[Hz] or below. Non-linear factor such as large backlash exists. Load inertia varies. Disturbance torque with harmonic component is applied.
Others	Settling range is very small.

Instantaneous Speed Observer

Related Parameter

Class	No.	Title	Function		
6	10	Function expansion setup	Speed observer enable bit (bit 0) valid/invalid the function. bit0 0: Invalid 1: Valid * bit 0 = LSB		

How to Use

(1) Setup of inertia ratio (Pr0.04)

Set up as exact inertia ratio as possible.

- When the inertia ratio (Pr0.04) is already obtained through real-time auto-gain tuning and is applicable at normal position control, use this value as Pr0.04 setup value.
- When the inertia ratio is already known through calculation, enter this calculated value.
- When the inertia ratio is not known, execute the normal mode auto-gain tuning and measure the inertia ratio.

(2) Adjustment at normal position control

• Adjust the position loop gain, velocity loop gain, etc.


(3) Setup of instantaneous velocity observer (Pr6.10)

- By enabling instantaneous speed observer function through function expansion setup (Pr6.10), the speed detection method changes to the instantaneous speed observer.
- When you experience a large variation of the torque waveform or noise, return this to 0, and reconfirm the above cautions and (1).
- When you obtain the effect such as a reduction of the variation of the torque waveform and noise, search an optimum setup by making a fine adjustment of Pr0.04 (Inertia ratio) while observing the position deviation waveform and actual speed waveform to obtain the least variation. If you change the position loop gain and velocity loop gain, the optimum value of the inertia ratio (Pr0.04) might have been changed, and you need to make a fine adjustment again.

Disturbance observer

Outline

This function uses the disturbance torque determined by the disturbance observer to reduce effect of disturbance torque and vibration.



Estimated disturbance torque value

Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the disturbance observer is activated
Control mode	 Control mode to be either or both position control or/and velocity control. Pr0.01 = 0 : Position control Pr0.01 = 1 : Velocity control
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly. Real-time auto-tuning should be disabled. (Pr0.02=0) Instantaneous speed observer should be disabled. (Pr6.10 bit0=0)

Caution

Effect may not be expected in the following condition.

	Conditions which obstruct disturbance observer action
Load	 Resonant frequency is lower than the cutoff frequency estimated by the disturbance observer. Disturbance torque contains many high frequency components.

Related page P.4-4..., P.4-57 "Details of parameter"

Related Parameter

Class	No.	Title	Function
6	10	Function expansion setup	Sets bits related to disturbance observer. bit1 0: Invalid 1: Valid bit2 0: Always valid 1: alid only when 1st gain is selected. * bit 0 = LSB Example) To use the disturbance observer in the enabled mode only when 1st gain is selected: Setup value = 6 To use the disturbance observer always in the enabled mode: Setup value = 2
6	23	Disturbance torque compen- sating gain	Set up compensating gain against disturbance torque.
6	24	Disturbance observer filter	Set up the filter time constant according to the disturbance torque compensation.

How to Use

1) With Pr6.10 Function enhancement setup, set observer enable/disable and operation mode (always enable/enable only when 1st gain is selected).

2) Setup of Pr6.24 (Disturbance observer filter)

First, set up Pr6.24 to a larger value and check the operation with Pr6.23 Disturbance torque compensating gain set to a low value, and then gradually decrease the setup value of Pr6.24. A low filter setup value assures disturbance torque estimation with small delay and effectively suppresses effects of disturbance. However, this results in larger operation noise. Well balanced setup is required.

3) Setup of Pr6.23 (Disturbance torque compensating gain)

After setting up Pr6.24, increase Pr6.23.

The disturbance suppressing capability increases by increasing the gain, but it is associated with increasing volume of operation noise.

This means that well balanced setup can be obtained by adjusting Pr6.24 and Pr6.23.

Setup

6

Adjustment

3rd gain switching function

Outline

In addition to the normal gain switching function described on P.5-17, 3rd gain switching function can be set to increase the gain just before stopping. The higher gain shortens positioning adjusting time.

Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the 3rd gain switching function is activated
Control mode	 Control mode to be either or both position control or/and full-closed control. Pr0.01 = 0 : Position control Pr0.01 = 6 : Full-closed control
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Related Parameter

Class	No.	Title	Function
6	5	Position 3rd gain valid time	Set up the time at which 3rd gain becomes valid.
6	6	Position 3rd gain scale factor	Set up the 3rd gain by a multiplying factor of the 1st gain: 3rd gain = 1st gain × Pr6.06/100

Preparation

3

Connection

4

Setup

5

Adjustment

3rd gain switching function

How to Use


While in the condition under which the normal gain switching functions, set the 3rd gain application time to Pr6.05 Position 3rd gain enable time, and set the 3rd gain (scale factor with reference to 1st gain) to Pr6.06 Position 3rd gain magnification ratio.

- If 3rd gain is not used, set Pr6.05 to 0 and Pr6.06 to 100.
- The 3rd gain is enabled only for position control or full closed control.
- During the 3rd gain period, only position loop gain/speed proportional gain becomes 3rd gain, during other periods, 1st gain setting is used.
- When the 2nd gain switching condition is established during 3rd gain period, 2nd gain is used.
- During transition from 2nd gain to 3rd gain, Pr1.19 Position gain switching time is applied.

Caution 🔅 When the gain is switched from 2nd to 1st by the change in parameter, the 3rd gain period appears.

Example)

Pr1.15 Position control switching mode = 7 switching condition: with positional command:



Time constant of velocity integration, speed detection filter and torque filter directly use the 1st gain value.

Friction torque compensation

Outline

To reduce effect of friction represented by mechanical system, 2 types of friction torque compensation can be applied: offset load compensation that cancels constant offset torque and the dynamic friction compensation that varies direction as the operating direction varies.

Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the Friction torque compensation is activated
Control mode	 Specific to individual functions. Refer to "Related parameters" shown below.
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Related Parameter


Combine the following 3 parameters to setup appropriate friction torque compensation.

Class	No.	Title	Function
6	7	Torque command additional value	Set up the offset load compensation value usually added to the torque command in a control mode except for the torque control mode.
6	8	Positive direction torque compensation value	Set up the dynamic friction compensation value to be added to the torque command when forward positional command is fed.
6	9	Negative direction torque compensation value	Set up the dynamic friction compensation value to be added to the torque command when negative direction positional command is fed.

Related page P.4-57 "Details of parameter"

Friction torque compensation

How to Use



The friction torque compensation will be added in response to the entered positional command direction as shown below.

The friction compensation torque is the sum of the offset load compensation value which is set according to the torque command additional value (always constant) and the dynamic friction compensation torque which is set according to positive/negative direction torque compensation value.

The command speed direction is reset upon power-up or when the motor is de-energized.

- Pr6.07 [Torque command additional value] reduces variations in positioning operation (performance is affected by direction of movement). These variations occur when constant offset torque resulting from weight on vertical axis is applied to the motor.
- Certain loads such as belt driven shaft requires high dynamic friction torque, which lengthens positioning setting time or varies positioning accuracy. These problems can be minimized by setting the friction torque of every rotating direction into individual parameters. Pr6.08 [Positive direction torque compensation value] and Pr6.09 [Negative direction torque compensation value] can be used for this purpose.

Caution 🔅

The offset load compensation and dynamic friction compensation can be used individually or in combination. However, some control modes impose limit on application.

- For torque control: Offset load compensation and dynamic friction compensation are set at 0 regardless of parameter setting.
- For velocity control with servo-off: Offset load compensation per Pr6.07 is enabled. Dynamic friction compensation is set at 0 regardless of parameter setting.
- For position control or full closed control with servo-on: Previous offset load compensation and dynamic friction compensation values are maintained until the first positional command is applied where the offset load compensation value is updated according to Pr6.07. The dynamic friction compensation value is updated to parameters Pr.6.08 and Pr6.09 depending on command direction.

Before Using the Products

6

Inertia ratio switching function

Outline

Inertia ratio can be switched between No.1 and No.2 by the switching input (J-SEL). This feature is useful in application where the load inertia changes in two steps.

Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the Inertia ratio switching function is activated
Control mode	 Can be used in all control modes. Pr0.01 = 0 : Position control Pr0.01 = 1 : Velocity control Pr0.01 = 2 : Torque control Pr0.01 = 3 : Position/Velocity control Pr0.01 = 4 : Position/Torque control Pr0.01 = 5 : Velocity/Torque control Pr0.01 = 6 : Full-closed control
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly. Real-time auto-tuning should be disabled. (Pr0.02=0) Adaptive filter should be disabled. (Pr2.00=0) Instantaneous speed observer should be disabled. (Pr6.10 bit0=0) Disturbance observer should be disabled. (Pr6.24=0 bit1=0)

Caution

- Be sure to change the inertia ratio while the motor is in stop state. Otherwise, vibration or oscillation will occur.
- If the difference between the 1st inertia ratio and 2nd inertia ratio is large, vibration, etc., may occur even in stop mode. These potential problems should be identified on the actual model.

Inertia ratio switching function

Related Parameter

Combine the following 3 parameters to setup appropriate inertia ratio switching function.

Class	No.	Title	Function
6	10	Function expansion setup	Sets bits related to inertia ratio switching function. bit1 0: Invalid 1: Valid bit2 0: Always valid 1: Valid only when 1st gain is selected. * bit 0 = LSB Example) To enable inertial ratio switching Setup value = 8
0	04	Inertia ratio	Set 1st inertia ratio. You can set up the ratio of the load inertia against the rotor (of the motor) inertia.
6	13	2nd Inertia ratio	Set 2nd inertia ratio. You can set up the ratio of the load inertia against the rotor (of the motor) inertia.

How to Use

· Select 1st inertia ratio or 2nd inertia ratio according to the inertia ratio select input (J-SEL).

Inertia ratio switching input (J-SEL)	Applicable inertia ratio
OFF	1st Inertia ratio (Pr0.04)
ON	2nd Inertia ratio (Pr6.13)

1

Before Using the Products

2

Preparation

Connection

5

Hybrid vibration damping function

Outline

This function suppresses vibration due to amount of twist between the motor and load in the full closed control mode. This function enables high gain setting.

Applicable range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the Hybrid vibration damping function is activated
Control mode	Full-closed control mode
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Caution

The effect of this function will be proportional to the amount of twist between the motor and load.

Related Parameter			
Class	No.	Title	Function
6	34	Hybrid vibration suppression gain	Set up the hybrid vibration suppression gain for full-closed controlling. First set it to the value identical to that of poison loop gain, and then fine tune as necessary.
6	35	Hybrid vibration suppression filter	Set up the time constant of the hybrid vibration suppression filter for full-closed controlling.

How to Use

- [1] Set Pr6.34 Hybrid vibration suppression gain to the value equal to that of positional loop gain.
- [2] Driving under full closed control, gradually increase the setup value of Pr6.35
 Hybrid vibration suppression filter while checking response change.
 When the response is improved, adjust Pr6.34 and Pr6.35 to determine the combination that provides the best response.

Related page P.4-62 "Details of parameter"

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

5. Manual Gain Tuning (Application)

Adjustment

A5I Two-degree-of-freedom control mode (Position control mode)

Outline

In the two-degree-of-freedom control mode, command response and servo rigidity can be independently set with improved responsiveness. This mode has enhanced position control functions.

Applicable Range

This function can be applicable only when the following condition are satisfied.

	Conditions under which the Two-degree-of-freedom control mode is activated.
Control Mode	Position control
Others	 Should be servo-on condition. Factors other than control parameters such as torque limit should be properly setup, allowing motor to operate normally.

Related Parameter

First, set Pr6.47 Function expansion setup 2 to 1 and write the setting to EEPROM. Reset the control power supply to enable the two-degree-of-freedom control mode. Adjust the gain by using the real-time auto-tuning (refer to P.5-10). If further improvement is necessary, manually fine tune the following parameters while checking the response.

Class	No.	Title	Function
6	47	Function expansion settings 2	Set up various functions bit by bit. bit 0 Two-degree-of-freedom control mode 0: Invalid 1: Valid bit 3 Two-degree-of-freedom control real-time auto-tuning select 0: Standard type 1: Synchronous type *The least significant bit is represented by bit0. *For bit3 (two-degree-of-freedom control real time auto tuning select): this is made usable when bit0 is at 1 (valid).
2	22	First order filter time constant for command	While the two-degree-of-freedom control real-time auto- tuning is selected, time constant of command filter is applied with the maximum value limited to 2000 (= 200.0 ms). (The value of the parameter is not limited but the value to be applied to driver is limited. Set attenuation term in Pr6.49 [Set attenuation term of command filter/adjustment filter].) Decreasing the value of this parameter makes command response fast and large, resulting smooth command response.

(continued)

A5II Two-degree-of-freedom control mode (Position control mode)

Class	No.	Title	Function
6	48	Adjust filter	Sets time constant of adjustment filter. When the torque filter setting is changed, set the parameter to a value close to real-time auto-tuning setting. Fine adjustment by checking positional deviation of the encoder near setting point may improve overshoot or oscillatory waveform.
6	49	Adjust/ Torque command attenuation term	Sets attenuation term of command filter and adjustment filter. Decimal notation: 1st digit sets command filter and 2nd digit sets adjustment filter. Value of digit 0 to 4: Without attenuation term (functions as 1st filter). Value of digit 5 to 9: The 2nd filter (attenuation term ζ is 1.0, 0.86, 0.71, 0.50 and 0.35, in that order). <example> To set command filter $\zeta = 1.0$, adjustment filter 1 $\zeta = 0.71$: Setup value = 75 1st digit = 5 ($\zeta = 1.0$), 2nd digit = 7 ($\zeta = 0.71$) Pr2.22 Command smoothing filter is applied as time constant of command filter.</example>
6	50	Viscous friction compensation gain	Adds the result of command speed multiplied by this setup value to torque command as viscous friction torque correction value. By setting the estimate value of viscous friction coefficient of real-time auto-tuning, encoder positional deviation near the setting point may be improved.

7

5

5. Manual Gain Tuning (Application)

Adjustment A

A5II Two-degree-of-freedom control mode (Velocity control mode)

Outline

In the two-degree-of-freedom control mode, command response and servo rigidity can be independently set with improved responsiveness. This mode has enhanced speed control functions.

Applicable Range

This function can be applicable only when the following condition are satisfied.

	Conditions under which the Two-degree-of-freedom control mode is activated.
Control Mode	Speed control
Others	 Should be servo-on condition. Factors other than control parameters such as torque limit should be properly setup, allowing motor to operate normally.

Related Parameter

First, set Pr6.47 Function expansion setup 2 to 1 and write the setting to EEPROM. Reset the control power supply to enable the two-degree-of-freedom control mode. Adjust the gain by using the real-time auto-tuning (refer to P.5-10). If further improvement is necessary, manually fine tune the following parameters while checking the response.


Class	No.	Title	Function
Class 6 2	47	Function expansion settings 2	Set up various functions bit by bit. bit 0 Two-degree-of-freedom control mode 0: Invalid 1: Valid *The least significant bit is represented by bit0.
647expansion settings 2222First order filter time constant for command223FIR filter time constant for		time constant	While the two-degree-of-freedom control real-time auto- tuning is selected, time constant of command filter is applied with the maximum value limited to 640 (= 64.0 ms). (The value of the parameter is not limited but the value to be applied to driver is limited.) Decreasing the value of this parameter makes command response fast and large, resulting smooth command response.
		constant for	Sets the time constant of FIR filter in response to the command when the two-degree-of-freedom control is applied.
6	48	Adjust filter	Sets time constant of adjustment filter. When the torque filter setting is changed, set the parameter to a value close to real-time auto-tuning setting. Fine adjustment by checking positional deviation of the encoder near setting point may improve overshoot or oscillatory waveform.

Related page P.4-64 "Details of parameter"

A5I Two-stage torque filter

Outline

In addition to existing 1st and 2nd torque filter (Pr1.04 and Pr1.09), the 3rd torque filter can be set. This 2-stage torque filter will effectively suppress oscillating component in high frequency range.



Applicable Range

This function can be applicable only when the following condition are satisfied.

	2-stage torque filter operating condition
Control Mode	Can be used in any control mode.
Others	 Should be servo-on condition. Factors other than control parameters such as torque limit should be properly setup, allowing motor to operate normally.

Caution

- Excessively high setup value makes control unstable and may cause oscillation.
- Set to an appropriate value by checking condition of the device.
- Changing Pr6.43 2-stage torque filter attenuation term during operation may cause oscillation. Stop operation before changing the term.

Related page P.4-63 "Details of parameter"

A51 Two-stage torque filter

Related Parameter

Class	No.	Title	Function
6	42	Two-stage torque filter time constant	[Setting range: 0 to 2500] Sets time constant of 2-stage torque filter. Setup value 0: invalid [When using in 2nd filter with Pr6.43≥50] Compatible time constant range is 5 to 159 (0.05 ms to 1.59 ms) (corresponding frequency range: 100 Hz to 3000 Hz) Setup values 1 to 4 function as 5 (3000 Hz) and 159 to 2500 as 159 (100 Hz).
6	43	Two-stage torque filter Attenuation term	[Setting range: 0 to 1000] Set the attenuation term of 2-stage torque filter. This setup value is used to switchover between 1st and 2nd filter of 2-stage filter. 0 to 49: Operates as 1st filter. 50 to 1000: Operates as 2nd filter with $\zeta = 1.0$ when setup value is 1000. Standard value is 1000; smaller setup value will cause oscillation.

How to Operate

When high frequency oscillation cannot be completely prevented by 1st and 2nd torque filter, setup the 2-stage torque filter. Set Pr6.43 2-stage torque filter attenuation term to 1000 ($\zeta = 1.0$) and adjust Pr6.42 2-stage torque filter time constant.

1

Adjustment


6. About Homing Operation

Caution on Homing Operation


 In homing action by using the host controller, stop position might not be stabilized if the origin input (Z-phase of the encoder) is entered while the motor is not decelerated enough after the proximity input is turned on. Set up the ON-positions of proximity input and the position of origin point, considering the necessary pulse counts for deceleration. Take the positioning action and homing action into account when you set put acceleration/deceleration time with parameter, since this affect these action as well.
 For the details of homing, observe the instruction manual of the host controller.

Example of Homing Action

Proximity dog on....Decelerates at an entry of the proximity input, and stops at an entry of the first origin input (Z-phase)



Proximity dog off... .Decelerates at an entry of the proximity input, and stops at an entry of the first origin input (Z-phase) after the input is tuned off



Adjustment


5

6. About Homing Operation

Homing with Hit & Stop

You can set up the homing position with "Hit & Stop" where it is not easy to install a sensor due to environment.

- (1) when you make a point where the work (load) hits as an origin
- (2) when you stop the work (load) using Z-phase after making a hitting point as a starting point, then make that stopping point as an origin.



Parameter No.	Title	Setup example			
5.22	Setup of 2nd torque limit	50 (Set up to less than 100 %)			
0.14	Excess setup of position deviation	25000			
5.13	Setup of over-speed level	0 (6000 r/min)			
5.21	Selection of torque limit	3			

Remarks 🔅

Assign TL-SEL to the input signal.

Upon completion of the homing with hit and stop, turn off TL-SEL (open if logical setting is a-contact; close if b-contact).

Related page P.4-12, 50, 52 "Details of parameter"

Preparation

3

Connection

4

Setup


5

Adjustment


6. About Homing Operation


Press & Hold Control

Application example



Parameter No.	Title	Setup example
5.21	Selection of torque limit	3
0.13	Setup of 1st torque limit	200
5.22	Setup of 2nd torque limit	50
0.14	Excess setup of position deviation	25000
5.13	Setup of over-speed level	0





Before Using the Products

1

2 Preparation

3

Connection

4

Setup

5

7

6. When in Trouble

1. When in Trouble

2.


3.

What to Check ?6-2	
Protective Function (What is Error Code ?)6-2	
Protective function (Detail of error code)6-4	
Setup of gain pre-adjustment protection6-20	
Troubleshooting	
Motor Does Not Run6-23	
Unstable Rotation (Not Smooth),	
Motor Runs Slowly Even with Speed Zero at Velocity Control Mode6-25	
Positioning Accuracy Is Poor6-26	
Origin Point Slips6-27	
Abnormal Motor Noise or Vibration6-27	
Overshoot/Undershoot,	
Overheating of the Motor (Motor Burn-Out)6-28	
Motor Speed Does Not Reach to the Setup,	
Motor Revolutions (Travel) Is Too Large or Small6-28	
Parameter Returns to Previous Setup	

1. When in Trouble

When in Trouble

What to Check ?



1. When in Trouble

When in Trouble

- Protective Function (What is Error Code ?)
- Various protective functions are equipped in the driver. When these are triggered, the motor will stall due to error, the driver will turn the Servo-Alarm output (ALM) to off (open).
- Error status and their measures
 - During the error status, the error code No. will be displayed on the front panel LED, and you cannot turn Servo-ON.
 - You can clear the error status by Alarm clear input(A-CLR) in 120 ms or longer.
 - When overload protection is triggered, you can clear it by Alarm clear input (A-CLR) in 10sec or longer after the error occurs. (*1 Table below) You can clear the Overload protection time characteristics (refer to P.6-14) by turning off the control power supply between L1C and L2C (100 V, 200 V), 24 V and 0 V (400 V) of the driver.
- You can clear the above error by operating the front panel keys and setup support softwear "PANATERM". Refer to P.2-111 "Alarm Clear Screen" of Preparation.
- Be sure to clear the alarm during stop after removing the cause of the error and securing safety.

Note	 The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2 X3 and X5.
Related page …	 P.2-88 "How to Use the Front Panel" • P.3-32 "Inputs and outputs on connector X4" P.7-26 "Outline of Setup support software "PANATERM"

⁶⁻² Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

1. When in Trouble

Protective Function (What is Error Code ?)

	code	Drotootive for sting	A	ttribut		Detail	Erro	code	Droto office from the se	A	ttribut		Detai	
lain	Sub	Protective function	History	Can be cleared	Immediate stop	page	Main	Sub	Protective function	History	Can be cleared	Immediate stop	page	
11	0	Control power supply under-		0			22	6	CL fitting error protection	0			6-10	
		voltage protection					33	7	INH fitting error protection	0			0-10	
12	0	Over-voltage protection	0	$ \circ$			34	0	Software limit protection	0	0			
	0	Main power supply under-volt- age protection (between P and N)		0		6-4	36	0 to	EEPROM parameter error pro-					
13		Main power supply under-					-	2	tection EEPROM check code error					
	1	voltage protection		0			37	0 to 2	protection				6-10	
		(AC interception detection)					38	0	Over-travel inhibit input protection		0		6-10	
14	0	Over-current protection	0					0	Analog input1 excess protection	0	0	0		
	1	IPM error protection	0			6-5	39	1	Analog input2 excess protection	0	0	0		
15	0	Over-heat protection	0	*i	0			2	Analog input3 excess protection	0	0	0		
16	0	Over-load protection	0	*1			40	0	Absolute system down error	0				
10	1	A5I Torque saturation error protection	0	0		6-6	-		protection Absolute counter over error		-			
	0	Over-regeneration load protection	0		0		41	0	protection	$ \circ $				
18	1	Over-regeneration Tr error	0				42	0	Absolute over-speed error pro-	0	0			
	-	protection						-	tection					
21 -	0	Encoder communication dis- connect error protection	0				43	0	Initialization failure Absolute single turn counter	0			6-11	
		Encoder communication error					44	0	error protection	0				
	1	protection	0			6-7	45	0	Absolute multi-turn counter er-	0				
23	0	Encoder communication data				0-7	45	0	ror protection					
24		error protection					47	0	Absolute status error protection	0				
	0	Position deviation excess pro- tection	0	0	0		48	0	Encoder Z-phase error protection	-				
		Velocity deviation excess pro-				49	49	0	Encoder CS signal error protection					
	1	tection	$ \circ $	0	0			0	Feedback scale connection er- ror protection	0				
25	0	Hybrid deviation excess error			0		50		Feedback scale communication					
	0	protection			_			1	error protection	0				
26	0	Over-speed protection 2nd over-speed protection	0	0	0				Feedback scale status 0 error	0				
	1	Command pulse input frequen-								protection Feedback scale status 1 error				
~7	0	cy error protection	$ \circ $	0	0	6-8		1	protection	0			6-12	
27	2	Command pulse multiplier error						•	Feedback scale status 2 error					
	2	protection	0	0	0		51	2	protection	0				
28	0	Limit of pulse replay error pro-	0	0	0			3	Feedback scale status 3 error	0				
		Deviation counter overflow							protection Feedback scale status 4 error	_				
29	0	protection	$ \circ $	$ \circ $				4	protection	0				
30	0	Safety detection		0				F	Feedback scale status 5 error					
	0	IF overlaps allocation error 1	0					5	protection	0				
		protection						0	A-phase connection error protection	-				
	1	IF overlaps allocation error 2 protection	0				55	1	B-phase connection error protection					
		IF input function number error 1				6-9	07	2	Z-phase connection error protection					
~~	2	protection	$ \circ $				87	0	Compulsory alarm input protection		0		6-13	
33	3	IF input function number error 2					95	0 to 4	Motor automatic recognition error protection				0-13	
	5	protection	0			99	99	0		0				
	4	IF output function number error 1 protection	0					her	Other error	0				
		IF output function number error					nur	nber						
	5	2 protection	0											

<List of error code No.> ASI : Only available on ASI series.

If the alarm clear input is not effective, turn off power, remove the cause of the error and then turn on power again.

Immediate stop...Instantaneous controlled stop upon occurrence of an error.

(Setting of "Pr.5.10 Sequence at alarm" is also required.)

Note 💮

• Only for position control type is not provided with X2, X3, X5 and analog input.

1

Setup

5

Supplement

6 When in Trouble

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error c Main	-	Causes	Measures
Control power supply under- voltage protection	11	0	 Voltage between P and N of the converter portion of the control power supply has fallen below the specified value. 100 V version: approx. 70 VDC (approx. 50 VAC) 200 V version: approx. 145 VDC (approx. 100 VAC) 400 V version: approx. 15 VDC 1) Power supply voltage is low. Instantaneous power failure has occurred 2) Lack of power capacityPower supply voltage has fallen down due to inrush current at the main power-on. 3) Failure of servo driver (failure of the circuit) 	 Measure the voltage between lines of connector and terminal block. 100 V, 200 V driver: L1C - L2C 400 V driver: 24 V - 0 V 1) Increase the power capacity. Change the power supply. 2) Increase the power capacity. 3) Replace the driver with a new one.
Over-voltage protection	12	0	 Voltage between P and N of the converter portion of the control power supply has exceeded the specified value 100 V version: approx. 200 VDC (approx. 140 VAC) 200 V version: approx. 400 VDC (approx. 280 VAC) 400 V version: approx. 800 VDC (approx. 560 VAC) 1) Power supply voltage has exceeded the permissible input voltage. Voltage surge due to the phase-advancing capacitor or UPS (Uninterruptible Power Supply) have occurred. 2) Disconnection of the regeneration discharge resistor 	 Measure the voltage between lines of connector (L1, L2 and L3). 1) Enter correct voltage. Remove a phase-advancing capacitor. 2) Measure the resistance of the external resistor connected between terminal B1 B2 of the driver. Replace the external resistor if the value is ∞.
			 3) External regeneration discharge resistor is not appropriate and could not absorb the regeneration energy. 4) Failure of servo driver (failure of the circuit) 	3) Change to the one with specified resistance and wattage.4) Replace the driver with a new one.
Main power supply under- voltage protection (PN) Main power supply under- voltage protection (AC)	13	0	 Instantaneous power failure has occurred between L1 and L3 for longer period than the preset time with Pr5.09 (Main power off detecting time) while Pr5.08 (LV trip selection at the main power-off) is set to 1. Or the voltage between P and N of the converter portion of the main power supply has fallen below the specified value during Servo-ON. 100 V version: approx. 80 VDC (approx. 55 VAC) 200 V version: approx. 110 VDC (approx. 75 VAC) 400 V version: approx. 180 VDC (approx. 125 VAC) 1) Power supply voltage is low. Instantaneous power failure has occurred 2) Instantaneous power failure has occurred. 3) Lack of power capacityPower supply voltage has fallen down due to inrush current at the main power-on. 4) Phase lack3-phase input driver has been operated with single phase input. 5) Failure of servo driver (failure of the circuit) 	 Measure the voltage between lines of connector (L1, L2 and L3). 1) Increase the power capacity. Change the power supply. Remove the causes of the shutdown of the magnetic contactor or the main power supply, then re-enter the power. 2) Set up the longer time to Pr5.09 (Main power off detecting time). Set up each phase of the power correctly. 3) Increase the power capacity. For the capacity, refer to P.2-10, "Driver and List of Applicable Peripheral Equipments" of Preparation. 4) Connect each phase of the power supply (L1, L2 and L3) correctly. For single phase, 100 V and 200 V driver, use L1 and L3. 5) Replace the driver with a new one.

Related page • P.2-12... "System Configuration and Wiring" • P.4-49 "Details of parameter"

1. When in Trouble

Protective function (Detail of error code)

Protective	Error co	ode No.	-	
function	Main	Sub	Causes	Measures
* Over-current	14	0	Current through the converter portion has exceeded the specified value.	
Protection * IPM error		1	 Failure of servo driver (failure of the circuit, IGBT or other components) Short of the motor wire (U, V and W) 	 Turn to Servo-ON, while disconnecting the motor. If error occurs immediately, replace with a new driver. Check that the motor wire (U, V and W) is
protection IPM: Intelligent Power Module				not shorted, and check the branched out wire out of the connector. Make a correct wiring connection.
			3) Earth fault of the motor wire	 Measure the insulation resistance between motor wires, U, V and W and earth wire. In case of poor insulation, replace the motor.
			4) Burnout of the motor	 Check the balance of resister between each motor line, and if unbalance is found, replace the motor.
			5) Poor contact of the motor wire.	5) Check the loose connectors. If they are, or pulled out, fix them securely.
			 Welding of contact of dynamic braking relay due to frequent servo ON/OFF operations. 	 Replace the servo driver. Do not use Servo-ON/Servo-OFF as a means of staring/stopping the operation.
			 Timing of pulse input is same as or earlier than Servo-ON. 	7) Enter the pulses 100 ms or longer after Servo-ON.
			 Blowout of thermal fuse due to overheating dynamic brake circuit. (Only F and G frames) 	8) Replace the driver.
* Over-heat protection	15	0	Temperature of the heat sink or power device has been risen over the specified temperature. 1) Ambient temperature has risen over	1) Improve the ambient temperature and
			the specified temperature.2) Over-load	 cooling condition. 2) Increase the capacity of the driver and motor. Set up longer acceleration/ deceleration time. Lower the load.

Before Using the Products

1

2

4

7

Note

• When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error c Main	-	Causes	Measures		
Over-load protection	<u>Main</u> 16	0	 Torque command value has exceeded the over-load level set with Pr5.12 (Setup of over-load level) and resulted in overload protection according to the time characteristics (described later) 1) Load was heavy and actual torque has exceeded the rated torque and kept running for a long time. 2) Oscillation and hunching action due to poor adjustment. Motor vibration, abnormal noise. Inertia ratio (Pr0.04) setup error. 3) Miswiring, disconnection of the motor. 4) Machine has collided or the load has gotten heavy. Machine has been distorted. 5) Electromagnetic brake has been kept engaged. 6) While wiring multiple axes, miswiring has occurred by connecting the motor cable to other axis. 	 Check that the torque (current) does not oscillates nor fluctuate up an down very much on the analog outoput and via communication. Check the over-load alarm display and load factor with the analog outoput and via communication 1) Increase the capacity of the driver and motor. Set up longer acceleration/ deceleration time. Lower the load. 2) Make a viring as per the wiring diagram. Replace the cables. 4) Remove the cause of distortion. Lower the load. 5) Measure the voltage between brake terminals. Release the brake 6) Make a correct wiring by matching the correct motor and encoder wires. 		
A5II Torque saturation anomaly protection	-	1	The over-load protection time chara Caution Once this error occurs, it Torque saturation has continued for the time set in Pr6.57 Torque saturation error protection detect time.	cteristics are described on P.6-14. cannot be cleared at least for 10 sec. • Check operation of the driver. • Refer to Measures described for Err16.0.		
* Over- regeneration load protection	18	0	 Regenerative energy has exceeded the capacity of regenerative resistor. 1) Due to the regenerative energy during deceleration caused by a large load inertia, converter voltage has risen, and the voltage is risen further due to the lack of capacity of absorbing this energy of the regeneration discharge resistor. 2) Regenerative energy has not been absorbed in the specified time due to a high motor rotational speed. 3) Active limit of the external regenerative resistor has been limited to 10 % duty. 	 Check the load factor of the regenerative resistor from the front panel or via communication. Do not use in the continuous regenerative brake application. 1) Check the running pattern (velocity monitor). Check the load factor of the regenerative resistor and over-regeneration warning display. Increase the capacity of the driver and the motor, and loosen the deceleration time. Use the external regenerative resistor. 2) Check the running pattern (speed monitor). Check the load factor of the driver and the motor, and loosen the deceleration time. Use the external regenerative resistor. 2) Check the running pattern (speed monitor). Check the load factor of the regenerative resistor. Increase the capacity of the driver and the motor, and loosen the deceleration time. Lower the motor rotational speed. Use an external regenerative resistor. 3) Set up Pr0.16 to 2. 		
Note 🔅	• Wh		Caution Install an external protection such as thermal fuse without fail when you set up Pr0.16 to 2. Otherwise, regenerative resistor loses the protection and it may be heated up extremely and may burn out.			

power, remove the cause, and then turn on power again. * A511: Only available on A5II series.

Related page • P.4-7... "Details of parameter"

Protective function (Detail of error code)

Protective function	Error c Main	ode No. Sub	Causes	Measures
* Regenerative transistor error protection	18	1	Regenerative driver transistor on the servo driver is defective.	Replace the driver.
* Encoder communica- tion discon- nection error protection	21	0	Communication between the encoder and the driver has been interrupted in certain times, and disconnection detecting function has been triggered.	Make a wiring connection of the encoder as per the wiring diagram. Correct the miswiring of the connector pins.
* Encoder communica- tion error protection		1	Communication error has occurred in data from the encoder. Mainly data error due to noise. Encoder cables are connected, but communication data has some errors.	 Secure the power supply for the encoder of DC4.90 V to 5.25 V)pay an attention especially when the encoder cables are long. Separate the encoder cable and the motor espla if they are bound together.
* Encoder communi- cation data error protection	23	0	Data communication between the encoder is normal, but contents of data are not correct. Mainly data error due to noise. Encoder cables are connected, but communication data has some errors.	cable if they are bound together. Connect the shield to FG.
Position deviation excess protection	24	0	 Deviation pulses have exceeded the setup of Pr0.14. 1) The motor movement has not followed the command. 2) Setup value of Pr0.14 (Position deviation excess setup) is small. 	 Check that the motor follows to the position command pulses. Check that the output toque has not saturated in torque monitor. Make a gain adjustment. Set up maximum value to Pr0.13 and Pr5.22. Make a encoder wiring as per the wiring diagram. Set up the longer acceleration/deceleration time. Lower the load and speed. Set up a larger value to Pr0.14.
Velocity deviation excess protection		1	The difference between the internal positional command speed and actual speed (speed deviation) exceeds the setup vale of Pr6.02. Note) If the internal positional command speed is forcibly set to 0 due to instantaneous stop caused by the command pulse inhibit input (INH) or CW/CCW over-travel inhibit input, the speed deviation rapidly increases at this moment. Pr6.02 setup value should have sufficient margin because the speed deviation also largely increases on the rising edge of the internal positional command speed.	 Increase the setup value of Pr6.02. Lengthen the acceleration/deceleration time of internal positional command speed, or improve the follow-up characteristic by adjusting the gain. Disable the excess speed deviation detection (Pr6.02 = 0).

3

5

Protective function (Detail of error code)

Protective	Protective Error code No.			
function	Main		Causes	Measures
*	25	0	Position of load by the external scale	Check the connection between the motor
Hybrid			and position of the motor by the	and the load.
deviation			encoder slips larger than the setup	Check the connection between the external
excess error			pulses with Pr3.28 (Setup of hybrid	scale and the driver.
protection			 deviation excess) at full-closed control. During full closed control, numerator of command division/multiplication is changed or switched over. 	 Check that the variation of the motor position (encoder feedback value) and the load position (external scale feedback value) is the same sign when you move the load. Check that the numerator and denominator of the external scale division (Pr3.24 and 3.25) and reversal of external scale direction (Pr3.26) are correctly set. Do not change command division/ multiplication during full closed control.
Over-speed protection	26	0	The motor rotational speed has exceeded the setup value of Pr5.13.	 Do not give an excessive speed command. Check the command pulse input frequency
2nd Over- speed protection		1	The motor rotational speed has exceeded the setup value of Pr6.15.	 and division/multiplication ratio. Make a gain adjustment when an overshoot has occurred due to a poor gain adjustment. Make a wiring connection of the encoder as per the wiring diagram.
Command pulse input frequency error protection	pulse input frequency error		The frequency of command pulse input is more than 1.2 times the setting in Pr5.32.	Check the command pulse input for frequency.
Electronic gear error protection		2	Division and multiplication ratio which are set up with the command pulse counts per single turn and the1st and the 4th numerator/denominator of the electronic gear are not appropriate. The command pulses per 0.167 ms multiplied by the command division and multiplication ratio exceeds 3000 Mpps. The command pulse input fluctuates. Noises mixed with the command pulse input cause counting error.	 Set the command division and multiplication ratio to a value as small as possible e.g. between 1/1000 and 1000. Check the setup value of electronic gear. If possible, use the line driver I/F. Set Pr5.32 (setting of max. command pulse input) to a value less than 1000 and enable digital filter.
Pulse regeneration limit protection	28	0	The output frequency of pulse regeneration has exceeded the limit.	 Check the setup values of Pr0.11 and 5.03. To disable the detection, set Pr5.33 to 0.

Protective function (Detail of error code)

Protective	Error co	ode No.	0	Maaaaaa
function	Main	Sub	Causes	Measures
Deviation counter overflow protection	29	0	Positional deviation of encoder pulse reference has exceeded 2 ²⁹ (536870912).	 Check that the motor runs as per the position command pulses. Check that the output toque has not saturated in torque monitor. Make a gain adjustment. Set up maximum value to Pr0.13 and Pr5.22. Make a wiring connection of the encoder as per the wiring diagram.
Safety input protection	30	0	Input photocoupler of both or one of safety input 1 and 2 is OFF.	Check wiring of safety input 1 and 2.
* I/F input duplicated allocation error 1 protection	33	0	Input signals (SI1, SI2, SI3, SI4, SI5) are assigned with two functions.	Allocate correct function to each connector pin.
* I/F input duplicated allocation error 2 protection		1	Input signals (SI6, SI7, SI8, SI9, SI10) are assigned with two functions.	
* I/F input function number error 1 protection	-	2	Input signals (SI1, SI2, SI3, SI4, SI5) are assigned with undefined number.	
* I/F input function number error 2 protection		3	Input signals (SI6, SI7, SI8, SI9, SI10) are assigned with undefined number.	
* I/F output function number error 1 protection		4	Output signals (SO1, SO2, SO3) are assigned with undefined number.	
* I/F output function number error 2 protection		5	Output signals (SO4, SO5, SO6) are assigned with undefined number.	

3

5

Note 🐳

• When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.

Only for position control type is not provided with X3 and anlaog input.

Protective function (Detail of error code)

Protective function	Error c Main	ode No. Sub	Causes	Measures
* CL assignment error	33 6		Counter clear function is assigned to a signal number other than SI7.	Allocate correct function to each connector pin.
* INH assignment error		7	Command pulse inhibit input function is assigned to a signal number other than SI10.	
Software limit protection	34	0	When a position command within the specified input range is given, the motor operates outside its working range specified in Pr5.14.	
			1) Gain is not appropriate. 2) Pr5.14 setup value is low.	 Check the gain (balance between position loop gain and speed loop gain) and inertia ratio. Increase the setup value of Pr5.14. Or, Set Pr5.14 to 0 to disable the protective function.
* EEPROM parameter error protection	36	0 1 2	Data in parameter storage area has been damaged when reading the data from EEPROM at power-on.	 Set up all parameters again. If the error persists, replace the driver (it may be a failure.) Return the product to the dealer or manufacturer.
* EEPROM check code error protection	37 0 1 2		Data for writing confirmation to EEPROM has been damaged when reading the data from EEPROM at power-on.	Replace the driver. (it may be a failure). Return the product to a dealer or manufacturer.
* Over-travel inhibit input protection	ver-travel hibit put		With Pr5.04, over-travel inhibit input setup = 0, both positive and negative over-travel inhibit inputs (POT/NOT) have been ON. With Pr5.04 = 2, positive or negative over-travel inhibit input has turned ON.	Check that there are not any errors in switches, wires or power supply which are connected to positive direction/ negative direction over-travel inhibit input. Check that the rising time of the control power supply (DC12 V to 24 V) is not slow.
Analog input 1 (Al1) excess protection	ss		Higher voltage has been applied to the analog input 1 than the value that has been set by Pr4.24.	 Set up Pr4.24 correctly. Check the connecting condition of the connector X4. Set up Pr4.24 to 0 and invalidate the protective function.
Analog input 2 (Al2) excess protection		1	Higher voltage has been applied to the analog input 2 than the value that has been set by Pr4.27.	 Set up Pr4.27 correctly. Check the connecting condition of the connector X4. Set up Pr4.27 to 0 and invalidate the protective function.
Analog input 3 (Al3) excess protection		2	Higher voltage has been applied to the analog input 3 than the value that has been set by Pr4.30.	 Set up Pr4.30 correctly. Check the connecting condition of the connector X4. Set up Pr4.30 to 0 and invalidate the protective function.

Note

• Only for position control type is not provided with analog input.

Protective function (Detail of error code)

Protective Error code No.		ode No.	Causes	Magguroo
function	Main	Sub	Causes	Measures
Absolute system down error protection	40	0	Voltage of the built-in capacitor has fallen below the specified value because the power supply or battery for the absolute encoder has been down.	After connecting the power supply for the battery, clear the absolute encoder.
			Caution : Once this error occurs, the encoder is reset.	ne alarm cannot be cleared until the absolute
* Absolute counter over error protection	41	0	Multi-turn counter of the absolute encoder has exceeded the specified value.	 Set Pr0.15 to 2 to ignore the multi-turn counter over. Limit the travel from the machine origin within 32767 revolutions.
Absolute 42 0 over- speed error protection		0	The motor speed has exceeded the specified value when only the supply from the battery has been supplied to 17-bit encoder during the power failure.	 Check the supply voltage at the encoder side (5 V±5 %) Check the connecting condition of the connector X2.
			Caution : Once this error occurs, the encoder is reset.	ne alarm cannot be cleared until the absolute
* Encoder initialization error protection *1	43	0	Encoder initialization error was detected.	Replace the motor.
* Absolute single turn counter error protection *1	44	0	Absolut: single turn counter error protection incremental: single turn counter error protection	Replace the motor.
* Absolute multi-turn counter error protection *1		0	Absolut: multi-turn counter error protection incremental: single turn counter error protection	Replace the motor.
* Absolute status error protection *1	47	0	Encoder has been running at faster speed than the specified value at power-on.	Arrange so as the motor does not run at power-on.
* Encoder Z-phase error protection*1	48	0	Missing pulse of Z-phase of serial incremental encoder has been detected. The encoder might be a failure.	Replace the motor.

1

4

Connection

7

Note 🔶

• When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.

Protective function (Detail of error code)

Protective	Error c	ode No.	Causes	Measures
function	Main	Sub	Causes	Micdoul co
* Encoder CS signal error protection *1	49	0	CS signal logic error of serial incremental encoder has been detected. The encoder might be a failure.	Replace the motor.
* Feedback scale wiring error protection	50	0	Communication between the external scale and the driver has been interrupted in certain times, and disconnection detecting function has been triggered.	 Make a wiring connection of the external scale as per the wiring diagram. Correct the miswiring of the connector pins.
* External communi- cation data error protection		1	Communication error has occurred in data from the external scale. Mainly data error due to noise. External scale cables are connected, but communication date has some error.	 Secure the power supply for the external scale of DC5±5 % (4.75 V to 5.25 V)pay attention especially when the external scale cables are long. Separate the external scale cable and the motor cable if they are bound together. Connect the shield to FGrefer to wiring diagram.
* External scale status 0 error protection *1	51	0	Bit 0 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	Remove the causes of the error, then clear the external scale error from the front panel. And then, shut off the power to reset.
* External scale status 1 error protection *1		1	Bit 1 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 2 error protection *1		2	Bit 2 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 3 error protection *1		3	Bit 3 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 4 error protection *1		4	Bit 4 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 5 error protection *1		5	Bit 5 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	

Note
When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.


• Only for position control type is not provided with X5.

Protective function (Detail of error code)

Protective	Error c	ode No.		•
function	Main	Sub	Causes	Measures
* A-phase wiring error protection	55 0		A-phase wiring in the external scale is defective, e.g. discontinued.	Check the A-phase wiring connection.
* B-phase wiring error protection	_	1	B-phase wiring in the external scale is defective, e.g. discontinued.	Check the B-phase wiring connection.
* Z-phase wiring error protection	_	2	Z-phase wiring in the external scale is defective, e.g. discontinued.	Check the Z-phase wiring connection.
Forced alarm input protection			Forced alarm input (E-STOP) is applied.	Check the wiring of forced alarm input (E-STOP).
* Motor automatic recognition error protection	tion		The motor and the driver has not been matched.	Replace the motor which matches to the driver.
* 99 0 Other error		0	Excessive noise or the like is detected as an abnormal signal. This type of error will occur if the alarm clear is attempted while the safety input 1/safety input 2 is not in normal state (input photocoupler is ON).	 Turn off the power once, then re-enter. If error repeats, this might be a failure. Stop using the products, and replace the motor and the driver. Return the products to the dealer or manufacturer. Adjust the condition of the safety input 1/ safety input 2 and then start the alarm clear.
Other No.		er	Control circuit has malfunctioned due to excess noise or other causes. Some error has occurred inside of the driver while triggering self-diagnosis function of the driver.	 Turn off the power once, then re-enter. If error repeats, this might be a failure. Stop using the products, and replace the motor and the driver. Return the products to the dealer or manufacturer.

Preparation

Protective function (Detail of error code)



Time characteristics of Err16.0 (Overload protection)



Use the motor so that actual torque stays in the continuous running range shown in "S-T characteristic" of the motor. For the S-T characteristics, see P.7-55 Motor characteristics (S-T characteristics).

Protective function (Detail of error code)

Setting Pr5.13 Over-speed level setup and Pr6.15 2nd over-speed level setup


In a specific condition, the motor will not stop normally when the immediate stop function is activated.

For example, as shown below, when the motor speed exceeds Pr5.13 Over-speed level setup, and immediate stop function is activated, the motor speed cannot be controlled.

As a safety measure against over-speed, Err26.1 (2nd over-speed protection) is provided. Because Err26.1 is an immediate stop unsupported alarm, it shuts off motor current and stops the motor by following sequence operation B of alarm process. In Pr6.15 2nd over-speed level setup, set the allowable over-speed level.

Set Pr5.13 to the lower value compared with that of Pr6.15 to have sufficient margin. When both settings are the same or margin is small, Err26.0 and Err26.1 may be detected at the same time. In this case Err26.0 is displayed, but because Err26.1 is also generated internally, immediate stop unsupported alarm is given priority and immediate stop is not performed.

Furthermore, if the setup value of Pr6.15 is lower than that of Pr5.13, Err26.1 is generated before Err26.0, disabling immediate stop.



Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

Protective function (Detail of error code)

Software Limit Function (Err34.0)

1) Outline

You can make an alarm stop of the motor with software limit protection (Err34.0) when the motor travels exceeding the movable range which is set up with Pr5.14 (Motor working range setup) against the position command input range.

You can prevent the work from colliding to the machine end caused by motor oscillation.

2) Applicable range

This function works under the following conditions.

	Conditions under which the software limit works
Control mode	Position control, Full-closed control
Others	 Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

3) Cautions

- This function is not a protection against the abnormal position command.
- When this software limit protection is activated, the motor decelerates and stops according to Pr5.10 (sequence at alarm).


The work (load) may collide to the machine end and be damaged depending on the load during this deceleration, hence set up the range of Pr5.14 including the deceleration movement.

• This software limit protection will be invalidated during the trial run and frequency characteristics functioning of the PANATERM.

4) Example of movement


(1) When no position command is entered (Servo-ON status),

The motor movable range will be the travel range which is set at both sides of the motor with Pr5.14 since no position command is entered. When the load enters to the Err34.0 occurrence range (oblique line range), software limit protection will be activated.




(2) When the load moves to the right (at Servo-ON),

When the position command to the right direction is entered, the motor movable range will be expanded by entered position command, and the movable range will be the position command input range + Pr5.14 setups in both sides.



(3) When the load moves to the left (at Servo-ON),

When the position command to the left direction, the motor movable range will be expanded further.



5) Condition under which the position command input range is cleared

The position command input range will be 0-cleared under the following conditions.

- when the power is turned on.
- while the position deviation is being cleared (Deviation counter clear is valid, Pr5.05 (Sequence at over-travel inhibition) is 2 and over-travel inhibition input is valid.)
- At the beginning and ending of trial run via communication.

7

2

Preparation

A5I Falling prevention function at alarm

Only available on A5II series.


Upon occurrence of immediate stop supported alarm, this function starts to keep the current flow after the brake release output (BRK-OFF) OFF until activation of external brake, preventing falling from vertical axis.

1) Related parameters

Class	No.	Title	Function
5	10	Sequence at alarm	Once an alarm occurs, sets the status during deceleration and after stop. Setup values 4-7 enable immediate stop.
6	10	Function expansion setup	Sets bits related to falling prevention function. bit10 Positional deviation of falling prevention function during alarm 0: Invalid (always) 1: Valid (clear) To enable the falling prevention function, set to 1. * The least significant bit is represented by bit0.
6	51	Immediate cessation completion wait time	When immediate stop alarm is issued, turn off brake release output (BRK-OFF) and set the time during which the current flows through the motor. When the setup value is 0, the falling prevention function is disabled. Setting resolution is 2 ms. For example: when the setup value is 11, the time required for processing is 12 ms.

2) Description

· Falling prevention operation at immediate stop supported alarm



Caution : To enable the falling prevention function at alarm, set Pr5.10 Sequence at alarm to "4" and set bit 10 of Pr6.10 Function expansion setup to "1". Set a time which is longer than the time period between brake release output (BRK-OFF) OFF and actual engagement of external brake to Pr6.51 Immediate stop complete wait time.

Protective function (Detail of error code)

Warning Function

When an error condition e.g. overloading occurs, the alarm code is issued to indicate that the corresponding protective function will be triggered if suitable corrective action is not taken. The alarm will be cleared as the cause of the error is removed. However, certain alarm will remain latched for predetermined period as shown in the table below. To forcibly clear the alarm, take the normal alarm clear procedure.

Alarm	Alarm No.	Pr6.27 *1	Content
Overload protection	A0	0	Load factor is 85 % or more the protection level.
Over-regeneration alarm	A1	0	Regenerative load factor is 85 % or more the protection level.
Battery alarm	A2	Fixed at no time limit.	Battery voltage is 3.2 V or lower.
Fan alarm	A3	0	Fan has stopped for 1 sec. *2
Encoder communication alarm	A4	0	The number of successive encoder communication errors exceeds the specified value.
Encoder overheat alarm	A5	0	The encoder detects overheat alarm.
Oscillation detection alarm	A6	0	The motor vibration exceeds oscillation detection level set in Pr6.37.
Lifetime detection alarm	A7	Fixed at no time limit.	The life expectancy of capacity or fan becomes shorter than the specified time.
External scale error alarm	A8	0	The feedback scale detects the alarm.
External scale communication alarm	A9	0	The number of successive feedback scale communication errors exceeds the specified value.

If alarm clear input (A-CLR) is kept valid, all warnings are always cleared.

*1 The "circle" means that a time in the range 1 s to 10 s or no time limit can be selected through Pr6.27 "Warning latching time". Note that the battery warning and the end of life warning have no time limit.

*2 The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal and no fan alarm is displayed.

3

5

6



2. Setup of gain pre-adjustment protection

Before starting gain adjustment, set the following parameters based on the conditions of use, to assure safe operation.

1) Setup of over-travel inhibit input

By inputting the limit sensor signal to the driver, the bumping against mechanical end can be prevented. Refer to interface specification, positive/negative direction over-travel inhibit input (POT/NOT). Set the following parameters which are related to over-travel inhibit input.

Pr5.04 Setup of over-travel inhibit input Pr5.05 Sequence at over-travel inhibit

Related page 🔅 P.3-40 (POT/NOT), P.4-47 (Pr5.04, Pr5.05)

2) Setup of torque limit

By limiting motor maximum torque, damage caused by failure or disturbance such as bite of the machine and collision will be minimized. To apply standardized limit through parameters, set Pr0.13 The 1st torque limit.

If the torque limit setup is lower than the value required during the actual application, the following two protective features will be triggered: over-speed protection when overshoot occurs, and excess positional deviation protection when response to the command delays.

By allocating the torque in-limit output (TLC) of interface specification to the output signal, torque limit condition can be detected externally.

Related page 🔅 P.3-48 (TLC), P.4-12 (Pr0.13), P.4-52 (Pr5.21)

3) Setup of over-speed protection

Generates Err26.0 Over-speed protection when the motor speed is excessively high. Default setting is the applicable motor maximum speed $[r/min] \times 1.2$.

If your application operates below the motor maximum speed, set Pr5.13 Setup of over-speed level by using the formula below.

Pr5.13 Setup of over-speed level = Vmax × (1.2 to 1.5) Vmax: motor maximum speed [r/min] in operating condition Factor in () is margin to prevent frequent activation of over-speed protection.

When running the motor at a low speed during initial adjustment stage, setup the overspeed protection by multiplying the adjusting speed by a certain margin to protect the mo-

tor against possible oscillation.

Related page P.4-50 (Pr5.13)

(Continued ...)

4) Setup of the excess positional deviation protection

During the position control or full-closed control, this function detects potential excessive difference between the positional command and motor position and issues Err24.0 Excess positional deviation protection.

Excess positional deviation level can be set to Pr0.14 Setup of positional deviation excess. The deviation can be detected through command positional deviation [pulse (command unit)] and encoder positional deviation [pulse (encoder unit)], and one of which can be selected by Pr5.20 Position setup unit select. (See the control block diagram.)

Default setting is 100000[pulse (command unit)].

Because the positional deviation during normal operation depends on the operating speed and gain setting, fill the equation below based on your operating condition and input the resulting value to Pr0.14.

• When Pr5.20 = 0 (detection through command positional deviation)

Pr0.14 Setup of positional deviation excess = $Vc/kp \times (1.2 \text{ to } 2.0)$

Vc: maximum frequency of positional command pulse [pulse (command unit)/s] Kp: position loop gain [1/s]

Factor in () is margin to prevent frequent activation of excess positional deviation protection.

Note 1) When switching position loop gain Kp, select the smallest value for calculation.

Note 2) When using the positional command filter and damping control, add the following values.

Positional command smoothing filter: Vc × filter time constant [s] Positional command FIR filter: Vc × filter time constant [s]/2 Damping control: Vc/(π × damping frequency [Hz])

• When Pr5.20 = 1 (detection through encoder positional deviation, full-closed positional deviation)

Pr0.14 Setup of positional deviation excess = $Ve/Kp \times (1.2 \text{ to } 2.0)$

Ve: maximum operation frequency [pulse/s] in encoder unit or full-closed unit Kp: position loop gain [1/s]

- Note 3) When switching position loop gain Kp, select the smallest value for calculation.
- Note 4) When Pr5.20 = 1, setups of positional command filter and damping control have no effect.

Related page ... P.4-12 (Pr0.14), P4-52 (Pr5.20)

5) Setup of motor working range

During the position control or full-closed control, this function detects the motor position which exceeds the revolutions set to Pr5.14 Motor working range setup, and issues Err34.0 Software limit protection.

Related page P.4-50 (Pr5.14)

7

Preparation

Before Using the Products

2

6

When in Trouble

6) Setup of hybrid deviation excess error protection

At the initial operation with full-closed control, operation failure may occur due to reverse connection of external scale or wrong external scale division ratio.

To indicate this type of defect, Err25.0 Hybrid deviation excess error protection is issued when the deviation of motor position (encoder unit) and load position (external scale unit) exceed Pr3.28 Setup of hybrid deviation excess.

Default setting is 16000 pulse (command unit). Because the deviation in normal operation varies with the operation speed and gain setup. Add a margin to this setting according to your operating condition.

Related page P.4-36 (Pr3.28)

3. Troubleshooting

Motor Does Not Run

When the motor does not run, refer to P.2-102, "Display of Factor of No-Motor Running" of Preparation as well.

Classification		Causes	Measures
Parameter	Setup of the control mode is not correct	Check that the present control mode is correct with monitor mode of the front panel.	 Set up Pr0.01 again. Check that the input to control mode switching (C-MODE) of the Cnnector X4 is correct, when Pr0.01 is set to 3 to 5.
	Selection of torque limit is not correct	Check that the external analog input (N-ATL/ P-ATL) is not used for the torque limit.	 Set up Pr05.21 to 0 and apply -9 [V] to N-ATL and +9 [V] to P-ATL when you use the external input. Set up Pr05.21 to 1 and set up the max. value to Pr0.13 when you use the parameter value.
	Setup of electronic gear is not correct. (Position/Full- closed)	Check that the motor moves by expected revolution against the command pulses.	 Check the setups of Pr0.09, Pr0.10 and Pr5.00 to Pr5.02 again. Connect the electronic gear switching input (DIV) of Connector X4 to COM–, or invalidate the division/ multiplication switching by setting up the same value to Pr0.09 and Pr5.00.
Wiring	Servo-ON input of Connector X4 (SRV-ON) is open.	In the front panel monitor mode, is the Pin No. corresponding to SRV- ON in " - " state?	Check and make a wiring so as to connect the SRV- ON input to COM–.
	Positive/negative direction over- travel inhibit input of Connector X4 (NOT/POT) is open.	In the front panel monitor mode, is the Pin No. corresponding to NOT/ POT in " A " state?	 Check and make a wiring so as to connect both NOT/POT inputs to COM–. Set up Pr5.04 to 1 (invalid) and reset the power.
	Command pulse input setup is incorrect. (Position/Full- closed)	Check that the input pulse counts and variation of command pulse sum does not slips, with monitor mode of the front panel.	 Check that the command pulses are entered correctly to the direction selected with Pr0.05. Check that the command pulses are entered correctly in the format selected with Pr0.07.
	Command pulse input inhibition (INH) of Connector X4 is open. (Position/ Full-closed)	In the front panel monitor mode, is the Pin No. corresponding to INH in " A " state?	 Check and make a wiring so as to connect the INH input to COM–. Set up Pr5.18 to 1 (invalid).
	Counter clear input (CL) of Connector X4 is connected to COM–. (Position/ Full-closed)	In the front panel monitor mode, is the Pin No. corresponding to CL in "A" state?	1) Check and make wiring so as to open the CL input 2) Set up Pr5.17 to 0 (invalid).

2

Preparation

5

6

When the motor does not run, refer to P.2-102, "Display of Factor of No-Motor Running" of Preparation as well.

Classification		Causes	Measures
Wiring	Speed command is invalid (Velocity)	Check that the velocity command input method (external analog command/internal velocity command) is correct.	 Check the setups of Pr3.02 to Pr3.03 again by setting up Pr3.00 to 0, when you use the external analog command. Set up Pr3.04 to Pr3.07 and Pr3.08 to Pr3.11 by setting up Pr3.00 to either one of 1, 2 or 3, when you use the internal speed command.
	Speed zero clamp input (ZEROSPD) of Connecter X4 is open. (Velocity/Torque)	In the front panel monitor mode, is the Pin No. corresponding to ZEROSPD in "A" state?	 Check and make wiring so as to connect speed zero clamp input to COM–. Set up Pr3.15.
	Torque command is invalid (Torque)	Check that the torque command input method (SPR/TRQR input, P-ATL/TRQR input) is correct.	 Check that the input voltage is applied correctly by setting up Pr3.17 to 0, when you use SPR/TRQR input. Check that the input voltage is applied correctly by setting up Pr3.17 to 1, when you use the P-ATL/ TRQR input.
	Velocity control is invalid (Torque)	Check that the velocity limit input method (parameter velocity, SPR/ TRQR/SPL input) is correct.	 Set up the desired value to Pr3.21 by setting up Pr3.17 to 0, when you use the parameter speed. Check that the input voltage is applied correctly by setting up Pr3.17 to 1, when you use the SPR/ TRQR/SPL input.
Installation	Main power is shut off.	In the front panel monitor mode, is the Pin No. corresponding to S-RDY in " - " state?	Check the wiring/voltage of main power of the driver (L1, L2 and L3).
	The motor shaft drags, the motor does not run.	 Check that you can turn the motor shaft, after turning off the power and separate it from the machine. Check that you can turn the motor shaft while applying DC24 V to the brake in case of the motor with electro- magnetic brake. 	If you cannot turn the motor shaft, consult with the dealer for repair.

3. Troubleshooting

When in Trouble

Unstable Rotation (Not Smooth), Motor Runs Slowly Even with Speed Zero at Velocity Control Mode

Classification	Causes	Measures				
Parameter	Setup of the control mode is not correct.	If you set up Pr0.01 to 1(Velocity control mode) by mistake at position control mode, the motor runs slowly at servo-ON due to speed command offset. Change the setup of Pr0.01 to 0.				
Adjustment	Gain adjustment is not proper.	Increase the setup of Pr1.01, 1st velocity loop gain. Enter torque filter of Pr1.04 and increase the setup of Pr1.01 again.				
	Velocity and position command are not stable.	Check the motor movement with connector X7 of the front panel or the waveform graphic function of the PANATERM. Review the wiring, connector contact failure and controller.				
Wiring	 Each input signal of Connector X4 is chattering. 1) Servo-ON signal 2) Positive/Negative direction torque limit input signal 	 Check the wiring and connection between Pin29 and 41 of the Connector X4 using the display function of I/O signal status. Correct the wiring and connection so that the Servo-ON signal can be turned on normally. Review the controller. Check the wiring and connection between Pin-18 and 17, 16 and 17 of the Connector X4 using tester or oscilloscope. Correct the 				
	3) Deviation counter input signal	 wiring and connection so that Positive/Negative direction torque limit input can be entered normally. 3) Check the wiring and connection between Pin-30 and 41 of the Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the deviation counter input can be turned on normally. Review the controller. 				
	4) Speed zero clamp signal	4) Check the wiring and connection between Pin-26 and 41of the Connector X4 using Display function of I/O signal status. Correct the wiring and connection so that the speed zero clamp input can be entered normally. Review the controller.				
	5) Command pulse inhibition input	5) Check the wiring and connection between Pin-33 and 41of the Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the command pulse inhibition input can be entered normally. Review the controller.				
	Noise is on the velocity command.	Use a shield cable for connecting cable to the Connector X4. Separate the power line and signal line (30 cm or longer) in the separate duct.				
	Slip of offset	Check the voltage between Pin-14 and 15 (speed command input) using a tester or an oscilloscope.				
	Noise is on the position command.	Use a shield cable for connecting cable to the Connector X4. Separate the power line and signal line (30 cm or longer) in the separate duct.				

1

5

3. Troubleshooting

When in Trouble

6

Positioning Accuracy Is Poor

Classification	Causes	Measures				
System	Position command is not correct. (Amount of command pulse)	Count the feedback pulses with a monitor function of the PANATERM or feedback pulse monitor mode of the console while repeating the movement of the same distance. If the value does not return to the same value, review the controller. Make a noise measure to command pulse.				
	Captures the positioning complete signal at the edge.	Monitor the deviation at positioning complete signal reception with the Connector X7 or the waveform graphic function of the PANATERM. Make the controller capture the signal not at the edge but with some time allowance.				
	Shape or width of the command pulse is not per the specifications.	If the shape of the command pulse is broken or narrowed, review the pulse generating circuit. Make a noise measure.				
	Noise is superposed on deviation counter clear input CL (Connector X4, Pin-30).	Make a noise measure to external DC power supply and make no wiring of the unused signal lines.				
Adjustment	Position loop gain is small.	Check the position deviation with the monitor function of the PANATERM or at the monitor mode of the console. Increase the setup of Pr1.00 within the range where no oscillation occurs.				
Parameter	Setup of the positioning complete range is large.	Lower the setup of Pr4.31 within the range where no chattering of complete signal occurs.				
	Command pulse frequency have exceeded 500kpps or 4Mpps.	Lower the command pulse frequency. Change the division/ multiplication ratio of 1st and 2nd numerator of command division/ multiplication, Pr0.09 and Pr0.10. Use a pulse line interface exclusive to line driver when pulse line interface is used.				
	Setup of the division/ multiplication is not correct.	Check if the repetition accuracy is same or not. If it does not change, use a larger capacity motor and driver.				
	Velocity loop gain is proportion action at motor in stall.	 Set up Pr1.02 and Pr1.07 of time constant of velocity loop integration to 9999 or smaller. Review the wiring and connection so that the connection between Pin-27 and 41 of the gain switching input connector, Connector X4 becomes off while you set up Pr1.14 of 2nd gain setup, to 1. 				
Wiring	Each input signal of Connector X4 is chattering.1) Servo-ON signal2) Deviation counter clear input signal	 Check the wiring and connection between Pin29 and 41 of the connector, Connector X4 using the display function of I/O signal status. Correct the wiring and connection so that the servo-On signal can be turned on normally. Review the controller. Check the wiring and connection between Pin-30 and 41 of the connector, Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the deviation counter clear input can be turned on normally. Review the controller. 				
	 Positive/Negative direction torque limit input signal 	 3 Check the wiring and connection between Pin-18 and 17, 16 and 17 of the connector, Connector X4 using tester or oscilloscope. Correct the wiring and connection so that Positive/Negative direction torque limit input can be entered normally. 				
	 Command pulse inhibition input 	4) Check the wiring and connection between Pin-33 and 41of the connector, Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the command pulse inhibition input can be entered normally. Review the controller.				
Installation	Load inertia is large.	Check the overshoot at stopping with graphic function of the PANATERM. If no improvement is obtained, increase the driver and motor capacity.				

Related page • P.4-4 "Details of parameter" • P.3-32 "Inputs and outputs on connector X4" P.7-26 "Outline of Setup support software "PANATERM"

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 6-26

3. Troubleshooting

Origin Point Slips

Classification	Causes	Measures		
System	Z-phase is not detected.	Check that the Z-phase matches to the center of proximity dog. Execute the homing matching to the controller correctly.		
	Homing creep speed is fast.	Lower the homing speed at origin proximity. Or widen the origin sensor.		
Wiring	Chattering of proximity sensor (proximity dog sensor) output .	Check the dog sensor input signal of the controller with oscilloscope. Review the wiring near to proximity dog and make a noise measure or reduce noise.		
	Noise is on the encoder line.	Reduce noise (installation of noise filter or ferrite core), shield treatment of I/F cables, use of a twisted pair or separation of power and signal lines.		
	No Z-phase signal output.	Check the Z-phase signal with oscilloscope. Check that the Pin- 13 of the connector, connector X4 is connected to the earth of the controller. Connect the earth of the controller because the open collector interface is not insulated. Replace the motor and driver. Request for repair.		
	Miswiring of Z-phase output.	Check the wiring to see only one side of the line driver is connected or not. Use a CZ output (open collector if the controller is not differential input.		

3. Troubleshooting

When in Trouble

6

Abnormal Motor Noise or Vibration

Classification	Causes	Measures				
Wiring	Noise is on the speed command.	Measure the speed command inputs of Pin-14 and 15 of the connector, Connector X4 with an oscilloscope. Reduce noise (installation of noise filter or ferrite core), shield treatment of I/F cables, use of a twisted pair, separation of power and signal lines.				
Adjustment	Gain setup is large.	Lower the gain by setting up lower values to Pr1.01 and 1.06, of velocity loop gain and Pr1.00 and Pr1.05 of position loop gain.				
Installation	Resonance of the machine and the motor.	Re-adjust Pr1.04 and 1.09. Check if the machine resonance exists or not with frequency characteristics analyzing function of the PANATERM. Set up the notch frequency to Pr2.01, Pr2.04, Pr2.07 or Pr2.10 if resonance exists.				
	Motor bearing	Check the noise and vibration near the bearing of the motor while running the motor with no load. Replace the motor to check. Request for repair.				
	Electro-magnetic sound, gear noise, rubbing noise at brake engagement, hub noise or rubbing noise of encoder.	Check the noise of the motor while running the motor with no load. Replace the motor to check. Request for repair.				

1



6

3. Troubleshooting

When in Trouble

Overshoot/Undershoot, Overheating of the Motor (Motor Burn-Out)

Classification	Causes	Measures			
Adjustment	Gain adjustment is not proper.	Check with graphic function of PANATERM or monitor (connector X7). Make a correct gain adjustment. Refer to "Adjustment".			
Installation	Load inertia is large.	Check with graphic function of PANATERM or monitor (Connector X7). Make an appropriate adjustment. Increase the motor and driver capacity and lower the inertia ratio. Use a gear reducer.			
	Looseness or slip of the machine.	Review the mounting to the machine.			
	Ambient temperature, environment.	Lower the temperature with cooling fan if the ambient temperature exceeds the predications.			
	Stall of cooling fan, dirt of fan ventilation duct.	Check the cooling fans of the driver and the machine. Replace the driver fan or request for repair. (The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal.)			
	Mismatching of the driver and the motor.	Check the name plates of the driver and the motor. Select a correct combination of them referring to the instruction manual or catalogue.			
	Failure of motor bearing.	Check that the motor does not generate rumbling noise while turning it by hand after shutting off the power. Replace the motor and request for repair if the noise is heard.			
	Electromagnetic brake is kept engaged (left un-released).	Check the voltage at brake terminals. Apply the power (DC24 V) to release the brake.			
	Motor failure (oil, water or others)	Avoid the installation place where the motor is subject to high temperature, humidity, oil, dust or iron particles.			
	Motor has been turned by external force while dynamic brake has been engaged.	Check the running pattern, working condition and operating status, and inhibit the operation under the condition of the left.			

3. Troubleshooting Motor Speed Does Not Reach to the Setup, When in Trouble

Motor Revolutions (Travel) Is Too Large or Small

Classification	Causes	Measures Check that the setup of Pr3.02, speed command input gain, is made so as to make the setup of 500 makes 3000 r/min/6 V.		
Parameter	Velocity command input gain is not correct.			
Adjustment	Position loop gain is low.	Set up Pr1.00and Pr1.05, position loop gain to approx. 1000.		
	Division/Multiplication is not proper.	Set up correct values to Pr0.09, 1st numerator of electronic gear, Pr0.11, numerator multiplier of electronic gear and Pr0.10, denominator of electronic gear. Refer to parameter setup at each mode.		

Related page ... • P.4-9... "Details of parameter" • P.7-26 "Outline of Setup support software "PANATERM"

3. Troubleshooting

When in Trouble Parameter Returns to Previous Setup

6

Classification	Causes	Measures		
Parameter	No writing to EEPROM has been carried out before turning off the power.	Refer to P.2-109, "EEPROM Writing Mode" of Preparation.		

5

Ν	/	Ε	Ν	/	Ο	

afaty function

Outline	
Input & output signals	
Safety Circuit Block Diagram	
Timing Chart	
Example of connection	7-8
2. Absolute system	
Outline	7-10
Configuration	
Battery (for Backup) Installation	
Setup (Initialization) of Absolute Encoder	
Transferring absolute data	
Transferring external scale absolute data	
Display of Battery Alarm	
3.Outline of Setup Support Software, "PANATERM"	
Setup on the PC	7-26
4. Communication	
Outline	7-27
Specifications	
List of Communication Command	
Details of Communication Command	
5. Motor Characteristics (S-T Characteristics)	
Motor	7-55
6. Dimensions	
Driver A-frame, B-frame	7-73
C-frame, D-frame (200 V)	7-74
D-frame (400 V), E-frame (200 V)	
E-frame (400 V), F-frame	
G-frame	
H-frame	
Motor	
	-
7. Options	
Noise Filter	
Surge Absorber	
Noise Filter for Signal Lines	
Junction Cable for Encoder	
Junction Cable for Encoder Junction Cable for Motor (Without brake)	7-103
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake)	7-103 7-106
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake) Junction Cable for Brake	7-103 7-106 7-108
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake) Junction Cable for Brake Connector Kit	7-103 7-106 7-108 7-109
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake) Junction Cable for Brake	7-103 7-106 7-108 7-109
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake) Junction Cable for Brake Connector Kit	7-103 7-106 7-108 7-109 7-118
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake) Junction Cable for Brake Connector Kit Battery For Absolute Encoder	7-103 7-106 7-108 7-109 7-118 7-119
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake) Junction Cable for Brake Connector Kit Battery For Absolute Encoder Mounting Bracket	7-103 7-106 7-108 7-109 7-118 7-119 7-120
Junction Cable for Encoder Junction Cable for Motor (Without brake) Junction Cable for Motor (With brake) Junction Cable for Brake Connector Kit Battery For Absolute Encoder Mounting Bracket Reactor	7-103 7-106 7-108 7-109 7-118 7-119 7-120 7-122

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

Supplement

Outline

Outline description of safe torque off (STO)

The safe torque off (STO) function is a safety function that shuts the motor current and turns off motor output torque by forcibly turning off the driving signal of the servo driver internal power transistor. For this purpose, the STO uses safety input signal and hardware (circuit).

When STO function operates, the servo driver turns off the servo ready output signal (S-RDY) and enters safety state.

This is an alarm condition and the 7-seg LED on the front panel displays the error code number.

Safety precautions

- When using the STO function, be sure to perform equipment risk assessment to ensure that the system conforms to the safety requirements.
- Even while the STO function is working, the following potential safety hazards exist. Check safety in risk assessment.
 - The motor may move when external force (e.g. gravity force on vertical axis) is exerted on it. Provide an external brake, etc., as necessary to secure the motor. Note that the purpose of motor with brake is holding and it cannot be used for braking application.
 - When parameter Pr5.10 Sequence at alarm is set to free run (disable dynamic brake), the motor is free run state and requires longer stop distance even if no external force is applied. Make sure that this does not cause any problem.
 - When power transistor, etc., becomes defective, the motor will move to the extent equivalent of 180 electrical angle (max.). Make sure that this does not cause any problem.
 - The STO turns off the current to the motor but does not turn off power to the servo driver and does not isolate it. When starting maintenance service on the servo driver, turn off the driver by using a different disconnecting device.
- External device monitor (hereafter EDM) output signal is not a safety signal. Do not use it for an application other than failure monitoring.
- Dynamic brake and external brake release signal output are not related to safety function. When designing the system, make sure that the failure of external brake release during STO condition does not result in danger condition.
- When using STO function, connect equipment conforming to the safety standards.

Note ···· Related page ····

• Only for position control type is not provided with X3 (Safety function connector).

P.2-2 "Conformance to international standards"
 P.2-98 "How to Use the Front Panel"
 P.3-32 "Inputs and outputs on connector X4"

Supplement

Input & output signals

Safety input signal

Signal	Symbol	Pin No.	Contents	Control mode
Safety input 1	SF1+	4	 Input 1 that triggers STO function. This input turns off the upper arm drive signal of power transistor. When using the function, connect this pin in a way 	Compatible
	SF1-	3	so that the photocoupler of this input circuit turns off to activate STO function.	
Safety	SF2+	6	Input 2 that triggers STO function. This input turns off the lower arm drive signal of power transistor.	all control mode
input 2	SF2-	5	• When using the function, connect this pin in a way so that the photocoupler of this input circuit turns off to activate STO function.	

For list of connector pin numbers, refer to P.2-53,

<Response time>

Safety input 1 or 2 enables STO to operate: within 5 ms of response time, the motor output torque will be turned off.


Caution 🔅 · Safety equipment self-diagnosis L pulse

Safety output signal from the safety controller and safety sensor may include L pulse for self-diagnosis.

To prevent the L pulse from mis-triggering STO function, the safety input circuit has built-in filter that removes the self-diagnosis L pulse.

Therefore, if the off period of safety input signal less than 1 ms, the safety input circuit does not detect this "off" event.

To validate this "off" period, turn off the input signal for more than 5 ms.



Note

Input & output signals

External device monitor (EDM) output signal

The monitor output signal is used by the external device to monitor the state of the safety input signal. Connect the monitor output to the external device monitor terminal of the safety devices such as safety controller and safety sensor.

Signal	Symbol	Pin No.	Contents	Control mode
EDM	EDM+	8	Outputs monitor signal that is used to check the safety function.	Compatible all control
output	EDM-	7	Caution This output signal is not a safety output.	mode

Logical relationship between safety input signal and EDM output signal

When both safety input 1 and 2 are off, i.e. when STO function of 2 safety input channels are active, the photocoupler in EDM output circuit turns on.


Signal	Symbol	photocoupler logic			
Safety input	SF1	ON	ON	OFF	OFF
	SF2	ON	OFF	ON	OFF
EDM output	EDM	OFF	OFF	OFF	ON

By monitoring the logics (all 4 states) of photocoupler shown in the table above, the external device can determine the status (normal or abnormal) of safety input circuit and EDM output circuit.

Note

Maximum delay time from input of safety 1 and 2 signals to output of EDM signal is 6 ms.

Note 🐳 • Only for position control type is not provided with X3 (Safety function connector).



Adjustment


Note

• Only for position control type is not provided with X3 (Safety function connector).

1. Safety function

Timing Chart

Operating timing for safety status




- *1 t1 is the value set to Pr4.38 Setup of mechanical brake action at running or the time at which the motor revolution speed drops below the time set to Pr4.39 Brake release speed setup, whichever comes first.
- *2 Dynamic brake operates to the setting of Pr5.10 Sequence at alarm.
- *3 When safety input 1 or 2 turns off, the state changes to STO condition.

 Note
 • Only for position control type is not provided with X3 (Safety function connector).

 Related page ↔
 • P.4-45, 4-46 "Pr4.38, Pr4.39"
 • P.4-49 "Pr5.10"

Return timing from safety state



*1 photocouplers for safety input 1 and 2 should be turned on again with servo-on input turned off. Otherwise, alarm occurs, and should be cleared.

Alarm clear should be performed after the safety input 1 and 2 have been turned back to on.

Otherwise, alarm occurs.


- *2 This is an alarm condition and the dynamic brake operates according to Pr5.10 Sequence at alarm.
- *3 This is normal servo-off condition and the dynamic brake operates according to Pr5.06 Sequence at servo-off.
- *4 The timing chart above shows an example setting of the dynamic brake (DB) which is engaged at alarm, and allowed for free running during servo off (DB.OFF). Release/ engagement of the dynamic brake in various conditions follow Pr5.06 Sequence at servo off and Pr5.10 Sequence at alarm.

3


1. Safety function

Example of connection


Example of connection to safety switch



Example of connection to safety sensor



Example of connection to safety controller




Note

Only for position control type is not provided with X3 (Safety function connector).

Example of connection

Example of connection when using multiple axes



- Capacity requirement per safety output (source) channel: $50 \times No.$ of connected axes (mA)
- 24 VDC supply allowable voltage: 24 V±15 %
- Maximum No. of connectable axes: 8
- * The number of connectable axes shown in the figure is for reference only.
 EDM output depends on external circuit because saturated voltage Vce (sat) of approx.
 1.0 V in the built-in photocoupler varies with collector current.

Amount of current flowing to SF input is 5 mA per circuit.

When increasing the number of axes to be connected, make sure that required amount of current does not exceed the maximum output current of the safety controller.

Note 🔅 • Only for position control type is not provided with X3 (Safety function connector).

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

∆djustment

6

When in Trouble

Supplement

Outline

Outline of Absolute System

When you compose an absolute system using an absolute encoder, you are not required to carry out homing operation at the power-on, and this function suits very well to such an application as a robot.

Connect the host controller with the MINAS-A5 with absolute specifications. (motor with absolute encoder and driver with absolute spec) and set up the parameter, Pr0.15 to 0 or 2, then connect the battery for absolute encoder to compose an absolute system with which you can capture the exact present position information after the power-ON.

Shift the system to origin once after installing the battery and clear the multi-turn data by clearing the absolute encoder, then you can detect the absolute position without carrying out homing operation.

Via RS232 or RS485 communication, the host controller can connect up to 32 MINAS-A5 and capture the present position information as serial data to obtain the absolute position of each axis by processing. each data.

Applicable Mode

You can use all of MINAS A5 series driver in absolute specifications by setting up parameter. Use the motor which 8th place (designated for rotary encoder specifications) is "S" (7-wire type).

M * M * * * S * * * * ^{8th place} Rotary encoder specifications


Absolute Specifications

There are 3 connecting methods of the host controller and MINAS-A5 driver as described below, and select a method depending on the interface of the host controller specs or number of axis to be connected. Designate a module ID to Pr5.31 of each MINAS-A5 driver when you connect multiple MINAS-A5 in communication to one host controller as shown below.

[Parameter Pr5.31]

- When you connect each MINAS-A5 to the host separately with RS232 and switch the communication individually, designate 0 to 31 to each MINAS-A5.
- When you connect one MINAS-A5 to the host with RS232 and connect each MINAS-A5 with RS485, designate 0 to the MINAS-A5 connected with the host, and designate 1 to 31 to other MINAS-A5. (Max 32 axis are connectable.)
- When you connect MINAS-A5 to the host with RS485, the host is given module ID of 0, and designate 1 to 31 to MINAS-A5. (Max 31 axis are connectable.)

 • Only for position control type is not provided with X2 (Communication connector).
 • Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.



7-11

2. Absolute system

Battery (for Backup) Installation

First Installation of the Battery

After installing and connecting the back-up battery to the motor, execute an absolute encoder setup. Refer to P.7-16, "Setup (initialization) of Absolute Encoder ".

It is recommended to perform ON/OFF action once a day after installing the battery for refreshing the battery.

A battery error might occur due to voltage delay of the battery if you fail to carry out the battery refreshment.

Caution :: Use the following battery for absolute encoder. BatteryPart No. : DV0P2990 (3.6 V 2000 mAh) Battery boxPart No. : DV0P4430

Replacement of the Battery

It is necessary to replace the battery for absolute encoder when battery alarm occurs. **Replace while turning on the control power. Data stored in the encoder might be lost when you replace the battery while the control power of the driver is off.** After replacing the battery, clear the battery alarm. Refer to P.7-25, "How to Clear the Battery Alarm".

Caution When you execute the absolute encoder with the front panel (refer to P.2-115 of Preparation), or via communication (refer to P.7-54), all of error and multi-turn data will be cleared together with alarm, and you are required to execute "Setup (Initialization) of absolute encoder" (refer to P.7-16).

How to Replace the Battery

min after.


Refresh the new battery. Connector with lead wire of the battery to CN601 and leave of 5 min. Pull out the connector from CN601 5

CN601

connection

Pull out after 5 min.

2) Take off the cover of the battery box.




 • Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.
 • P.7-118 "Battery For Absolute Encoder"

3) Install the battery to the battery box.

4) Close the cover of the battery box.

come corroded, and/or the battery itself may rupture.

1) Insert the battery with its "+" and "-" electrodes oriented correctly.



Close the cover not to pinch the connector cable.

Be absolutely sure to follow the precautions below since improper use of the battery can

cause electrolyte to leak from the battery, giving rise to trouble where the product may be-

Connect the connector.





Before Using the Products

2

Preparation

3

6

Supplement

2) Leaving a battery which has been used for a long period of time or a battery which is no longer usable sitting inside the product can cause electrolyte leakage and other trouble. For this reason, ensure that such a battery is replaced at an early date. (As a general guideline, it is recommended that the battery be replaced every two years.) The electrolyte inside the battery is highly corrosive, and if it should leak out, it will not only corrode the surrounding parts but also give rise to the danger of short-circuiting since it is electrically conductive. For this reason, ensure that the battery is replaced periodically. 3) Do not disassemble the battery or throw it into a fire. Do not disassemble the battery since fragments of the interior parts may fly into your eyes, which is extremely dangerous. It is also dangerous to throw a battery into a fire or apply heat to it as doing to may cause it to rupture. tube be peeled off. leading to the rupture of the battery. recharge it. restrictions imposed by local governing authorities. In such cases, ensure

4) Do not cause the battery to be short-circuited. Under no circumstances must the battery

- It is dangerous for metal items to make contact with the "+" and "-" electrodes of the battery since such objects may cause a high current to flow all at once, which will not only reduce the battery performance but also generate considerable heat, possibly
- 5) This battery is not rechargeable. Under no circumstances must any attempt be made to

Caution 🔅

Caution 🔅

The disposal of used batteries after they have been replaced may be subject to that their disposal is in accordance with these restrictions.

7-13 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Battery (for Backup) Installation

Life of the battery

Following example shows the life calculation of the back-up battery used in assumed robot operation.


2000[mAh] of battery capacity is used for calculation.

Note that the following value is not a guaranteed value, but only represents a calculated value.

Caution 🔅

The values below were calculated with only the current consumption factored in. The calculations do not factor in electrolyte leakage and other forms of battery deterioration. Life time may be shortened depending on ambient condition.

1) 2 cycles/day



- a : Current consumption in normal mode 3.6 [µA]
- b : Current consumption at power failure timer mode 180 [μ A]
 - * Power failure timer mode...Action mode in time period when the motor can respond to max. speed even the power is off (5 sec).
- c : Current consumption at power failure mode 60 [µA]

Annual consumption capacity =

(10 h × a + 0.0014 h × b + 2 h × c) × 2 × 313 days + 24 h × c × 52 days = 172.7 [mAh]) Battery life = 2000 [mAh]/172.7 [mAh/year] = 11.6 (11.581) [year]

2) 1 cycle/day

(2nd cycle of the above 1) is for rest.

Annual consumption capacity = $(10 \text{ h} \times \text{a} + 0.0014 \text{ h} \times \text{b} + 14 \text{ h} \times \text{c}) \times 313 \text{ days} + 24 \text{ h} \times \text{c} \times 52 \text{ days} =$ 349.1 [mAh]) Battery life = 2000 [mAh]/349.1 [mAh/year] = 5.7 (5.728) [year] Battery (for Backup) Installation

3

Connection

4

When you make your own cable for 17-bit absolute encoder

When you make your own cable for 17-bit absolute encoder, connect the optional battery for absolute encoder, DV0P2990 as per the wiring diagram below. Connector of the battery for absolute encoder shall be provided by customer as well.

Caution 🔅

Install and fix the battery securely. If the installation and fixing of the battery is not appropriate, it may cause the wire breakdown or damage of the battery. Refer to the instruction manual of the battery for handling the battery.

Installation Place

- 1) Indoors, where the products are not subjected to rain or direct sun beam.
- 2) Where the products are not subjected to corrosive atmospheres such as hydrogen sulfide, sulfurous acid, chlorine, ammonia, chloric gas, sulfuric gas, acid, alkaline and salt and so on, and are free from splash of inflammable gas, grinding oil, oil mist, iron powder or chips and etc.
- 3) Well-ventilated and humid and dust-free place.
- 4) Vibration-free place

Wiring Diagram

	E5V	E0V	BAT+	BAT-	PS	PS	FG	
Small motor MSME 50 W to 750 W	6	3	5	2	7	4	1	
Small motor MSMD 50 W to 750 W MHMD 200 W to 750 W	7	8	1	2	4	5	3	
Large motor (IP67)	4	1	6	5	3	7	9	
Large motor (IP65)	Н	G	Т	S	K	L	J	
Junction connector for encoder cable (Optional connector kit) E5V E0V BAT+ BAT- PS FG	2 B/	DV AT+ E AT- E	tery box 0P4430 BAT+ 3AT- 2 connector by J.S.T.)	Batte	ute enco ry*1]		(Optic 1 2 5 6	FG (Case)
Title Part No.	-	ufacture	er				e encode	er (Option):
Connector ZMR-2		J.S.T.		_	0V0P299	-		
Connector pin SMM-003T-P0.5		J.S.T.						eters of the batt
Clamping Jig YRS-800		J.S.T.		C	connecto	r and con	nector at	encoder side a

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page P.7-118 "Battery For Absolute Encoder"

Note

7

Supplement

Supplement

2. Absolute system

Setup (Initialization) of Absolute Encoder

Absolute multi-turn data will be maintained by the absolute encoder battery. When operating the machine for the first time after installing the battery to the absolute encoder, clear the encoder data (multi-turn data) to 0 at the origin by following the procedure described below.

Clear the absolute encoder from the front panel (see P.2-115) or PANATERM. Turn off power and then on again.

7 Supplement

2. Absolute system

Transferring absolute data

Transfer the absolute data (absolute data of external scale) from the servo driver to the host controller: turn on power and wait until the servo ready output (S-RDY) is turned on, and then start transfer.

Setup of serial communication interface on host controller

• RS232

Baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200 bps
Data	8 bit
Parity	none
Start bit	1 bit
Stop bit	1 bit

The baud rate is set according to Pr5.29 Baud rate setup of RS232 communication.

• RS485

Baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200 bps
Data	8 bit
Parity	none
Start bit	1 bit
Stop bit	1 bit

The baud rate is set according to Pr5.30 Baud rate setup of RS485 communication.

Note


Only for position control type is not provided with X2 (Communication connector).

 Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page :: P.3-32 "Inputs and outputs on connector X4" • P.4-54 "Details of parameter"

RS232 Communication Protocol

Refer to the instruction manual of the host for the transmission/reception method of command.



Data of *1 and *2 are determined by th	e setup
of Pr5.31 "Axis address".	

Axis address (example)	Data of *1	Data of *2
0	00h	2Eh
1	01h	2Dh
2	02h	2Ch
3	03h	2Bh
4	04h	2Ah
5	05h	29h
6	06h	28h
7	07h	27h
8	08h	26h
9	09h	25h
10	0Ah	24h
11	0Bh	23h
12	0Ch	22h
13	0Dh	21h
14	0Eh	20h
15	0Fh	1Fh
16	10h	1Eh
17	11h	1Dh
18	12h	1Ch
19	13h	1Bh
20	14h	1Ah
21	15h	19h
22	16h	18h
23	17h	17h
24	18h	16h
25	19h	15h
26	1Ah	14h
27	1Bh	13h
28	1Ch	12h
29	1Dh	11h
30	1Eh	10h
31	1Fh	0Fh

Check sum becomes OK'ed when the lower 8-bit of the sum of the received absolute data (15 characters) is 0.

Enter the Pr5.31 value of the driver to which you want to communicate from the host to axis (*1 data) of the command block, and transmit the command according to the RS232 communication protocol. For details of communication, refer to P.7-27, "Communication".


Caution 🔅

- Allow 50 ms or longer interval for axis switching when you want to capture multiple axes data.
 - It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

• Only for position control type is not provided with X2 (Communication connector).
• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification. 6

RS485 Communication Protocol

Refer to the instruction manual of the host for the transmission/reception method of command. Following shows the communication example of the driver to Pr5.31 "Axis address = 1".



Axis address (example)	Data of *1	Data of *2	Data of *3			
0	not usable v	not usable with RS485 communication				
1	81h	01h	2Dh			
2	82h	02h	2Ch			
3	83h	03h	2Bh			
4	84h	04h	2Ah			
5	85h	05h	29h			
6	86h	06h	28h			
7	87h	07h	27h			
8	88h	08h	26h			
9	89h	09h	25h			
10	8Ah	0Ah	24h			
11	8Bh	0Bh	23h			
12	8Ch	0Ch	22h			
13	8Dh	0Dh	21h			
14	8Eh	0Eh	20h			
15	8Fh	0Fh	1Fh			
16	90h	10h	1Eh			
17	91h	11h	1Dh			
18	92h	12h	1Ch			
19	93h	13h	1Bh			
20	94h	14h	1Ah			
21	95h	15h	19h			
22	96h	16h	18h			
23	97h	17h	17h			
24	98h	18h	16h			
25	99h	19h	15h			
26	9Ah	1Ah	14h			
27	9Bh	1Bh	13h			
28	9Ch	1Ch	12h			
29	9Dh	1Dh	11h			
30	9Eh	1Eh	10h			
31	9Fh	1Fh	0Fh			

Data of *1, *2 and *3 are determined by the setup of Pr5.31 "Axis address".

Check sum becomes OK'ed when the lower 8-bit of the sum of the received absolute data (15 characters) is 0.

Command from the host will be transmitted to the desired driver based on RS485 transmission protocol. For details of communication, refer to P.7-27, "Communication".

Caution 🔅


- Allow 50 ms or longer interval for axis switching when you want to capture multiple axes data.
- It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

• Only for position control type is not provided with X2 (Communication connector).
• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.


⁷⁻¹⁸ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Composition of Absolute Data

Absolute data consists of singe-turn data which shows the absolute position per one revolution and multi-turn data which counts the number of revolution of the motor after clearing the encoder.



Single-turn data and multi-turn data are composed by using 15-character data (hexadecimal binary code) which are received via RS232 or RS485.



date after deducting 65536.

Remarks 🔅

Note

Only for position control type is not provided with X2 (Communication connector).
Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification. 7

2

Preparation

3

Connection

4

5

Adjustment

	Encoder status (L)						
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
			0				
(1)	 (2)	 (3)		(4)	 (5)	(6)	 (7)
(1)	(2)	(3)		(4)	(5)	(6)	(

• Encoder status (L)-----1 represents error occurrence.

(1) Over-speed	→ Err42.0 (Absolute over-speed error protection)
(2) Full absolute status	s → Err47.0 (Absolute status error protection)
(3) Counter error	→ Err44.0 (Absolute single-turn counter error protection)
(4) Counter overflow	— Err41.0 (Absolute counter over error protection)
(5) Multi-turn error	→ Err45.0 (Absolute multi-turn counter error protection)
(6) Battery error	Err40.0 (Absolute system down error protection)
(7) Battery alarm	→ Alarm No.A2 "Battery alarm"

• Encoder status (L)-----1 represents error occurrence.

	Encoder status (H)						
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
0	0			0	0	0	0

- Battery error

One of the following has occurred. Battery alarm, multi-turn error, counter overflow, counter error, full absolute status, Counter overflow multi-turn error, battery error or battery alarm

Remarks 🔅 For detail of the Encoder status, refer to the Encoder specification.

Remarks 🔅 • Transmit the absolute data while fixing the motor with brake by turning to Servo-Off.

 • Only for position control type is not provided with X2 (Communication connector).
 • Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.
 • P.6-4 "Protective Function" • P.7-25 "Display of Battery Alarm"

⁷⁻²⁰ Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com


Supplement

2. Absolute system

Transferring external scale absolute data

External scale RS232 communication procedure

Refer to the instruction manual of the host for the transmission/reception method of command. Following shows the communication example of the driver to Pr5.31 "Axis address



Data of *1 and *2 are determined by the setup
of Pr5.31 "Axis address".

Axis address (example)	Data of *1	Data of *2
0	00h	3Eh
1	01h	3Dh
2	02h	3Ch
3	03h	3Bh
4	04h	3Ah
5	05h	39h
6	06h	38h
7	07h	37h
8	08h	36h
9	09h	35h
10	0Ah	34h
11	0Bh	33h
12	0Ch	32h
13	0Dh	31h
14	0Eh	30h
15	0Fh	2Fh
16	10h	2Eh
17	11h	2Dh
18	12h	2Ch
19	13h	2Bh
20	14h	2Ah
21	15h	29h
22	16h	28h
23	17h	27h
24	18h	26h
25	19h	25h
26	1Ah	24h
27	1Bh	23h
28	1Ch	22h
29	1Dh	21h
30	1Eh	20h
31	1Fh	1Fh

Check sum becomes OK'ed when the lower 8-bit of the sum of the received absolute data (15 characters) is 0.

Enter the Pr5.31 value of the driver to which you want to communicate from the host to axis (*1 data) of the command block, and transmit the command according to the RS232 communication protocol. For details of communication, refer to P.7-27, "Communication".

Caution 🔅

- Allow 50 ms or longer interval for axis switching when you want to capture multiple axes data.
 - It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

Note	
------	--

Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).


6

[•] Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Transferring external scale absolute data

External scale RS485 communication procedure

Refer to the instruction manual of the host for the transmission/reception method of command. Following shows the communication example of the driver to Pr5.31 "Axis address = 1".



Command from the host will be transmitted to the desired driver based on RS485 transmission protocol. For details of communication, refer to P.7-27, "Communication".

Caution 🔅

 Allow 50 ms or longer interval for axis switching when you want to capture multiple axes data.


 It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

 Note
 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
 Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

⁷⁻²² Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Transferring external scale absolute data

Composition of external scale absolute data



Using 15-character data received through RS232/RS485, organize 1-turn data and multiturn data.

External scale absolute data

- ← Absolute data (6)×1000000000h
 - +Absolute data (5)×10000000h
 - +Absolute data (4)×1000000h
 - +Absolute data (3)×10000h
 - +Absolute data (2)×100h
 - +Absolute data (1)

Absolute data of external scale is represented as 48 bit number (negative value is represented as two's complement).

Remarks 🔅 If the multi-turn data of the above fig. is between 32768 to 65535, convert it to signed date after deducting 65536.

 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Preparation

5

6

	External scale status (L)						
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
			0				
I				I			I
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)

• External scale status (L)-----1 represents error occurrence.

(1) Alarm No. A8 "External scale error alarm"

(2) Alarm No. A8 "External scale error alarm"

(3) Err51.5 "External scale status 5 error protection"

(4) Err51.4 "External scale status 4 error protection"

(5) Err51.3 "External scale status 3 error protection"

(6) Err51.2 "External scale status 2 error protection"

(7) Err51.1 "External scale status 1 error protection"

(8) Err51.0 "External scale status 0 error protection"

• External scale status (H)-----1 represents error occurrence.

External scale status (H)							
bit7 bit6 bit5 bit4 bit3 bit2 bit1 bit0							
0	0			0	0	0	0

Logical sum of bit6 and bit 7 of external scale status (L)

- Logical sum of bit0 to bit 5 of external scale status (L)

Remarks 🔅 For detail of the external scale status, refer to the external scale specification.

Remarks : • Transmit the External scale absolute data while fixing the motor with brake by turning to Servo-Off.


 Note
 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
 Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.
 Related page ···
 P.6-4 "Protective Function" • Next page "Display of Battery Alarm"

Supplement

2. Absolute system

Display of Battery Alarm

Following alarm will be displayed when making the front panel to alarm execution mode of monitor mode.



Kinds of alarm

alarm No.	Alarm	Content	Latched time *1
A0	Overload protection	Load factor is 85 % or more the protection level.	1 s to 10 s or ∞
A1	Over-regeneration alarm	Regenerative load factor is 85% or more the protection level.	10 s or ∞
A2	Battery alarm	Battery voltage is 3.2 V or lower.	Fixed at ∞
A3	Fan alarm	Fan has stopped for 1 sec.	1 s to 10 s or ∞
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.	1 s to 10 s or ∞
A5	Encoder overheat alarm	The encoder detects overheat alarm.	1 s to 10 s or ∞
A6	Oscillation detection alarm	Oscillation or vibration is detected.	1 s to 10 s or ∞
A7	Lifetime detection alarm	The life expectancy of capacity or fan becomes shorter than the specified time.	Fixed at ∞
A8	External scale error alarm The external scale detects the alarm.		1 s to 10 s or ∞
A9	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.	1 s to 10 s or ∞

*1 Alarms can be cleared by using the alarm clear. Because the all existing alarms are kept cleared while the alarm clear input (A-CLR) is kept ON, be sure to turn it OFF during normal operation. Either 1 s-10 s or∞ can be selected by using user parameter.

Exception: Battery alarm is fixed at ∞ because it is latched by the encoder.

Because the end of life alarm means that the life expectancy cannot be extended, the alarm is set at ∞.

How to Clear the Battery Alarm

Replace the battery for absolute encoder when battery alarm occurs according to P.7-12, "How to Replace the Battery". After replacement, clear the battery alarm in the following 3 methods.

- (a) "Connector X4" Connecting Alarm clear input (A-CLR) to COM– for more than 120 ms.
- (b) Executing the alarm clear function in auxiliary function mode by using the front panel.
- (c) Click the "Battery warning" Clear button, after select the "Absolute encoder" tab in the monitor display window by using the PANATERM (option).

 Note
 • Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

 Related page ····
 • P.2-111 "Alarm Clear Screen"
 • P.3-32 "Inputs and outputs on connector X4"

 • P.7-26 "Outline of Setup Support Software, "PANATERM""

 2

6

Supplement

3. Outline of Setup Support Software, "PANATERM"

Setup on the PC

Connector X1 of MINAS A5 can be connected to your PC through USB cable for computer. Once you download the setup support software PANATERM from our web site and install it to your PC, the following tasks can be easily performed.


Outline of PANATERM

With the PANATERM, you can execute the followings.

- (1) Setup and storage of parameters, and writing to the memory (EEPROM).
- (2) Monitoring of I/O and pulse input and load factor.
- (3) Display of the present alarm and reference of the error history.
- (4) Data measurement of the wave-form graphic and bringing of the stored data.
- (5) Normal auto-gain tuning
- (6) Frequency characteristic measurement of the machine system.

Note \Rightarrow Distribution media such as CD-ROM for this software are not prepared. Download the software from our web site and install it to your PC.

How to Connect



Connect to connector X1. (USB mini-B)



Download setup support software PANATERM from our web site and install it to your PC.

• USB cable

The connection cable should be provided with USB mini-B connector at the driver side and the PC compatible connector on the other end.

If the cable has no noise filter, install a signal noise filter (DV0P1460) to both ends of the cable.

System required for PANATERM

To use PANATERM, the following system components are required.

۰PC

۰D

PC O		Windows [®] XP SP3 (32-bit Ver.)
	os	Windows [®] VISTA SP1 (32-bit Ver.)
	03	Windows [®] 7 (32-bit Ver., 64-bit Ver.)
		(Japanese, English, Chinese or Korean version)
	CPU	Pentium III 512 MHz or better
	Memory	256 MB or more (512 MB recommended)
	Hard disk	512 MB or more free space
	Serial communication	USB port
Display	Resolution	1024 × 768 pixel or more
	No. of colors	24-bit color (True Color) or better

* Please confirm the latest system requirements on the homepage.

Supplement

Outline

You can connect up to 32 MINAS-A5 series with your computer or NC via serial communication based on RS232 and RS484, and can execute the following functions. Before Using the Products

2

Preparation

3

Connection

4

Setup

5

∆djustment

6

When in Trouble

Supplement

- (1) Change over of the parameters
- (2) Referring and clearing of alarm data status and history
- (3) Monitoring of control conditions such as status and I/O.
- (4) Referring of the absolute data
- (5) Saving and loading of the parameter data

• Merits

- You can write parameters from the host to the driver in batch when you start up the machine.
- · You can display the running condition of machine to improve serviceability.
- You can compose multi-axis absolute system with simple wiring.

Note	 Only for position control type is not provided with X2 (Communication connector) and X5 (Con- nector for External Scale).
	 Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.
Related page 🔅	 P.2-51 "Wiring to the Connector, X1" P.7-10 "Absolute system" P.7-26 "Outline of Setup Support Software, "PANATERM""

Supplement


Specifications

Connection of Communication Line

MINAS-A5 series provide 2 types of communications ports of RS232 and RS485, and support the following 3 types of connection with the host.

RS232 communication


Connect the host and the driver in one to one with RS232, and communicate according to RS232 transmission protocol.



• Set up the module ID of MINAS-A5. In the above case, you can set any value of 0 to 31. You can set the same module ID as long as the host has no difficulty in control.

RS232 and RS485 communication

When you connect one host to multiple MINAS-A5s, connect the host to connector X2 of one driver with RS232 communication, and connect each MINAS-A5 with RS485 communication. Set up the Pr5.31 of the driver to 0 which is connected to the host, and set up 1 to 31 to other drivers each.




 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

RS485 communication

Connect the host to multiple MINAS-A5s with RS485 communication, set up the Pr5.31 of each front panel of MINAS-A5 to 1 to 31.



Allow 50 ms or longer interval for switching the axes while capturing data of multiple axes.

· Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

Setup

5

Adjustment


Before Using the Products


[•] Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Specifications

Interface of Communication Connector







Communication Method

	RS232	RS485
	Full duplex, asynchronous	Half duplex, asynchronous
Communication baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200 bps	2400, 4800, 9600, 19200, 38400, 57600, 115200 bps
Data	8 bit	8 bit
Parity	none	none
Start bit	1 bit	1 bit
Stop bit	1 bit	1 bit

 Set up the RS232 communication baud rate with Pr5.29, and RS485 communication baud rate with Pr5.30. The change of these parameters will be validated after the control power entry. For details, refer to the following list of parameters related to communication.

Note

 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

[·] Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

List of User Parameters for Communication

Class	No.	Title	Setup value	Function
5	31	Axis address	0 to 127	Set the axis number for serial communication to 0 to 31. This parameter setup value has no effect on servo operation.
5	29	Baud rate setup of RS232 communication	0 to 6	Set up the communication speed of RS232 communication. 0 : 2400[bpps], 1 : 4800[bps], 2 : 9600[bps], 3 : 19200[bps], 4 : 38400[bps], 5 : 57600[bps], 6 : 115200[bps] Updated setup of is validated upon turning on of control power.
5	30	Baud rate setup of RS485 communication	0 to 6	Set up the communication speed of RS485 communication. 0 : 2400[bpps], 1 : 4800[bps], 2 : 9600[bps], 3 : 19200[bps], 4 : 38400[bps], 5 : 57600[bps], 6 : 115200[bps] Updated setup of is validated upon turning on of control power.

• Required time for data transmission per 1 byte is calculated in the following formula in case of 9600[bps].

1000 / 9600 × (1 + 8 + 1) = 1.04 [ms/byte] Start bit _____ | _ ____ Stop bit Data

Note that the time for processing the received command and time for switching the line and transmission/reception control will added to the actual communication time.

Handshake code

Following codes are used for line control.

Title	Code	Function
ENQ	05h (Module recognition byte of the transmitted)	Enquire for transmission
EOT	04h (Module recognition byte of the transmitted)	Ready for receiving
ACK	06h	Acknowledgement
NAK	15h	Negative acknowledgement

ENQ..... The module (host or driver) sends out ENQ when it has a block to send.

- EOT The module (host or driver) sends out EOT when it is ready to receive a block. The line enters to a transmission mode when ENQ is transmitted and EOT is received.
- ACK When the received block is judged normal, the module (host or driver) will send out ACK.
- NAK When the received block is judged abnormal, NAK will be sent. A judgment is based on checksum and timeout.

Caution 🔅

1 byte of module recognition is added to ENQ and EOT at RS485 communication. Module recognition byte... Make the Pr5.31 value of the front panel as a module ID, and data which makes its bit7 as 1, becomes a module recognition byte.

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
1	0	0	0	Module ID			

Module ID : The module ID of the host side will be 0 in case of RS485 communication, therefore set up Pr5.31 of MINAS-A5 to 1 to 31.

Note

Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.


6

Specifications


Transmission Sequence

Transmission protocol

In case of RS232



In case of RS485



Line control

Decides the direction of transmission and solves the contention.

Reception mode... From when the module (host or driver) returns EOT after receiving ENQ. Transmission mode... From when the module (host or driver) receives EOT after transmitting ENQ.

At contention of transmission and reception... Slave side will enter to reception mode when it receives ENQ while waiting for EOT after transmitting ENQ, by giving priority to ENQ (of master side).

Transmission control

On entering to transmission mode, the module transmits the command block continuously and then waits for ACK reception. Transmission completes at reception of ACK. ACK may not be returned at transmission failure of command byte counts. If no ACK is received within T2 period, or other code than NAK or ACK is received, sequence will be retried. Retry will start from ENQ.

Reception control

On entering to reception mode, the module receives the transmitted block continuously. It will receive the command byte counts from the first byte, and continuously receive extra 3 bytes. It will return ACK when the received data sum becomes 0, by taking this status as normal. In case of a check sum error or a timeout between characters, it will return NAK.


Note

Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

[•] Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Data Block Composition

Below shows the composition of data block which is transmitted in physical phase.



N : Command byte counts (0 to 240)

Shows the number of parameters which are required by command.

- : Sets up the value of Pr5.31.(0 to 127)
- command : Control command (0 to 15)
- mode : Command execution mode (0 to 15) Contents vary depending on the mode.
- check sum : 2's complement of the total number of bytes, ranging from the top to the end of the block

Protocol Parameter

axis

Following parameters are used to control the block transmission. You can set any value with the INIT command (described later).

Title	Function		Initial value	Setup range	Unit	
T1	Time out between characters	RS232	5 (0.5 sec)	1 to 255	0.1 sec	
	Time out between characters	RS485	1 (0.1 sec)	1 10 255	0.1 Sec	
T2	Protocol time out	RS232	5 (0.5 sec)	1 to 055	1 sec	
		RS485	1 (0.1 sec)	1 to 255		
T6	Driver response time	RS232	0 (0 ms)	0 to 255	1 ms	
10	Driver response time	RS485	6 (6 ms)	2 to 255	1 1115	
RTY	Retry limit		1 (once)	1–8	Once	
M/S	Master/Slave	0 (Slave)	0, 1 (Master)			

- T1: Permissible time interval for this driver to receive the consecutive character cods which exists between the module recognition bytes and ENQ/EOT, or in the transmission/reception data block. Time out error occurs and the driver returns NAK to the transmitter when the actual reception time has exceed ed this setup time.
- T2: Permissible time interval for the driver to transmit ENQ and to receive EOT. If the actual reception time exceeds this setup, this represents that the receiver is not ready to receive, or it has failed to receive ENQ code in some reason, and the driver will re-transmit ENQ code to the receiver. (retry times)
 - Permissible time interval for the driver to transmit EOT and to receive the reception of the 1st character code. The driver will return NAK and finishes the reception mode if the actual reception has exceeded this setup time.
 - Permissible time interval for the module to transmit the check sum bytes and to receive ACK. The module will re-transmit ENQ code to the receiver in the same way as the NAK reception, if the actual reception time exceeds this setup time.
- T6: Permissible time interval for the driver to receive ENQ and to transmit EOT; Permissible time interval for the driver to receive the check sum bytes and to transmit ACK; and Permissible time interval for the driver to receive EOT and to transmit the 1st character.
- RTY: Maximum value of retry times. Transmission error occurs if the actual retry has exceeds this setup value.
- M/S: Switching of master and slave. When contention of ENQ has occurred, the module decides which is to be given priority.

Only for position control type is not provided with X2 (Communication connector) and X5 (Con-

Priority is given to the transmitter which is set up as a master. (0: Slave mode, 1 : Master mode)

Note

nector for External Scale).
Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification. 4

Before Using the Products

2

Preparation


3

6

Example of Data Communication


e.g. Reference of Absolute Data

When you connect the host to one driver with RS232 communication, and connect multiple MINAS-A5s with RS485 communication. Following flow chart describes the actual flow of the communication data when you want to capture the absolute data of the module ID=1.



e.g. of capturing the absolute data


Following shows the communication data in time series when you want to capture the absolute data. Data is presented in hexadecimals.



7-34 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Example of Parameter Change

Following shows the communication data in time series when you change parameters. Communication in general will be carried out in sequence of (1) Request for capturing of execution right, (2) Writing of individual parameter, and (3) Writing to EEPROM when saving of data is required, and (4) Release of execution right. Here the hardware connection shows the case that the driver (user ID=1) is directly connected to the host with RS232. Date is presented in hexadecimals.



Note


 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification. Before Using the Products

6

Specifications

Status Transition Chart






Note

 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

RS485 Communication





 Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale). 6


2


Preparation

3

Specifications

Timing of Data Communication





Symbol	Title	Minimum	Maximum
Т3	Continuous inter-character time	Stop bit length	Protocol parameter T1
T4	Response time of driver	Protocol parameter T6	Protocol parameter T2
T5	Response time of host	2 ms	Protocol parameter T2

Caution \Rightarrow Above time represents a period from the rising edge of the stop bit.

Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).

[•] Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Supplement

4. Communication

List of Communication Command

command	mode	Content				
		NOP				
0	1	Read out of CPU version				
0	5	Read out of driver model				
6		Read out of motor model				
		INIT				
4	7	Capture and release of execution right				
1	8	Setup of RS232 protocol parameter				
	9	Setup of RS485 protocol parameter				
		POS, STATUS, I/O				
	0	Read out of status				
	1	Read out of command pulse counter				
	2	Read out of feedback pulse counter				
	4	Read out of present speed				
	5	Read out of present torque output				
2	6	Read out of present deviation counter				
	7	Read out of input signal				
	8	Read out of output signal				
	9	Read out of present speed, torque and deviation counter				
	A	Read out of status, input signal and output signal				
	С	Read out of external scale				
	D	Read out of absolute encoder				
	E	Read out of external scale deviation and sum of pulses				
		PARAMETER				
	0	Individual read out of parameter				
	1	Individual writing of parameter				
7	2	Writing of parameter to EEPROM				
	6	Individual read out of user parameter				
	7	Read out of two or more user parameter				
	8	Writing of two or more user parameter				
		ALARM				
	0	Read out of present alarm data				
0	2	Batch read out of alarm history				
9	3	Clear of user alarm history				
	4	Alarm clear				
	В	Absolute clear				

• Use the above commands only. If you use other commands, action of the driver cannot be guaranteed.

• When the reception data counts are not correct in the above command, transmission byte1 (Error code only) will be returned regardless of communication command.

7

1

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

Supplement

4. Communication

Details of Communication Command

			Reception data	a		Transmissior	n data	
			0			3		
			axis			axis		
		1	1 0			1	0	
			checksum			Version (upper)		
						Version (lov	ver)	
						Error cod	е	
						checksur	n	
Fror code	I	-			-			
	6	5	4	3	2	1	0	
bit7			RS485 error					

(Decimal point will be returned by making the lower 4 bit of the upper dataas 0.)

• Version will be displayed in figures from 0 to 9. (e.g. Version 3.1 will be upper data 30h, lower data 13h.)

	[Re	ception data 0			Transmission of 0Dh	lata
	-		axis			axis	
	ŀ	5	checksum	0	N	/odel of driver (u	0 pper)
						Model of driver (lo Error code checksum	ower)
bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error				
	l consist of 12-o HT1105***"	characters, and	will be transmit	ted in ASCII cod	е.		

	[0 0			Transmission o		
	-	6	axis	0	6	axis	0	
	-		checksum	<u> </u>		Model of motor (upper)		
Error code						Model of motor (I Error code checksum	ower)	
	-	5	4	3	2	1	0	
bit7	6	-						
bit7 0 : Normal 1 : Error	6	Command error						

Details of Communication Command

	mode 7	Capture a	and release o	of execution	n right		
1		F	Reception data		-	Transmission	data
			1			1	
		7	axis	1		axis 7	1
		,	mode	·		Error code	1
			checksum			checksum	
ror code							
bit7	6	5	4	3	2	1	0
: Normal : Error		Command erro	or RS485 error	mode error			in use
right after the mode = 1 : En You cannot op communicatio	action finishe quires for the erate with th n.	es. e capture of the e front panel at	right at paramete execution right other than moni cution right, it wil	mode = 0 : E itor mode while	Enquires for the interview of the execution in the execution is the execution in the execution is the execution in the execution is the execut	release of the ex right is captured	ecution right
command	mode	• Setup of	RS232 proto	col parame	ter		
1	8		Reception data	boi parame		Transmission	data
			4			1	
		8	axis	1		axis 8	1
			T1			Error code	
			T2			checksum	
		0	T6	TY			
		0	checksum				
ror code							
bit7	6	5	4	3	2	1	0
: Normal : Error		T6error	RS485 error	RTYerror	T2error	T1error	
	nand has be	en executed, th	et up protocol pa iis parameter se			command.	
command	mode 9	Setup of	RS485 proto	col parame	ter		
		F	Reception data			Transmission	data
<u> </u>			4 axis			1 axis	
				1		9	1
· ·		9				Error code	
		9	T1				
·		9	T2			checksum	
		9	T2 T6	ITY			
			T2 T6	ITY			
rror code	6		T2 T6	ТҮ 3			0

1

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble

7

Supplement

After this command has been executed, this parameter setup will be valid from the next command. • RTY is 4-bit.

• Unit... T1 : 0.1 s, T2 : 0.1 s, T6 : 1 ms

Details of Communication Command


	0	Da	contion data				Transmission d	ata
	F	Re	ception data			-		ata
	-		0 axis				3 axis	
	-	0		2		0	axis	2
			checksum	2		0	control mode	_
	L		onconsum				status	
							error code	
							checksum	
status								
bit7	6	5	4	3		2	1	0
				Positive direction		gative direction	Slower than DB	Torque in-limi
				running	rur	nning	permission	
Error code		-		-				
bit7	6	5	4	3		2	1	0
0 : Normal		Command error	RS485 error					
1 : Error								
Control m	odes are defined	as follows						
	Position contro		٦					
0			-					
1	Velocity contro		_					
2	Torque control		1					
3	Full-closed cor	ماسما سمم	1					

Slower than DB permission : This becomes 1 when motor speed (after converted to r/min) is below 30 r/min.
Torque in-limit : This becomes 1 when torque command is limited by analog input or parameter.


		Re	ception data			Transmission	data
			0			5	
			axis			axis	
		1		2	1		2
			checksum			counter value	e L
ror code	6	5	4	3	2	error code checksum	
: Normal		Command error			L		

Counter value will be "-" for negative direction and "+" for positive direction.

Details of Communication Command




Details of Communication Command



Output value in 32 bit

• Becomes "+" when the encoder is located at negative direction against position command, and "-" when it is located at positive direction.



• CW over-travel inhibit input and CCW over-travel inhibit input will change according to the input logic, even if they have been disabled by the parameter,

Details of Communication Command

			Reception da	ata				Transmission	data			
	[0			Ē		7				
	-	8	axis	2	_	ŀ	8	axis	2			
	-	0	checksum	2		ŀ	0	data L	2			
	L		onconcum			ŀ						
						-		data H	1			
						-		alarm data	<u>-</u> H			
						ŀ		error code	•			
								checksum				
rror code					-							
bit7 0 : Normal	6	5 Command e	error RS485 er	ror	3		2	1	0			
1 : Error		Command C										
Data												
bit7	6	5	4		3		2	1	0			
For manufacturer's us	In-speed	Torque in-lin	nit Zero spee detection		hanical e released	Pos con	sitioning nplete position)	Servo-Alarm	Servo-Ready			
manulacturer 5 US	~	I	detection	Diak		(in-	position)					
bit15	14	13	12		11		10	9	8			
Excite motor	Control power latch	Dynamic bra engagemen		, rege	eneration	pos	-closed itioning	At-speed	For manufacturer's use			
		5.35		n relay břa			nplete					
bit23	22	21	20	u u Ond	19	Dee	18	17	16			
Safety EDM	Speed command ON/OFF	Alarm attribu output	ute Speed in- output	com	positioning plete position)	com	sitional nmand /OFF	Alarm output 2	Alarm output 1			
		output	output	<u> </u>	005111011)							
bit31	31	29	28	_	27	_	26	25	24			
For manufacturer's us	For manufacturer's use	For manufacturer's	For use manufacture	For er's use manu	ufacturer's use	For	ufacturer's use	For manufacturer's use	For manufacturer's use			
		manalataron o	uoo manaratata			man						
bit7	6	5	4		3	<u> </u>	2	1	0			
Overload	Fan	Over-regenera	· ·	Enco	der overheat	Life	time	For	Battery			
protection	alarm	alarm	alarm	alarn	n	dete	ection alarm	manufacturer's use	alarm			
bit15	14	13	12		11		10	9	8			
For	For	For					ernal scale	Oscillation detection	External scale			
manufacturer's us	e manufacturer's use	manufacturer's	use			alar	m	alarm	error alarm			
• The table b	elow shows the r	elation of the	e signals and	actions								
	Signal title		o lightaid and	0				1				
	Servo-Ready			ervo-Not R	oodu		1 At Sorvo Boody					
	Servo-Alarm		36	Normal	eauy		At Servo-Ready					
	ositioning comple	atad	Popitic	ning not co	omploted		At Servo-Alarm Positioning in-complete					
	hanical brake rel			nical brake	-			hanical brake r	-			
INIEC	ero speed detect			speed not of				ero speed dete				
1 7	Torque in-limit			rque not in			2	-				
Z	speed (Speed ar			-	not arrived	4)		Torque in-lim Speed arrivin				
			Not in-spe			,	In-en	eed (Speed co	-			
At-	In-speed (Speed coincidence)				not comple	,		sed positioning				
At- In-spe		Full-closed positioning complete				Jieu		rn on regenera				
At- In-spe Full-clo	osed positioning	-	Turn off regeneration Tr					-				
At- In-spe Full-clc Con	osed positioning of trol regeneration	brake		Release inrush suppression relay								
At- In-spe Full-clc Con Contro	osed positioning trol regeneration I inrush suppress	brake sion relay	Release ir			Dynamic brake released			Dynamic brake engaged			
At- In-spe Full-clc Con Contro Dyna	osed positioning o trol regeneration I inrush suppress amic brake engag	brake sion relay gement	Release ir Dyna	mic brake i	released		-					
At- In-spe Full-clc Con Contro Dyna	osed positioning trol regeneration I inrush suppress	brake sion relay gement	Release ir Dynai Rele		released r latch		-	namic brake en ver abnormal la Servo free				

different meaning for different series.

6

When in Trouble

7

Supplement

Adjustment

Before Using the Products

2

Preparation


3


Connection

4

Setup

Details of Communication Command





Details of Communication Command

		Re	ception data			Transmission	data
	Г	-	0			11 (0Bh)	
	F		axis			axis	
	Γ	С		2	C	;	2
			checksum			encoder ID	(L)
							(H)
						status_(L)	
						(H)	
						(L)	
					abs	solute position da	 ata (48bit)
						(H))
						error code	
						checksum	
Encoder ID						-	
	771	Encode			er ID (H)	-	
	771 Oseries		ta of EEPROM ta of EEPROM		2h 1h	-	
A130	0361163	Address 0 dd				_	
Command e	error occurs at o	ther control mod	tes than full-clo	sed control.			
ST771 Status (L)							
bit7	6	5	4	3	2	1	0
bit7	Signal intensity	Signal intensity	Transducer	ABS detection	Hardware	1 Initialization	0 Over speed
bit7 Thermal alarm		-		-		1 Initialization error	
bit7 Thermal alarm Status (H)	Signal intensity alarm	Signal intensity error	Transducer error	ABS detection error	Hardware error	error	Over speed
bit7 Thermal alarm itatus (H) bit7	Signal intensity alarm 6	Signal intensity error 5	Transducer error 4	ABS detection error	Hardware error 2	error 1	Over speed
bit7 Thermal alarm itatus (H) bit7	Signal intensity alarm	Signal intensity error	Transducer error 4 Encoder	ABS detection error	Hardware error	error	Over speed
bit7 Thermal alarm Status (H) bit7 0	Signal intensity alarm 6 0	Signal intensity error 5 Encoder error *1	Transducer error 4 Encoder error *2	ABS detection error 3 0	Hardware error 2 0	error 1 0	Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica	Signal intensity alarm 6	Signal intensity error 5 Encoder error *1	Transducer error 4 Encoder error *2	ABS detection error	Hardware error 2 0	error 1 0	Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series	Signal intensity alarm 6 0	Signal intensity error 5 Encoder error *1	Transducer error 4 Encoder error *2	ABS detection error 3 0	Hardware error 2 0	error 1 0	Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7	Signal intensity alarm 6 0 al sum of bit0 to bi	Signal intensity error 5 Encoder error *1 t 5 of status (L) 5	Transducer error 4 Encoder error *2 *2 bit4	ABS detection error 3 0 : logical sum of t	Hardware error 0 bit6 and bit 7 of st	error 1 0 catus (L) 1	Over speed 0 0 0 0 0
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7	Signal intensity alarm 6 0 al sum of bit0 to bi	Signal intensity error Encoder error *1 t 5 of status (L) 5 Communication	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory	ABS detection error 3 0 : logical sum of t	Hardware error 0 bit6 and bit 7 of st	error 1 0 atus (L) 1 Initialization	Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm	Signal intensity alarm 6 0 al sum of bit0 to bi	Signal intensity error 5 Encoder error *1 t 5 of status (L) 5	Transducer error 4 Encoder error *2 *2 bit4	ABS detection error 3 0 : logical sum of t	Hardware error 2 0 bit6 and bit 7 of st	error 1 0 catus (L) 1	Over speed 0 0 0 0 0
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm Status (H)	Signal intensity alarm 6 0 al sum of bit0 to bi 6 0	Signal intensity error Encoder error *1 t 5 of status (L) 5 Communication error	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory error	ABS detection error 3 0 : logical sum of t 3 Capacity and photoelectric error	Hardware error 2 0 bit6 and bit 7 of st 2 Encoder non-matching error	error 1 0 catus (L) 1 Initialization error	Over speed Over speed Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm Status (H) bit7	Signal intensity alarm 6 0 al sum of bit0 to bi 6 0	Signal intensity error Encoder error *1 t 5 of status (L) 5 Communication error 5	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory error 4	ABS detection error 3 0 : logical sum of t 3 Capacity and photoelectric error 3	Hardware error 2 0 bit6 and bit 7 of st 2 Encoder non-matching error 2	error 1 0 atus (L) 1 Initialization error 1	Over speed Over speed Over speed Over speed Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm Status (H) bit7	Signal intensity alarm 6 0 al sum of bit0 to bi 6 0	Signal intensity error Encoder error *1 t 5 of status (L) 5 Communication error	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory error	ABS detection error 3 0 : logical sum of t 3 Capacity and photoelectric error	Hardware error 2 0 bit6 and bit 7 of st 2 Encoder non-matching error	error 1 0 catus (L) 1 Initialization error	Over speed Over speed Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm Status (H) bit7 0	Signal intensity alarm 6 0 al sum of bit0 to bi 6 0 6 0	Signal intensity error 5 Encoder error *1 t 5 of status (L) 5 Communication error 5 Encoder error *3	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory error 4 Encoder alarm *4	ABS detection error 3 0 : logical sum of t Capacity and photoelectric error 3 0	Hardware error 2 0 bit6 and bit 7 of st 2 Encoder non-matching error 2 0	error 1 0 iatus (L) 1 Initialization error 1 0	Over speed Over speed Over speed Over speed Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm Status (H) bit7 0 3 bit5 : Logica	Signal intensity alarm 6 0 al sum of bit0 to bi 6 0	Signal intensity error 5 Encoder error *1 t 5 of status (L) 5 Communication error 5 Encoder error *3	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory error 4 Encoder alarm *4	ABS detection error 3 0 : logical sum of t 3 Capacity and photoelectric error 3	Hardware error 2 0 bit6 and bit 7 of st 2 Encoder non-matching error 2 0	error 1 0 iatus (L) 1 Initialization error 1 0	Over speed Over speed Over speed Over speed Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm Status (H) bit7 0 3 bit5 : Logica Error code	Signal intensity alarm 6 0 al sum of bit0 to bi 6 0 6 0 al sum of bit0 to bi	Signal intensity error Encoder error *1 t 5 of status (L) 5 Communication error 5 Encoder error *3 t 5 of status (L)	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory error 4 Encoder alarm *4 *4 bit4	ABS detection error 3 0 : logical sum of t Capacity and photoelectric error 3 0 : logical sum of t	Hardware error 2 0 bit6 and bit 7 of st Encoder non-matching error 2 0 bit6 and bit 7 of st	error 1 0 atus (L) Initialization error 1 0 atus (L)	Over speed Over speed Over speed Over speed Over speed Over speed
bit7 Thermal alarm Status (H) bit7 0 1 bit5 : Logica AT500 series Status (L) bit7 Thermal alarm Status (H) bit7 0	Signal intensity alarm 6 0 al sum of bit0 to bi 6 0 6 0	Signal intensity error 5 Encoder error *1 t 5 of status (L) 5 Communication error 5 Encoder error *3	Transducer error 4 Encoder error *2 *2 bit4 4 CPU, memory error 4 Encoder alarm *4 *4 bit4	ABS detection error 3 0 : logical sum of t Capacity and photoelectric error 3 0	Hardware error 2 0 bit6 and bit 7 of st 2 Encoder non-matching error 2 0	error 1 0 iatus (L) 1 Initialization error 1 0	Over speed Over speed Over speed Over speed Over speed

Adjustment 6

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Details of Communication Command

		Re	eception data			Transmission	data
	Г		0			11 (0Bh)	uuu
	-		axis			axis	
		D		2		D C	2
	[checksum			encoder ID	(L)
							(H)
						^ .	L)
							H)
						single-turn da	L)
							на Н)
						multi-turn data	/
							(H)
						0	
						Error code	
						checksum	
		Encode	er ID (L)	Encod	er ID (H)	7	
17bit a	absolute		3		l1h		
tatus (L)				1			
i tatus (L) bit7	6	5	4	3	2	1	0
bit7	6 System down	5 Multi-turn error	4 0	3 Counter overflow	2 Count error	1 Full absolute status	0 Over speed
		-		Counter			-
bit7 Battery alarm tatus (H) • bit4 : Syster	System down	Multi-turn error	0	Counter overflow	Count error	status	Over speed
bit7 Battery alarm tatus (H) • bit4 : Syster	System down	-	0	Counter overflow	Count error	status	Over speed
bit7 Battery alarm itatus (H) • bit4 : Systen • bit5 : Battery	System down	Multi-turn error	0	Counter overflow	Count error	status	Over speed

		Re	ception data				Transmission	data
			0				9	
			axis				axis	
		E		2		E		2
			checksum					(L)
							external scal	le
							FB pulse sur	
								<u>(H)</u>
								(L)
						e	external scale de	
								(H)
							error code	
							checksum	
bit7	6	5	4	3		2	1	0
: Normal		Command error	·			2	1	
: Error								
E demail : :						-1		undimente en forma
	•	m will return the	present position	n of the exte	ernal sca	ale counter i	n absolute coo	rainates from
the starting	•							
- Evtornal aar	נוס בפונות FR בוג	m will be "-" for I	negative directi	on and "+" f	or posit	ive direction		

Details of Communication Command

command 7	mode 0	• Individual	read out of	parameter			
/	<u> </u>		ception data	-		Transmission o	lata
			2			5	
			axis			axis	
		0	rameter type	7	C)	7 (L)
			arameter No.			parameter valu	
			checksum				
						orror oodo	(H)
						error code checksum	
bit7	6	5	4	3	2	1 1	0
: Normal	0	Command error		No.Error	2		0
: Error							
command 7	mode 1	Individual	writing of p	arameter		Transmission o	lata
			6			1	iala
			axis			axis	
		1		7	1		7
			rameter type arameter No.			error code checksum	
			(L)			Checksum	
		pa	rameter value				
			(H)				
			checksum				
	6	5	4	3	2	1	0
	0	-	RS485 error	No.Error	2	1	0
bit7	Data Error						
bit7 : Normal	Data Error						
bit7 : Normal : Error If the parar This comm to EEPRO Set up para exceeds th	neter type or th and change pa M (mode = 2). ameters not in u ne setup range.	e parameter No. i rameters only ten use to 0 without fa	nporarily. If you ail, or it leads to) want to write in o data error. Da	nto EEPROM, e ta error also occ		
bit7 : Normal : Error If the parar This comm to EEPRO Set up para exceeds th	meter type or th land change pa M (mode = 2). ameters not in u ne setup range. value should be mode	e parameter No. i rameters only ten use to 0 without fa sign-extended to 3	nporarily. If you ail, or it leads to 32 bits before be	o data error. Da bing transmitted.	nto EEPROM, e ta error also occ		
bit7 : Normal : Error If the parar This comm to EEPRO Set up para exceeds th Parameter	neter type or th land change pa M (mode = 2). ameters not in u ne setup range. value should be	e parameter No. i rameters only ten use to 0 without fa sign-extended to 3 • Writing of	nporarily. If you ail, or it leads to 32 bits before be parameter t	o data error. Da bing transmitted.	nto EEPROM, e ta error also occ	curs when the pa	arameter value
bit7 : Normal : Error If the parar This comm to EEPRO Set up para exceeds th Parameter command	meter type or th land change pa M (mode = 2). ameters not in u ne setup range. value should be mode	e parameter No. i rameters only ten use to 0 without fa sign-extended to 3 • Writing of	nporarily. If you ail, or it leads to 32 bits before be parameter to ception data	o data error. Da bing transmitted.	nto EEPROM, e ta error also occ	curs when the pa	arameter value
bit7 : Normal : Error If the parar This comm to EEPRO Set up para exceeds th Parameter command	meter type or th land change pa M (mode = 2). ameters not in u ne setup range. value should be mode	e parameter No. i rameters only ten use to 0 without fa sign-extended to 3 • Writing of Re	nporarily. If you ail, or it leads to 32 bits before be parameter t	o data error. Date ing transmitted.	nto EEPROM, e ta error also occ	curs when the pa	arameter value
bit7 : Normal : Error If the parar This comm to EEPRO Set up para exceeds th Parameter command	meter type or th land change pa M (mode = 2). ameters not in u ne setup range. value should be mode	e parameter No. i rameters only ten use to 0 without fa sign-extended to 3 • Writing of Re	nporarily. If you ail, or it leads to 32 bits before be parameter to ception data 0	o data error. Da bing transmitted.	nto EEPROM, e ta error also occ	curs when the pa Transmission of 1 axis	arameter value

Error code							
bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error	Data Error	Command error	RS485 error			Control LV	

• Writes the preset parameters to EEPROM.

- Transmission data will be returned after EEPROM writing completes. It may take max. 5sec for EEPROM writing (when all parameters have been changed.)
- Data error will occur when writing fails.

• When under-voltage occurs, error code of control LV will be returned instead of executing writing.

1

Before Using the Products

2

Preparation

3

Connection

4

5


6

Details of Communication Command

command 7	mode 6	 Individual 	read out of	user param	leter		
1	0		ception data	•		Transmissio	n data
	Г		2			17 (11h)
			axis			axis	,
		6		7		6	7
	_		rameter type			parameter	
	-		arameter No.			parameter	
	L		checksum			parameter v	(L) value
							(H)
						MIN valu	(L) ie
							(H)
						MAX valu	(L)
						Property	(H)
						Tiopenty	<u>с</u> Н
						Error coo	le
						checksu	m
Property							
bit7	6	5	4	3	2	1	0
Parameter not in use	Display inhibited		Change at initialization				
bit15	14	13	12	11	10	9	8
							Read only
rror code		-				· ·	·
bit7 0 : Normal	6	5 Command error	4 RS485 error	3 No.Error	2	1	0

If the parameter type or the parameter No. is outside the range, returns No. error.
Parameter value, MIN value and MAX value should be sign-extended to 32 bits before being transmitted.

Details of Communication Command



1

Before Using the Products

2

Preparation

3

Connection

4

Setup

5


Adjustment

Details of Communication Command

7	mode 8	Writing of	wo or more	e user parar	neter			
		Re	ception data				Transmissio	n data
			30h(48)				17(11h)
			axis				axis	
		8		7		8		7
			arameter type				(1) paramete	~ ~ ~
		(1) p	arameter No.		(1) parameter No.			
			(L)		(2) parameter type			
		(1) p	arameter value				(2) paramete	er No.
			(H)		*			
			(1)				(8) paramete	er type
	1	ř		$\widetilde{\gamma}$			(8) paramete	
		(8) p	arameter type				Error coo	
		(8) p	arameter No.				checksu	m
			(L)					
		(8) p	arameter value					
			(H) checksum					
			checksum					
rror code								
bit7	6	5	4	3		2	1	0
) : Normal I : Error	Data Error	Command error	RS485 error	No.Error				
error occurs	6.	er. Otherwise data ne parameter No. i				•	setting range	e is sent, data

			axis		_	axis		
		0		9		0 9		
		C	checksum				alarm No. (N	/lain)
							alarm No. (S	Sub)
							error cod	е
					checksum			
							CHECKSU	
irror code bit7	6	5	4	3		2	1	0

Details of Communication Command



1

7

Supplement

Error code	-				_		-
bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							
Clears the p	resent alarm. (only those you c	an clear)				

Details of Communication Command


		Re	ception data				Transmission	data
			0			1		
			axis				axis	
		В	9		B 9			
			checksum				Error code	
			checksum					
							checksum	
rror code bit7	6	5	4	3		2	1	0
bit7) : Normal	6	5 Command error	-	3		2	1	0
) : Normal : Error		-	RS485 error	3		2	1	0

5. Motor Characteristics (^{S-T}_{Characteristics})

Supplement


MSMD series (50 W to 100 W)

- Note that the motor characteristics may vary due to the existence of oil seal or brake.
- Continuous torque vs. ambient temperature characteristics have been measured with an aluminum flange attached to the motor (approx. twice as large as the motor flange).



* These are subject to change. Contact us when you use these values for your machine design.

* Ratio to the rated torque at ambient temperature of 40 °C is 100 % in case of without oil seal, without brake.





Preparation

5

5. Motor Characteristics (^{S-T} Characteristics)


MSMD series (200 W)





5. Motor Characteristics (^{S-T} Characteristics)

MSMD series (400 W to 750 W)



* These are subject to change. Contact us when you use these values for your machine design.

Before Using the Products

2

Preparation

3


4

5

Adjustment

5. Motor Characteristics (^{S-T}_{Characteristics})

MSME series (50 W to 100 W)




* These are subject to change. Contact us when you use these values for your machine design.


* Ratio to the rated torque at ambient temperature of 40 °C is 100 % in case of without oil seal, without brake.

5. Motor Characteristics (^{S-T}_{Characteristics})

MSME series (200 w)



* These are subject to change. Contact us when you use these values for your machine design.



Before Using the Products

2

Preparation

3

4

Setup

5

Adjustment

6

When in Trouble

7


Supplement

speed

torque

5. Motor Characteristics (^{S-T}_{Characteristics})

MSME series (400 W to 750 W)



5. Motor Characteristics (S-T Characteristics)

Before Using the Products

2

Preparation

3

4

5

∆djustment


6


When in Trouble

7

Supplement


MSME series (1.0 kW to 2.0 kW)






5. Motor Characteristics (^{S-T}_{Characteristics})

MSME series (3.0 kW to 5.0 kW)





• MDME044 * 1 *

toraue

[N·m]

6

(3.5

(1.3

0

torque [N·m]

15

10

(6.0)

(4.0) (3.2)

0

torque [N·m]

20

10

(4.8)

0

torque [N·m]

30

15 (11)

(6.4)

0

• MDME202 * 1 *

• MDME152 * 1 *

· MDME102 * 1 *

MDME series (400 W to 2.0 kW)

Input voltage to driver: AC400 V

Peak running range

Continuous running range

1000

Peak running range

Continuous running range

1000

Input voltage to driver: AC200 V

Peak running range

Continuous running range

Input voltage to driver: AC200 V

1000

Peak running range

Continuous running range

1000

2000

2000

20Ò0

Input voltage to driver: AC200 V

(2400) (2)

speed [r/min]

^{00)</sub> ' 3000}

ratio vs. rated torque

[%]

100

50

0 10

ratio vs. rated torque

[%]

100

50

0 10

ratio vs. rated torque

[%]

100

50

0 10

ratio vs. rated torque

[%]

100

50

0 10

3000

speed [r/min]

3000


speed [r/min]

3000

speed [r/min]

5. Motor Characteristics (S-T Characteristics)

MDME series (400 W to 2.0 kW)



* These are subject to change. Contact us when you use these values for your machine design.

40

ambient temp. [°C]

20 30 Trouble

7

20 30 40

ambient temp. [°C]

0 10

3000

speed [r/min]

20Ò0


(6.4)


0

Continuous running range

5. Motor Characteristics (^{S-T}_{Characteristics})

MDME series (3.0 kW to 5.0 kW)





toraue

[N·m]

(119 100

(60)

(12) 0

torque

[N·m]

(175)

150 (130)

75 (70) (52.5)

0

torque [N·m]

(224)

200

100


(57

0

50 (47.8

5. Motor Characteristics (S-T Characteristics)

MDME series (7.5 kW to 15.0 kW)



5

Before Using the Products

2


Preparation


3

4

5. Motor Characteristics (^{S-T}_{Characteristics})


MFME series (1.5 kW to 4.5 kW)





5. Motor Characteristics (^{S-T} Characteristics)

MGME series (0.9 kW to 3.0 kW)



* These are subject to change. Contact us when you use these values for your machine design.

Before Using the Products

2

Preparation

3


4


5

Adjustment

5. Motor Characteristics (^{S-T}_{Characteristics})


MGME series (4.5 kW to 6.0 kW)





5. Motor Characteristics (S-T Characteristics)

MHMD series (200 w)



* These are subject to change. Contact us when you use these values for your machine design.

1

Before Using the Products

2

Preparation

3

Connection

4

Setup


5


Adjustment

6

5. Motor Characteristics (^{S-T}_{Characteristics})


MHMD series (400 W to 750 W)





5. Motor Characteristics (^{S-T} Characteristics)

MHME series (1.0 kW to 3.0 kW)



* These are subject to change. Contact us when you use these values for your machine design.

Before Using the Products

2


Preparation

3


4

5. Motor Characteristics (^{S-T}_{Characteristics})

MHME series (4.0 kW to 7.5 kW)




^{*} These are subject to change. Contact us when you use these values for your machine design.



6. Dimensions

Driver

A-frame



Related page … • P.1-3 "Driver" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.2-10 "Driver and List of Applicable Peripheral Equipments"

5

Before Using the Products

2

Preparation

3

Connection


4


Setup

[Unit: mm]

6. Dimensions


C-frame





Related page : P.1-3 "Driver" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.2-10 "Driver and List of Applicable Peripheral Equipments" Driver

D-frame (400 V)



1

Before Using the Products

2

Preparation

3

Connection

4

Setup

5

Adjustment

6

When in Trouble


7

Supplement

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 7-75

E-frame (400 V)


[Unit: mm]



HHHHHH


HUNHBURGHUN


[Unit: mm]



7-76 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

G-frame (200 V/ 400 V)





*1 The height of the safety by-pass plug provided with connector X3, can be either 14 mm or 24 mm.

Related page :: • P.1-3 "Driver" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.2-10 "Driver and List of Applicable Peripheral Equipments"

[Unit: mm]


1


3

Setup


H-frame (200 V/ 400 V)

[Unit: mm]





MSMD 50 W to 100 W



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

	51151011		change without notice. Contact us or a dealer	[Unit: mm]			
			MSMD series (Low inertia	a)			
	Moto	or output	50 W	100 W			
Motor	model	MSMD	5A * * 1 🗌 *	01 * * 1 *			
	L	Without brake	72	92			
L	.∟	With brake	102	122			
		LR	2	5			
		S	8	3			
		LA	4	5			
		LB	30	0			
		LC	3	8			
		LE	3	3			
		LF	6				
		LH	3:				
		LN	26.3	46.5			
_		LZ	3.4				
D-cut dimensions		LW	2				
D-cut mensior		LK	20	7			
ons t		RH	7.				
		LW	14				
Key way dimensions		LK	12				
ey v		KW	3h				
Key way imension		КН					
้ จ		RH	6.				
		TP	M3 de	•			
Mass	s (kg)	Without brake	0.32	0.47			
		With brake	0.53	0.68			
Con	nector	specifications	Refer to P.2-48 "Specifica	tions of Motor connector"			

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

1

Before Using the Products

2

Preparation


3

Connection

4

Setup

MSMD 200 W to 750 W



[Unit: mm]


* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

			MSMD serie	s (Low inertia)				
	Moto	or output	200 W	400 W	750 W			
Motor	model	MSMD	02 * * 1 🗌 *	04 * * 1 🗌 *	08 * * 1 🗌 *			
		Without brake	79.5	99	112.2			
	-L	With brake	116 135.5		149.2			
		LR	3	0	35			
		S	11	14	19			
		LA	7	0	90			
		LB	5	0	70			
		LC	6	0	80			
		LE		3				
		LF	6	.5	8			
		LH	4	3	53			
		LZ	4	6				
dim 🗖		LW	3	0	35			
D-cut dimensions		LK	2	2	25			
lt ons		RH	10	12.5	17.5			
		LW	20	25	25			
di x		LK	18	22.5	22			
Key way dimensions		KW	4h9	5h9	6h9			
wa		KH	4	5	6			
ns Y		RH	8.5	11	15.5			
		TP	M4 depth 8	M5 de	pth 10			
Mag	s (kg)	Without brake	0.82	1.2	2.3			
ivias	s (rg)	With brake	1.3	1.7	3.1			
Con	nector	specifications	Refer to	P.2-48 "Specifications of Motor c	onnector"			

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

MSME 50 W to 750 W




LW KW

퓨

Shaft end spec.





* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

* Dime	ension	s are subject to	change without not	lice. Contact us o	r a dealer for the la	test information.	[Unit: mm
			M	SME series (Lo	ow inertia)		
	Moto	or output	50 W	100 W	200 W	400 W	750 W
Motor	model	MSME	5A * * 1 *	01 * * 1 *	02 * * 1 *	04 * * 1 *	082 * 1 *
		Without brake	72	92	79.5	99	112.2
L	.L	With brake	102	122	116	135.5	148.2
		LR	25		3	0	35
		S	8		11	14	19
		LA	45	5	7	0	90
		LB	30)	5	0	70
		LC	38	3	6	0	80
		LE	3				•
		LF	_		6.5		8
		LH	46.	6	52.5		61.6
	м	Without brake	44.8	64.8	53	72.5	85.7
L	IVI	With brake	74.8	94.8	89.5	109	121.7
		LN	23	43	_	—	_
		LT	27.	2	26.5		
		LZ	3.4	4	4.5		6
		LW	14	Ļ	20 25		25
dir 🖌		LK	12.	5	18	22.5	22
Key way dimensions		KW	3h	9	4h9	5h9	6h9
wa		KH	3		4	5	6
iy Sug		RH	6.2	2	8.5	11	15.5
		TP	M3 de	pth 6	M4 depth 8	M5 de	pth 10
Mari	- <i>(lca</i>)	Without brake	0.31	0.46	0.78	1.2	2.3
iviass	s (kg)	With brake	0.51	0.66	1.2	1.6	3.1
Con	nector	specifications		Refer to P.2-48	"Specifications of M	lotor connector"	•
		opeoindutione					

Caution 🔅 Related page …

Reduce the moment of inertia ratio if high speed response operation is required.


• P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" · P.7-58 to 60 "S-T Characteristics"

2


5

Supplement

MSME 750 W(400 V), 1.0 kW to 5.0 kW (DesignOrder: 1)



<MSME 3.0 kW to 5.0 kW> * All sizes are identical to those of MSME 1.0 kW to 2.0 kW versions except for LF.



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.


[Unit: mm]

		· · · · · · · · · · · · · · · · · · ·		MSME s	eries (Low	inertia)			
	Moto	r output	750 W	1.0 kW	1.5 kW	2.0 kW	3.0 kW	4.0 kW	5.0 kW
Motor	model	MSME	084 * 1 *	10 * * 1 *	15 * * 1 *	20 * * 1 *	30 * * 1 *	40 * * 1 *	50 * * 1 *
L		Without brake	131.5	141	159.5	178.5	190	208	243
L	L	With brake	158.5	168	186.5	205.5	215	233	268
		LR			55	65			
S				1	9		22	2	4
LA				11	5			145	
		LB		9	5			110	
		LC		10	00		120	1:	30
		LD		13	35		162	10	65
		LE			3			6	
		LF		1	0		12		
		LG				60			
		LH		10)1		113	1	18
LI	Л	Without brake	87.5	97	115.5	134.5	146	164	199
LI	VI	With brake	114.5	124	142.5	161.5	171	189	224
		LZ				9			
<u>م</u>		LW			45			5	5
lime		LK		4	2		41	5	1
Key way imension		KW		61	19			8h9	
Key way dimensions		КН		6	6			7	
		RH		15	5.5		18	2	0
Mass	(kg)	Without brake	3.1	3.5	4.4	5.3	8.3	11.0	14.0
Iviass	, (ne)	With brake	4.1	4.5	5.4	6.3	9.4	12.6	16.0
Conr	nector	specifications		Refe	er to P.2-49 "S	pecifications o	f Motor conne	ctor"	


Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

MSME 1.0 kW to 5.0 kW (DesignOrder: C)



<MSME 3.0 kW to 5.0 kW> * All sizes are identical to those of MSME 1.0 kW to 2.0 kW versions except for LF.



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

* Dim	ension	s are subject to	change without	t notice. Contac	t us or a dealer	for the latest in	formation.	[Unit: mm]	
				MSME serie	s (Low inertia	a)			
	Moto	or output	1.0 kW	1.5 kW	2.0 kW	3.0 kW	4.0 kW	5.0 kW	
Motor	model	MSME	10 * * C *	15 * * C *	20 * * C *	30 * * C *	40 * * C *	50 * * C *	
	L	Without brake	143	161.5	180.5	192	210	245	
L	_L	With brake	170	188.5	207.5	217	235	270	
		LR		5	5	`	6	5	
		S		19		22	2	4	
		LA		115			145		
		LB		95			110		
		LC		100		120	10	30	
		LD		135		162	16	65	
		LE		:	3		6		
		LF	10			12			
		LG			8	4			
		LH		101		113	11	18	
	M	Without brake	97	115.5	134.5	146	164	199	
L	.1VI	With brake	124	142.5	161.5	171	189	224	
		LZ			(Э			
Q		LW		4	5	55			
Key way dimensions		LK		42		41	5	1	
Key way imension		KW		6h9			8h9		
ay ons		КН		6			7		
		RH		15.5		18	2	0	
Mas	s (kg)	Without brake	3.5	4.4	5.3	8.3	11.0	14.0	
		With brake	4.5	5.4	6.3	9.4	12.6	16.0	
Con	nector	specifications		Refer to	P.2-49 "Specifica	ations of Motor co	onnector"		

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page : P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-61, 62 "S-T Characteristics" 1

Before Using the Products


2

Preparation

5

Setup

MDME 400 W to 5.0 kW (DesignOrder: 1)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

[Unit: mm]


MDME series (Middle inertia)										
Motor output		400 W	600 W	1.0 kW	1.5 kW	2.0 kW	3.0 kW	4.0 kW	5.0 kW	
Motor model		MDME	044 * 1 *	064 * 1 *	10 * * 1 *	15 * * 1 *	20 * * 1 *	30 * * 1 *	40 * * 1 *	50 * * 1 *
	L	Without brake	131.5	141	138	155.5	173	208	177	196
		With brake	158.5	168	163	180.5	198	233	202	221
LR			55				65	70		
S			19		22			24	35	
LA			115		145				200	
LB			95		110				114.3	
LC			100		130				176	
LD			135		165				233	
LE			3		6				3.2	
LF			10		12				18	
LG			60							
LH			101		116			118	140	
LM		Without brake	87.5	97	94	111.5	129	164	133	152
		With brake	114.5	124	119	136.5	155	189	158	177
LZ			9						13.5	
Key way dimensions		LW			45			55		
		LK	42		41			51	50	
	KW		6h9		8h9				10h9	
	КН		6		7				8	
	RH		15.5		18			20	30	
Mass	s (kg)	Without brake	3.1	3.5	5.2	6.7	8.0	11.0	15.5	18.6
(Kg)		With brake	4.1	4.5	6.7	8.2	9.5	12.6	18.7	21.8
Con	nector	specifications	Refer to P.2-49 "Specifications of Motor connector"							

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page • P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-63, 64 "S-T Characteristics"

MDME 400 W to 5.0 kW (DesignOrder: C)



MDME152*C*M and MDME102*C*M has the same dimensions but a bit different design.

* Dimensions are subject to change without notice. Contact us of	or a dealer for the latest information.
--	---

				MDME corios	Middle iner	tia)			
	MDME series (Middle inertia)								
Motor output			1.0 kW	1.5 kW	2.0 kW	3.0 kW	4.0 kW	5.0 kW	
Motor	model	MDME	10 * * C *	15 * * C *	20 * * C *	30 * * C *	40 * * C *	50 * * C *	
	.L	Without brake	140	157.5	175	210	179	198	
L	-L-	With brake	165	182.5	200	235	204	223	
LR				55		65	7	0	
		S		2	2		3	5	
		LA		14	45		20	00	
		LB		11	10		11-	4.3	
		LC		10	30		17	76	
LD				16	35		233		
LE			6			3.2			
LF			12			18			
LG			84						
LH			116 118			140			
	M	Without brake	94	111.5	129	164	133	152	
L	IVI	With brake	119	136.5	155	189	158	177	
		LZ	9			13.5			
	LW 45		55						
dim	di z LK			41 51			50		
		KW	8h9			10h9			
		KH	7				8		
		RH	18		20	30			
Mas		Without brake	5.2	6.7	8.0	11.0	15.5	18.6	
IVIAS	s (kg)	With brake	6.7	8.2	9.5	12.6	18.7	21.8	
Con	nector	specifications		Refer to	P.2-49 "Specifica	ations of Motor co	onnector"		

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page : P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-63, 64 "S-T Characteristics" 1


Before Using the Products

4

[Unit: mm]

Setup

MDME 7.5 kW to 15.0 kW



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.


[Unit: mm]

			MDME series	(Middle inertia)		
	Moto	or output	7.5 kW	11.0 kW	15.0 kW	
Motor model MDME		MDME	75 * * 1 *	C1 * * 1 *	C5 * * 1 *	
LL		Without brake	312	316	348	
L	.L	With brake	337	364	432	
		LR	113	11	6	
S		S	42	5	5	
LA LB LC		LA	200	23	5	
		LB	114.3	20	0	
		LC	176	22	20	
LD		LD	233	26	8	
LE		LE	3.2	4		
LF		LF	24	32		
LG		LG	60			
	LH		184	205		
	М	Without brake	268	272	340	
L	IVI	With brake	293	320	388	
		LZ		13.5		
_		LW	96	9	8	
		LK	90	90		
Key way dimensions		KW	12h9	16h9		
ion	KH		8	10		
s	RH		37 ⁰ _{-0.2}	49 ⁰ _{-0.2}		
Maar	(((m)	Without brake	36.4	52.7	70.2	
iviass	s (kg)	With brake	40.4	58.9	76.3	
Con	nector	specifications	Refer to	P.2-49 "Specifications of Motor co	nnector"	

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

MFME 1.5 kW to 4.5 kW



* Dimensions are subject to	change without notice.	Contact us or a dealer	for the latest information.

			MFME series	(Middle inertia)		
	Moto	or output	1.5 kW	2.5 kW	4.5 kW	
		MFME	15 * * 1 *	25 * * 1 *	45 * * 1 *	
LL		Without brake	142	136	156	
L	-L	With brake	167	169	189	
		LR	6	5	70	
		S		35		
		LA	200	23	35	
		LB	114.3	20	00	
		LC	176	22	20	
LD		LD	233	266		
LE		LE	3.2	4		
LF		LF	18	16		
LG		LG	60			
		LH	140	162		
	M	Without brake	98	91	111	
L	.1VI	With brake	123	124	144	
		LZ		176		
		LW		55		
Key way dimensions		LK		50		
Key way		KW	10h9			
ay		КН	8			
	RH		30			
Mae	s (kg)	Without brake	9.5	13.1	18.2	
Mas	5 (NG)	With brake	12.5	17.2	23.1	
Con	nector	specifications	Refer to	P.2-49 "Specifications of Motor co	onnector"	

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page :: P.1-21 "Check of the Model" · P.1-23 "Check of the Combination of the Driver and the Motor" · P.7-66 "S-T Characteristics"


1

Setup

4

[Unit: mm]

MGME 900 W to 3.0 kW (DesignOrder: 1)



[Unit: mm]

MGME092*C*M has the same dimensions but a bit different design.

	* Dimensions are sub	pject to change without notice.	Contact us or a dealer	for the latest information.
--	----------------------	---------------------------------	------------------------	-----------------------------


			MGME series	s (Middle inertia)		
	Moto	or output	900 W	2.0 kW	3.0 kW	
Motor model MGME		MGME	09 * * 1 *	20 * * 1 *	30 * * 1 *	
LL		Without brake	155.5	163.5	209.5	
L	.L	With brake	180.5	188.5	234.5	
		LR	70	8	0	
S		S	22	3	5	
		LA	145	20	00	
		LB	110	114	4.3	
		LC	130	17	76	
LD		LD	165	23	33	
	LE		6	3.2		
LF		LF	12	18		
	LG			60		
		LH	116	140		
	М	Without brake	111.5	119.5	165.5	
L	IVI	With brake	136.5	144.5	190.5	
		LZ	9	13.5		
		LW	45	5	5	
Key way dimensions		LK	41	50		
Key way dimension:		KW	8h9	10h9		
ay	КН		7	8		
	RH		18	30		
Maar	$(k\alpha)$	Without brake	6.7	14.0	20.0	
was	s (kg)	With brake	8.2	17.5	23.5	
Con	nector	specifications	Refer to	P.2-49 "Specifications of Motor co	onnector"	

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page : P.1-21 "Check of the Model" · P.1-23 "Check of the Combination of the Driver and the Motor" · P.7-67 "S-T Characteristics"

MGME 900 W to 3.0 kW (DesignOrder: C)



			MGME series	(Middle inertia)				
	Motor output 900 W 2.0 kW 3.0 kW							
Motor	model	MGME	09 * * C *	20 * * C *	30 * * C *			
		Without brake	157.5	165.5	211.5			
	.L	With brake	182.5	190.5	236.5			
		LR	70	8	0			
S		S	22	3	5			
		LA	145	20	00			
		LB	110	114	4.3			
LC		LC	130	17	76			
LD		LD	165	23	33			
	LE		6	3.2				
LF		LF	12	18				
	LG		84					
		LH	116	140				
	N.4	Without brake	111.5	119.5	165.5			
	M	With brake	136.5	144.5	190.5			
		LZ	9	13.5				
		LW	45	5	5			
din Z		LK	41	50				
Key way imension	KW		8h9	10h9				
Key way dimensions		КН	7	8				
	RH		18	30				
Mag		Without brake	6.7	14.0	20.0			
ivias:	s (kg)	With brake	8.2	17.5	23.5			
Con	nector	specifications	Refer to	P.2-49 "Specifications of Motor co	onnector"			

Caution 🔅


Reduce the moment of inertia ratio if high speed response operation is required.

1

[Unit: mm]

5

MGME 4.5 kW, 6.0 kW



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

[Unit: mm]


	MGME series (Middle inertia)						
Motor output			4.5 kW	6.0 kW			
Motor	model	MGME	45 * * 1 *	60 * * 1 *			
		Without brake	266	312			
	L	With brake	291	337			
		LR	1'	13			
		S	4	2			
		LA	20	00			
		LB	11,	4.3			
		LC	17	76			
		LD	23	33			
	LE		3.2				
	LF		24				
		LG	60				
		LH	140 184				
	М	Without brake	222	268			
	IVI	With brake	247	293			
	-	LZ	13.5				
0		LW	9	6			
Key way KH		LK	90				
		KW	12h9				
ion:		КН	8				
N N		RH	37	0 -0.2			
Maa		Without brake	29.4	36.4			
was	s (kg)	With brake	33.0	40.4			
Con	nector	specifications	Refer to P.2-49 "Specifica	tions of Motor connector"			

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page : P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-68 "S-T Characteristics"

MHMD 200 W to 750 W



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

			MHMD serie	s (High inertia)	
	Moto	r output	200 W	400 W	750 W
Motor	model	MHMD	02 * * 1 *	04 * * 1 *	08 ** 1 *
		Without brake	99	118.5	164.2
LL		With brake	135.5	155	127.2
		LR	3	0	35
		S	11	14	19
		LA	7	0	90±0.2
		LB	5	0	70
LC		LC	6	0	80
LE					
LF			6.5		8
LH		LH	4	53	
LZ		LZ	4.5		6
Ļ D		LW	3	0	35
ロカット		LK	2	2	25
ΆŔ	RH		10	12.5	17.5
		LW	20	25	25
din K		LK	18	22.5	22
Key way imension		KW	4h9	5h9	6h9
Key way dimensions		КН	4	5	6
ns Y	RH		8.5	11	15.5
		TP	M4 depth 8	M5	depth 10
Mae	s (kg)	Without brake	0.96	1.4	2.5
Mass	5 (NB)	With brake	1.4	1.8	3.3
Con	nector	specifications	Refer to	P.2-48 "Specifications of Motor	connector"

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page : P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-69, 70 "S-T Characteristics" 1

Before Using the Products

2

Preparation


3

Connection

4

Setup

MHME 1.0 kW to 7.5 kW (DesignOrder: 1)



[Unit: mm]

* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MHME series (High inertia) Motor output 1.0 kW 1.5 kW 2.0 kW 3.0 kW 4.0 kW 5.0 kW 7.5 kW Motor model MHME 10 * * 1 * 15 * * 1 * 20 * * 1 * 30 * * 1 * 40 * * 1 * 50 * * 1 * 75 * * 1 * 209.5 Without brake 173 190.5 177 196 238.5 357 LL 202 With brake 198 215.5 221 234.5 263.5 382 LR 70 80 113 S 22 42 35 LA 200 145 LB 110 114.3 LC 130 176 LD 165 233 LE 6 3.2 LF 12 18 24 LG 60 LH 116 140 184 152 Without brake 129 146.5 194.5 133 165.5 313 LM With brake 171.5 158 177 190.5 219.5 338 154 LΖ 9 13.5 LW 45 55 96 dimensions Key LΚ 41 50 90 KW 8h9 10h9 12h9 way KH 7 8 18 RH 30 37 -0.2

Caution 🔅

Mass (kg)

Without brake

With brake

Connector specifications

6.7

8.1

Reduce the moment of inertia ratio if high speed response operation is required.

12.2

15.5

16.0

19.2

Refer to P.2-49 "Specifications of Motor connector"

18.6

21.8

23.0

26.2

42.3


46.2


Related page • P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-71, 72 "S-T Characteristics"


8.6

10.1

MHME 1.0 kW to 5.0 kW (DesignOrder: C)







	MHME series (High inertia)							
Motor output			1.0 kW	1.5 kW	2.0 kW	3.0 kW	4.0 kW	5.0 kW
Motor	model	МНМЕ	10 * * C *	15 * * C *	20 * * C *	30 * * C *	40 * * C *	50 * * C *
		Without brake	175	192.5	179	198	211.5	240.5
L	.L	With brake	200	217.5	204	223	236.5	265.5
		LR	7	0		8	0	
		S	2	2		3	5	
		LA	14	45		20	00	
		LB	1-	10		114	4.3	
		LC	1:	30		17	76	
LD		1(65	233				
LE			(6	3.2			
LF			1	2	18			
		LG	84					
		LH	1.	16	140			
	М	Without brake	129	146.5	133	152	165.5	194.5
	.1VI	With brake	154	171.5	158	177	190.5	219.5
		LZ	(9		13	8.5	
-		LW	4	5		5	5	
Key way dimensions		LK	4	1	50			
Key way dimension:		KW	81	h9	10h9			
ay ons		KH	-	7		8		
		RH	1	8		3	0	
Mase	s (kg)	Without brake	6.7	8.6	12.2	16.0	18.6	23.0
10103	- (NB)	With brake	8.1	10.1	15.5	19.2	21.8	26.2
Con	nector	specifications		Refer to	P.2-49 "Specifica	tions of Motor co	onnector"	

Caution 🔅

Reduce the moment of inertia ratio if high speed response operation is required.

Related page …

P.1-21 "Check of the Model"
P.1-23 "Check of the Combination of the Driver and the Motor"
P.7-71, 72 "S-T Characteristics"

[Unit: mm]

1

Before Using the Products

2

Preparation

3

5

Supplement


7. Options

Noise Filter

When you install one noise filter at the power supply for multi-axes application, contact to a manufacture of the noise filter. If noise margin is required, connect 2 filters in series to emphasize effectiveness.


Options

Option part No.	Voltage specifications for driver	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
DV0P4170	Single phase 100 V, 200 V	SUP-EK5-ER-6	A and B-frame	Okaya Electric Ind.




Option part No.	Voltage specifications for driver	specifications Manufacturer's		Manufacturer	
	3-phase 200 V		A and B-frame		
DV0PM20042	Single phase 100 V, 200 V 3-phase 200 V	3SUP-HU10-ER-6	C-frame	Okaya Electric Ind.	
DV0P4220	Single/3-phase 200 V	3SUP-HU30-ER-6	D-frame		
DV0PM20043	3-phase 200 V	3SUP-HU50-ER-6	E-frame		

[DV0PM20042, DV0P4220]



Related page P.2-2 "Conformance to international standards" • P.2-10 "Driver and List of Applicable Peripheral Equipments"




Recommended components


Part No.	Voltage specifications for driver	Current rating (A)	Applicable driver (frame)	Manufacturer
RTHN-5010	Single phase	10	A, B, C-frame	
RTHN-5030	100 V, 200 V	30	D-frame	TDK-Lambda Corp.
RTHN-5050	3-phase 200 V	50	E, F-frame	


[RTHN-5030]

[Unit: mm]


[RTHN-5010]







[RTHN-5050]



Remarks 🔅


- Select a noise filter of capacity that exceeds the capacity of the power source (also check for load condition).
- · For detailed specification of the filter, contact the manufacturer.

Caution Use options correctly after reading operation manuals of the options to better understand the precautions. Take care not to apply excessive stress to each optional part.

Before Using the Products


part No.	Voltage specifications for driver	Current rating (A)	Applicable driver (frame)	Manufacturer	
FS5559-60-34	3-phase 200 V	60	G-frame		
FS5559-80-34	S-phase 200 V	80	H-frame		
FN258L-16-07		16	D, E-frame	Schaffner	
FN258L-30-07		30	F-frame	Schanner	
FN258-42-07	3-phase 400 V	42			
FN258-42-33		42	G, H-frame		


[FS5559-60-34, FS5559-80-34]




[Size]				
		Α	В	С	D
	FS5559-60-34	410	170	370	388
ſ	FS5559-80-34	460	180	420	438


Circuit diagram

























- Select a noise filter of capacity that exceeds the capacity of the power source (also check for load condition).
- For detailed specification of the filter, contact the manufacturer.

Caution Use options correctly after reading operation manuals of the options to better understand the precautions. Take care not to apply excessive stress to each optional part.

1

Before Using the Products

2

Preparation


5

6


Surge Absorber

Provide a surge absorber for the primary side of noise filter.

Option Voltage specifications for driver		Manufacturer's part No.	Manufacturer
DV0P1450	3-phase 200 V	R∙A∙V-781BXZ-4	Okova Electric Ind
DV0PM20050	3-phase 400 V	R∙A∙V-801BXZ-4	Okaya Electric Ind.




Circuit diagram



Option part No. Voltage specifications for driver		Manufacturer's part No.	Manufacturer	
DV0P4190	Single phase 100 V, 200 V	R·A·V-781BWZ-4	Okaya Electric Ind.	

..5±0.5



Remarks 🔅

Take off the surge absorber when you execute a dielectric test to the machine or equipment, or it may damage the surge absorber.

Related page · P.2-2 "Conformance to international standards" • P.2-10 "Driver and List of Applicable Peripheral Equipments"

Supplement


7. Options Noise Filter for Signal Lines

Install noise filters for signal lines to all cables (power cable, motor cable, encoder cable and interface cable)

Options

<24 V Power cable, Motor cable, Encoder cable, Interface cable, USB cable>

Option part No.	Manufacturer's part No.	Manufacturer
DV0P1460	ZCAT3035-1330	TDK Corp.





Remarks 🔅 To connect the noise filter to the connector XB connection cable, adjust the sheath length at the tip of the cable, as required.

Recommended components

<Power cable>

Part No.	Applicable driver (frame)	Manufacturer
RJ8035	E-frame 200 V, F-frame 200 V	
RJ8095	G-frame, H-frame	KK-CORP.CO.JP






Manufacturer's	Current	100kHz	Dimension [Unit: mm]							
part No.	value	(µH)	Α	В	С	D1	D2	Core thikness	E	F
RJ8035	35 A	9.9±3	170	150	23	80	53	24	R3.5	7
RJ8095	95 A	7.9±3	200	180	34	130	107	35	R3.5	7

<Motor cable>

Part No.	Applicable driver (frame)	Manufacturer
T400-61D	G-frame, H-frame	MICROMETALS



[Unit: mm]

Remarks \Rightarrow Fix the signal line noise filter in place to eliminate excessive stress to the cables.

1


5

Setup

6




Junction Cable for Encoder



7-100 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Junction Cable for Encoder


	MFECA0 * * 0MJE (Highly bendable type, Direction of motor shaft)		
Devit Ne	MFECA0 * * 0MKE (Highly bendable type, Opposite direction of motor shaft)	Compatible	MSME
Part No.	MFECA0 * * 0TJE (Standard bendable type, Direction of motor shaft)	motor output	50 W to 750 W (200 V)
	MFECA0 * * 0TKE (Standard bendable type, Opposite direction of motor shaft)		
Specifications	For 17-bit absolute encoder (With battery box)	·	



Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 2M *1	3	MFECA0030MJE
Shell kit	3E306-3200-008	Sumitomo 3M *1	5	MFECA0050MJE
Connector	ZMR-02		10	MFECA0100MJE
Connector pin	SMM-003T-P0.5	J.S.T Mfg. Co., Ltd.	20	MFECA0200MJE
Connector	JN6FR07SM1	Japan Aviation		
Connector pin	LY10-C1-A1-10000	Electronics Ind.		
Cable	AWG24 ×4P, AWG22×2P	Hitachi Cable, Ltd.		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	MFECA0 * * 0ETD	Compatible motor output	400 W (400 V), 600 W (400 V), 750 W (400 V), 0.9 kW to 15.0 kW					
Specifications	For 20-bit incremental encoder (Without battery box), Design order: 1							
			[Unit: mm]					



Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M *1	3	MFECA0030ETD
Shell kit	3E306-3200-008		5	MFECA0050ETD
Connector	JN2DS10SL1-R	Japan Aviation	10	MFECA0100ETD
Connector pin	JN1-22-22S-PKG100	Electronics Ind.	20	MFECA0200ETD
Cable	0.2 mm ² ×3P	Oki Electric Cable Co., Ltd.		


*1 Old model number: 55100-0670 (Japan Molex Inc.)

Caution 🔅 Option cable does not conform to IP65 and IP67.

Related page • P.1-29 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

1

6



Caution \Rightarrow Option cable does not conform to IP65 and IP67.

Cable

*1 Old model number: 55100-0670 (Japan Molex Inc.)


0.2 mm² ×4P (8-wire type)

Oki Electric Cable Co., Ltd.

Supplement


Junction Cable for Motor (Without brake)


Part No.	MFMCA0 * * 0EED	Applicable model	MSMD	50 W to 750 W,	MHMD	200 W to 750 W	
----------	-----------------	------------------	------	----------------	------	----------------	--



7. Options

Title	Part No.	Manufacturer	L (m)	Part No.
Connector	172159-1	Tugo Electronico	3	MFMCA0030EED
Connector pin	170366-1	Tyco Electronics	5	MFMCA0050EED
Rod terminal	AI0.75-8GY	Phoenix Contact	10	MFMCA0100EED
Nylon insulated round terminal	N1.25-M4	J.S.T Mfg. Co., Ltd.	20	MFMCA0200EED
Cable	ROBO-TOP 600 V 0.75 mm ² 4-wire type	Daiden Co.,Ltd.		





Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JN8FT04SJ1	Japan Aviation	3	MFMCA0030NJD
Connector pin	ST-TMH-S-C1B-3500	Electronics Ind.	5	MFMCA0050NJD
Rod terminal	AI0.75-8GY	Phoenix Contact	10	MFMCA0100NJD
Nylon insulated round terminal	N1.25-M4	J.S.T Mfg. Co., Ltd.	20	MFMCA0200NJD
Cable	AWG18×4P	Hitachi Cable, Ltd.		

Caution ··· Option cable does not conform to IP65 and IP67. Related page ··· P.1-29 "Junction cable for motor" · P.2-48 "Specifications of Motor connector" Before Using the Products

2

Preparation

3

Connection

4

Setup

5


Adjustment

6


When in Trouble

[Unit: mm]

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 7-103



Title	Part No.	Manufacturer	L (m)	Part No.	
Connector	JL04V-6A20-4SE-EB-R	Japan Aviation	3	MFMCD0032ECD	
Cable clamp	JL04-2022CK(14)-R	Electronics Ind.	5	MFMCD0052ECD	
Rod terminal	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCD0102ECD	
Nylon insulated round terminal	N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCD0202ECD	
Cable	ROBO-TOP 600 V 2.0 mm ²	Daiden Co.,Ltd.			




Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A22-22SE-EB-R	Japan Aviation	3	MFMCE0032ECD
Cable clamp	JL04-2022CK(14)-R	Electronics Ind.	5	MFMCE0052ECD
Rod terminal	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCE0102ECD
Nylon insulated round terminal	N2-M4 J.S.T Mfg. Co., Ltd.		20	MFMCE0202ECD
Cable	ROBO-TOP 600 V 2.0 mm ²	Daiden Co.,Ltd.		

Part No.	MFMCA0 * * 3ECT	Applicable model		3.0 kW to 5.0 kW, 3.0 kW to 5.0 kW,		
		۲ (¢14)	(50)			[Unit: mm]

Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A22-22SE-EB-R	Japan Aviation	3	MFMCA0033ECT
Cable clamp	JL04-2022CK(14)-R	Electronics Ind.	5	MFMCA0053ECT
Nylon insulated	N5.5-5		10	MFMCA0103ECT
round terminal	al N5.5-5 J.S.T Mfg. Co., Ltd.		20	MFMCA0203ECT
Cable	ROBO-TOP 600 V 3.5 mm ²	Daiden Co.,Ltd.		

Caution Option cable does not conform to IP65 and IP67.

Related page • P.1-29 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A24-11SE-EB-R	Japan Aviation	3	MFMCA0033ECT
Cable clamp	JL04-2428CK(17)-R	Electronics Ind.	5	MFMCA0053ECT
Nylon insulated	N5.5-5		10	MFMCA0103ECT
round terminal	N5.5-5 J.S.T Mfg. Co., Ltd.		20	MFMCA0203ECT
Cable	ROBO-TOP 600 V 3.5 mm ²	Daiden Co.,Ltd.		

7

Supplement

Caution Option cable does not conform to IP65 and IP67.


Related page • P.1-29 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"



Junction Cable for Motor (With brake)

Part No. MFMCA		Applicable model	MDME MFME MHME	1.0 kW to 2.0 kW (200 V) 1.0 kW to 2.0 kW (200 V) 1.5 kW (200 V) 1.0 kW to 1.5 kW (200 V) 0.9 kW (200 V)
----------------	--	---------------------	----------------------	--


[Unit: mm]



Title		Part No.	Manufacturer	L (m)	Part No.
Connector		JL04V-6A20-18SE-EB-R	Japan Aviation	3	MFMCA0032FCD
Cable clam	p	JL04-2022CK(14)-R	Electronics Ind.	5	MFMCA0052FCD
Rod termina	al	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCA0102FCD
Nylon insulated	Earth	N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCA0202FCD
round terminal	Brake	N1.25-M4	J.S.T Wig. Co., Ltd.		
Cable		ROBO-TOP 600 V 0.75 mm ² and ROBO-TOP 600 V 2.0 mm ²	Daiden Co.,Ltd.		

Part No.	MFMCE0 * * 2FCD	Applicable model	MDME MFME MGME	750 W to 2.0 kW (400 V) 400 W to 2.0 kW (400 V) 1.5 kW (400 V), 2.5 kW 0.9 kW (400 V) 1.0 kW (400 V), 1.5 kW (400 V), 2.0 kW
----------	-----------------	---------------------	----------------------	--

[Unit: mm]



Title		Part No.	Manufacturer	L (m)	Part No.
Connector		JL04V-6A24-11SE-EB-R	Japan Aviation	3	MFMCE0032FCD
Cable clam	р	JL04-2428CK(17)-R	Electronics Ind.	5	MFMCE0052FCD
Rod termina	al	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCE0102FCD
Nylon insulated	Earth	N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCE0202FCD
round terminal	Brake	N1.25-M4	J.S.T WIG. CO., LIU.		
Cable		ROBO-TOP 600 V 0.75 mm ² and ROBO-TOP 600 V 2.0 mm ²	Daiden Co.,Ltd.		

Caution 🔅 Option cable does not conform to IP65 and IP67.

Related page • P.1-29 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

Junction Cable for Motor (With brake)

Part No.	MFMCA0 * * 3FCT	Applicable model	MFME	3.0 kW to 5.0 kW, 4.5 kW, 2.0 kW to 4.5 kW	3.0 kW to 5.0 kW 3.0 kW to 5.0 kW	
						[Unit: mm]

Title		Part No.	Manufacturer	L (m)	Part No.
Connector		JL04V-6A24-11SE-EB-R	Japan Aviation	3	MFMCA0033FCT
Cable clam	p	JL04-2428CK(17)-R	Electronics Ind.	5	MFMCA0053FCT
Nylon insulated	Earth	N5.5-5	J.S.T Mfg. Co., Ltd.	10	MFMCA0103FCT
round terminal	Brake	N1.25-M4	5.5.1 Wilg. Co., Ltd.	20	MFMCA0203FCT
Cable		ROBO-TOP 600 V 0.75 $\rm mm^2 and$ ROBO-TOP 600 V 3.5 $\rm mm^2$	Daiden Co.,Ltd.		



1

Before Using the Products

2

Preparation

3

Connection

4

Setup


5

Adjustment




Junction Cable for Brake


Part No.	MFMCB0 * * 0GET	Applicable model	MSMD	50 W to 750 W,	MHMD	200 W to 750 W	
							[Unit: mm]
	ľ	(40)	L		(50)		



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	172157-1	Tugo Electronico	З	MFMCB0030GET
Connector pin	170366-1, 170362-1	Tyco Electronics	5	MFMCB0050GET
Nylon insulated	N1.25-M4	J.S.T Mfg. Co., Ltd.	10	MFMCB0100GET
round terminal	IN 1.23-1014	5.5.1 Mig. Co., Liu.	20	MFMCB0200GET
Cable	ROBO-TOP 600 V 0.75 mm ² ×2-wire	Daiden Co.,Ltd.		
Cable	type	Daiuen CO.,Llu.		



0



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JN4FT02SJMR	Japan Aviation	3	MFMCB0030PJT
Connector pin	ST-TMH-S-C1B-3500	Electronics Ind.	5	MFMCB0050PJT
Nylon insulated	N1.25-M4		10	MFMCB0100PJT
round terminal	IN 1.23-MI4	J.S.T Mfg. Co., Ltd.	20	MFMCB0200PJT
Cable	AWG22	Hitachi Cable, Ltd.		

Identification label

Caution ··· Option cable does not conform to IP65 and IP67. Related page ··· • P.1-29 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

Connector Kit

Connector Kit for Interface




Components

Title	Part No.	Number	Manufacturer	Note
Connector	10150-3000PE equivalent	1	Sumitomo 3M *1	For Connector X4
Connector cover	10350-52A0-008 equivalent	1	Sumitorno Sivi	(50-pins)

*1 Old model number: Connector 54306-5019, Connector cover 54331-0501 (Japan Molex Inc.)


· Pin disposition (50 pins) (viewed from the soldering side)



1) Check the stamped pin-No. on the connector body while making a wiring.

- 2) For the function of each signal title or its symbol, refer to the wiring example of the connector X4.
- 3) Do not connect anything to NC pins in the above table.

Interface Cable



This 2 m connector cable contains AWG28 conductors.

Table for wiring

Pin No.	color	Pin No.	color	Pin No.	color	Pin No.	color	Pin No.	color
1	Orange (Red1)	11	Orange (Black2)	21	Orange (Red3)	31	Orange (Red4)	41	Orange (Red5)
2	Orange (Black1)	12	Yellow (Black1)	22	Orange (Black3)	32	Orange (Black4)	42	Orange (Black5)
3	Gray (Red1)	13	Gray (Red2)	23	Gray (Red3)	33	Gray (Red4)	43	Gray (Red5)
4	Gray (Black1)	14	Gray (Black2)	24	Gray (Black3)	34	White (Red4)	44	White (Red5)
5	White (Red1)	15	White (Red2)	25	White (Red3)	35	White (Black4)	45	White (Black5)
6	White (Black1)	16	Yellow (Red2)	26	White (Black3)	36	Yellow (Red4)	46	Yellow (Red5)
7	Yellow (Red1)	17	Yel (Blk2)/Pink (Blk2)	27	Yellow (Red3)	37	Yellow (Black4)	47	Yellow (Black5)
8	Pink (Red1)	18	Pink (Red2)	28	Yellow (Black3)	38	Pink (Red4)	48	Pink (Red5)
9	Pink (Black1)	19	White (Black2)	29	Pink (Red3)	39	Pink (Black4)	49	Pink (Black5)
10	Orange (Red2)	20	-	30	Pink (Black3)	40	Gray (Black4)	50	Gray (Black5)

<Remarks>

Color designation of the cable e.g.) Pin-1 Cable color : Orange (Red1) : One red dot on the cable The shield of this cable is connected to the connector shell but not to the terminal.

Before Using the Products

2

Preparation


Connector Kit for Communication Cable (for RS485, RS232)


Part No. DV0PM20024

Components

Title	Part No.	Manufacturer	Note
Connector	2040008-1	Tyco Electronics	For Connector X2 (8-pins)

Pin disposition of connector, connector X2





[Unit: mm]

Connector Kit for Safety


Part No. DV0PM20025

Components

Title	Part No.	Manufacturer	Note
Connector	2013595-1	Tyco Electronics	For Connector X3 (8-pins)

Dimensions

Pin disposition of connector, connector X3



	±
(06.7	5.2

[Unit: mm]


Safety bypass plug

Part No. DV0PM20094

Components

Title	Part No.	Manufacturer	Note
Connector	CIF-PB08AK-GF1R	J.S.T Mfg. Co., Ltd.	For Connector X3
 Internal wiring 		Dimensions (Resin color	: black) [Unit: mm]

(Wiring of the following has been applied inside the plug.)





24

A design and color may vary from the plug provided together with driver. There is no difference in function.

Remarks : • Connector X1: use with commercially available cable. • Configuration of connector X1: USB mini-B




 For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".


Connector Kit for External Scale


Part No. DV0PM20026

Components

Title	Part No.	Manufacturer	Note
Connector	MUF-PK10K-X	J.S.T Mfg. Co., Ltd.	For Connector X5







37 4

33.0


4.5

Connector Kit for Encoder

Part No. DV0PM20010

Components

Title	Part No.	Manufacturer	Note	
Connector	3E206-0100 KV	Sumitomo 3M *1	For Connector X6	
Shell kit	3E306-3200-008			
*1 Old model number: 55100				
Pin disposition of cor	nector, connector X6 •	Dimensions	[Unit: mm]	
	<	Shell kit>	<connector></connector>	




*1 Do not connect anything to NC pins.

Connector Kit for Analog Monitor Signal

Part No. DV0PM20031

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	510040600	1	Moley Inc	For Connector V7 (C nine)
Connector pin	500118100	6	Molex Inc	For Connector X7 (6-pins)



Remarks ·· For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

Preparation

[Unit: mm]

5

Supplement

Connector Kit for Power Supply Input

Part No. DV0PM20032 (For A to D-frame: Single row type)

Components


Title	Part No.	Number	Manufacturer	Note
Connector	05JFAT-SAXGF	1		For Connector VA
Handle lever	J-FAT-OT	2	J.S.T Mfg. Co., Ltd.	For Connector XA

Part No. DV0PM20033 (For A to D-frame: double row type)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	05JFAT-SAXGSA-C	1		For Connector XA
Handle lever	J-FAT-OT	2	J.S.T Mfg. Co., Ltd.	FOI CONNECTOR XA

Dimensions



* When connecting multiple axes in series, make sure the sum of the current value does not exceed the rated current (11.25 A) of DV0PM20033.

Remarks 🔅

When using drivers MDDKT5540 *** or MDDHT5540 *** in single-phase power supply, do not use DV0PM20033.

Driver part No.	Power supply	Rated input current
MADHT1105 *** MADKT1105 ***	Single phase 100 V	1.7 A
MADHT1107 *** MADKT1107 ***	Single phase 100 V	2.6 A
MADHT1505 *** MADKT1505 ***	Single phase/3-phase 200 V	1.6 A/0.9 A
MADHT1507 *** MADKT1507 ***	Single phase/3-phase 200 V	2.4 A/1.3 A
MBDHT2110 *** MBDKT2110 ***	Single phase 100 V	4.3 A
MBDHT2510 *** MBDKT2510 ***	Single phase/3-phase 200 V	4.1 A/2.4 A
MCDHT3120 *** MCDKT3120 ***	Single phase 100 V	7.6 A
MCDHT3520 *** MCDKT3520 ***	Single phase/3-phase 200 V	6.6 A/3.6 A
MDDHT3530 *** MDDKT3530 ***	Single phase/3-phase 200 V	9.1 A/5.2 A
MDDHT5540 *** MDDKT5540 ***	Single phase/3-phase 200 V	14.2 A/8.1 A

Part No. DV0PM20044 (For E-frame 200 V)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	05JFAT-SAXGSA-L	1		For Connector VA
Handle lever	J-FAT-OT-L	2	J.S.T Mfg. Co., Ltd.	For Connector XA

Part No. DV0PM20053 (For D-frame 400 V, E-frame 400 V and 24 V Input power)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	02MJFAT-SAGF	1		For Connector VD
Handle lever	MJFAT-OT	2	J.S.T Mfg. Co., Ltd.	For Connector XD

Part No. DV0PM20051 (For D-frame 400 V)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAYGSA-M	1	J.S.T Mfg. Co., Ltd.	For Connector XA
Handle lever	J-FAT-OT-L	2		

Part No.	DV0PM20052 (For E-frame 400 V)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAYGSA-L	1		For Connector VA
Handle lever	J-FAT-OT-L	2	J.S.T Mfg. Co., Ltd.	For Connector XA

Connector Kit for Regenerative Resistor Connection (E-frame)

Part No. DV0PM20045 (For E-frame)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	04JFAT-SAXGSA-L	1		For Connector XC
Handle lever	J-FAT-OT-L	2	J.S.T Mfg. Co., Ltd.	For Connector XC

Part No. DV0PM20055 (For D-frame 400 V)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	04JFAT-SAXGSA-M	1		For Connector VC
Handle lever	J-FAT-OT-L	2	J.S.T Mfg. Co., Ltd.	For Connector XC

Connector Kit for Motor Connection

Part No. DV0PM20034 (For A to D-frame)

Components

Title	Part No.	Number	Manufacturer	Note
Connector	06JFAT-SAXGF	1		For Connector XB
Handle lever	J-FAT-OT	2	J.S.T Mfg. Co., Ltd.	

Part No. DV0PM20046 (For E-frame)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAXGSA-L	1		For Connector XB
Handle lever	J-FAT-OT-L	2	J.S.T Mfg. Co., Ltd.	For Connector XB

Part No. DV0PM20054 (For D-frame 400 V)


Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAXGSA-M	1		For Connector VD
Handle lever	J-FAT-OT-L	2	J.S.T Mfg. Co., Ltd.	For Connector XB

1

Connection

Connector Kit for Motor/Encoder Connection





Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1	Sumitomo Sivi	For Connector X6 (6-pins)
Connector	172160-1	1	Tugo Electropico	For Encoder cable
Connector pin	170365-1	6	Tyco Electronics	(6-pins)
Connector	172159-1	1	Tugo Electropico	For Motor cable
Connector pin	170366-1	4	Tyco Electronics	(4-pins)


*1 Old model number: 55100-0670 (Japan Molex Inc.)


· Pin disposition of connector, connector X6





· Pin disposition of connector for motor cable





Part No. DV0PM20035

Applicable MSME 50 W to 750 W model

Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	For Connector X6 (6-pins)
Shell kit	Shell kit 3E306-3200-008		Sumilomo Sivi	
Encoder plug connector	JN6FR07SM1	1	Japan Aviation	For Encoder cable
Socket contact	LY10-C1-A1-10000	7	Electronics Ind.	(7-pins)
Motor plug connector	JN8FT04SJ1	1	Japan Aviation	For Motor cable
Socket contact ST-TMH-S-C1B-3500		4	Electronics Ind.	(4-pins)

*1 Old model number: 55100-0670 (Japan Molex Inc.) · Pin disposition of connector, Pin disposition of connector Pin disposition of connector for motor cable connector X6 for encoder cable [Direction of motor shaft] Gasket 4 PS 1 U 7 PS 1 E5V 2 E0V Gasket 2 V 3 E0V 6 E5V 3 NC*1 4 NC*1 зW 2 BAT $6 \overline{PS}$ 5 PS PE E 1 FG 5 BAT+ Do not connect (Case FG [Opposite direction of motor shaft] anything to NC pins. Gasket 1 FG PE E 5 BAT+ Gasket 2 BATзW Remarks 🔅 6 E5V 2 V Secure the gasket in place 3 E0V without removing it from the 1 U 4 <u>PS</u> 7 PS connector. Otherwise, the degree of protection of IP67 will not be * Pins 2 and 5 are left unused (NC) guaranteed. with an incremental encoder. Caution 🔅 When IP65 or IP67 are necessary, the customer must give approriate processing.

Remarks 🔅 · For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

7-114 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

7. Options Connector Kit

Part No.	DV0PM20036		<ip67 motor=""></ip67>	
	DV0F1020030	Applicable	MSME 750 W (400 V), 1.0 kW to 2.0 kW,	Without
Specifications	Design order: 1	model	MDME 400 W (400 V), 600 W (400 V), 1.0 kW to 2.0 kW MHME 1.0 kW to 1.5 kW. MGME 0.9 kW	brake

Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		For Connector X6 (8-pins)
Encoder connector	JN2DS10SL1-R	1	Japan Aviation	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5	Electronics Ind.	FOI Encoder cable
Motor connector	JL04V-6A-20-4SE-EB-R	1	Japan Aviation	For Motor cable
Cable clamp	JL04-2022CK(14)-R	1	Electronics Ind.	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4310	Applicable	<ip65 motor=""> MSME 1.0 kW to 2.0 kW,</ip65>	Without
Specifications		model	MDME 400 W (400 V), 600 W (400 V), 1.0 kW to 2.0 kW MHME 1.0 kW to 1.5 kW, MGME 0.9 kW	brake

\cdot Components

Part No.	Number	Manufacturer	Note	
3E206-0100 KV	1	Sumitomo 2M *1	For Connector X6 (6-pins)	
3E306-3200-008	1			
N/MS3106B20-29S	1	Japan Aviation	For Encoder cable	
N/MS3057-12A	1	Electronics Ind.	For Encoder cable	
N/MS3106B20-4S	1	Japan Aviation	For Motor cable	
N/MS3057-12A	1	Electronics Ind.	For Motor cable	
	3E206-0100 KV 3E306-3200-008 N/MS3106B20-29S N/MS3057-12A N/MS3106B20-4S	3E206-0100 KV 1 3E306-3200-008 1 N/MS3106B20-29S 1 N/MS3057-12A 1 N/MS3106B20-4S 1	3E206-0100 KV 1 Sumitomo 3M *1 3E306-3200-008 1 Sumitomo 3M *1 N/MS3106B20-29S 1 Japan Aviation N/MS3106B20-4S 1 Electronics Ind. N/MS3106B20-4S 1 Japan Aviation	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0PM20037	Applicable	<ip67 n<br="">MSMF</ip67>	notor> 3.0 kW to 5.0 kW,	MDMF	3.0 kW to 5.0 kW	Without
Specifications	Design order: 1	model		2.0 kW to 5.0 kW,			brake

Components

Title	Part No.	Number	Manufacturer	Note	
Connector (Driver side)	3E206-0100 KV	3E206-0100 KV 1 Sumitomo 3M *1 For Connector X6 (6-		For Connector V6 (6 pipe)	
Shell kit	3E306-3200-008	1	Sumitomo Sivi	For Connector X6 (6-pins)	
Encoder connector	JN2DS10SL1-R	1	Japan Aviation	For Encoder cable	
Connector pin	JN1-22-22S-PKG100	5	Electronics Ind.	For Encoder cable	
Motor connector	JL04V-6A22-22SE-EB-R	1	Japan Aviation	For Motor cable	
Cable clamp	JL04-2022CK(14)-R	1	Electronics Ind.	For Motor Cable	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4320	Applicable	<ip65 n<br="">MSMF</ip65>	notor> 3.0 kW to 5.0 kW,	MDME	3.0 kW to 5.0 kW	Without
Specifications	Design order: C	model		2.0 kW to 5.0 kW,			brake

$\boldsymbol{\cdot} \text{ Components}$

Part No.	Number	Manufacturer	Note	
3E206-0100 KV	1	Sumitomo 2M *1	For Connector X6 (6-pins)	
3E306-3200-008	1	Sumilomo Sivi		
N/MS3106B20-29S	1	Japan Aviation	For Freedor coble	
N/MS3057-12A	1	Electronics Ind.	For Encoder cable	
N/MS3106B22-22S	1	Japan Aviation		
N/MS3057-12A	1	Electronics Ind.	For Motor cable	
	3E206-0100 KV 3E306-3200-008 N/MS3106B20-29S N/MS3057-12A N/MS3106B22-22S	3E206-0100 KV 1 3E306-3200-008 1 N/MS3106B20-29S 1 N/MS3057-12A 1 N/MS3106B22-22S 1	3E206-0100 KV 1 Sumitomo 3M *1 3E306-3200-008 1 Japan Aviation N/MS3106B20-29S 1 Japan Aviation N/MS3057-12A 1 Electronics Ind. N/MS3106B22-22S 1 Japan Aviation	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Caution 🔅 Remarks 🔅 When IP65 or IP67 are necessary, the customer must give approriate processing.

 For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com 7-115

1

6

When in Trouble

Part No.	DV0PM20038	Applicable	<ip67 motor=""> MSME 1.0 kW to 2.0 kW (200 V), MDME 1.0 kW to 2.0 kW (200 V),</ip67>	With
Specifications	Design order: 1	model	MFME 1.5 kW (Common to with/without brake) (200 V), MFME 1.5 kW (Common to with/without brake) (200 V), MHME 1.0 kW to 1.5 kW (200 V), MGME 0.9 kW (200 V)	brake

Components

Title	Part No.	Number	Manufacturer	Note	
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	For Connector V6 (6 pine)	
Shell kit	3E306-3200-008	1	Sumilomo Sivi	For Connector X6 (6-pins)	
Encoder connector	JN2DS10SL1-R	1	Japan Aviation	For Encoder cable	
Connector pin	JN1-22-22S-PKG100	5	Electronics Ind.	FOI Elicodel cable	
Motor connector	JL04V-6A20-18SE-EB-R	1	Japan Aviation	For Motor cable	
Cable clamp	JL04-2022CK(14)-R	'		FOI MOLOI CADIE	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4330	Applicable	<ip65 motor=""> MSME 1.0 kW to 2.0 kW,</ip65>	With
Specifications	Design order: C	model	MDME 400 W (400 V), 600 W (400 V), 1.0 kW to 2.0 kW MHME 1.0 kW to 1.5 kW, MGME 0.9 kW	brake

Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitama 2M *1	For Connector V6 (6 pipe)
Shell kit	3E306-3200-008	Sumitomo 3M *1 For Connector 3		For Connector X6 (6-pins)
Encoder connector	N/MS3106B20-29S	1	Japan Aviation	For Encoder cable
Cable clamp	N/MS3057-12A	1	Electronics Ind.	FOI ETICOUEI Cable
Motor connector	N/MS3106B20-18S	1	Japan Aviation	For Motor cable
Cable clamp	N/MS3057-12A	1	Electronics Ind.	FOI MOLOI Cable

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0PM20039	Applicable	<ip67 motor=""> MSME 750 W to 2.0 kW (400 V), 3.0 kW to 5.0 kW MDME 400 W to 2.0 kW (400 V), 3.0 kW to 5.0 kW</ip67>	With
Specifications	Design order: 1	model	MFME 1.5 kW (400 V), 2.5 kW to 4.5 kW (Common to with/without brake) MHME 1.0 kW to 1.5 kW (400 V), 2.0 kW to 5.0 kW MGME 0.9 kW (400 V), 2.0 kW to 4.5 kW	brake

Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV			For Connector V6 (6 pine)
Shell kit	3E306-3200-008	1	Sumitomo Sivi	For Connector X6 (6-pins)
Encoder connector	JN2DS10SL1-R	1	Japan Aviation	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5	Electronics Ind.	FOI Elicodel cable
Motor connector	JL04V-6A24-11SE-EB-R	1	Japan Aviation	For Motor cable
Cable clamp	JL04-2428CK(17)-R	1	Electronics Ind.	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4340	Applicable	<ip65 motor=""> MSME 3.0 kW to 5.0 kW, MDME 3.0 kW to 5.0 kW</ip65>	With
Specifications	Design order: C	model	MHME 2.0 kW to 5.0 kW, MGME 2.0 kW to 3.0 kW	brake

Components

Title Part No. Nu		Number	Manufacturer	Note	
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	Ear Connector V6 (6 pipe)	
Shell kit	3E306-3200-008	1	Sumitorno Sivi	For Connector X6 (6-pins)	
Encoder connector	N/MS3106B20-29S	1	Japan Aviation		
Cable clamp	N/MS3057-12A	1	Electronics Ind.	For Encoder cable	
Motor connector	N/MS3106B24-11S	1	Japan Aviation		
Cable clamp	N/MS3057-16A	1	Electronics Ind.	For Motor cable	

	Caution 🔅 🔸 Wh
--	----------------

When IP65 or IP67 are necessary, the customer must give approriate processing.

· For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer Remarks 🔅 or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

7-116 Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com

Part No.	DV0PM20056	Applicable	<ip67 motor=""> MDME 7.5 kW to 15.0 kW</ip67>	Without
Specifications	Design order: 1	model	MGME 6.0 kW, MHME 7.5 kW	brake

· Components

Title	Part No.		Manufacturer	Note	
Connector (Driver side)	3E206-0100 KV	1 Sumitomo 3M *1		For Connector V6 (6 pipe)	
Shell kit	3E306-3200-008	1	Sumitomo Sivi	For Connector X6 (6-pins)	
Encoder connector	JN2DS10SL1-R	1	Japan Aviation	For Encoder cable	
Connector pin	JN1-22-22S-PKG100	5	Electronics Ind.	FOI Elicodel cable	
Motor connector	JL04V-6A32-17SE-EB-R	1	Japan Aviation	For Motor cable	
Cable clamp	JL04-32CK(24)-R *2	1	Electronics Ind.	FOI MOLOI CADIE	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

*2 Cable cover size: Φ22 to Φ25. Cable core material is not specified. The user can select the cable compatible with the connector to be used.

Part No.	DV0PM20057	Applicable	<ip67 motor=""></ip67>	With
Specifications	Design order: 1	model	MDME 7.5 kW to 15.0 kW MGME 6.0 kW, MHME 7.5 kW	brake

Components

Title	Part No.	Number	Manufacturer	Note	
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	For Connector X6 (6-pins)	
Shell kit	3E306-3200-008	1	Sumilomo 3ivi	For Connector X6 (6-pins)	
Encoder connector	JN2DS10SL1-R	1	Japan Aviation	Far Freeder coble	
Connector pin	JN1-22-22S-PKG100	5	Electronics Ind.	For Encoder cable	
Motor connector	JL04V-6A32-17SE-EB-R	1	Japan Aviation		
Cable clamp	JL04-32CK(24)-R *2	1	Electronics Ind.	For Motor cable	
Brake connector	N/MS3106B14S-2S	1	Japan Aviation		
Cable clamp	N/MS3057-6A	1	Electronics Ind.	For Brake cable	

*1 Old model number: 55100-0670 (Japan Molex Inc.)

*2 Cable cover size: Φ22 to Φ25. Cable core material is not specified. The user can select the cable compatible with the connector to be used.

Connector Kit for Motor/Brake Connection


Part No.	DV0PM20040
----------	------------

Applicable MSME 50 W to 750 W

Components

Title	Part No.	Number	Manufacturer	Note
Connector	JN4FT02SJM-R	1	Japan Aviation	
Socket contact	ST-TMH-S-C1B-3500	2	Electronics Ind.	

· Pin disposition of connector for brake cable



Remarks \Rightarrow Secure the gasket in place without removing it from the connector. Otherwise, the degree of protection of IP67 will not be guaranteed.

Caution 🔅 •

• When IP65 or IP67 are necessary, the customer must give approriate processing.

Remarks ↔ • For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

2

Preparation




Battery For Absolute Encoder

Battery For Absolute Encoder



Lithium battery: 3.6 V 2000 mAh





Caution This battery is categorized as hazardous substance, and you may be required to present an application of hazardous substance when you transport by air (both passenger and cargo airlines).

Battery Box For Absolute Encoder

Part No. DV0P4430

Components






Related page P.7-10 "Absolute system"

[Unit: mm]

[Unit: mm]



Caution For E, F and G-frame, you con make a front end and back end mounting by changing the mounting direction of L-shape bracket (attachment).

[Unit: mm]

[Unit: mm]

Supplement

Related page ···· P.7-73... "Dimensions of driver"


lement P


7. Options

Supplement

Reactor








• Wiring of the reactor <3-Phase>

В


		Servo
Power	NP	driver side
supply side		


200 V


2.5 kW











distance on slotted hole

Power supply side

• Wiring of the reactor <Single phase>



												[Onit: mini
	Part No.	Α	В	с	D	E(Max)	F	G	н	I	Inductance (mH)	Rated current (A)
	DV0P220	65±1	125±1	(93)	136 _{Max}	155	70+3/-0	85±2	4-7φ×12	M4	6.81	3
	DV0P221	60±1	150±1	(113)	155мах	130	60+3/-0	75±2	4-7φ×12	M4	4.02	5
Fig.1	DV0P222	60±1	150±1	(113)	155мах	140	70+3/-0	85±2	4-7φ×12	M4	2	8
Fig. I	DV0P223	60±1	150±1	(113)	155мах	150	79+3/–0	95±2	4-7φ×12	M4	1.39	11
	DV0P224	60±1	150±1	(113)	160мах	155	84+3/-0	100±2	4-7φ×12	M5	0.848	16
	DV0P225	60±1	150±1	(113)	160Max	170	100+3/-0	115±2	4-7φ×12	M5	0.557	25
	DV0P227	55±0.7	80±1	66.5±1	110 _{Мах}	90	41±2	55±2	4-5φ×10	M4	4.02	5
Fig.2	DV0P228	55±0.7	80±1	66.5±1	110 _{Max}	95	46±2	60±2	4-5φ×10	M4	2	8
	DV0PM20047	55±0.7	80±1	66.5±1	110мах	105	56±2	70±2	4-5φ×10	M4	1.39	11

Motor series	Power supply	Rated output	Part No.	Motor series	Power supply	Rated output	Part No.	
MSME	Single phase,	Single phase, 50 W to 100 W DV0P227 MSME						
IVISIVIE	100 V	200 W to 400 W	DV0P228	MDME		0.0.1444		
MSME	Single phase,	50 W to 200 W	DV0P227	MHME		2.0 kW	DV0P223	
INISINE	200 V	400 W to 750 W	DV0P228	MGME				
MSME	Single phase,	1.0 kW	DV0P228	MSME]			
MDME MHME	200 V	1.5 kW	DV0PM20047	MDME	3-phase, 200 V			
MGME	Single phase, 200 V	0.9 kW	DV0P228	MHME	200 V	3.0 kW	DV0P224	
MSME		50 W to 750 W	DV0P220	MGME]			
MGME		0.9 kW	DV0P221	MSME]			
MSME	3-phase, 200 V	3-phase,		MDME]	4.0 kW	DV0P225	
MDME	200 1	1.0 kW 1.5 kW	DV0P222	MHME]			
MHME		1.0 KW			·	·		
	Single phase, 200 V	1.5 kW	DV0PM20047					
MFME	3-phase,	1.5 kW	DV0P222					

DV0P224

5

Harmonic restraint

Harmonic restraint measures are not common to all countries. Therefore, prepare the measures that meet the requirements of the destination country.

With products for Japan, on September, 1994, "Guidelines for harmonic restraint on heavy consumers who receive power through high voltage system or extra high voltage system" and "Guidelines for harmonic restraint on household electrical appliances and general-purpose articles" established by the Agency for Natural Resources and Energy of the Ministry of Economy, Trade and Industry (the ex-Ministry of International Trade and Industry). According to those guidelines, the Japan Electrical Manufacturers' Association (JEMA) have prepared technical documents (procedure to execute harmonic restraint: JEM-TR 198, JEM-TR 199 and JEM-TR 201) and have been requesting the users to understand the restraint and to cooperate with us. On January, 2004, it has been decided to exclude the general-purpose inverter and servo driver from the "Guidelines for harmonic restraint on household electrical appliances and general-purpose articles". After that, the "Guidelines for harmonic restraint on household electrical appliances and general-purpose articles" was abolished on September 6, 2004.

We are pleased to inform you that the procedure to execute the harmonic restraint on general-purpose inverter and servo driver was modified as follows.

- 1. All types of the general-purpose inverters and servo drivers used by specific users are under the control of the "Guidelines for harmonic restraint on heavy consumers who receive power through high voltage system or extra high voltage system". The users who are required to apply the guidelines must calculate the equivalent capacity and harmonic current according to the guidelines and must take appropriate countermeasures if the harmonic current exceeds a limit value specified in a contract demand. (Refer to JEM-TR 210 and JEM-TR 225.)
- 2. The "Guidelines for harmonic restraint on household electrical appliances and generalpurpose articles" was abolished on September 6, 2004. However, based on conventional guidelines, JEMA applies the technical documents JEM-TR 226 and JEM-TR 227 to any users who do not fit into the "Guidelines for harmonic restraint on heavy consumers who receive power through high voltage system or extra high voltage system" from a perspective on enlightenment on general harmonic restraint. The purpose of these guidelines is the execution of harmonic restraint at every device by a user as usual to the utmost extent.

Supplement

External Regenerative Resistor

			Spec				
Part No.	Manufacturer's	Resistance	cable core outside	Mass		power nce) ^{*1}	Activation temperature of
	part No.		diameter		Free air	with fan	built-in thermal protector
		Ω	mm	kg	W	W	
DV0P4280	RF70M	50		0.1	10	25	
DV0P4281	RF70M	100		0.1	10	25	
DV0P4282	RF180B	25	φ1.27	0.4	17	50	140±5 °C
DV0P4283	RF180B	50	/ AWG18 \	0.2	17	50	B-contact
DV0P4284	RF240	30	stranded	0.5	40	100	Open/Close capacity
DV0P4285	RH450F	20	\ wire /	1.2	52	130	(resistance load)
DV0PM20048	RF240	120		0.5	35	80	1 A 125 VAC 6000 times
DV0PM20049	RH450F	80		1.2	65	190	0.5 A 250 VAC 10000 times
DV0PM20058	RH450F × 6	3.3	_ *2	16	— *3	780	
DV0PM20059	RH450F × 6	13.3	_ *2	16	— * ³	1140	

Manufacturer : Iwaki Musen Kenkyusho

*1 Power with which the driver can be used without activating the built-in thermal protector.

A built-in thermal fuse and a thermal protector are provided for safety.

The built-in thermal fuse blows depending on changes in heat dissipation condition, operating temperature limit, power supply voltage or load.

Mount the regenerative resistor on a machine operating under aggressive regenerating condition (high power supply voltage, large load inertia, shorter deceleration time, etc.) and make sure that the surface temperature will not exceed 100 °C.

Select and install a fan that maintains the surface temperature of regenerative resistor at 100 °C or below during operation.

*2 Terminal block with screw tightening torque as shown below.


T1, T2, 24 V, 0 V, E $\stackrel{:}{_{\scriptstyle \sim}}$ M4 $\stackrel{:}{_{\scriptstyle \sim}}$ 1.2 N·m to 1.4 N·m


R1, R2 : M5 : 2.0 N·m to 2.4 N·m


Use the cable with the same diameter as the main circuit cable. (Refer to P.2-10).

*3 With built-in fan which should always be operated with the power supply connected across 24 V and 0 V.

	Power supply					
Frame	Single phase, 100 V Single phase, 200 V 3-phase, 200 V		3-phase, 400 V			
A	DV0P4280	DV0P4281 (50 W, 100 W) DV0P4283 (200 W)	_			
В	DV0P4283	DV0P4283				
С	DV0P4282	DV0F4203				
D		DV0P4284	DV0PM20048			
Е		DV0P4284 × 2 in parallel or DV0P4285	DV0PM20049			
F] _ [DV0P4285 × 2 in parallel	DV0PM20049 × 2 in parallel			
G		DV0P4285 × 3 in parallel	DV0PM20049 × 3 in parallel			
Н		DV0P4285 × 6 in parallel or DV0PM20058	DV0PM20049 × 6 in parallel or DV0PM20059			







<Caution when using external regenerative resistor>

Regenerative resistor gets very hot.

Configure a circuit so that a power supply shuts down when built-in thermal protector of the regenerative resistor works. Because it is automatic reset thermal protector, please apply a self-holding circuit to the outside in order to maintain safety in case of sudden activation. During the failure of the driver, the surface temperature of the regenerative resistor may exceed the operating temperature before thermal protector starts to work. Built-in thermal fuse of regenerative resistor is intended to prevent from ignition during the

- failure of the driver and not intended to suppress the surface temperature of the resistor.Be attached the regenerative resistance to non-combustible material such as metal.
 - Built-in thermal fuse of regenerative resistor is intended to prevent from ignition during the
 - failure of the driver and not intended to suppress the surface temperature of the resistor.
 - Do not install the regenerative resistor near flammable materials.

7

When in Trouble

Supplement

Recommended components

Surge absorber for motor brake

	Motor	Part No.	Manufacturer		
MSMD	50 W to 750 W	Z15D271	SEMITEC Corporation		
MSMJ	200 W to 750 W	or TNR15G271K	or NIPPON CHEMI-CON		
	50 W to 750 W	mm3027 m	CORPORATION		
MSME	750 W (400 V) 1.0 kW to 5.0 kW	Z15D151	SEMITEC Corporation		
	400 W (400 V), 600 W (400 V)				
MDME	1.0 kW to 3.0 kW	NVD07SCD082	KOA Corporation		
	4.0 kW to 7.5 kW	Z15D151	SEMITEC Corporation		
	11 kW, 15 kW				
MFME	1.5 kW	NVD07SCD082	KOA Corporation		
	2.5 kW, 4.5 kW				
MGME	0.9 kW to 6.0 kW	Z15D151	SEMITEC Corporation		
MHMD MHMJ	200 W to 750 W	Z15D271 or TNR15G271K	SEMITEC Corporation or NIPPON CHEMI-CON CORPORATION		
МНМЕ	1.0 kW, 1.5 kW	NVD07SCD082	KOA Corporation		
	2.0 kW to 7.5 kW	Z15D151	SEMITEC Corporation		

7	7. Options	T Be
Supplement	List of Peripheral Equipments	fore Us
		sing the
		Produ
		ucts

2

Preparation

3

Connection

4

Setup

5

Adjustment

Warranty period

• The warranty period is one year from the date of purchase or 18 months from the month of manufacture in our plant.

For a motor with brake, the axis accelerated and decelerated more times than the specified limit is not covered by warranty.

Warranty information

- Should any defect develop during warranty period under standard service conditions as described in the manual, the company agrees to make repairs free of charge. Even during warranty period, the company makes fee-based repair on product containing:
 - [1] Failure or damage due to misuse, improper repair or alteration.
 - [2] Failure or damage due to falling, or damage during transportation, after the original delivery
 - [3] Defects resulting from neglect of the specification in use of the product.
 - [4] Failure or damage due to unregulated voltage and fire, and act of natural disasters such as earthquake, lightning, wind, flood and salt pollution.
 - [5] Defects resulting from invasion of foreign materials such as water, oil and metal pieces.

Parts exceeding their standard lifetime specified in this document are excluded.

• The company shall not be liable for any indirect, incidental or consequential damage or loss of any nature that may arise in connection with the product.

- Practical considerations for exporting the product or assembly containing the product When the end user of the product or end use of the product is associated with military affair or weapon, its export may be controlled by the Foreign Exchange and Foreign Trade Control Law. Complete review of the product to be exported and export formalities should be practiced.
- This product is intended to be used with a general industrial product, but not designed or manufactured to be used in a machine or system that may cause personal death when it is failed.
- Installation, wiring, operation, maintenance, etc., of the equipment should be done by qualified and experienced personnel.
- Apply adequate tightening torque to the product mounting screw by taking into consideration strength of the screw and the characteristics of material to which the product is installed. Overtightening can damage the screw and/or material; undertightening can result in loosening.

Example) Steel screw into steel section:

M4	1.35 N	l∙m	to	1.65	N∙m.
M5	2.7 N	l∙m	to	3.3	N∙m.
M6	4.68 N	l∙m	to	5.72	N∙m.
M8	11.25 N	l∙m	to	13.75	N∙m.
M10	22.05 N	l∙m	to	26.95	N∙m.
M11	37.8 N	l∙m	to	46.2	N∙m.

- Install a safety equipments or apparatus in your application, when a serious accident or loss of property is expected due to the failure of this product.
- Consult us if the application of this product is under such special conditions and environments as nuclear energy control, aerospace, transportation, medical equipment, various safety equipments or equipments which require a lesser air contamination.
- We have been making the best effort to ensure the highest quality of the products, however, application of exceptionally larger external noise disturbance and static electricity, or failure in input power, wiring and components may result in unexpected action. It is highly recommended that you make a fail-safe design and secure the safety in the operative range.
- If the motor shaft is not electrically grounded, it may cause an electrolytic corrosion to the bearing, depending on the condition of the machine and its mounting environment, and may result in the bearing noise. Checking and verification by customer is required.
- Failure of this product depending on its content, may generate smoke of about one cigarette. Take this into consideration when the application of the machine is clean room related.
- Please be careful when using in an environment with high concentrations of sulfur or sulfric gases, as sulfuration can lead to disconnection from the chip resistor or a poor contact connection.
- Take care to avoid inputting a supply voltage which significantly exceeds the rated range to the power supply of this product. Failure to heed this caution may result in damage to the internal parts, causing smoking and/or a fire and other trouble.
- The user is responsible for matching between machine and components in terms of configuration, dimensions, life expectancy, characteristics, when installing the machine or changing specification of the machine. The user is also responsible for complying with applicable laws and regulations.
- The product will not be guaranteed when it is used outside its specification limits.
- Parts are subject to minor change to improve performance.

Repair

Consult to a dealer from whom you have purchased the product for details of repair. When the product is incorporated to the machine or equipment you have purchased, consult to the manufacturer or the dealer of the machine or equipment.

Technical information

Technical information of this product (Operating Instructions, CAD data) can be downloaded

For your records:

The model number and serial number of this product can be found on either the back or the bottom of the unit. Please note them in the space provided and keep for future reference.

Model No.	M D M M			Serial No.	Serial No.		
Date of purchase							
	Name						
Dealer	Address						
	Phone	()	-			

Panasonic Corporation, Appliances Company, Motor Business Division

7-1-1 Morofuku, Daito, Osaka, 574-0044, Japan © Panasonic Corporation 2009

Buy: www.ValinOnline.com | Phone 844-385-3099 | Email: CustomerService@valin.com