

**TOSHIBA**  
Leading Innovation >>>

October, 2014



**vlp**  
technology

# P9 ASD >>>>

## INSTALLATION & OPERATION MANUAL

# P9 ASD Installation & Operation Manual



DN: 64054-005

October, 2014



# Introduction

Congratulations on the purchase of the new **P9 Adjustable Speed Drive**!

The **P9 Adjustable Speed Drive** (ASD) is a solid-state AC drive that features Toshiba International Corporation's (TIC) new **Virtual Linear Pump** function. The **VLP** algorithm was designed to remove the guess work that is associated with the setup of pumping systems. The **VLP** algorithm allows for precise, linear, and consistent pump curve responses at any flow or pressure setting!

The **Virtual Linear Pump** function allows for direct and precise pumping system control. This is accomplished without the normal concerns of the adverse effects of conventional pumping system control response curves.

Toshiba's **VLP** algorithm is further enhanced by the introduction of the new **Time-Based Alternation** (TBA) function! **Time-Based Alternation** optimizes load sharing and offers a significantly decreased level of system down-time.

**Time-Based Alternation** provides a more evenly-spread machine wear pattern for all motors and pumps of the system. Load sharing is optimized by allowing all pumps to alternate as the primary pump while the remaining pump(s) operate in an ancillary mode for time intervals that are determined by the user.

The decreased system down-time is realized in the event of a failure of one or more pumps, when seamlessly, the system continues to operate, albeit with a diminished capacity.

Using **VLP** and **Time-Based Alternation**, the system seamlessly and easily adapts to peak load demands while maintaining the same degree of high performance and reliability output across the entire load range - without any user intervention!

The **VLP** and **Time-Based Alternation** algorithms coupled with Toshiba International Corporation's **Vector Control Algorithm** provides setup ease, enhanced reliability, and precise control under the most demanding conditions. All while enabling the motors of the system to develop high starting torque and provide compensation for motor slip, which results in smooth, quick starts, and highly efficient operation.

The programmable functions may be accessed via the easy-to-use menu or via the Direct Access Numbers (see [pg. 81](#)). This feature, combined with Toshiba International Corporation's high-performance software, delivers unparalleled motor control, reliability, and ease of use.

The P9 is a very powerful tool, yet surprisingly simple to operate. The user-friendly **Electronic Operator Interface** (EOI) of the P9 has an easy-to-read LCD screen. There is also a high-visibility LED screen that can be read from a greater distance. The EOI provides easy access to the many monitoring and programming features of the P9.

To maximize the abilities of your new P9, a working familiarity with this manual is required. This manual has been prepared for the ASD installer, user, and maintenance personnel. This manual may also be used as a reference guide or for training. With this in mind, use this manual to develop a familiarity with the P9 before attempting to install, operate, or perform maintenance on the device.

# Important Notice

The instructions contained in this manual are not intended to cover all details or variations in equipment types, nor may it provide for every possible contingency concerning the installation, operations, or maintenance of this equipment. Should additional information be required, contact your TIC Sales Representative.

The contents of this manual shall not become a part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of Toshiba International Corporation. The warranty contained in the contract between the parties is the sole warranty of Toshiba International Corporation and any statements contained herein do not create new warranties or modify the existing warranty.

**Any electrical or mechanical modifications to this equipment without prior written consent of Toshiba International Corporation may void all warranties and may void the UL/CSA listing or other safety certifications. Unauthorized modifications may also result in a safety hazard or equipment damage.**

**Misuse of this equipment could result in injury and equipment damage. In no event will Toshiba International Corporation be responsible or liable for direct, indirect, special, or consequential damage or injury that may result from the misuse of this equipment.**

# About This Manual

This manual was written by the Toshiba International Corporation Technical Publications Group. This group is tasked with providing technical documentation for the **P9 Adjustable Speed Drive**. Every effort has been made to provide accurate and concise information to you, our customer.

At Toshiba International Corporation we are continuously striving for better ways to meet the constantly changing needs of our customers. E-mail your comments, questions, or concerns about this publication to [Technical-Publications-Dept.](#)

## Manual's Purpose and Scope

This manual provides information on how to safely install, operate, maintain, and dispose of your **P9 Adjustable Speed Drive**. The information provided in this manual is applicable to the **P9 Adjustable Speed Drive** only.

This manual provides information on the various features and functions of this powerful cost-saving device, including

- Installation,
- System operation,
- Configuration and menu options, and
- Mechanical and electrical specifications.

Included is a section on general safety instructions that describe the warning labels and symbols that are used on the device and throughout the manual. Read the manual completely before installing, operating, performing maintenance, or disposing of this equipment.

This manual and the accompanying drawings should be considered a permanent part of the equipment and should be readily available for reference and review. Dimensions shown in the manual are in English and/or the metric equivalent.

Because of our commitment to continuous improvement, Toshiba International Corporation reserves the right, without prior notice, to update information, make product changes, or to discontinue any product or service identified in this publication.

**Toshiba International Corporation (TIC) shall not be liable for direct, indirect, special, or consequential damages resulting from the use of the information contained within this manual.**

This manual is copyrighted. No part of this manual may be photocopied or reproduced in any form without the prior written consent of Toshiba International Corporation.

© Copyright 2014 Toshiba International Corporation.

**TOSHIBA®** is a registered trademark of Toshiba Corporation. All other product or trade references appearing in this manual are registered trademarks of their respective owners.

All rights reserved.

Printed in the U.S.A.

# Contacting TIC's Customer Support Center

Toshiba International Corporation's Customer Support Center can be contacted to obtain help in resolving any **Adjustable Speed Drive** system problem that you may experience or to provide application information.

The Support Center is open from 8 a.m. to 5 p.m. (CST), Monday through Friday. The Center's toll free number is US (800) 231-1412/Fax (713) 937-9349 CAN (800) 872-2192 MEX 01 (800) 527-1204. For after-hours support follow the directions in the outgoing message when calling.

You may also contact Toshiba International Corporation by writing to:

Toshiba International Corporation

13131 West Little York Road

Houston, Texas 77041-9990

Attn: ASD Product Manager.

For further information on Toshiba International Corporation's products and services, please visit our website.

## TOSHIBA INTERNATIONAL CORPORATION

### P9 Adjustable Speed Drive

Please complete the Warranty Card supplied with the P9 ASD and return it to Toshiba International Corporation by prepaid mail. This will activate the 12-month warranty from the date of installation; but, shall not exceed 18 months from the shipping date.

Complete the following information and retain for your records.

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Project Number (if applicable): \_\_\_\_\_

Date of Installation: \_\_\_\_\_

Inspected By: \_\_\_\_\_

Name of Application: \_\_\_\_\_

# Table of Contents

<b>General Safety Information .....</b>	<b>1</b>
Safety Alert Symbol .....	1
Signal Words .....	1
Special Symbols .....	2
Equipment Warning Labels .....	2
Qualified Personnel .....	2
Equipment Inspection .....	3
Handling and Storage .....	3
Disposal .....	3
<b>Installation Precautions .....</b>	<b>4</b>
Location and Ambient Requirements .....	4
Mounting Requirements .....	4
Conductor Routing and Grounding Precautions .....	5
Power Connections Precautions .....	6
Protection .....	6
<b>System Integration Precautions .....</b>	<b>7</b>
Personnel Protection .....	7
System Setup Requirements .....	8
<b>Operational and Maintenance Precautions .....</b>	<b>9</b>
<b>Motor Characteristics .....</b>	<b>10</b>
Motor Autotuning .....	10
Pulse Width Modulation Operation .....	10
Low-Speed Operation .....	10
Overload Protection Adjustment .....	10
Operation Above 60 Hz .....	10
Power Factor Correction .....	11
Light Load Conditions .....	11
Motor/Load Combinations .....	11
Load-Produced Negative Torque .....	12
Motor Braking .....	12
<b>ASD Characteristics .....</b>	<b>13</b>
Over-Current Protection .....	13
ASD Capacity .....	13
Using Vector Control .....	13
<b>Installation and Connections .....</b>	<b>14</b>
Installation Notes .....	14
Mounting the ASD .....	15

Connecting the ASD .....	16
Lead Length Specifications .....	20
I/O and Control .....	21
<b>Electronic Operator Interface .....</b>	<b>28</b>
EOI Operation .....	28
Battery Backup .....	28
Real-Time Clock Setting .....	29
EOI Remote Mounting .....	29
EOI Features .....	30
EOI Remote Mounting .....	33
<b>System Operation .....</b>	<b>36</b>
Initial Setup .....	36
Standard Startup Wizard Parameters .....	36
Operation (Hand) .....	39
Default Setting Changes .....	40
Saving User Settings .....	41
<b>Command Mode and Frequency Mode Control .....</b>	<b>42</b>
Command Control (F003) .....	42
Frequency Control (F004) .....	43
Override Operation .....	44
<b>System Configuration and Menu Options .....</b>	<b>47</b>
Root Menus .....	47
<b>Virtual Linear Pump .....</b>	<b>77</b>
<b>Direct Access Parameter Information .....</b>	<b>81</b>
Direct Access Parameters/Numbers .....	81
<b>Alarms, Trips, and Troubleshooting .....</b>	<b>260</b>
Alarms and Trips .....	260
User Notification Codes .....	261
Alarms .....	262
Trips/Faults .....	265
<b>Enclosure and Conduit Plate Dimensions .....</b>	<b>271</b>
Enclosure Dimensions .....	271
Conduit Plate Dimensions .....	276
<b>Current/Voltage Specifications .....</b>	<b>279</b>
<b>Cable/Terminal/Torque Specifications .....</b>	<b>281</b>
<b>Dynamic Braking Protection .....</b>	<b>283</b>
<b>Short Circuit Protection Recommendations .....</b>	<b>285</b>
<b>P9 ASD Optional Devices .....</b>	<b>286</b>



# General Safety Information

**DO NOT** attempt to install, operate, maintain, or dispose of this equipment until you have read and understood all of the product safety information and directions that are contained in this manual.

## Safety Alert Symbol

The **Safety Alert Symbol** is comprised of an equilateral triangle enclosing an exclamation mark. This indicates that a potential personal injury hazard exists.



## Signal Words

Listed below are the signal words that are used throughout this manual followed by their descriptions and associated symbols. When the words **DANGER**, **WARNING**, and **CAUTION** are used in this manual, they will be followed by important safety information that must be carefully followed.

The word **DANGER** preceded by the safety alert symbol indicates that an imminently hazardous situation exists that, if not avoided or if instructions are not followed precisely, will result in serious injury to personnel or loss of life.



The word **WARNING** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided or if instructions are not followed precisely, could result in serious injury to personnel or loss of life.



The word **CAUTION** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided or if instructions are not followed precisely, may result in minor or moderate injury.



The word **CAUTION** without the safety alert symbol indicates a potentially hazardous situation exists that, if not avoided or if instructions are not followed precisely, may result in equipment and property damage.

## CAUTION

# Special Symbols

To identify special hazards, other symbols may appear in conjunction with the **DANGER**, **WARNING**, and **CAUTION** signal words. These symbols indicate areas that require special and/or strict adherence to the procedures to prevent serious injury to personnel or loss of life.

## Electrical Hazard Symbol

A symbol that is comprised of an equilateral triangle enclosing a lightning bolt indicates a hazard of injury from electrical shock or burn.



## Explosion Hazard Symbol

A symbol that is comprised of an equilateral triangle enclosing an explosion indicates a hazard of injury from exploding parts.



# Equipment Warning Labels

**DO NOT** attempt to install, operate, perform maintenance, or dispose of this equipment until you have read and understood all of the product labels and user directions that are contained in this manual.

Warning labels that are attached to the equipment will include the exclamation mark within a triangle. **DO NOT** remove or cover any of these labels. If the labels are damaged or if additional labels are required, contact your TIC Sales Representative.

Labels attached to the equipment are there to provide useful information or to indicate an imminently hazardous situation that may result in serious injury, severe property and equipment damage, or loss of life if safe procedures or methods are not followed as outlined in this manual.

# Qualified Personnel

Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**. A Qualified Person is one that has the skills and knowledge relating to the construction, installation, operation, and maintenance of the electrical equipment and has received safety training on the hazards involved (Refer to the latest edition of NFPA 70E for additional safety requirements).

**Qualified Personnel** shall:

- Have carefully read the entire manual.
- Be familiar with the construction and function of the ASD, the equipment being driven, and the hazards involved.
- Be able to recognize and properly address hazards associated with the application of motor-driven equipment.
- Be trained and authorized to safely energize, de-energize, ground, lock out/tag out circuits and equipment, and clear faults in accordance with established safety practices.
- Be trained in the proper care and use of protective equipment such as safety shoes, rubber gloves, hard hats, safety glasses, face shields, flash clothing, etc., in accordance with established safety practices.

For further information on workplace safety, visit [www.osha.gov](http://www.osha.gov).

# Equipment Inspection

- Upon receipt of the equipment, inspect the packaging and equipment for shipping damage.
- Carefully unpack the equipment and check for parts that may have been damaged during shipping, missing parts, or concealed damage. If any discrepancies are discovered, it should be noted with the carrier prior to accepting the shipment, if possible. File a claim with the carrier if necessary and immediately notify your TIC Sales Representative.
- **DO NOT** install the ASD if it is damaged or if it is missing any component(s).
- Ensure that the rated capacity and the model number specified on the nameplate conform to the order specifications.
- Modification of this equipment is dangerous and is to be performed by factory trained personnel. When modifications are required contact your TIC Sales Representative.
- Inspections may be required after moving equipment.
- Contact your TIC Sales Representative to report discrepancies or for assistance if required.

# Handling and Storage

- Use proper lifting techniques when moving the ASD; including properly sizing up the load, getting assistance, and using a forklift if required.
- Store in a well-ventilated location and preferably in the original packaging if the equipment will not be used upon receipt.
- Store in a cool, clean, and dry location. Avoid storage locations with extreme temperatures, rapid temperature changes, high humidity, moisture, dust, corrosive gases, or metal particles.
- The storage temperature range of the P9 ASD is -13° to 149° F (-25° to 65° C).
- **DO NOT** store the unit in places that are exposed to outside weather conditions (i.e., wind, rain, snow, etc.).
- Store in an upright position.

# Disposal

Never dispose of electrical components via incineration. Contact your state environmental agency for details on disposal of electrical components and packaging in your area.

# Installation Precautions

## Location and Ambient Requirements

- The TIC ASD is intended for permanent installations only.
- Installation should conform to the **National Electrical Code — Article 110** (NEC) (*Requirements For Electrical Installations*), all regulations of the **Occupational Safety and Health Administration**, and any other applicable national, regional, or industry codes and standards.

***Note:** For ALL references to the National Electrical Code (NEC), see the latest release of the National Electrical Code.*

- Select a mounting location that is easily accessible, has adequate personnel working space, and adequate illumination for adjustment, inspection, and maintenance of the equipment (refer to the NEC Article 110-13).
- **DO NOT** mount the ASD in a location that would produce catastrophic results if it were to become dislodged from its mounting location (equipment damage or injury).
- **DO NOT** mount the ASD in a location that would allow it to be exposed to flammable chemicals or gases, water, solvents, or other fluids.
- Avoid installation in areas where vibration, heat, humidity, dust, fibers, metal particles, explosive/corrosive mists or gases, or sources of electrical noise are present.
- The installation location shall not be exposed to direct sunlight.
- Allow proper clearance spaces for installation. Do not obstruct the ventilation openings. Refer to the section titled [Installation and Connections on pg. 14](#) for further information on ventilation requirements.
- The ambient operating temperature range of the P9 ASD is 14° to 104° F (-10° to 40° C).

## Mounting Requirements

- Only **Qualified Personnel** should install this equipment.
- Install the unit in a secure and upright position in a well-ventilated area.
- As a minimum, the installation of the equipment should conform to the **NEC — Article 110** (NEC), OSHA, as well as any other applicable national, regional, or industry codes and standards.
- Installation practices should conform to the latest revision of NFPA 70E Electrical Safety Requirements for Employee Workplaces.
- It is the responsibility of the ASD installer/maintenance personnel to ensure that the unit is installed into an enclosure that will protect personnel against electric shock.

# Conductor Routing and Grounding Precautions



- Use separate metal conduits for routing the input power, output power, and control circuits.
- A separate ground cable should be run inside the conduit with the input power, output power, and control circuits.
- **DO NOT** connect **CC** to earth ground.
- Use **IICC** terminal as the return for the **V/I** input.
- Always ground the unit to prevent electrical shock and to help reduce electrical noise.
- If the ASD is being used in an ungrounded system (floating system) or in an asymmetrically grounded system, the EMI filter must be disconnected or removed. The ASD may be damaged if the EMI filter is used.
- It is the responsibility of the ASD installer/maintenance personnel to provide proper grounding and branch circuit protection in accordance with the **NEC** and any applicable local codes.

— The Metal Conduit Is Not An Acceptable Ground —

## Grounding Capacitor Setting Precaution



If operating using an ungrounded 3-phase power source or within a high-resistance grounding system, the **Grounding Capacitance** must be set to **Small** or **Out** (typeform-specific) as shown on [pg. 19](#). If set to **High**, a system malfunction, component failure, or fire may result.

## Grounding Capacitor Switching

The ASD is equipped with noise reduction capacitors which are used to reduce the EMI leakage via the 3-phase power-input circuit and for compliance with the **Electromagnetic Compatibility Directive** (EMC).

The effective value of the capacitor may be increased, reduced, or removed entirely via the **Selector Switch**, **Switching Bar**, or the **Switching Screw** — the type used is typeform-specific.

The **Grounding Capacitor Switch** allows the user to quickly change the value of the capacitance of the 3-phase input circuit without the use of tools. The **Switching Bar** and the **Switching Screw** are easily changed with the use of a wrench or a screw driver, respectively.

See the section titled [System Grounding on pg. 18](#) for more on the [Grounding Capacitor](#).

See figures [4](#), [5](#), [6](#), and [7 on pg. 19](#) for an electrical depiction of the leakage-reduction functionality of the [Grounding Capacitor](#) and the methods used to set the capacitance value.

# Power Connections Precautions



**CONTACT WITH ENERGIZED WIRING WILL CAUSE SEVERE INJURY OR LOSS OF LIFE.**

- Turn off and lock out/tag out all power sources before proceeding to connect the power wiring to the equipment.
- After ensuring that all power sources are turned off and isolated in accordance with established lock out/tag out procedures, connect the 3-phase power source wiring of the correct voltage to the correct input terminals and connect the output terminals to a motor of the correct voltage and type for the application (refer to the NEC Article 300 – Wiring Methods and Article 310 – Conductors For General Wiring). Size the branch circuit conductors in accordance with the NEC Table 310.16.
- Ensure that the 3-phase input power is **NOT** connected to the output of the ASD. This will damage the ASD and may cause injury to personnel.
- **DO NOT** connect resistors across terminals PA – PC or PO – PC. This may cause a fire.
- Ensure the correct phase sequence and the desired direction of motor rotation in the **Bypass** mode (if applicable).

## Protection

- Ensure that primary protection exists for the input wiring to the equipment. This protection must be able to interrupt the available fault current from the power line. The equipment may or may not be equipped with an input disconnect (option).
- All cable entry openings must be sealed to reduce the risk of entry by vermin and to allow for maximum cooling efficiency.
- External dynamic braking resistors must be thermally protected.
- It is the responsibility of the ASD installer/maintenance personnel to set up the **Emergency Off** braking system of the ASD. The function of the **Emergency Off** braking function is to remove output power from the ASD in the event of an emergency. A supplemental braking system may also be engaged in the event of an emergency. For further information on braking systems, see parameters [F250](#) and [F304](#).

***Note:** A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.*

- Follow all warnings and precautions and do not exceed equipment ratings.

# System Integration Precautions

The following precautions are provided as general guidelines for the setup of the ASD within the system.

- The TIC ASD is a general-purpose product. It is a system component only and the system design should take this into consideration. Please contact your TIC Sales Representative for application-specific information or for training support.
- The TIC ASD is part of a larger system and the safe operation of the ASD will depend upon observing certain precautions and performing proper system integration.
- Improperly designed or improperly installed system interlocks may render the motor unable to start or stop on command.
- The failure of external or ancillary components may cause intermittent system operation (i.e., the system may start the motor without warning).
- A detailed system analysis and job safety analysis should be performed by the systems designer and/or systems integrator before the installation of the ASD component. Contact your TIC Sales Representative for options availability and for application-specific system integration information if required.

## Personnel Protection

- Installation, operation, and maintenance shall be performed by **Qualified Personnel ONLY**.
- A thorough understanding of the ASD will be required before the installation, operation, or maintenance of the ASD.



- Rotating machinery and live conductors can be hazardous and shall not come into contact with personnel. Personnel should be protected from all rotating machinery and electrical hazards at all times.
- Insulators, machine guards, and electrical safeguards may fail or be defeated by the purposeful or inadvertent actions of workers. Insulators, machine guards, and electrical safeguards are to be inspected (and tested where possible) at installation and periodically after installation for potential hazardous conditions.
- **DO NOT** allow personnel near rotating machinery. Warning signs to this effect shall be posted at or near the machinery.
- **DO NOT** allow personnel near electrical conductors. Contact with electrical conductors can be fatal. Warning signs to this effect shall be posted at or near the hazard.
- Personal Protection Equipment (PPE) shall be provided and used to protect employees from any hazards inherent to system operation.

# System Setup Requirements

- With the exception of the **TBA Pump Number (F434)**, ensure that all **Time-Based Alternation** parameter settings and the real-time clock settings for each ASD within the system are the same.
- When using the ASD as an integral part of a larger system, it is the responsibility of the ASD installer/maintenance personnel to ensure that there is a fail-safe in place (i.e., an arrangement designed to switch the system to a safe condition if there is a fault or failure).
- Power factor improvement capacitors or surge absorbers **MUST NOT** be installed on the output of the ASD.
- Use of the built-in system protective features is highly recommended (i.e., E-Off, Overload Protection, etc.).
- The operating controls and system status indicators should be clearly readable and positioned where the operator can see them without obstruction.
- Additional warnings and notifications shall be posted at the equipment installation location as deemed required by [Qualified Personnel](#).



## CAUTION

- System safety features should be employed and designed into the integrated system in a manner such that system operation, even in the event of system failure, will not cause harm or result in system damage or injury to personnel (i.e., E-Off, Auto-Restart settings, System Interlocks, etc.).
- The programming setup and system configuration of the ASD may allow it to start the motor unexpectedly. A familiarity with the **Time-Based Alternation (F404)**, **VLP Auto Start-Stop (F385)**, **Auto-Restart (F301)**, and the **Sleep Timer (F383)** settings are a requirement to use this product.
- The setup procedures included within this manual may require a **Reset** before performing the procedure. Application-specific settings may then be performed. The pre-Reset conditions may be saved (see [F007](#)).
- There may be thermal or physical properties, or ancillary devices integrated into the overall system that may allow for the ASD to start the motor without warning. Signs to this effect must be posted at the equipment installation location.
- If a secondary magnetic contactor (MC) or an ASD output disconnect is used between the ASD and the load, it should be interlocked to halt the ASD before the secondary contact opens. If the output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the ASD output terminals (U, V, or W).
- When using an ASD output disconnect, the ASD and the motor must be stopped before the disconnect is either opened or closed. Closing the output disconnect while the 3-phase output of the ASD is active may result in equipment damage or injury to personnel.



# Operational and Maintenance Precautions



- Turn off and lock out/tag out the main power, the control power, and instrumentation connections before inspecting or servicing the ASD, opening the door of the enclosure, or connecting/disconnecting the power wiring to the equipment.
- The capacitors of the ASD maintain a residual charge for a period of time after turning the ASD off. The required time for each ASD typeform is indicated with a cabinet label and a **Charge Indicator LED** (shown for smaller ASDs in [Figure 2 on pg. 16](#)). Wait at least the minimum time indicated on the enclosure-mounted label and ensure that the **Charge Indicator LED** has gone out once the ASD power has been turned off before coming into contact with any circuits or performing any maintenance operations on the P9 ASD.
- Turn the power on only after attaching (or closing) the front cover and **DO NOT** remove or open the front cover of the ASD when the power is on.
- **DO NOT** attempt to disassemble, modify, or repair the ASD. Call your TIC Sales Representative for repair information.
- **DO NOT** place any objects inside of the ASD.
- If the ASD should emit smoke, or an unusual odor or sound, turn off the power immediately.
- The heat sink and other components may become extremely hot to the touch. Allow the unit to cool before coming in contact with these items.
- The **Auto Start-Stop** and the **Sleep Timer** programmable functions of the ASD may allow for the system to start or stop unexpectedly. Signs to this effect are to be clearly posted at the installation location.
- Remove power from the ASD during extended periods of non-use.
- The system should be inspected periodically for damaged or improperly functioning parts, cleanliness, and to ensure that the connectors are tightened securely.

# Motor Characteristics

Listed below are some variable speed AC motor control concepts with which the user of the ASD should become familiar.

## Motor Autotuning

Motor production methods may cause minor differences in the motor operation. The negative effects of these differences may be minimized by using the **Autotune** feature of the ASD. **Autotuning** is a function of the ASD that measures several parameters of the connected motor and places these readings in a stored table. The software uses the information in the table to help optimize the response of the ASD to application-specific load and operational requirements. The **Autotuning** function may be enabled for automatic tuning, configured manually at [F400](#), or disabled.

The measured parameters include the rotor resistance, the stator resistance, the required excitation inductance, rotational inertia values, and leakage inductance values.

## Pulse Width Modulation Operation

The ASD uses sinusoidal **Pulse Width Modulation** (PWM) control. The output current waveform generated by the ASD approaches that of a perfect sine wave; however, the output waveform is slightly distorted. For this reason, the motor may produce more heat, noise, and vibration when operated by an ASD, rather than directly from commercial power.

## Low-Speed Operation

Operating a general-purpose motor at lower speeds may cause a decrease in the cooling ability of the motor. Reducing the torque requirement of the motor at lower speeds will decrease the generated heat at lower speeds.

When the motor is to be operated at low speed (less than 50% of full speed) and at the rated torque continuously, a TIC VF motor (designed for use in conjunction with an ASD) is recommended.

## Overload Protection Adjustment

The ASD software monitors the output current of the system and determines when an overload condition occurs. The overload current level is a percentage of the rating of the motor. This function protects the motor from overload.

The default setting for the overload detection circuit is set to the maximum rated current of the ASD at the factory. This setting will have to be adjusted to match the rating of the motor with which the ASD is to be used. To change the overload reference level, see [Motor Overload Protection Level 1 on pg. 198](#).

## Operation Above 60 Hz

A motor produces more noise and vibration when it is operated at frequencies above 60 Hz. Also, when operating a motor above 60 Hz, the rated limit of the motor or its bearings may be exceeded; this may void the motor warranty.

Contact the motor manufacturer for additional information before operating the motor above 60 Hz.

# Power Factor Correction

**DO NOT** connect a power factor correction capacitor or surge absorber to the output of the ASD.

If the ASD is used with a motor that is equipped with a capacitor for power factor correction, remove the capacitor from the motor.

Connecting either of these devices to the output of the ASD may cause the ASD to malfunction and trip, or the output device may cause an over-current condition resulting in damage to the device or the ASD.

## Light Load Conditions

When a motor is operated under a continuous light load (i.e., at a load of less than 50% of its rated capacity) or it drives a load which produces a very small amount of inertia, it may become unstable and produce abnormal vibration or trips because of an over-current condition. In such a case, the carrier frequency may be lowered to compensate for this undesirable condition (see Program  $\Rightarrow$  Special  $\Rightarrow$  Carrier Frequency  $\Rightarrow$  [PWM Carrier Frequency](#)).

**Note:** When operating in the **Vector Control** mode, the carrier frequency should be set to 2.2 kHz or above.

## Motor/Load Combinations

When the ASD is used in combination with one of the following motors or loads, it may result in unstable operation.

- A motor with a rated capacity that exceeds the motor capacity recommended for the ASD.
- An explosion-proof motor.

When using the ASD with an explosion-proof motor or other special motor types, lower the carrier frequency to stabilize the operation. **DO NOT** set the carrier frequency below 2.2 kHz if operating the system in the vector control mode.

**Note:** When operating in the **Vector Control** mode, the carrier frequency should be set to 2.2 kHz or above.

If the motor being used is coupled to a load that has a large backlash or if coupled to a reciprocating load, use one of the following procedures to stabilize motor operation.

- Adjust the **S-pattern** acceleration/deceleration setting,
- If operating in the **Vector** control mode, adjust the response time, or
- Switch to the **Constant Torque** control mode.

# Load-Produced Negative Torque

When the ASD is used with a load that produces negative torque (an overhauling load), the over-voltage or over-current protective functions of the ASD may cause nuisance tripping.

To minimize the undesirable effects of negative torque, the dynamic braking system may be used. The dynamic braking system converts the regenerated energy into heat that is dissipated using a braking resistor. The braking resistor must be suitably matched to the load. Dynamic braking is very effective in reducing the DC bus voltage during a momentary over-voltage condition.



If under extreme conditions the dynamic braking system or a component of this system were to fail, the dynamic braking resistor may experience an extended over-current condition. The DBR circuit was designed to dissipate excessive amounts of heat and if the extended over-current condition were allowed to exceed the circuit parameters, this condition could result in a fire hazard.

To combat this condition, the 3-phase input may be connected using contactors that are configured to open in the event of an extended DBR over-current condition or an internal circuit failure. Using a thermal sensor and/or overload protection as the 3-phase input contactor drive signal, the contactors will open and remove the 3-phase input power in the event of an extended DBR over-current or system over-voltage condition. See [Dynamic Braking Protection on pg. 283](#) for more information on using dynamic braking with the P9 ASD.

## Motor Braking

The motor may continue to rotate and coast to a stop after being shut off due to the inertia of the load. If an immediate stop is required, a braking system should be used. The two most common types of motor braking systems used with the ASD are **DC Injection Braking** and **Dynamic Braking**.

For further information on braking systems, see [DC Injection Braking on pg. 129](#) and [Dynamic Braking on pg. 141](#).

# ASD Characteristics

## Over-Current Protection

Each ASD model is designed for a specified operating power range. The ASD will incur a trip if the design specifications are exceeded.

However, the ASD may be operated at 100% of the specified output-current range continuously or at 120% for a limited amount of time as indicated in the section titled [Current/Voltage Specifications on pg. 279](#). Also, the [Stall Prevention Level](#) may be adjusted to help with nuisance over-current trips (see [F601](#)).

When using the ASD for an application to control a motor that is rated significantly less than the maximum current rating of the ASD, the over-current limit (Thermal Overload Protection) setting will have to be changed to match the FLA of the motor. For further information on this parameter, see [Motor Overload Protection Level 1 on pg. 198](#).

## ASD Capacity

The ASD must not be used with a motor that has a larger capacity than the ASD, even if the motor is operated under a small load. An ASD being used in this way will be susceptible to a high-output peak current which may result in nuisance tripping.

**DO NOT** apply a level of input voltage to an ASD that is beyond that which the ASD is rated. The input voltage may be stepped down when required with the use of a step-down transformer or some other type of voltage-reduction system.

## Using Vector Control

Using **Vector Control** enables the system to produce very high torque over the entire operating range even at extremely low speeds. **Vector Control** may be used with or without feedback. However, using feedback increases the speed accuracy for applications requiring precise speed control.

See [F015 on pg. 86](#) for further information on using **Vector Control**.

# Installation and Connections

The **P9 True Torque Control<sup>2</sup> Adjustable Speed Drive** may be set up initially by performing a few simple configuration settings. To operate properly, the ASD must be securely mounted and connected to a power source (3-phase AC input at the R/L1, S/L2, and T/L3 terminals). The control terminals of the ASD may be used by connecting the terminals of the **Terminal Board** to the proper sensors or signal input sources (see the section titled [I/O and Control on pg. 21](#) and [Figure 9 on pg 24](#)).

System performance may be further enhanced by assigning a function to the output terminals of the **Terminal Board** and connecting the terminals to the proper indicators or actuators (e.g., LEDs, relays, contactors, etc.).

**Note:** *The optional ASD interface boards may be used to expand the I/O functionality of the ASD. See the section titled [P9 ASD Optional Devices on pg. 286](#) for more information on the available options.*

## Installation Notes



When a brake-equipped motor is connected to the ASD, it is possible that the brake may not release at startup because of insufficient voltage. To avoid this, **DO NOT** connect the brake or the brake contactor to the output of the ASD.

If an output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the output terminals of the ASD (U/T1, V/T2, and W/T3).

**DO NOT** apply commercial power to the ASD output terminals **U/T1, V/T2, and W/T3**.

If a secondary magnetic contactor (MC) is used between the output of the ASD and the motor, it should be interlocked such that the **ST – CC** connection is disconnected before the output contactor is opened.

**DO NOT** open and then close a secondary magnetic contactor between the ASD and the motor unless the ASD is off and the motor is not rotating.

**Note:** *Re-application of power via a secondary contact while the ASD is on or while the motor is still turning may cause ASD damage.*

The ASD input voltage should remain within 10% of the specified input voltage range. Input voltages approaching the upper or lower-limit settings may require that the over-voltage and under-voltage stall protection level parameters be adjusted. Voltages outside of the permissible tolerance should be avoided.

The frequency of the input power should be  $\pm 2$  Hz of the specified input frequency.

**DO NOT** use an ASD with a motor that has a current rating that is greater than the rated current of the ASD.


The P9 ASD is designed to operate NEMA B motors. Consult with your TIC Sales Representative before using the ASD for special applications such as with an explosion-proof motor or applications with a piston load.

Disconnect the ASD from the motor before megging or applying a bypass voltage to the motor.

Interface problems may occur when an ASD is used in conjunction with some types of process controllers. Signal isolation may be required to prevent controller and/or ASD malfunction (contact your TIC Sales Representative or the process controller manufacturer for additional information on compatibility and signal isolation).

Use caution when setting the output frequency. Over speeding a motor decreases its ability to deliver torque and may result in damage to the motor and/or the driven equipment.

Not all P9 ASDs are equipped with internal primary power input fuses (HP dependent). When connecting two or more ASDs that have no internal fuse to the same power line as shown in [Figure 1](#), select a circuit-breaking configuration that will ensure that if a short circuit occurs in ASD 1, only MCCB2 trips, not MCCB1. If it is not feasible to use this configuration, insert a fuse between MCCB2 and ASD 1.



## Mounting the ASD

### CAUTION

— The following thermal specifications apply to the 230-volt and 460-volt ASDs ONLY —

Install the unit securely in a well ventilated area that is out of direct sunlight.

The ambient operating temperature rating of the P9 ASD is 14° to 104° F (-10° to 40° C).

The process of converting AC to DC, and then back to AC produces heat. During normal ASD operation, up to 5% of the input energy to the ASD may be dissipated as heat. If installing the ASD in a cabinet, ensure that there is adequate ventilation.

**DO NOT** operate the ASD with the enclosure door open or with any enclosure panels removed.

When installing adjacent ASDs horizontally, TIC recommends at least 5 cm of space between adjacent units. However, horizontally mounted ASDs may be installed side-by-side with no space in between the adjacent units — side-by-side installations require that the top cover be removed from each ASD.

For 150 HP and above ASDs, a minimum of 50 cm of space is required above and below adjacent units and any obstruction. This space is the recommended minimum space requirement for the ASD and ensures that adequate ventilation is provided for each unit. More space will provide a better environment for cooling (see the section titled [Enclosure and Conduit Plate Dimensions on pg. 271](#) for additional information on mounting space requirements).

**Note:** Ensure that the ventilation openings are not obstructed.

# Connecting the ASD



Refer to the section titled [Installation Precautions on pg. 4](#) and the section titled [Lead Length Specifications on pg. 20](#) before attempting to connect the ASD and/or the motor to electrical power.

## Power Connections



**Contact With 3-Phase Input/Output Terminals May Cause An Electrical Shock Resulting In Injury Or Loss Of Life.**

See the [Typical Connection Diagram on pg. 26](#) for a system I/O connectivity schematic.

An inductor (DCL) may be connected across the **PO** and **PA/+** terminals to provide additional filtering. When not used, a jumper must be connected across these terminals.

**PA/+** and **PB** are used for the DBR connection if using a braking resistor.

**PC/-** is the negative terminal of the DC bus.


**R/L1**, **S/L2**, and **T/L3** are the 3-phase input supply terminals for the ASD.

**U/T1**, **V/T2**, and **W/T3** are the output terminals of the ASD that connect to the motor.

The location of the **Charge Indicator LED** for the smaller typeform ASD is provided in [Figure 2](#).

**Note:** The Charge Indicator LED shown is of the 1 HP P9 ASD. See the accompanying drawings of your received P9 ASD for the actual location of the Charge Indicator LED.

Figure 2. Typical P9 ASD Input/Output Terminals, Charge Indicator LED, and the [Grounding Capacitor Switching](#).



[Grounding Capacitor Switching](#) — Pull for **Small** capacitance/push for **Large** capacitance.



## Power Connection Requirements

Connect the 3-phase input power to the input terminals of the ASD at **R/L1**, **S/L2**, and **T/L3** (see [Figure 3](#) for the typical electrical connection scheme). Connect the output of the ASD to the motor from the ASD terminals **U/T1**, **V/T2**, and **W/T3**. The input and output conductors and terminal lugs used shall be in accordance with the requirements listed in the section titled [Current/Voltage Specifications](#) on pg. 279.

If multiple conductors are used in parallel for the input or output power and it is necessary to use separate conduits, each parallel set shall have its own conduit and not share its conduit with other parallel sets (i.e., place U1, V1, W1, and a ground wire in one conduit and U2, V2, W2 and a ground wire in another; refer to the NEC Article 300.20 and Article 310.4). National and local electrical codes should be referenced if three or more power conductors are run in the same conduit (refer to the NEC Article 310 adjustment factors).

**Note:** *National and local codes should be referenced when running more than three conductors in the same conduit.*


Install a molded case circuit breaker (MCCB) or fuse between the 3-phase power source and the ASD in accordance with the fault current setting of the ASD and the **NEC Article 430**.

The ASD is designed and tested to comply with UL Standard 508C. Modifications to the ASD system or failure to comply with the short circuit protection requirements outlined in this manual may disqualify the UL rating. See [Table 23](#) on pg. 285 for typeform-specific short circuit protection recommendations.

As a minimum, the installation of the ASD shall conform to the **NEC Article 110**, the **Occupational Safety and Health Administration** requirements, and to any other local and regional industry codes and standards.

**Note:** *In the event that the motor rotates in the wrong direction when powered up, reverse any two of the three ASD output power leads (U, V, or W) connected to the motor.*

Figure 3. P9 ASD/Motor Typical Connection Diagram.



# System Grounding

Proper grounding helps to prevent electrical shock and to reduce electrical noise. The ASD is designed to be grounded in accordance with **Article 250** of the **NEC** or **Section 10/Part One** of the **Canadian Electrical Code (CEC)**.

The grounding conductor shall be sized in accordance with **Article 250-122** of the **NEC** or **Part One-Table 6** of the **CEC**.

## — The Metal Conduit Is Not An Acceptable Ground —

The input, output, and control lines of the system shall be run in separate metal conduits and each shall have its own ground conductor.

ASDs produce high-frequency noise — take steps to avoid the negative effects of noise. Listed below are some examples of measures that will help to combat noise problems.

- **DO NOT** install the input power and output power wires in the same duct or in parallel with each other, and do not bind them together.
- **DO NOT** install the input/output power wires and the wires of the control circuit in the same duct or in parallel with each other, and do not bind them together.
- Use shielded wires or twisted wires for the control circuits.
- Ensure that the grounding terminals (G/E) of the ASD are securely connected to ground.
- Connect a surge suppressor to every electromagnetic contactor and every relay installed near the ASD.
- Install noise filters as required.

## Grounding Capacitor



If operating using an ungrounded 3-phase power source or within a high-resistance grounding system, the **Grounding Capacitance** must be set to **Small** or **Out** (typeform-specific) as shown on [pg. 19](#). If set to **High** or **In**, a system malfunction, component failure, or fire may result.

The **Grounding Capacitor** plays a role in minimizing the effects of leakage current through the ASD system and through ground paths to other systems. Leakage current may cause the improper operation of earth-leakage current breakers, leakage-current relays, ground relays, fire alarms, and other sensors — and it may cause superimposed noise on CRT screens.

The [Grounding Capacitor Switching](#) allows the user to quickly change the value of the leakage-reduction capacitance of the 3-phase input circuit. See figures [4](#), [5](#), [6](#), and [7](#) on [pg. 19](#) for an electrical depiction of the leakage-reduction functionality and the methods used to change the capacitance value. The method used is typeform-specific.

If using a 460-volt 5 HP ASD or a 460-volt ASD that is in the range of 7.5 HP to 25 HP, and the **U/T1**, **V/T2**, and **W/T3** connections to the motor are 100 meters or more in length, the ASD **Carrier Frequency** must be set to 4 kHz or less when activating or deactivating the [Grounding Capacitor Switching](#). ASD overheating may occur if the **Carrier Frequency** is set above 4 kHz when activating or deactivating the [Grounding Capacitor Switching](#).

See [pg. 5](#) for more information on the [Grounding Capacitor Switching](#) and [pg. 16](#) for the switch location.

Figure 4. The **Grounding Capacitor**

**Switch** is used on typeforms **230-volt** 0.75 HP to 10 HP and the 25 and 30 HP/**460-volt** 1.0 HP to 25 HP.

The value may be set to **Maximum** (default setting) or to **Zero** by pushing or pulling the switch actuator, respectively.




Figure 5. The **Grounding Capacitor**

**Switch** is used on typeforms **230-volt** 15 HP and 20 HP and the 40 HP to 60 HP/**460-volt** 30 HP to 100 HP.

The value may be set to **Large** (default setting) or **Small** by pushing or pulling the switch actuator, respectively.




Figure 6. The **Grounding Capacitor**

**Bar** is used on typeforms **230-volt** 75 HP to 125 HP/**460-volt** 125 HP and the 150 HP.

The value may be set to **Large** or **Small** (default setting) by connecting or disconnecting the switching bar, respectively.





Figure 7. The **Grounding Capacitor**

**Screw** is used on typeforms **460-volt** 200 HP and above.

The value may be set to **Large** or **Small** (default setting) by placing the screw in the **A** position or by placing the screw in the **B** position, respectively.



# Lead Length Specifications

Adhere to the NEC and any local codes during the installation of ASD/motor systems. Excessive lead lengths may adversely affect the performance of the motor. Special cables are not required.

Lead lengths from the ASD to the motor in excess of those listed in [Table 1](#) may require filters to be added to the output of the ASD.

All Toshiba CT motors use an insulation system that is NEMA MG1 Part 30 compliant.

All Toshiba XT motors use an insulation system that is NEMA MG1 Part 31 compliant.

[Table 1](#) lists the suggested maximum lead lengths for the listed motor voltages.

Table 1. Lead Length Recommendations.

Model	PWM Carrier Frequency	NEMA MG1 Part 30 Compliant Motors	NEMA MG1 Part 31 Compliant Motors
230-Volt	All	450 feet	1000 feet
460-Volt	≤ 5 kHz	200 feet	600 feet
	> 5 kHz	100 feet	300 feet

**Note:** *Contact the TIC Customer Support Center for application assistance when using lead lengths in excess of those listed or for filter selection assistance for a given application.*

*Exceeding the peak voltage rating or the allowable thermal rise time of the motor insulation will reduce the life expectancy of the motor.*

*When operating in the **Vector Control** mode, the carrier frequency should be set to 2.2 kHz or above.*

# I/O and Control

The ASD can be controlled by several input types and combinations thereof, as well as operate within a wide range of output frequency and voltage levels. This section discusses the ASD control methods and supported I/O functions.

The **Terminal Board** supports discrete and analog I/O functions and is shown in [Figure 9 on pg 24](#). [Table 2](#) lists the names, functions, and settings (default settings of programmable terminals) of the input and output terminals of the **Terminal Board**.

**Note:** To use the input lines of the **Terminal Board** to provide **Run** commands, the **Command Mode** setting must be set to **Terminal Block**.

[Typical Connection Diagram on pg. 26](#) shows the typical connection diagram for the ASD system.

Table 2. Terminal Board Terminal Names and Functions.

Terminal Name	Input/Output	Function (Default Setting If Programmable) (See <a href="#">Terminal Descriptions on pg. 22</a> )	Circuit Config.
ST	Discrete Input	<b>Standby</b> — Multifunctional programmable discrete input. Activation required for normal ASD operation.	<a href="#">Figure 10 on pg 25</a> .
RES		<b>Reset</b> — Multifunctional programmable discrete input. Resets a faulted ASD.	
F		<b>Forward</b> — Multifunctional programmable discrete input.	
R		<b>Reverse</b> — Multifunctional programmable discrete input.	
S1		<b>Preset Speed 1</b> — Multifunctional programmable discrete input.	
S2		<b>Preset Speed 2</b> — Multifunctional programmable discrete input.	
S3		<b>Preset Speed 3</b> — Multifunctional programmable discrete input.	
S4		<b>Preset Speed 4</b> — Multifunctional programmable discrete input.	
O1A/B (OUT1)	Switched Output	<b>External Device 1</b> — Programmable contact (N.O.).	<a href="#">Figure 16 on pg 25</a> .
O2A/B (OUT2)		<b>External Device 2</b> — Programmable contact (N.O.).	
FLA		Fault relay (N.O.).	<a href="#">Figure 19 on pg 25</a> .
FLB		Fault relay (N.C.).	
FLC		Fault relay (common).	
RR	Analog Input	<b>Frequency Mode 1</b> — Multifunction programmable analog input. (0.0 to 10 VDC input — 0 Hz to Maximum Frequency).	<a href="#">Figure 11 on pg 25</a> .
RX		Multifunctional programmable analog input (-10 to +10 VDC input).	<a href="#">Figure 12 on pg 25</a> .
V/I (Select V or I via SW301)		Unassigned — <b>V</b> — Multifunctional programmable isolated analog voltage input (0 to 10 VDC input).	<a href="#">Figure 13 on pg 25</a> .
		<b>Frequency Mode 2</b> (default SW301 setting) — <b>I</b> — Multifunctional programmable isolated analog current input (4 [0] to 20 mADC input — 0 Hz to Maximum Frequency).	
AM	Analog Output	<b>Output Current</b> — Current output that is proportional to the output current of the ASD or to the magnitude of the function assigned to this terminal.	<a href="#">Figure 18 on pg 25</a>
FM		<b>Output Frequency</b> — <u>Current</u> or <u>Voltage</u> output that is proportional to the output frequency of the ASD or to the magnitude of the function assigned to this terminal. Select <b>Current</b> or <b>Voltage</b> at F681.	
SU+	DC Input	Externally-supplied 24 VDC backup control power (1.1 A min.).	
P24	DC Output	24 VDC output (200 mA max.).	<a href="#">Figure 14 on pg 25</a> .
PP		10.0 VDC/10 mA voltage source for an external potentiometer.	<a href="#">Figure 15 on pg 25</a> .
FP	Pulsed Output	<b>Frequency Pulse</b> — Multifunctional programmable output pulse train of a frequency based on the output frequency of the ASD.	<a href="#">Figure 17 on pg 25</a> .
IICC	—	Return for the <b>V/I</b> input terminal (see <b>IICC</b> on <a href="#">pg. 110</a> ).	<b>DO NOT</b> connect to <b>Earth Gnd</b> .
CCA	—	Return for the <b>RR</b> , <b>RX</b> , <b>P24</b> , and the <b>PP</b> terminals.	
CC	—	Return for the <b>AM</b> , <b>FM</b> , <b>SU+</b> , and the discrete input terminals.	

# Terminal Descriptions

**Note:** The programmable terminal assignments may be accessed and changed from the default settings as mapped on [pg. 52](#) or via the **Direct Access** method: Program  $\Rightarrow$  Direct Access  $\Rightarrow$  **Applicable Parameter Number**. See the section titled [Program Mode Menu Navigation on pg. 52](#) for the applicable **Direct Access** parameter numbers. For further information on terminal assignments and default setting changes, see the sections titled [Terminal on pg. 54](#) and [Default Setting Changes on pg. 40](#).

**Note:** See the section titled [Cable/Terminal/Torque Specifications on pg. 281](#) for the ASD conductor and terminal electrical specifications.

**ST** — The default setting for this terminal is the **Standby** mode controller. As the default setting, this terminal must be activated for normal system operation. The **ST** terminal is activated by connecting **CC** to this terminal (Sink mode). When deactivated, **OFF** is flashed on the LED screen and the **Not-Ready-to-Run** icon is displayed on the LCD screen as shown in [Figure 22 on pg 32](#). This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F113](#)).

**RES** — The default setting for this terminal is **Reset**. The **RES** terminal is activated by connecting **CC** to this terminal (Sink mode). A momentary connection to **CC** resets the ASD and any fault indications from the display. **Reset** is effective when faulted only. This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F114](#)).

**F** — The default setting for this terminal is the **Forward** run command. The **F** terminal is activated by connecting **CC** to this terminal (Sink mode). This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F111](#)).

**R** — The default setting for this terminal is the **Reverse** run command. The **R** terminal is activated by connecting **CC** to this terminal (Sink mode). This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F112](#)).

**S1** — The default setting for this terminal is the **Preset Speed 1** (see [Preset Speed 1 on pg. 88](#)). The **S1** terminal is activated by connecting **CC** to this terminal (Sink mode). This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F115](#)).

**S2** — The default setting for this terminal is the **Preset Speed 2** (see [Preset Speed 2 on pg. 88](#)). The **S2** terminal is activated by connecting **CC** to this terminal (Sink mode). This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F116](#)).

**S3** — The default setting for this terminal is the **Preset Speed 3** (see [Preset Speed 3 on pg. 89](#)). The **S3** terminal is activated by connecting **CC** to this terminal (Sink mode). This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F117](#)).

**S4** — The default setting for this terminal is the **Preset Speed 4** (see [Preset Speed 4 on pg. 89](#)). The **S4** terminal is activated by connecting **CC** to this terminal (Sink mode). This input terminal may be programmed to any of the functions listed in [Table 6 on pg. 249](#) (see [F118](#)).

**RR** — The default function assigned to this terminal is [Frequency Mode 1](#). The **RR** terminal accepts a 0 – 10 VDC input signal that is used to control the function assigned to this terminal. This input terminal may be programmed to control the speed or torque of the motor via an amplitude setting or regulate by setting a limit. The gain and bias of this terminal may be adjusted for application-specific suitability (see [F210 – F215](#)).

**RX** — The default function assigned to this terminal is [Torque Command](#). The **RX** terminal accepts a  $\pm 10$  VDC input signal that is used to control the function assigned to this terminal. This input terminal may be programmed to raise or lower the speed or torque of the motor via an amplitude setting or this terminal may be used to regulate the speed or torque of a motor by setting a limit. The gain and bias of this terminal may be adjusted for application-specific suitability (see [F216 – F221](#)).

**V/I** — The V/I terminal has the dual function of being able to receive an input voltage or current. The function as a voltage input is to receive a 0 – 10 VDC input signal. The function as a current input is to receive a 0 – 20 mA input signal. Using either input type, the function is to control the 0.0 – Maximum Frequency output or the 0.0 to 250% torque output of the ASD. This is an isolated input terminal. This terminal may be programmed to control the speed or torque of the motor and cannot process both input types simultaneously. [SW301](#) must be set to V or I to receive a voltage or current, respectively (see [Figure 9 on pg 24](#)). Terminal scaling is accomplished via [F201 – F206](#). The gain and bias of this terminal may be adjusted for application-specific suitability (see [F470](#) and [F471](#)).

**SU+** — **Control Power Supply Backup** input terminal. This terminal accepts the user-supplied 24 VDC backup power to the control circuits (only). Backup power is used in the event of an open MCCB or during a momentary loss of the 3-phase input power. Parameter settings, real-time clock information, and trip history information are retained with the use of the **SU+** backup power.

The P9 ASD is also equipped with an EOI-mounted battery for this function. The battery backup has the added feature of allowing for the transfer of the EOI to another ASD while retaining the control programming. See the section titled [Battery Backup on pg. 28](#) for more information on the battery backup features.

**P24** — +24 VDC at 200 mA power supply for customer use.

**PP** — The function of output **PP** is to provide a 10 VDC/10 mADC (max.) output that may be divided using a potentiometer. The tapped voltage is applied to the **RR** input to provide manual control of the **RR** programmed function.

**O1A/B** (OUT1A/B) — The default function assigned to this terminal is [External Device 1](#). The function as **External Device 1** is to activate or deactivate an auxiliary motor once the VLP level has remained within the **VLP Maximum Zone** or the **VLP Minimum Zone**, respectively, for the time setting of [F480](#). The **OUT1** terminal is rated at 2 A/120 VAC and 2 A/30 VDC. This terminal may be set to any of the functions listed in [Table 9 on pg. 255](#) (see [F130](#)).

**O2A/B** (OUT2A/B) — The default function assigned to this terminal is [External Device 2](#). The function as **External Device 2**, in conjunction with External Device 1, is to activate or deactivate an auxiliary motor once the VLP level has remained within the **VLP Maximum Zone** or the **VLP Minimum Zone**, respectively, for the time setting of [F480](#). The **OUT2** terminal is rated at 2 A/120 VAC and 2 A/30 VDC. This terminal may be set to any of the functions listed in [Table 9 on pg. 255](#) (see [F131](#)).

**FP** — The default function of this output terminal is to output a series of pulses at a rate that is a function of the ASD output frequency (50 mA max. at 1.0 kHz to 43.3 kHz). As the output frequency of the ASD goes up so does the **FP** output pulse rate. This terminal may be programmed to provide an output pulse rate that is proportional to the magnitude of the user-selected item from [Table 7 on pg. 253](#). For further information on this terminal, see parameter [F676 on pg. 209](#).

**AM** — This output terminal produces an output current that is proportional to the output frequency of the ASD or of the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 7 on pg. 253](#). For further information on this terminal, see [F670 on pg. 208](#).

**FM** — This output terminal produces an output current or voltage that is proportional to the output frequency of the ASD or of the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 7 on pg. 253](#). For further information on this terminal, see [F005 on pg. 83](#). The Voltage/Current output selection is performed at [F681](#).

**FLA** — One of two normally open contacts that, under user-defined conditions, connect to **FLC**.

**FLB** — One of two normally closed contacts that, under user-defined conditions, connect to **FLC**.



**FLC** — **FLC** is the common leg of a single-pole double-throw form C relay. The **FL** relay is the **Fault Relay** by default, but may be programmed to any of the selections of [Table 9 on pg. 255](#). For further information on this terminal, see [F132](#) and [Figure 8 on pg 24](#).

**Note:** The **FLA**, **FLB**, and **FLC** contacts are rated at 2A/120 VAC and 2A/30 VDC.

Figure 8. FLA, FLB, and FLC Switching Contacts Shown in the Normal Operating Condition.





Figure 9. Terminal Board.



See the section titled [Terminal Descriptions on pg. 22](#) for terminal descriptions.

See the section titled [Cable/Terminal/Torque Specifications on pg. 281](#) for information on the proper cable/terminal sizes and torque specifications when making **Terminal Board** connections.



# I/O Circuit Configurations

Figure 10. Discrete Input.




Figure 11. RR Input.




Figure 12. RX Input.




Figure 13. V/I Isolated Input.




Figure 14. P24 Output.




Figure 15. PP Output.




Figure 16. OUT1/OUT2 Output.




Figure 17. FP Output.




Figure 18. AM/FM Output.






Figure 19. Fault Relay (shown not faulted).



# Typical Connection Diagram

Figure 20. The P9 ASD Typical Connection Diagram.

**Note:** When connecting multiple wires to the PA, PB, PC, or PO terminals, do not connect a solid wire and a stranded wire to the same terminal.



**Note:** The AM, FM, and the +SU analog terminals are referenced to CC.  
The RR, RX, P24, and the PP analog terminals are referenced to CCA.  
The isolated V/I analog terminal references IICC.

## Startup and Test



# DANGER

Before turning on the ASD ensure that:

- **R/L1, S/L2, and T/L3** are connected to the 3-phase input power.
- **U/T1, V/T2, and W/T3** are connected to the motor.
- The 3-phase input voltage is within the specified tolerance.
- There are no shorts and all grounds are secured.
- All personnel are at a safe distance from the motor and the motor-driven equipment.

Use the following table to record any changed parameters for future reference.

Table 3. ASD Parameter Changes by Installer/Maintenance Personnel.

ASD ID _____ Name: _____ Date: _____					Notes
Parameter Number	Parameter Name	Default or Previous Setting	New Setting	Unit of Measure	

**Note:** Settings may also be recorded via Program ⇒ Utilities ⇒ Type Reset ⇒ *Save User Settings*.

# Electronic Operator Interface

The P9 ASD **Electronic Operator Interface** (EOI) is comprised of an LED screen, an LCD screen, two LEDs, a rotary encoder, and five keys. These items are shown and described on [pg. 30](#).

## EOI Operation

The **EOI** is the primary input/output device for the user. The **EOI** may be used to monitor system functions, input data into the system, perform diagnostics, and view performance data (e.g., motor frequency, bus voltage, torque, etc.).

The software used with the P9 ASD is menu driven; thus, making it a select and click environment. The operating parameters of a motor may be selected and viewed or changed using the **EOI** (or via communications).

## Battery Backup

The EOI is equipped with a battery backup system. The function of the backup system is to retain the EOI SRAM programming in the event of a power outage, or if an EOI removal and installation from one system to another is required without the loss of programming.

Listed below are the items retained by the battery backup system:

- [Trip History](#),
- [EOI Contrast](#),
- [Real-Time Clock](#) Information,
- [Monitored Items](#),
- [Password and Lockout](#) Information,
- [Alarm](#) Information,
- [Main Monitor](#) Items,
- [Prohibited](#) Items, and
- [Save User Settings](#) (Parameter settings may be saved by the user).

**Note:** *User settings must be stored by the user to result in battery backup support. Otherwise, in the event of a power outage, the user settings will not be retained. Retained settings will be erased and/or overwritten during a **Type Reset** via selections **3** or **12**.*

The battery backup system must be activated by the installer or maintenance personnel to use the backup function.

To activate the battery backup system, remove the Phillips screw from the front of the LED/LCD display unit. Remove the LED/LCD display unit from the ASD. From the circuit side of the display unit, remove the jumper at **J1**, pins **2** and **3**. Place the jumper at **J1**, pins **1** and **2** (as shown).

The expected battery life cycle is four and a half years.

**Note:** *The Battery backup system does not supply power to the LED/LCD display.*

### LED/LCD Screen Installation Note

When installing the LED/LCD display unit of the EOI, ensure that the left side of the display is inserted first with the top and bottom catches (See Phillips screws at underside of display) securely in



place. This ensures the proper alignment and electrical connection of the CNX connector of the LED/LCD display unit PCB. Gently hold the display in place while securing the Phillips mounting screw.

If improperly seated, the periphery of the LED/LCD display unit will not be flush with the EOI surface and the unit will not function properly.

## Real-Time Clock Setting

The Real-Time Clock of the P9 ASD provides a time stamp of the trip history, Time-Based Alternation control timing, and other real-time event control functions.

The Real-Time Clock must be set in order to use the real-time monitoring and control functions of the ASD (trip history dates, Time-Based Alternation, etc.).

Set the Real-Time Clock from Program\Utilities\**Real-Time Clock Setup**. Scroll to select the field to be changed. Press **Enter** to enter the **Edit** mode. Turn the rotary encoder to change the value. Once set, press **Escape** to exit without accepting the change, or press **Enter** to accept the change.

Continue to subsequent fields of the **Real-Time Clock Setup** screen and repeat the procedure until done.

## EOI Remote Mounting


The EOI may be mounted remotely using the optional **ASD-MTG-KIT-P9**. Or if operating in a **NEMA 4** environment, the **ASD-EOI-N4-G9** is best suited for this application. Each kit contains all of the hardware required to mount the EOI of the HX7+ ASD remotely.

System operation and EOI operation while using the remotely-mounted EOI are the same as with the ASD-mounted configuration.

See the section titled [EOI Remote Mounting on pg. 33](#) for more information on mounting the EOI remotely.

# EOI Features

Figure 21. The P9 ASD Electronic Operator Interface Features.



**LED Screen** — Displays the running frequency, active **Fault**, or active **Alarm** information.

**Rotary Encoder** — Used to access the P9 ASD menu selections, change the value of a displayed parameter, and performs the **Enter** key function. Turn the **Rotary Encoder** either clockwise or counterclockwise to perform the **Up** or **Down** functions of the displayed menu selection. Press the **Rotary Encoder** to perform the **Enter** (select) function. Press while turning for times-ten increment/decrement.

**LCD Screen** — Displays configuration information, performance data (e.g., output frequency, bus voltage, torque, etc.), diagnostic information, and **LED** screen information in expanded normal text.

**Hand/Auto Key** — Toggles the system to and from the **Hand** and **Auto** modes. The **Hand/Auto** key is disabled while the **Fault** screen is active. The **Hand/Auto** key LED is on when the system is in the **Hand** mode. The **Hand** mode allows the **Command** and **Frequency** control functions to be carried out via the **EOI**.

The **Auto** mode enables the **Command** and **Frequency** control functions to be carried out via the **Terminal Board**, **RS485**, **Communication Board**, **Pulse Input**, or the settings of **F003/F004**. The (**F003/F004**) selection may be made via Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Command Mode** and **Frequency Mode 1**, respectively.

The availability of **Hand** mode control (**Command** and **Frequency** control) may be disabled via Program ⇒ Utilities ⇒ Prohibition ⇒ **Hand/Auto Key Command Override** and **Hand/Auto Key Frequency Override**. The availability of the **Hand** mode of operation may be reinstated by changing this setting or performing a **Reset** (See **F007**).

**ESC Key** — Returns the system to the previous level of the menu tree, toggles between the **EOI Command** screen and the **Frequency Command** screen, or cancels changes made to a field if pressed while still in the reverse video mode (dark background/light text). The three functions are menu-specific.

**Run Key** — Issues the **Run** command while in the **Hand** mode. The **Run** key LED illuminates green while stopped or red while running to alert personnel.

**Mode Key** — Provides a means to access the three root menus. Pressing the **Mode** key repeatedly loops the system through the three root menus (See [Figure 28 on pg. 47](#)). While looping through the root menus, the **Program** menu will display the root menu screen or the **Program** sub-menu item being accessed prior to pressing the **Mode** key.

**Stop-Reset Key** — This key has three functions.

1. Issues the **Off** command (decelerates to **Stop** at the programmed rate) if pressed once while in the **Hand** mode in accordance with the setting of [F721](#).
2. Initiates an **Emergency Off Fault** if pressed twice quickly from the **Hand** or **Auto** modes. The **Emergency Off** function terminates the P9 ASD output and stops the motor in accordance with the setting of [F603](#).
3. Resets active **Faults** and/or active **Alarms** if pressed twice quickly. The source of the **Faults** or **Alarms** must be determined and corrected before normal ASD operation can resume.

## LED/LCD Screens

### LED Display

The LED screen displays the output frequency, active alarms and/or active faults.

If there are no active alarms or faults, the output frequency is displayed.

During an active alarm, the display toggles to and from the running frequency and the active alarm.

During an active fault, the fault is displayed.

Loss of the **ST-to-CC** connection flashes **Off**.

### LED Character/Font Information

Characters displayed on the LED screen will be of the seven-segment format. Not all alpha-numeric characters are used with the LED screen.

Listed are the seven-segment characters used with the LED screen along with the same characters as they are displayed on the LCD screen.

### LCD Display

The LCD screen displays the percentage of the Maximum Frequency (if running), running frequency (if running), Ready-to-Run indicator, Main Monitor Selections, and the discrete I/O terminal status.

### LCD Character/Font Information

All alpha-numeric characters are available.

LED/LCD Screen Information			
LED	LCD	LED	LCD
A	A	1	1
b	b	2	2
C	C	3	3
d	d	4	4
E	E	5	5
F	F	6	6
G	G	7	7
H	H	8	8
I	I	9	9
J	J	0	0
L	L		
M	M		
n	n		
O	O		
P	P		
q	q		
r	r		
S	S		
t	t		
U	U		
v	v		
y	y		
-	-		

## Using the LCD Screen

The **LCD** screen is the primary user input/output information center. Parameter settings may be viewed or changed using the LCD display unit of the **EOI**. To view or change a parameter setting using the LCD screen, press the **Mode** key until the **Program** menu is displayed. Turn the **Rotary Encoder** until the desired **Primary Menu** item (See [pg. 52](#)) is within the cursor block. Press the **Rotary Encoder** to select the item from the **Primary Menu** (repeat the press-to-select for submenu items).

See the section titled [Default Setting Changes on pg. 40](#) for more information on changing parameter settings.

Upon reaching the desired parameter selection, the current setting may be viewed, or selected and changed by pressing the **Rotary Encoder** and the setting will take on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter setting. Press the **ESC** key while the new parameter setting is in the reverse video mode to exit the selection without saving the change or press the **Rotary Encoder** while the parameter setting is in the reverse video mode to accept the change.

Repeated **ESC** key entries at any time takes the menu back one level each time the **ESC** key is pressed until the **Frequency Command** screen is reached. Further **ESC** entries will toggle the system to and from the **Frequency Command** screen and the **EOI Command** menu.

**Note:** Changes carried out from the **EOI Command** screen will be effective for **EOI-controlled ASD operation only**. See the section titled [EOI Command Mode on pg. 48](#) for further information on [EOI Command Mode](#) operations.

## Primary Menus of the LCD Screen

The three primary screens of the LCD screen are displayed while accessing the associated operating mode: the **Frequency Command**, **Monitor**, and the **Program Menu** screens.

Figure 22. **Frequency Command** Screen.




Figure 23. **Monitor** Screen (See [pg. 49](#) for more on the Monitor screen items).





Figure 24. **Program Menu** Screen (See [pg. 52](#) for more on the Program Menu Screen).





# EOI Remote Mounting

The P9 ASD may be controlled from a remotely-mounted EOI. For safety and application-specific reasons, some ASD installations will warrant that the operator not be in the vicinity during operation or that the EOI not be attached to the ASD housing. Remote mounting will also allow for multiple EOI mountings at one location if controlling and monitoring several ASDs from a central location is required.

The door-mounted EOI of the 230-volt 30-HP and above ASDs, and the 460-volt 40 HP and above ASDs, use the remote mounting kit **58333** to allow for the door-mount EOI configuration.

The ease of installation and mounting distance away from the ASD may be increased with the use of the optional remote mounting kit [ASD-MTG-KIT-P9](#).

The **ASD-EOI-N4-G9** remote-mount kit is recommended for **NEMA 4** applications. Contact your TIC Sales Representative for more information on the **NEMA 4** remote mounting kit.

An EOI extender cable is required for remote mounting. The EOI extender cable is available in a 10-ft. length and may be ordered through your TIC Sales Representative. Remote mounting may be extended up to the distance supported by standard RS485 communication — typically 4000 feet (1200 meters) maximum.

The optional dust cover (P/N ASD-BPC) may be used to cover the EOI opening of the ASD housing after removing the EOI.

## Remote EOI Hardware

### EOI Mounting Hardware

- EOI Remote-Mount Housing — P/N 58333 (included with the 230-volt 30-HP and above; and with the 460-volt 40 HP and above)
- 6-32 x 5/16" Pan Head Screw — P/N 50595 (4 ea.)
- #6 Split-Lock Washer — P/N 01884 (4 ea.)
- #6 Flat Washer — P/N 01885 (4 ea.)

### Bezel Plate Mounting Hardware

- Bezel Plate — P/N 52291
- 10-32 Hex Nut — P/N 01922 (4 ea.)
- #10 Split-Lock Washer — P/N 01923 (4 ea.)
- #10 Flat Washer — P/N 01924 (4 ea.)
- Dust Cover — P/N ASD-BPC (Optional)

### Extender Cable

- ASD-CAB10F: Cable, 10 ft.

## EOI Installation Precautions

Install the unit securely in a well ventilated area that is out of direct sunlight using the four mounting holes at the rear of the EOI. The ambient operating temperature rating is 14° to 104° F (-10° to 40° C).

- Select a mounting location that is easily accessible by the user.
- Avoid installation in areas where vibration, heat, humidity, dust, metal particles, or high levels of electrical noise (EMI) are present.
- **DO NOT** install the EOI where it may be exposed to flammable chemicals or gases, water, solvents, or other fluids.
- Turn on the power only after securing the front cover of the ASD.


## EOI Remote Mounting w/o the ASD-MTG-KIT-P9

*Note:* See [Figure 25](#) for the dimensions and the item locations referenced in steps 1 through 5.

1. At the EOI mounting location, mark the 4.00" by 3.63" hole and the four 3/16" screw holes.
2. Cut the 4.00" by 3.63" rectangular hole.
3. Drill the four 3/16" screw holes.
4. Attach and secure the EOI to the front side of the mounting location using the four 6-32 x 5/16" pan head screws, the #6 split lock washers, and the #6 flat washers.
5. Connect the extension cable.

## EOI Mounting Dimensions

Figure 25. EOI Mounting Dimensions.



Unless otherwise specified,  
dimensions are in inches (millimeters).


# EOI Remote Mounting Using the ASD-MTG-KIT-P9

*Note:* See [Figure 26](#) for the dimensions and the item locations referenced in steps 1 through 6.

1. At the EOI mounting location, mark the 4.60" by 4.50" hole and the four 11/32" screw holes.
2. Cut the 4.60" by 4.50" rectangular hole.
3. Drill the four 11/32" holes for the Bezel Plate mount.
4. Attach and secure the Bezel Plate to the front side of the mounting location using the four 10-32 hex nuts, #10 split lock washers, and the #10 flat washers.
5. Attach and secure the EOI to the front side of the Bezel Plate using the four 6-32 x 5/16" pan head screws, #6 split lock washers, and the #6 flat washers.
6. Connect the extension cable.

## EOI ASD-MTG-KIT-P9 Mounting Dimensions

Figure 26. EOI Bezel Plate Mounting Dimensions.



# System Operation

## Initial Setup

The **Standard Startup Wizard** is run from Program\Utilities\Standard Startup Wizard and is used to assist the user with the initial configuration of the input power settings and the output signal parameters of the ASD. The **Standard Startup Wizard** is comprised of the more commonly used parameters of the ASD. The parameters of the wizard may also be viewed or changed individually via the associated **Direct Access Numbers** or the **Program Menu** hierarchy.

## Standard Startup Wizard Parameters

Startup parameter settings may be viewed or changed. Change the parameter setting and click **Next**. Or click **Next** without making any changes to go to the next startup parameter.

See the section titled [Standard Startup Wizard Parameter Requirements on pg. 37](#) for further information on the **Standard Startup Wizard** parameters.

1. The [Voltage and Frequency Rating of the Motor \(F409/F014\)](#) (Must make a selection to continue, or select **Exit**).
2. The [Upper-Limit Frequency \(F012\)](#).
3. The [Lower-Limit Frequency \(F013\)](#).
4. The [Automatic Acceleration/Deceleration \(F000\) Setting](#).
5. The [Acceleration Time \(F009\)](#).
6. The [Deceleration Time \(F010\)](#).
7. The [Volts per Hertz Setting \(F015\)](#).
8. The [Motor Current Rating \(F406\)](#).
9. The [Motor RPM \(F407\)](#).
10. The [Command Source \(F003\)](#).
11. The [Frequency Reference Source \(F004\)](#).
12. The [Display Unit \(F701\)](#).
13. [Exit >>](#).

Click **Exit** to close the **Standard Startup Wizard** when done.

# Standard Startup Wizard Parameter Requirements

The **Standard Startup Wizard** queries the user for information on the I/O signal parameters, control, and the EOI display settings of the ASD. The ASD may also be setup by directly accessing each of the startup settings via the [Program](#) menu or the associated **Direct Access Numbers** (See the section titled [Direct Access Parameter Information on pg. 81](#)).

## Voltage and Frequency Rating of the Motor ([F409/F014](#))

Motors are designed and manufactured to be operated within a specific voltage and frequency range. The voltage and frequency specifications for a given motor may be found on the name-plate of the motor. Highlight and click the voltage and frequency of the motor being used.

## Upper-Limit Frequency ([F012](#))

This parameter sets the highest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD may output frequencies higher than the **Upper-Limit Frequency** (but, lower than the **Maximum Frequency**) when operating in the **PID Control** mode, **Torque Control** mode, or the **Vector Control** modes (sensorless or feedback).

## Lower-Limit Frequency ([F013](#))

This parameter sets the lowest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD will output frequencies lower than the **Lower-Limit Frequency** when accelerating to the lower-limit or decelerating to a stop. Frequencies below the **Lower-Limit** may be output when operating in the **PID Control** mode, **Torque Control** mode, or the **Vector Control** modes (sensorless or feedback).

## Automatic Acceleration/Deceleration ([F000](#))

When **Automatic ACC/DEC** is chosen, the ASD adjusts the acceleration and deceleration rates according to the applied load. The minimum accel/decel time may be set using [F508](#). The motor and the load must be connected prior to selecting **Automatic Accel/Decel**.

Select **Manual** to allow the settings of [F009](#) and [F010](#) to control the accel/decel, respectively. The acceleration and deceleration times range from 12.5% to 800% of the programmed values for the active acceleration time.

Select **Automatic ACC Only** to allow for the acceleration rate to be controlled automatically only.

## Acceleration Time ([F009](#))

This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** for the **1 Acceleration** profile. The **Accel/Decel Pattern** may be set using [F502](#).

## Deceleration Time ([F010](#))

This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **1 Deceleration** profile. The **Accel/Decel Pattern** may be set using [F502](#).

## Volts per Hertz Setting (F015)

This function establishes the relationship between the output frequency and the output voltage of the ASD.

Settings:

- Constant Torque
- Voltage Decrease Curve
- Automatic Torque Boost
- Sensorless Vector Control (Speed)
- Sensorless Vector Control (Speed/Torque Switching)
- V/f 5-Point Curve (Go to [F190](#) to Configure the V/f 5-Point Settings)
- PM Drive (Permanent Magnet)
- PG Feedback Vector Control (Speed)
- PG Feedback Vector Control (Speed/Torque Switching)

## Motor Current Rating (F406)

This parameter allows the user to input the full load amperage (FLA) of the motor. This value is found on the name-plate of the motor and is used by the ASD to determine the **Thermal Overload Protection** setting for the motor.

## Motor RPM (F407)

This parameter is used to input the (name-plated) rated speed of the motor.

## Command Source (F003)

This selection allows the user to establish the source of the **Run** commands. Run commands are **Run**, **Stop**, **Jog**, etc.

Settings:

- Use Terminal Block
- Use EOI Keypad
- Use RS485
- Use Communication Option Board

## Frequency Reference Source (F004)

This selection allows the user to establish the source of the **Frequency** command.

Settings:

- Use VI/II (V/I)
- Use RR
- Use RX
- EOI Keypad
- RS485
- Communication Option Board
- RX2 Option (AI1)
- Option V/I
- UP/DOWN Frequency
- Pulse Input (Option)
- Pulse Input (Motor CPU)
- Binary/BCD Input (Option)

## Display Unit (F701)

This parameter sets the unit of measurement for current and voltage values displayed on the EOI.

## Exit >>

This is the final screen of the **Standard Startup Wizard**. The basic parameters of the ASD have been set. Click **Exit** to return to the [Frequency Command Screen](#). Additional application-specific programming may be required.


# Operation (Hand)

**Note:** See the section titled [EOI Features on pg. 30](#) for information on **Auto** operation.

To turn the motor on, perform the following:

1. Connect the **CC** terminal to the **ST** terminal.
2. Press the **Mode** key until the **Frequency Command** screen is displayed.
3. Press the **Hand/Auto** key to enter the **Hand** mode (green **Hand** LED illuminates).
4. Turn the **Rotary Encoder** clockwise until the desired **Frequency Command** value is displayed in the **SET** field of the LCD screen.
5. Press the **Run** key and the motor runs at the **Frequency Command** value.

Frequency Command Screen

0 ————— 100%			
SET:	0.00 Hz		
DC Voltage:		0.00%	
Output Current:		0.00%	
F R ST RES S1 S2 S3 S4			
OUT1 OUT2 FL			

**Note:** The speed of the motor may be changed while the motor is running by using the **Rotary Encoder** to change the **Frequency Command** value.

6. Press the **Stop-Reset** key to stop the motor.

# Default Setting Changes

To change a default parameter setting, go to the root level of the [Program](#) menu. Turn the **Rotary Encoder** until the desired parameter group is within the cursor block. Press the **Rotary Encoder** to select an item or to access a subgroup (repeat if required until reaching the parameter to be changed).

Press the **Rotary Encoder** to enter the **Edit** mode and the value/setting takes on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter value/setting.

Press **ESC** key while the new parameter setting is still in the reverse video mode to exit the menu without saving the change or press the **Rotary Encoder** while the parameter setting is in the reverse video mode to accept the new setting.

For a complete listing of the [Program](#) mode menu selections, see the section titled [Program Mode Menu Navigation on pg. 52](#). [Program](#) menu items are listed and mapped for convenience. The **Direct Access Numbers** are listed where applicable.

The default settings may also be changed by entering the **Parameter Number** of the setting to be changed at the **Direct Access** menu (Program ⇒ Direct Access ⇒ *Applicable Parameter Number*). A listing of the **Direct Access Numbers** and a description of the associated parameter may be found in the section titled [Direct Access Parameter Information on pg. 81](#).

A listing of all parameters that have been changed from the default setting may be viewed sequentially by accessing the **Changed From Default** screen (Program ⇒ Utilities ⇒ **Changed From Default**).

The **Changed From Default** feature allows the user to quickly access the parameters that are different from the factory default settings or the post-Reset settings. Once the **Changed From Default** screen is displayed, the system scrolls through all of the system parameters automatically and halts once reaching a changed parameter.

Once stopped at a changed parameter, the **Rotary Encoder** may be clicked once clockwise to continue scrolling forward or clicked once counterclockwise to begin scrolling in reverse. With each click of the **Rotary Encoder** from a stop, the system scrolls through the parameters and stops at the next parameter that has been changed.

Press the **Rotary Encoder** while stopped at a changed parameter to display the settings of the changed parameter. Press the **Rotary Encoder** to enter the **Edit** mode — the parameter value/setting takes on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter setting.


Press the **ESC** key while the setting is in the reverse video format to exit the **Edit** mode without saving the change and to resume the **Changed From Default** search. Or press the **Rotary Encoder** while the setting is in the reverse video format to save the change. Press **ESC** to return to the **Changed From Default** search.

Pressing **ESC** while the system is performing a **Changed From Default** search terminates the search. Pressing **ESC** when finished searching (or halted at a changed parameter) takes the menu back one level.

**Note:** *Communications setting changes will require that the power be removed and then re-applied for the changes to take affect.*

**Note:** *Parameter [F201](#) was changed to create the example shown in [Figure 27](#).*

Figure 27. Changed From Default Screen.





# Saving User Settings

A profile of an existing setup (user-settable parameters) may be saved and re-loaded when required by using the **Save User Settings/Restore User Settings** feature or via the **Save/Restore Wizard**.

Both Save functions are accessed via the **Utilities** menu.

## Save/Restore User Settings

The **Save User Settings** feature is selection seven (7) of the Program\Utilities\**Type Reset** menu. This function saves the user parameter settings to the EEPROM of the ASD. Because this feature is not available while the ASD is running, the ASD must be stopped to save or restore data using either of these selections.

The **8:Restore User Settings** selection of the Program\Utilities\**Type Reset** menu restores the saved user parameters for system operation.

## Save/Restore Wizard

The **Save/Restore Wizard** feature is accessed via Program\Utilities\**Save/Restore Wizard**. This function saves the user parameter settings to the SRAM of the EOI and is menu-driven. From the **Save/Restore Wizard** dialog box, select either **Save User Settings to EOI** or **Restore User Settings from EOI**. The restore feature is not available or displayed for selection until a profile is saved.

Because the **Save/Restore Wizard** saves to the EOI, the saved data may be loaded into other systems as required by installing the loaded EOI and executing the **Restore User Settings from EOI**.

From the Program\Utilities\**Type Reset** menu, selections **3:Reset to Factory Settings** and **12:Set EOI Memory to Default** will clear the EOI memory of any user-stored information.

**Note:** See the section titled [Battery Backup on pg. 28](#) for more information on the EOI storage function.

# Command Mode and Frequency Mode Control

**Command** control includes instructions such as **Stop**, **Run**, **Jog**, etc. The source of the **Command** signal must be established for normal operation.

**Frequency** commands control the output speed of the P9 ASD. The source of the frequency control signal must be established for normal operation.

The source of the command control and frequency control may be either internal or external. Once the source signal is selected for either function, the system may be configured to use the selected signal all of the time or switch under user-defined conditions.

**Command** and **Frequency** control may be carried out using any one of several control methods (signal sources) or combinations thereof. In the event that multiple control commands are received, the signal sources are assigned priority levels. The primary control method for **Command** and **Frequency** control uses the settings of **F003** and **F004**, respectively.

## Command Control (**F003**)

The **Command Mode** selection of **F003** establishes the primary source of the command input for the ASD. However, the **Override** feature may supersede the **F003** setting as indicated in [Table 4 on pg. 44](#).

[Table 4](#) shows the hierarchy of the control sources managed by the **Override** function. The level of the control item of the hierarchy is listed from left to right, most to least, respectively. As indicated in the table, the **Override** setting may supersede the **F003** setting.

01:06
Standard Mode Selection
(F003) Command Mode Selection
Terminal Block

Placing the EOI in the **Hand** mode selects the **RS485** (2-wire) as the **Command Mode** control source. **Hand** mode operation may be superseded by other **Override** settings.

**Example:** With the EOI set to **Hand**, **Communication Board** input or **RS485** (4-wire) input will supersede EOI control input.

The remaining control sources may be placed into the **Override Mode** using communications.

The source of the **Command** control signal may be selected by:

- The **F003** setting,
- Placing an item from the **Command** signal source selections in the **Override Mode** via communications, or
- Placing the EOI in the **Hand** mode (places only the RS485 [2-wire] or the RS485 [4-wire] in the **Override Mode**).

Possible **Command** signal source selections include the following:

- Terminal Block (default),
- EOI Keypad,
- RS485,
- Communication Option Board, or
- **F003** setting (is used if no signal sources are in the **Override Mode**).

**Note:** The **Terminal Board** is placed in the **Override Mode** for **Command** functions by activating a discrete terminal that is assigned to **Command Terminal Board Priority**.

# Frequency Control (F004)

The **Frequency Mode 1** (or the Frequency Mode 2) setting establishes the user-selected source of the frequency-control input for the P9 ASD. The signal source selected here is used for speed control unless the **Reference Priority Selection** parameter is configured to switch this setting automatically (See F200) or if the **Override** feature is enabled.

02:06
Standard Mode Selection
(F004) Frequency Mode 1
RR

Table 4 on pg. 44 shows the hierarchy of the control sources managed by the **Override** function. The level of the control item of the hierarchy is listed from left to right, most to least, respectively. As indicated in the table, the **Override** setting may supersede the selection at F004.

Placing the EOI in the **Hand** mode selects the **RS485** (2-wire) as the **Frequency Mode 1** control source. **Hand** mode operation may be superseded by other **Override** settings.

**Example:** With the EOI set to **Hand**, the **Communication Board** input or the **RS485** (4-wire) input will supersede EOI control input.

The remaining control sources may be placed into the **Override Mode** using communications.

The source of the **Frequency** control signal may be selected by:

- The F004 setting,
- Placing an item from the **Frequency** control source selections in the **Override Mode** via communications, or
- Placing the EOI in the **Hand** mode (places only the **RS485** [2-wire] in the **Override Mode**).

Possible **Frequency** control source selections include the following:

- Communication Board,
- RS485,
- EOI Keypad,
- Terminal Block (the default setting), or
- F004 setting (used if no other items are in the **Override mode**).

**Note:** The **Terminal Board** is placed in the **Override Mode** for **Speed** control functions by activating a discrete terminal that is assigned to **V/I Terminal Priority**. Once the discrete terminal is activated, **V/I** is used as the **Terminal Board Override** speed-control input.

## Command and Frequency Control Selections

The user may select only one **Command** source and only one source for **Frequency** control. The default settings for **Command** and **Frequency** control are **Terminal Block** and **RR**, respectively.

The P9 ASD has a command register that holds each of the items listed in Table 4 on pg. 44 as a **Command** or **Frequency** source. The listed items are continuously scanned to determine if any of the listed items are providing a **Command** or **Frequency** command.

The first active item of the **Command** section and the first active item of the **Frequency** section (both are read from left to right) detected as having an active signal will be used for **Command** and **Frequency** control, respectively. If no items are detected as having an active signal, the settings of F003 and F004 will be used for **Command** and **Frequency** control, respectively.

Placing the P9 ASD in the **Hand** mode (Hand/Auto LED on) via the EOI places the **RS485** (2-wire) control selection in the **Override Mode** for **Command** and **Frequency** input (See the section titled [Override Operation](#) for the proper setting). The **Hand/Auto** control **Override** feature for **Command** and **Frequency** (or either) may be enabled/disabled at Program ⇒ Utilities ⇒ Prohibition ⇒ **Hand/Auto Key** (Command or Frequency) **Override**.

**Communications** may be used to place the remaining **Command** and eligible **Frequency** control input sources in the **Override Mode**. Once placed in the **Override Mode**, this setting is valid until it is cancelled, the power supply is turned off, or the P9 ASD is reset.

## Override Operation

The signal sources of [Table 4](#) are scanned from left to right in the order that they are listed to determine which input sources are in the **Override Mode** (active Command or Frequency command signal present). The first item detected as having the **Override** function turned on is the selection that is used for **Command** or **Frequency** control input.

The **Override** control setting supersedes the setting of the **Command** mode setting ([F003](#)) and the **Frequency** mode setting ([F004](#)). However, the [F003](#) and [F004](#) settings will be used in the event that the register scan returns the condition that none of the listed items have the **Override** feature turned on or a discrete input terminal is set to **Hand Priority** and is activated.

## Command and Frequency-Control Override Hierarchy

[Table 4](#) lists the input conditions and the resulting output control source selections for **Command** and **Frequency** control **Override** operation.

The P9 ASD software reads the listed control sources from the left to the right as listed in [Table 4](#).

The first item to be read that has the **Override** feature turned on will be used for **Command** or **Frequency** control.

Table 4. Command and Frequency Control Hierarchy.

1	2	3	4	5	6	← Priority Level
Forced F003/ F004 by I/P Terminal (Assign to Hand Priority)	Comm. Board	RS485 (4-Wire)	RS485 (2-Wire)	Terminal Board (Binary/BCD Input)	F003/F004	Command/ Frequency Mode
1	X	X	X	X	X	F003/F004 Setting
0	1	X	X	X	X	Communication Board
0	0	1	X	X	X	RS485 (4-Wire)
0	0	0	1	X	X	RS485 (2-Wire)
0	0	0	0	1	X	Terminal Board
0	0	0	0	0	F003/F004 Setting	F003/F004 Setting
<b>Note:</b> 1 = Override feature is turned on for that control input source; 0 = Override Off; X = Don't Care.						

## Command Control Selections

The following is a listing with descriptions of the **Command Mode** (F003) selections (Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Command Mode Selection**).

Settings:

**0 — Terminal Block**

Allows for **Command** control input via the **Terminal Board**.

**2 — EOI Keypad**

Used for EOI command control.

**3 — RS485**

Used to transfer commands to the ASD via 4-wire RS485.

**4 — Communication Option Board**

Use this setting if using the optional **Communication Board** for command control.

01:06
Standard Mode Selection
(F003) Command Mode Selection
Terminal Block ← (Default)

## Frequency Control Selections

The following is a listing with descriptions of the **Frequency Mode** (F004) selections (Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Frequency Mode 1**).

Settings:

**1 — V/I**

Used when a 0 to 10 VDC analog input or a 0 – 20 mADC current input is used as the speed control input. Only one input signal type may be used at a time. Set [SW301](#) to the desired input signal type.

**2 — RR**

Used for a 0 to 10 VDC analog input signal.

**3 — RX**

Used for a -10 to +10 VDC analog input signal.

**5 — EOI Keypad**

Used for EOI frequency control.

**6 — RS485**

Used to transfer speed commands to the ASD via 4-wire RS485.

02:06
Standard Mode Selection
(F004) Frequency Mode 1
RR ← (Default)

**7 — Communication Option Board**

Use this setting if using the optional **Communication Board** for frequency control.

**8 — RX2 Option (AI1)**

Used for a -10 to +10-volt DC analog input signal.

**9 — Option V/I**

Allows for the use of the optional voltage/current frequency-control interface.

**10 — UP/DOWN Frequency**

A discrete terminal may be configured to increase or decrease the speed of the motor by momentarily connecting the assigned discrete input terminal to **CC**. See [F264 on pg. 133](#) for further information on this feature.

**11 — Pulse Input Option**

Used to allow the system to use a pulsed input for frequency control. See [PG Input Point 1 Setting on pg. 127](#) for further information on this feature.

**12 — Pulse Input (motor CPU)**

Used to allow the system to use a pulsed input for frequency control. See [PG Input Point 1 Setting on pg. 127](#) for further information on this feature.

**13 — Binary/BCD Input Option**

Allows for discrete terminal to be used for frequency-control input.


# System Configuration and Menu Options

## Root Menus

The **Mode** key accesses the three primary modes of the P9 ASD: the **Frequency Command** mode, the **Monitor** mode, and the **Program** mode. From either mode, press the **Mode** key to loop through to the other two modes (See [Figure 28](#)). While in the **Frequency Command** mode, pressing the **ESC** key toggles the menu to and from the **EOI Command** mode and the **Frequency Command** mode.

The **Alarm** or **Fault** information will be displayed in the event of an active **Alarm** or **Fault**. **Alarm** text will be displayed on the **Frequency Command** screen and on the LED screen when active. **Fault** information will be displayed via the **Fault** screen. See [Alarms and Trips on pg. 260](#) for more information on **Alarms** and **Trips**.

Figure 28. P9 ASD Root Menu Navigation.



## Frequency Command Mode

### Frequency Setting

While operating in the **Hand** mode (**Hand** LED is illuminated on the EOI), the running frequency of the motor may be set from the **Frequency Command** screen. Using the **Rotary Encoder**, enter the **Frequency Command** value, connect **ST** to **CC**, and provide a **Run** command (F and/or R) and then press the **Run** key. The motor will run at the **Frequency Command** speed and may be changed while running. See [Figure 22 on pg. 32](#) and [Operation \(Hand\) on pg. 39](#) for more information on the **Frequency Command** mode.

## EOI Command Mode

The **EOI Command** mode is accessed by pressing the **ESC** key from the **Frequency Command** screen.

With the exception of the **VLP Control Enable/Disable**, the control settings of the **EOI Command** menu are effective for **EOI** control only.

The **EOI Command** mode provides quick access to the following menu parameters:

**Direction** — **Forward** or **Reverse**.

**Stop Pattern** — The **Decel Stop** or **Coast Stop** setting determines the method used to stop the motor when using the **Stop-Reset** key of the **EOI**. The **Decel Stop** setting enables the **Dynamic Braking** system setup at [F304](#) or the **DC Injection Braking** system setup at [F250](#), [F251](#), and [F252](#). The **Coast Stop** setting allows the motor to stop at the rate allowed by the inertia of the load.

*Note:* The **Stop Pattern** setting has no effect on the **Emergency Off** settings of [F603](#).

**V/f Group** — One of 4 **V/f** profiles may be selected and run. Each **V/f** profile is comprised of 4 user settings: **Base Frequency**, **Base Frequency Voltage**, **Manual Torque Boost**, and **Electronic Thermal Protection**. Expanded descriptions of these parameters may be found in the section titled [Direct Access Parameter Information on pg. 81](#).

**Accel/Decel Group** — One of 4 **Accel/Decel** profiles may be selected and run. Each of the **Accel/Decel** profiles is comprised of three user settings: **Acceleration**, **Deceleration**, and **Pattern**. Expanded descriptions of these parameters may be found in the section titled [Direct Access Parameter Information on pg. 81](#) (See [F009](#)).

**PID Control** — This setting enables or disables the **PID** feedback function.

**Torque Limit Group** — This parameter is used to select 1 of 4 preset positive torque limits to apply to the active motor (of a multiple motor configuration). The settings of profiles 1 – 4 may be set up at [F441](#), [F444](#), [F446](#), and [F448](#), respectively.

**VLP Control** — This setting enables or disables the **VLP** function.



# Monitor Mode

The **Monitor** mode allows the user to monitor motor performance variables, control settings, and configuration data during motor operation. There are 43 items that may be monitored from this mode. The items are listed and described below.

**Note:** The **Monitor** mode is a read-only mode. The settings cannot be changed from the **Monitor** mode. For information on how to change the values, see the section titled [Default Setting Changes on pg. 40](#).

**Note:** Any two of the Underlined monitored items may be selected for display at the **Frequency Command** screen while running via Program ⇒ Utilities ⇒ [Main Monitor Selections](#).

**Note:** The **F701** setting will determine if the Current and Voltage values displayed appear as A (Amps) and V (Voltage), or if the value is shown as a % (percentage) of the ASD rating.

**Frequency at Trip** — Displays the at-trip frequency.

**Frequency Reference** — Displays the **Frequency Setpoint**.

**Output Current** — Displays the **Output Current** as a percentage of the rated capacity of the P9 ASD.

**DC Bus Voltage** — Displays the **Bus Voltage** as a percentage of the rated capacity of the P9 ASD.

**Output Voltage** — Displays the **Output Voltage** as a percentage of the rated capacity of the P9 ASD.

**AM Output** — Displays the **AM** output terminal value for the function assigned to the **AM** terminal.

**FM Output** — Displays the **FM** output terminal value for the function assigned to the **FM** terminal.

**Motor OL (Overload) Real** — Displays the real-time **Motor Overload** value as a percentage of the rated capacity of the motor.

**Motor OL (Overload) Trip** — Displays the **Motor Overload Trip** value as a percentage of the rated capacity of the motor.

**Motor Load** — Displays the real-time **Motor Load** as a percentage of the rated capacity of the motor.

**ASD OL (Overload) Real** — Displays the real-time **ASD Overload** as a percentage of the rated capacity of the P9 ASD.

**ASD OL (Overload) Trip** — Displays the **ASD Overload Trip** value as a percentage of the rated capacity of the ASD.

**ASD Load** — Displays the **ASD Load** as a percentage of the rated capacity of the P9 ASD.

**Run Time** — Displays the **Cumulative Run Time** in hours.

**Compensation Frequency** — Displays the **Output Frequency** after the application of the slip compensation correction value (Post Compensation Frequency).

**DBR OL (Overload) Real** — Displays the real-time **DBR Overload** value as a percentage of the **Dynamic Braking Resistor** capacity.

**DBR OL (Overload) Trip** — Displays the **DBR Overload Trip** value as a percentage of the **Dynamic Braking Resistor** capacity.

**DBR Load** — Displays the **DBR Load** as a percentage of the **Dynamic Braking Resistor** capacity.

**Feedback (Inst)** — Provides a status of the **Real-Time Feedback** in Hz.

**Feedback (1 Second)** — Provides a status of the **1-Second Averaging** feedback in Hz.

**Torque** — Displays the **Output Torque** as a percentage of the rated capacity of the P9 ASD.

**Torque Reference** — Displays the **Torque Reference** as a percentage of the maximum torque available.

**Torque Current** — Displays the torque-producing current value.

**Excitation Current** — Displays the current value required to produce the excitation field.

**PID Feedback** — Provides a status of the **PID Real-Time Feedback** in Hz.

**Input Power** — Displays the **Input Power** in Kilowatts (kW).

**Output Power** — Displays the **Output Power** in Kilowatts (kW).

**Pattern Group Number** — Displays the active **Pattern Run Group Number**.

**Pattern Group Cycle** — Displays the cycle number of the active **Pattern Run Group**.

**Pattern Group Preset** — Displays the active **Preset Speed** being run of the active **Pattern Run Group**.

**Pattern Time** — Displays the remaining time for the active **Pattern Run Group**.

**RR** — Displays the **RR** input value as a percentage of the full range of the **RR** value (potentiometer input).

**V/I** — Displays the **V/I** input setting as a percentage of the full range of the **V/I** value.

**Note:** *The isolated **V/I** input terminal may receive **Current** or **Voltage** to control the output speed or the output torque. The input signal type must be selected at **SW301** on the **Terminal Board**.*

*The **V** input setting of **SW301** is used for the 0 – 10 VDC analog input signal and the **I** input setting of **SW301** is used for the 0 – 20 mA analog input signal. Either may be used as a frequency or torque command source. See parameter **F201** for more information on the setup of this terminal.*

**RX** — Displays the **RX** input setting as a percentage of the full range of the **RX** value (-10 to +10 VDC input).

**RX2 Option (AI1)** — Displays the **RX2** input setting as a percentage of the full range of the **RX2** value.

**Note:** *The **RX2** function is available on the **Expansion IO Card Option 1** option board (P/N ETB003Z) only.*

**Trip Code** — Displays **None** if there are no errors, or displays one of the associated **Fault Codes** listed in the **P9 ASD Installation and Operation Manual** if there is an active **Fault** (e.g., **E** = **Emergency Off**).

**Past Trip 1** — This function records and displays the last trip incurred. Subsequent trips will replace **Past Trip 1**. As trip records are replaced they are shifted to the next level of the **Past Trip** locations until being deleted (i.e., **Past Trip 1** is moved to **Past Trip 2** and then to **Past Trip 3** until being shifted out of **Past Trip 4**). Once shifted out of **Past Trip 4** the record is deleted. If no trips have occurred since the last reset, **No Error** is displayed for each trip record.

**Past Trip 2** — Past trip information or **None**.

**Past Trip 3** — Past trip information or **None**.

**Past Trip 4** — Past trip information or **None**.

**Note:** *An improper P9 ASD setup may cause some trips — reset the P9 ASD to the **Factory Default** settings before pursuing a systemic malfunction (Program ⇒ Utilities ⇒ Type Reset ⇒ **Reset to Factory Settings**).*

**Direction** — Displays the **Direction** command (forward/reverse).

**Discrete Input Terminals** — Displays the status (activated = reverse video) of the discrete input terminals of the **Terminal Board**.

**Discrete Output Terminals** — Displays the status (activated = reverse video) of the discrete output lines of the **Terminal Board**.

**Output Frequency** — Displays the running frequency.

## Main Monitor Selections

Two (2) **Monitor Mode** items may be selected from the **Main Monitor Selections** screen to be displayed on the **Frequency Command** screen while the P9 ASD is running.

**Note:** ***VLP Technology Average** and **Work Hours** may also be selected as **Main Monitor** items, but are not displayed at the **Monitor** screen.*

The selected items, along with their real-time values, are displayed on the **Frequency Command** screen while running. Not all **Monitor Mode** items are available for display on the **Frequency Command** screen. The available items are underlined on [pg. 49](#) and [pg. 50](#).

Any two of the underlined items may be selected from the listing at Program ⇒ Utilities ⇒ **Main Monitor Selections**. Select an item from the **Monitor 1** listing and another item from the **Monitor 2** listing to be displayed as shown in [Figure 22 on pg. 32](#) (DC Voltage and Output Current shown).

## Program Mode Menu Navigation

The following table lists the menu items of the **Program** mode and maps the flow of the menu selections. The **Parameter Numbers** for the listed functions are provided where applicable.

The functions listed may be viewed, or selected and changed as mapped below or via the **Direct Access** method: Program ⇒ Direct Access ⇒ *Applicable Parameter Number*.

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>VIRTUAL LINEAR PUMP</b> (See <a href="#">Virtual Linear Pump</a> on pg. 77 for more information on VLP.)	<b>VLP Setup Wizard</b>	VLP Motor/ASD Setup	N/A
		VLP Transducer Setup	
		VLP Setup	
	<b>VLP Settings</b>	VLP Mode Switch	<a href="#">F390</a>
		VLP Application Type	<a href="#">F391</a>
		VLP Application Operating Mode	<a href="#">F380</a>
		Transducer Units	N/A
		VLP Transducer Output Range	<a href="#">F392</a>
		VLP Transducer Maximum Reading	<a href="#">F393</a>
		VLP Transducer Minimum Reading	<a href="#">F403</a>
		VLP Minimum	<a href="#">F394</a>
		VLP Maximum	<a href="#">F395</a>
		VLP Command Source	<a href="#">F396</a>
		VLP Command Value	<a href="#">F397</a>
		VLP Low Frequency Limit	<a href="#">F398</a>
	<b>VLP Start and Stop Points</b>	VLP Start and Stop Mode	<a href="#">F385</a>
		VLP Start and Stop Delay Timer	<a href="#">F387</a>
		VLP Low Start and Stop Point	<a href="#">F388</a>
		VLP High Start and Stop Point	<a href="#">F389</a>
		Input Terminal 5 (S1) Function	<a href="#">F115</a>
	<b>VLP Sleep Timer</b>	VLP Sleep Timer	<a href="#">F382</a>
		VLP Sleep Timer Delay	<a href="#">F383</a>
	<b>VLP Run External Devices</b>	VLP External Delay Timer	<a href="#">F480</a>
		VLP External Device Low Band	<a href="#">F481</a>
		VLP External Device High Band	<a href="#">F482</a>

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>VIRTUAL LINEAR PUMP</b>	<b>VLP Run External Devices</b>	Output Terminal 1 (OUT1) Function	F130
		Output Terminal 2 (OUT2) Function	F131
	<b>VLP Low Suction/No-Flow Cut Off</b>	VLP Low Suction/No-Flow Cut Off Mode	F483
		VLP Low Suction/No-Flow Cut Off Delay Timer	F484
		Input Terminal 5 (S1) Function	F115
		Low Suction/No-Flow Cut Off Fault Disposition	F450
	<b>VLP Sealing Water</b>	VLP Sealing Water Mode	F485
		Input Terminal 5 (S1) Function	F115
		Output Terminal 1 (OUT1) Function	F130
	<b>VLP Time-Based Alternation</b>	Time-Based Alternation	F417
		Time-Based Alternation Period	F418
		Total Number of ASDs on TBA	F437
		Time-Based Alternation Pump Number	F434
		Time-Based Alternation Process Hold Mode Response Time	F438
		TBA Direct Mode Response Time	F439
		TBA Direct Mode Emergency Setpoint	F456
		Input Terminal 5 (S1) Function	F115
		Time-Based Alternation Emergency Timer	F404
<b>FUNDAMENTAL</b>	<b>Accel/Decel 1 Settings</b>	Automatic Acceleration/Deceleration	F000
		Acceleration Time 1	F009
		Deceleration Time 1	F010
		Acceleration/Deceleration Suspended Function	F349
		Acceleration Suspend Frequency	F350
		Acceleration Suspend Time	F351
		Deceleration Suspend Frequency	F352
		Deceleration Suspend Time	F353
	<b>Frequency Settings</b>	Maximum Frequency	F011
		Upper-Limit Frequency	F012
		Lower-Limit Frequency	F013
		V/f Pattern	F015

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FUNDAMENTAL	Frequency Settings	Time Limit for Lower-Limit Frequency Operation	F256
	Motor Set 1	Automatic Torque Boost	F001
		Base Frequency 1	F014
		Manual Torque Boost 1	F016
		Motor Overload Protection Level 1	F600
	Standard Mode Selection	Command Mode	F003
		Frequency Mode 1	F004
		Forward/Reverse Run	F008
		Frequency Priority	F200
		Frequency Mode 2	F207
		Frequency Mode Priority Switching Frequency	F208
TERMINAL	Analog Output Terminals	FM Output Terminal Function	F005
		FM Output Terminal Adjustment	F006
		FM Output Gradient Characteristic	F682
		FM Bias Adjustment	F683
		FM Voltage/Current Output Switching	F681
		AM Output Terminal Function	F670
		AM Output Terminal Adjustment	F671
		AM Output Gradient Characteristic	F685
		AM Bias Adjustment	F686
		MON 1 Terminal Meter Selection	F672
		MON 1 Terminal Meter Adjustment	F673
		MON 1 Output Gradient Characteristic	F689
		MON 1 Bias Adjustment	F690
		MON 1 Voltage/Current Output Switching	F688
		MON 2 Terminal Meter Selection	F674
		MON 2 Terminal Meter Adjustment	F675
		MON 2 Output Gradient Characteristic	F692
		MON 2 Bias Adjustment	F693
		MON 2 Voltage/Current Output Switching	F691

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>TERMINAL</b>	<b>Analog Output Terminals</b>	FP Terminal Assignment	<a href="#">F676</a>
		FP Terminal Frequency	<a href="#">F677</a>
	<b>Input Special Functions</b>	Forward/Reverse Run Priority When Both Are Activated	<a href="#">F105</a>
		Input Terminal Priority	<a href="#">F106</a>
		16-Bit Binary/BCD Input	<a href="#">F107</a>
		V/I Analog Input Broken Wire Detection Level	<a href="#">F633</a>
		V/I Analog Input Loss Response	<a href="#">F644</a>
	<b>Input Terminal Delays</b>	Input Terminal 1 (F) Response Time	<a href="#">F140</a>
		Input Terminal 2 (R) Response Time	<a href="#">F141</a>
		Input Terminal 3 (ST) Response Time	<a href="#">F142</a>
		Input Terminal 4 (RES) Response Time	<a href="#">F143</a>
		Input Terminal 5–12 Response Time	<a href="#">F144</a>
		Input Terminal 13–20 Response Time	<a href="#">F145</a>
	<b>Input Terminals</b>	Always ON Terminal Function	<a href="#">F110</a>
		Input Terminal 1 (F) Function	<a href="#">F111</a>
		Input Terminal 2 (R) Function	<a href="#">F112</a>
		Input Terminal 3 (ST) Function	<a href="#">F113</a>
		Input Terminal 4 (RES) Function	<a href="#">F114</a>
		Input Terminal 5 (S1) Function	<a href="#">F115</a>
		Input Terminal 6 (S2) Function	<a href="#">F116</a>
		Input Terminal 7 (S3) Function	<a href="#">F117</a>
		Input Terminal 8 (S4) Function	<a href="#">F118</a>
		Input Terminal 9 (LI1) Function	<a href="#">F119</a>
		Input Terminal 10 (LI2) Function	<a href="#">F120</a>
		Input Terminal 11 (LI3) Function	<a href="#">F121</a>
		Input Terminal 12 (LI4) Function	<a href="#">F122</a>
		Input Terminal 13 (LI5) Function	<a href="#">F123</a>
		Input Terminal 14 (LI6) Function	<a href="#">F124</a>
		Input Terminal 15 (LI7) Function	<a href="#">F125</a>
		Input Terminal 16 (LI8) Function	<a href="#">F126</a>

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TERMINAL	Input Terminals	Input Terminal 17 (B12) Function	F164
		Input Terminal 18 (B13) Function	F165
		Input Terminal 19 (B14) Function	F166
		Input Terminal 20 (BI5) Function	F167
		Virtual Input Terminal Selection 1	F973
		Virtual Input Terminal Selection 2	F974
		Virtual Input Terminal Selection 3	F975
		Virtual Input Terminal Selection 4	F976
	Line Power Switching	Commercial Power/ASD Switching Output	F354
		Commercial Power/ASD Switching Frequency	F355
		ASD Side Switching Delay	F356
		Commercial Power-Side Switching Delay	F357
		Commercial Power Switching Frequency Hold Time	F358
	Output Terminals	Output Terminal 1 (OUT1) Function	F130
		Output Terminal 2 (OUT2) Function	F131
		Output Terminal 3 (FL) Function	F132
		Output Terminal 4 (OUT3) Function	F133
		Output Terminal 5 (OUT4) Function	F134
		Output Terminal 6 (R1) Function	F135
		Output Terminal 7 (OUT5) Function	F136
		Output Terminal 8 (OUT6) Function	F137
		Output Terminal 9 (R2) Function	F138
		Output Terminal 10 (R3) Function	F168
		Output Terminal 11 (R4) Function	F169
	Reach Settings	Low-Speed Signal Output Frequency	F100
		Speed Reach Frequency	F101
		Speed Reach Detection Band	F102
DIRECT ACCESS		Parameter Number Input Field	N/A
		Unknown Numbers Accepted	
UTILITIES	Version	EOI / ASD Type / CPU Level / EEPROM / MC Level	N/A



Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Standard Startup Wizard	See the section titled <a href="#">Initial Setup on pg. 36</a> for Startup Wizard Requirements.	N/A
	Prohibition	Hand/Auto Key Command Override	N/A
		Hand/Auto Key Frequency Override	
		Show Uninitialized Parameters at Changed From Default Screen	
	Alarm Prohibition (prohibits an EOI alarm display ONLY — alarm still activates)	Over-Current Alarm	N/A
		ASD Overload Alarm	
		Motor Overload Alarm	
		Over-Heat Alarm	
		Over-Voltage Alarm	
		Main Power Under-Voltage Alarm	
		Reserved (POFF) Alarm	
		Under-Current Alarm	
		(Approaching) Over-Torque Alarm Threshold	
		Dynamic Braking Resistor (DBR) Overload Alarm	
		Cumulative Run Timer Alarm	
		DeviceNet/Profibus/CC-Link Alarm	
		RS485 Communication	
		Main Power Under-Voltage Alarm	
		Stop After Instantaneous Power-Off Alarm	
		Stop After Lower-Limit Continuous Time	
		Light-Load Alarm	
		Heavy-Load Alarm	N/A
		Maintenance Timer Alarm	
		Over-Torque Alarm	
		Soft Stall Alarm	
		VLP Low Suction/No-Flow Cut Off Alarm	
		Time-Based Alternation Alarm Float Active	
	Type Reset	Reset Selections	F007
	Real-Time Clock Setup	Set Real-Time Clock (See <a href="#">page 29</a> for more info.)	N/A

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Trip History (read-only)	Trip Number	N/A
		Trip Type	
		Frequency at Trip	
		Output Current	
		Output Voltage	
		Direction	
		Frequency Reference	
		DC Voltage	
		Discrete Input Terminals	
		Discrete Output Terminals	
		Run Timer	
		Post Compensation Frequency	
		Speed Feedback (Real Time)	
		Speed Feedback (1 Second)	
		Torque Feedback	
		Torque Reference	
		Torque Current	
		Excitation Current	
		PID Feedback	
		Motor Overload Ratio	
		ASD Overload Ratio	
		Dynamic Braking Resistor (DBR) Overload Ratio	
		Motor Load	N/A
		ASD Load	
		Dynamic Braking Resistor (DBR) Load	
		Input Power	
		Output Power	
	Changed From Default	Display Changed Parameters	N/A
	Display Parameters	Automatic Function Selection	F040
		Current/Voltage Display Units	F701

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Display Parameters	Free Unit Multiplication Factor	F702
		Free Unit	F703
		Free Unit Display Gradient Characteristic	F705
		Free Unit Display Bias	F706
		Change Step Selection 1	F707
		Change Step Selection 2	F708
	Main Monitor Selections	Monitor 1	N/A
		Monitor 2	
	Contrast	Contrast Adjustment	N/A
	Trace	Trace Selection	F740
		Trace Cycle	F741
		Trace Data 1	F742
		Trace Data 2	F743
		Trace Data 3	F744
		Trace Data 4	F745
	View Trace Data	View Trace Data	N/A
	Save/Restore Wizard	Save/Restore ASD Settings (See <a href="#">page 41</a> for more info.)	
PROTECTION	Abnormal Speed Settings	Abnormal Speed Detection Time	F622
		Over-Speed Detection Frequency Upper Band	F623
		Over-Speed Detection Frequency Lower Band	F624
	Base Frequency Voltage	Supply Voltage Correction	F307
	DC Injection Braking	DC Injection Braking Start Frequency	F250
		DC Injection Braking Current	F251
		DC Injection Braking Time	F252
		Forward/Reverse DC Injection Braking Priority	F253
		Motor Shaft Stationary Control	F254
	Dynamic Braking	Dynamic Braking Selection	F304
		Dynamic Braking Resistance	F308
		Continuous Dynamic Braking Capacity	F309
		Braking Resistance Overload Time (10x Rated Torque)	F639

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PROTECTION	Emergency Off Settings	Emergency Off	F603
		Emergency DC Injection Braking Control Time	F604
	Low-Current Settings	Low-Current Trip	F610
		Low-Current Detection Current	F611
		Low-Current Detection Time	F612
		Low-Current Detection Hysteresis Width	F609
	Overload	Motor Overload Protection Configuration	F017
		Overload Reduction Start Frequency	F606
		Motor 150% Overload Time Limit	F607
		ASD Overload	F631
	Over-Torque Parameters	Over-Torque Trip	F615
		Over-Torque Detection Level During Power Running	F616
		Over-Torque Detection Level During Regenerative Braking	F617
		Over-Torque Detection Time	F618
		Over-Torque Detection Hysteresis	F619
	Phase Loss	ASD Output Phase Loss Detection	F605
		ASD Input Phase Loss Detection	F608
	Retry/Restart	Auto Restart Selection	F301
		Number of Times to Retry	F303
		Ridethrough Time	F310
		Random Mode	F312
	Stall	Over-Voltage Limit Operation	F305
		Stall Prevention Factor 1	F416
		Power Running Stall Continuous Trip Detection Time	F452
		Stall Prevention During Regeneration	F453
		Stall Prevention Level	F601
		Over-Voltage Limit Operation Level	F626
	Trip Settings	Retain Trip Record at Power Down	F602
	Under-Voltage/ Ridethrough	Regenerative Power Ridethrough Mode	F302

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PROTECTION	Under-Voltage/ Ridethrough	Synchronized Deceleration Time	F317
		Synchronized Acceleration Time	F318
		Under-Voltage Trip	F627
		Under-Voltage (Trip Alarm) Detection Time	F628
		Regenerative Power Ridethrough Control Level	F629
	Special Protection Parameters	Short Circuit Detection at Start	F613
		Cooling Fan Control	F620
		Cumulative Operation Time Alarm Setting	F621
		Brake Answer Delay Time	F630
FREQUENCY	Analog Filter	Analog Input Filter	F209
	Forward/Reverse Disable	Forward/Reverse Disable	F311
	Jog Settings	Jog Frequency	F260
		Jog Stop Pattern	F261
		EOI Operation Jog Mode	F262
	UP/DOWN Frequency Functions	UP/DOWN Up Response Time	F264
		UP/DOWN Up Frequency Step	F265
		UP/DOWN Down Response Time	F266
		UP/DOWN Down Frequency Step	F267
		Initial UP/DOWN Frequency	F268
		Initial UP/DOWN Frequency Rewriting	F269
	V/I Settings	Option V/I Terminal Voltage/Current Selection (AI2 Option Board Input)	F109
	Preset Speeds	Preset Speed 1	F018
		Preset Speed 2	F019
		Preset Speed 3	F020
		Preset Speed 4	F021
		Preset Speed 5	F022
		Preset Speed 6	F023
		Preset Speed 7	F024
		Preset Speed 8	F287

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FREQUENCY	Preset Speeds	Preset Speed 9	F288
		Preset Speed 10	F289
		Preset Speed 11	F290
		Preset Speed 12	F291
		Preset Speed 13	F292
		Preset Speed 14	F293
		Preset Speed 15	F294
	Speed Reference Setpoints	V/I Input Point 1 Setting	F201
		V/I Input Point 1 Frequency	F202
		V/I Input Point 2 Setting	F203
		V/I Input Point 2 Frequency	F204
		RR Input Point 1 Setting	F210
		RR Input Point 1 Frequency	F211
		RR Input Point 2 Setting	F212
		RR Input Point 2 Frequency	F213
		RX Input Point 1 Setting	F216
		RX Input Point 1 Frequency	F217
		RX Input Point 2 Setting	F218
		RX Input Point 2 Frequency	F219
		RX2 Option (AI1) Input Point 1 Setting	F222
		RX2 Option (AI1) Input Point 1 Frequency	F223
		RX2 Option (AI1) Input Point 2 Setting	F224
		RX2 Option (AI1) Input Point 2 Frequency	F225
		BIN Input Point 1 Setting	F228
		BIN Input Point 1 Frequency	F229
		BIN Input Point 2 Setting	F230
		BIN Input Point 2 Frequency	F231
		PG Input Point 1 Setting	F234
		PG Input Point 1 Frequency	F235
		PG Input Point 2 Setting	F236

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FREQUENCY	Speed Reference Setpoints	PG Input Point 2 Frequency	F237
		V/I Input Bias	F470
		V/I Input Gain	F471
		RR Input Bias	F472
		RR Input Gain	F473
		RX Input Bias	F474
		RX Input Gain	F475
		RX2 Option (AI1) Input Bias	F476
		RX2 Option (AI1) Input Gain	F477
		V/I Input Bias (AI2 Option Board Input)	F478
		V/I Input Gain (AI2 Option Board Input)	F479
SPECIAL	Acc/Dec 1 – 4 Settings	Acceleration Time 2	F500
		Deceleration Time 2	F501
		Acceleration/Deceleration Pattern 1	F502
		Acceleration/Deceleration Pattern 2	F503
		Acceleration Time 3	F510
		Deceleration Time 3	F511
		Acceleration/Deceleration Pattern 3	F512
		Acceleration Time 4	F514
		Deceleration Time 4	F515
		Acceleration/Deceleration Pattern 4	F516
	Acc/Dec Special	Acceleration/Deceleration Pattern 1 – 4	F504
		Acceleration/Deceleration Switching Frequency 1	F505
		S-Pattern Acceleration Lower-Limit Adjustment	F506
		S-Pattern Acceleration Upper-Limit Adjustment	F507
		S-Pattern Deceleration Lower-Limit Adjustment	F508
		S-Pattern Deceleration Upper-Limit Adjustment	F509
		Acceleration/Deceleration Switching Frequency 2	F513
		Acceleration/Deceleration Switching Frequency 3	F517
	Carrier Frequency	PWM Carrier Frequency	F300
		Carrier Frequency Control Mode	F316

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>SPECIAL</b>	<b>V/f 5-Point Setting</b>	V/f 5-Point Setting Frequency 1	F190
		V/f 5-Point Setting Voltage 1	F191
		V/f 5-Point Setting Frequency 2	F192
		V/f 5-Point Setting Voltage 2	F193
		V/f 5-Point Setting Frequency 3	F194
		V/f 5-Point Setting Voltage 3	F195
		V/f 5-Point Setting Frequency 4	F196
		V/f 5-Point Setting Voltage 4	F197
		V/f 5-Point Setting Frequency 5	F198
		V/f 5-Point Setting Voltage 5	F199
	<b>Frequency Control</b>	Start Frequency	F240
		Run Frequency	F241
		Run Frequency Hysteresis	F242
		End Frequency	F243
	<b>Special Parameters</b>	0 Hz Dead Band Signal	F244
		0 Hz Command Output	F255
		Exciting Strengthening Coefficient	F415
		Annual Average Ambient Temperature	F634
		Rush Current Suppression Relay Activation Time	F635
		PTC 1 Thermal Selection	F637
		PTC 2 Thermal Selection	F638
	<b>Jump Frequencies</b>	Jump Frequency 1	F270
		Jump Frequency 1 Bandwidth	F271
		Jump Frequency 2	F272
		Jump Frequency 2 Bandwidth	F273
		Jump Frequency 3	F274
		Jump Frequency 3 Bandwidth	F275
	<b>Operation Panel Parameters</b>	Operation Command Clear Selection When Standby Terminal is Off	F719
		Panel Stop Pattern	F721
		Panel Torque Command	F725



Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>SPECIAL</b>	<b>Operation Panel Parameters</b>	Panel Tension Torque Bias	<a href="#">F727</a>
		Panel Load Sharing Gain	<a href="#">F728</a>
		Panel Override Multiplication Gain	<a href="#">F729</a>
		Panel Frequency Lock Out	<a href="#">F730</a>
		Panel Emergency Off Lock Out	<a href="#">F734</a>
		Panel Reset Lock Out	<a href="#">F735</a>
<b>MOTOR</b>	<b>Motor Set 2</b>	Motor Set 2 Base Frequency	<a href="#">F170</a>
		Motor Set 2 Base Frequency Voltage	<a href="#">F171</a>
		Motor Set 2 Manual Torque Boost	<a href="#">F172</a>
		Motor Set 2 Overload Protection Level	<a href="#">F173</a>
	<b>Motor Set 3</b>	Motor Set 3 Base Frequency	<a href="#">F174</a>
		Motor Set 3 Base Frequency Voltage	<a href="#">F175</a>
		Motor Set 3 Manual Torque Boost	<a href="#">F176</a>
		Motor Set 3 Overload Protection Level	<a href="#">F177</a>
	<b>Motor Set 4</b>	Motor Set 4 Base Frequency	<a href="#">F178</a>
		Motor Set 4 Base Frequency Voltage	<a href="#">F179</a>
		Motor Set 4 Manual Torque Boost	<a href="#">F180</a>
		Motor Set 4 Overload Protection Level	<a href="#">F181</a>
	<b>PM Motor</b>	PM Motor Constant 1 (D-Axis Inductance)	<a href="#">F498</a>
		PM Motor Constant 2 (Q-Axis Inductance)	<a href="#">F499</a>
		Step-Out Detection-Current Level (For PM Motors)	<a href="#">F640</a>
		Step-Out Detection-Current Time (For PM Motors)	<a href="#">F641</a>
	<b>Vector Motor Model</b>	Autotune 1	<a href="#">F400</a>
		Slip Frequency Gain	<a href="#">F401</a>
		Autotune 2	<a href="#">F402</a>
		Motor Rated Capacity (Nameplate)	<a href="#">F405</a>
		Motor Rated Current (Nameplate)	<a href="#">F406</a>
		Motor Rated RPM (Nameplate)	<a href="#">F407</a>
		Base Frequency Voltage 1	<a href="#">F409</a>
		Motor Constant 1 (Torque Boost)	<a href="#">F410</a>

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>MOTOR</b>	<b>Vector Motor Model</b>	Motor Constant 2 (No Load Current)	F411
		Motor Constant 3 (Leak Inductance)	F412
		Motor Constant 4 (Rated Slip)	F413
<b>TORQUE</b>	<b>Manual Torque Limit Settings</b>	Power Running Torque Limit 2 Level	F444
		Regenerative Braking Torque Limit 2 Level	F445
		Power Running Torque Limit 3 Level	F446
		Regenerative Braking Torque Limit 3 Level	F447
		Power Running Torque Limit 4 Level	F448
		Regenerative Braking Torque Limit 4 Level	F449
	<b>Setpoints</b>	V/I Input Point 1 Rate	F205
		V/I Input Point 2 Rate	F206
		RR Input Point 1 Rate	F214
		RR Input Point 2 Rate	F215
		RX Input Point 1 Rate	F220
		RX Input Point 2 Rate	F221
		RX2 Option (AI1) Input Point 1 Rate	F226
		RX2 Option (AI1) Input Point 2 Rate	F227
	<b>Torque Control</b>	Braking Mode	F341
		Torque Bias Input	F342
		Panel Torque Bias	F343
		Panel Torque Gain	F344
		Release Time	F345
		Creeping Frequency	F346
		Creeping Time	F347
		Braking Time Learning Function	F348
		Torque Command	F420
		Tension Torque Bias Input (Torque Control)	F423
		Load Sharing Gain Input	F424
		Forward Speed Limit Input	F425
		Forward Speed Limit Input Level	F426

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TORQUE	Torque Control	Reverse Speed Limit Input	F427
		Reverse Speed Limit Input Level	F428
	Torque Limit Settings	Power Running Torque Limit 1	F440
		Power Running Torque Limit 1 Level	F441
		Regenerative Braking Torque Limit 1	F442
		Regenerative Braking Torque Limit 1 Level	F443
		Acceleration/Deceleration Operation After Torque Limit	F451
	Torque Speed Limiting	Speed Limit (Torque = 0) Center Value Reference	F430
		Speed Limit (Torque = 0) Center Value	F431
		Speed Limit (Torque = 0) Band	F432
		Allow Rotation in Specified Direction ONLY	F435
FEEDBACK	Drooping Control	Drooping Gain	F320
		Speed at 0% Drooping Gain	F321
		Speed at F320 Drooping Gain	F322
		Drooping Insensitive Torque	F323
		Drooping Output Filter	F324
	Feedback Settings	PID Control Switching	F359
		PID Feedback Signal	F360
		PID Feedback Delay Filter	F361
		PID Feedback Proportional Gain	F362
		PID Feedback Integral Gain	F363
		PID Deviation Upper-Limit	F364
		PID Deviation Lower-Limit	F365
		PID Feedback Differential Gain	F366
		Process Upper-Limit	F367
		Process Lower-Limit	F368
		PID Control Delay	F369
		PID Output Upper-Limit	F370
		PID Output Lower-Limit	F371
		Process Increasing Rate	F372

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FEEDBACK	Feedback Settings	Process Decreasing Rate	F373
		Speed PI Switching Frequency	F466
	Override Control	Adding Input Selection	F660
		Multiplying Input Selection	F661
	PG Settings	Number of PG Input Pulses	F375
		Number of PG Input Phases	F376
		PG Disconnection Detection	F377
		Simple Positioning Completion Range	F381
		Current Control Proportional Gain	F458
		Speed Loop Proportional Gain	F460
		Speed Loop Stabilization Coefficient	F461
		Load Moment of Inertia 1	F462
		Second Speed Loop Proportional Gain	F463
		Second Speed Loop Stabilization Coefficient	F464
		Load Moment of Inertia 2	F465
MY FUNCTION	My Function Selection	My Function Operating Mode	F977
	My Function Unit 1	Input Function Target 1	F900
		Input Function Command 1	F901
		Input Function Target 2	F902
		Input Function Command 2	F903
		Input Function Target 3	F904
		Output Function Assigned	F905
	My Function Unit 2	Input Function Target 1	F906
		Input Function Command 1	F907
		Input Function Target 2	F908
		Input Function Command 2	F909
		Input Function Target 3	F910
		Output Function Assigned	F911

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>MY FUNCTION</b>	<b>My Function Unit 3</b>	Input Function Target 1	F912
		Input Function Command 1	F913
		Input Function Target 2	F914
		Input Function Command 2	F915
		Input Function Target 3	F916
		Output Function Assigned	F917
	<b>My Function Unit 4</b>	Input Function Target 1	F935
		Input Function Command 1	F936
		Input Function Target 2	F937
		Input Function Command 2	F938
		Input Function Target 3	F939
		Output Function Assigned	F940
	<b>My Function Unit 5</b>	Input Function Target 1	F941
		Input Function Command 1	F942
		Input Function Target 2	F943
		Input Function Command 2	F944
		Input Function Target 3	F945
		Output Function Assigned	F946
	<b>My Function Unit 6</b>	Input Function Target 1	F947
		Input Function Command 1	F948
		Input Function Target 2	F949
		Input Function Command 2	F950
		Input Function Target 3	F951
		Output Function Assigned	F952
	<b>My Function Unit 7</b>	Input Function Target 1	F953
		Input Function Command 1	F954
		Input Function Target 2	F955
		Input Function Command 2	F956
		Input Function Target 3	F957
		Output Function Assigned	F958

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>MY FUNCTION</b>	<b>My Function Data</b>	My Function Percent Data 1	<a href="#">F918</a>
		My Function Percent Data 2	<a href="#">F919</a>
		My Function Percent Data 3	<a href="#">F920</a>
		My Function Percent Data 4	<a href="#">F921</a>
		My Function Percent Data 5	<a href="#">F922</a>
		My Function Frequency Data 1	<a href="#">F923</a>
		My Function Frequency Data 2	<a href="#">F924</a>
		My Function Frequency Data 3	<a href="#">F925</a>
		My Function Frequency Data 4	<a href="#">F926</a>
		My Function Frequency Data 5	<a href="#">F927</a>
		My Function Time Data 1	<a href="#">F928</a>
		My Function Time Data 2	<a href="#">F929</a>
		My Function Time Data 3	<a href="#">F930</a>
		My Function Time Data 4	<a href="#">F931</a>
		My Function Time Data 5	<a href="#">F932</a>
		My Function Count Data 1	<a href="#">F933</a>
		My Function Count Data 2	<a href="#">F934</a>
	<b>My Function Analog</b>	Analog Input Function Target 11	<a href="#">F959</a>
		Analog Function Assigned Object 11	<a href="#">F961</a>
		Analog Input Function Target 21	<a href="#">F962</a>
		Analog Function Assigned Object 21	<a href="#">F964</a>
	<b>My Function Monitor</b>	Monitor Output Function 11 (2000–3099=FD00–FE99)	<a href="#">F965</a>
		Monitor Output Function Command 11	<a href="#">F966</a>
		Monitor Output Function 21 (2000–3099=FD00–FE99)	<a href="#">F967</a>
		Monitor Output Function Command 21	<a href="#">F968</a>
		Monitor Output Function 31 (2000–3099=FD00–FE99)	<a href="#">F969</a>
		Monitor Output Function Command 31	<a href="#">F970</a>
		Monitor Output Function 41 (2000–3099=FD00–FE99)	<a href="#">F971</a>
		Monitor Output Function Command 41	<a href="#">F972</a>

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>COMMUNICATIONS</b>	<b>Communication Adjustments</b>	Frequency Point Selection	F810
		Point 1 Setting	F811
		Point 1 Frequency	F812
		Point 2 Setting	F813
		Point 2 Frequency	F814
	<b>Communication Settings</b>	Baud Rate (2-Wire RS485)	F800
		Parity (2-Wire and 4-Wire RS485)	F801
		ASD Number	F802
		Communications Time-Out (2-Wire and 4-Wire RS485)	F803
		Communication Time-Out Action (2-Wire and 4-Wire RS485)	F804
		Send Delay (2-Wire RS485)	F805
		ASD-to-ASD Communication (2-Wire RS485)	F806
		Baud Rate (4-Wire RS485)	F820
		RS485 Send Delay (4-Wire RS485)	F825
		ASD-to-ASD Communication (4-Wire RS485)	F826
		4-Wire RS485 Protocol (TSB/MODBUS)	F829
		Communication Option (DeviceNet/Profibus) Setting 1	F830
		Communication Option (DeviceNet/Profibus) Setting 2	F831
		Communication Option (DeviceNet/Profibus) Setting 3	F832
		Communication Option (DeviceNet/Profibus) Setting 4	F833
		Communication Option (DeviceNet/Profibus) Setting 5	F834
		Communication Option (DeviceNet/Profibus) Setting 6	F835
		Communication Option (DeviceNet/Profibus) Setting 7	F836
		Communication Option (DeviceNet/Profibus) Setting 8	F841
		Communication Option (DeviceNet/Profibus) Setting 9	F842
		Communication Option (DeviceNet/Profibus) Setting 10	F843
		Communication Option (DeviceNet/Profibus) Setting 11	F844
		Communication Option (DeviceNet/Profibus) Setting 12	F845
		Communication Option (DeviceNet/Profibus) Setting 13	F846
		Disconnection Detection Extended Time	F850

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
COMMUNICATIONS	Communication Settings	ASD Operation at Disconnection	F851
		Preset Speed Operation	F852
		Communication Option Station Address Monitor	F853
		Communication Option Speed Switch Monitor DeviceNet/CC-Link	F854
		Block Write Data 1	F870
		Block Write Data 2	F871
		Block Read Data 1	F875
		Block Read Data 2	F876
		Block Read Data 3	F877
		Block Read Data 4	F878
		Block Read Data 5	F879
		Free Notes	F880
		Network Option Reset Setting	F899
	Ethernet Settings	IP	N/A
		Sub Net	
		Gateway	
		DHCP Mode	
		MAC ID	
PATTERN RUN	Operation Mode	Preset Speed Operation Mode	F560
		<b>Preset Speed 1</b>	F561
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		<b>Preset Speed 2</b>	F562
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	



Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PATTERN RUN	Operation Mode	Preset Speed 3	F563
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 4	F564
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 5	F565
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 6	F566
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 7	F567
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 8	F568
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PATTERN RUN	Operation Mode	Preset Speed 9	F569
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 10	F570
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 11	F571
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 12	F572
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 13	F573
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
		Preset Speed 14	F574
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PATTERN RUN	Operation Mode	Preset Speed 15	F575
		Direction	
		Acceleration/Deceleration Group	
		V/f Group	
		Torque Limit Group	
	Operation Time	Speed 1 Operation Time	F540
		Speed 2 Operation Time	F541
		Speed 3 Operation Time	F542
		Speed 4 Operation Time	F543
		Speed 5 Operation Time	F544
		Speed 6 Operation Time	F545
		Speed 7 Operation Time	F546
		Speed 8 Operation Time	F547
		Speed 9 Operation Time	F548
		Speed 10 Operation Time	F549
		Speed 11 Operation Time	F550
		Speed 12 Operation Time	F551
		Speed 13 Operation Time	F552
		Speed 14 Operation Time	F553
		Speed 15 Operation Time	F554
	Pattern Run	Pattern Operation	F520
		Pattern Operation Mode	F521
		Pattern 1 Repeat	F522
		Pattern 2 Repeat	F531
	Speeds	Pattern Group 1, Selection 1	F523
		Pattern Group 1, Selection 2	F524
		Pattern Group 1, Selection 3	F525
		Pattern Group 1, Selection 4	F526
		Pattern Group 1, Selection 5	F527
		Pattern Group 1, Selection 6	F528

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PATTERN RUN	Speeds	Pattern Group 1, Selection 7	F529
		Pattern Group 1, Selection 8	F530
		Pattern Group 2, Selection 1	F532
		Pattern Group 2, Selection 2	F533
		Pattern Group 2, Selection 3	F534
		Pattern Group 2, Selection 4	F535
		Pattern Group 2, Selection 5	F536
		Pattern Group 2, Selection 6	F537
		Pattern Group 2, Selection 7	F538
		Pattern Group 2, Selection 8	F539
PASSWORD AND Lock Outs	Enter Password	Password is 0 (zero) for a new unit	N/A
	Change Password	Enter New Password	N/A
	Lock Outs	Reset From Trip	N/A
		Hand/Auto	
		Run/Stop from EOI	
		Frequency Change From EOI	
		Monitor Screen	
		Parameter Access	
		Parameter Write	

# Virtual Linear Pump

Toshiba International Corporation's **Virtual Linear Pump** (VLP) algorithm allows for direct and precise control of pressure, flow rate, or level. This is achieved without the concerns, instabilities, or complexities that are traditionally associated with pumping system control.

This section provides useful setup and operational information of the **VLP** system.

The **VLP** system is initially configured using the **VLP Setup Wizard** selection via Program ⇒ Virtual Linear Pump ⇒ **VLP Setup Wizard**. Once the **VLP Setup Wizard** is started it must be completed for normal **VLP** operations to function.

However, the **VLP** parameters addressed while using the wizard or the **VLP Settings** menu selection are also accessible via their associated direct access numbers for specific adjustments when required.

The **VLP** setup procedure and the **VLP Setup Wizard** setup screens are shown below.

Figure 29. Input the Electrical Specifications of the Motor.

<ol style="list-style-type: none"><li>1. From the nameplate of the motor, enter the FLA.</li><li>2. Select <b>Pressure</b> or <b>Level</b>.</li><li>3. Select the command source; <b>EOI</b> or <b>V/I</b> analog input.</li><li>4. Set the <b>Low Frequency Limit</b>. For most applications 15 Hz is ideal.</li><li>5. Click <b>Next</b> to continue.</li></ol>	<b>VLP Setup Wizard</b>		
	Back	Next	Exit
	Motor Full Load Amps		3.4A
	Application Type		Pressure
	Command Source		EOI
Low Frequency Limit		15.00Hz	

Figure 30. Input the Specifications of the Transducer.

<ol style="list-style-type: none"><li>6. Set the unit of measure for the transducer. Selections are PSI, GPM, "WC, 'WC, CFM, °C, °F, or Custom. Custom allows for 3 characters to represent the unit of measure.</li><li>7. Select the transducer output signal type; <b>Current</b> or <b>Voltage</b> and the range.</li><li>8. Set the full-scale reading of the transducer.</li><li>9. Click <b>Next</b> to continue.</li></ol>	<b>VLP Setup Wizard</b>		
	Back	Next	Exit
	Transducer Units:		Custom
	Transducer Type:		4-20mA
	Max Scale:		75.5
Min Scale:		10.2	

# DANGER

## WARNING! — THE FOLLOWING STEP WILL START THE MOTOR!

Figure 31. The VLP Maximum Value.

10. Set the system for normal flow and ensure that all system valves are set for normal operation.

11. Place the system in the **Hand** mode and press the **Run** key. The system will run at the **Upper Limit** setting (F012).

12. Click **Next** to continue.

The Motor/Pump combination capacity is automatically calculated and displayed as the **VLP Maximum**. Normally, no further adjustment is required for the **VLP Maximum** setting.

The **VLP Maximum** value may be adjusted, if required, at F395. The **VLP Maximum** setting (F395) minus the F482 setting comprises the range of the **VLP Maximum Zone**.

VLP Setup Wizard		
Back	Next	Exit
Use Encoder To Set VLP		
<b>Maximum</b>		80
Transducer Value		12 %

Figure 32. Set the VLP Minimum Value.

14. The **VLP Minimum** value setting is typically above the electrical stall of the motor, above the minimum system pressure, above the manual change plateau, and well below the typical operating point of the system.

Click in the **VLP Minimum** field and, using the **Rotary Encoder**, slowly decrease the **VLP Minimum** value while observing the LED display.

If either of the conditions listed below should occur while decreasing the **VLP Minimum** value, increase the **VLP Minimum** number until the condition is no longer true to set the **VLP Minimum**:

- The motor stalls,
- The output frequency is greater than the setting of F505, or
- The output frequency no longer changes with continued **VLP** number changes.

The **VLP Minimum** setting (F394) plus the F481 setting comprises the range of the **VLP Minimum Zone**.

15. Click **Next** to continue.

VLP Setup Wizard		
Back	Next	Exit
Use Encoder To Set VLP		
<b>Minimum</b>		70
Transducer Value		12 %

Figure 33. Complete the VLP Setup.

16. Press the **Stop** key to complete the **VLP** setup.

17. Click **Exit** to save settings (Exit available at zero Hz).

VLP Setup Wizard

BackNextExit

Press [STOP]  
Virtual Linear Pump Setup  
Is Now Complete

Figure 34. Run the Motor/Pump in the Direct Mode.

18. From the **Frequency Command** screen press **ESC**, scroll to the **VLP Control** field, and select **Direct Mode** if using no feedback (if using feedback go to [Step 21. on pg. 80](#)).

19. While in the **Hand** mode, and from the **Frequency Command** screen, press **Run**.

20. During operation, adjust parameters **F500** and **F501** to stabilize **VLP** operation if unstable.

0100%

SET:0.00 Hz

VLP Technology Avg:0%  
V/I Input:0.00%

F R ST RES S1 S2 S3 S4  
OUT1 OUT2 FL

Press **ESC**

Command

Torque Limit Group  
VLP Technology

Process Hold


Figure 35. Run the Motor/Pump in Process Hold Mode.

21. From the **Frequency Command** screen press **ESC**, scroll to the **VLP Control** field, and select **Process Hold** if using feedback (if not using feedback go to [Step 18. on pg. 79](#)).

22. From the **Frequency Command** screen press **Run**.

23. During operation, adjust parameters **F500** and **F501** to stabilize **VLP** operation if unstable.

0 ————— 100%

SET: 0.00 Hz 

VLP Technology Avg: 0%

V/I Input: 0.00%

F R ST RES S1 S2 S3 S4

OUT1 OUT2 FL

Press **ESC**

Command

Torque Limit Group

VLP Control 

Process Hold



## Direct Access Parameter Information

The P9 ASD has the ability to allow the user direct access to the motor control functions. There are two ways in which the motor control parameters may be accessed for modification from the EOI: Program ⇒ **Applicable Menu Path** or Program ⇒ Direct Access ⇒ **Applicable Parameter Number**. Both methods access the parameter via the **Program** mode. Parameters may also be accessed via communications. Once accessed, the parameter may be viewed or changed.

The **Program** mode allows the user to develop an application-specific motor control profile. Motor control functions may be set to accommodate specific power and timing requirements for a given application. The configurable parameters of the **Program** mode that have user-accessible **Parameter Numbers** are listed and described below.

**Note:** *Parameter Settings are preceded by the number used to select an item if using communications to write to a parameter location in memory (i.e., F000 ⇒ 0-Manual, 1- No Trip on Acc/Dec, 2-No trip on Acc Only, etc.).*

**Note:** *Communications setting changes will require that the ASD input power be removed and then re-applied for the changes to take affect.*

## Direct Access Parameters/Numbers

---

### Automatic Acceleration/Deceleration

Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings

This parameter is used to enable acceleration and deceleration rates in accordance with the applied load automatically.

The adjusted acceleration and deceleration times range from 12.5% to 800% of the programmed values for **Acceleration Time 1 (F009)** and **Deceleration Time 1 (F010)**.

Settings:

- 0 — Manual
- 1 — Automatic ACC/DEC
- 2 — Automatic ACC Only

**Note:** *The motor and the load must be connected prior to selecting Automatic Acceleration/Deceleration.*

**Direct Access Number — F000**

Parameter Type — **Selection List**

Factory Default — **Manual**

Changeable During Run — **No**

---

### Automatic Torque Boost

Program ⇒ Fundamental ⇒ Motor Set 1

This parameter allows the ASD to adjust the output torque in accordance with the applied load automatically. When enabled Autotuning is performed — the motor should be connected before performing an Autotune.

Settings:

- 0 — Disabled
- 1 — Automatic Torque Boost + Autotuning
- 2 — Sensorless Vector Control + Autotuning

**Direct Access Number — F001**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

---

**Command Mode Selection**

Program ⇒ Fundamental ⇒ Standard Mode Selection

The **Command Mode Selection** establishes the source of the command input for the ASD. Command inputs include **Run**, **Stop**, **Forward**, etc. The **Override** feature may supersede the **Command Mode Selection** setting (See [Command Mode and Frequency Mode Control on pg. 42](#)).

Settings:

- 0 — Terminal Block
- 2 — EOI (Keypad)
- 3 — RS485
- 4 — Communication Option Board

**Direct Access Number — F003**

Parameter Type — **Selection List**

Factory Default — **Terminal Block**

Changeable During Run — **No**

---

**Frequency Mode 1**

Program ⇒ Fundamental ⇒ Standard Mode Selection

The **Frequency Mode 1** setting establishes the source of the frequency-control input for the ASD. The **Frequency Mode 2** setting or the **Override** feature may supersede the **Frequency Mode 1** setting.

**Note:** Only **Bolded** items from the **Settings** list below may be placed in the **Override Mode**. See the section titled [Command Mode and Frequency Mode Control on pg. 42](#) for more information on the **Override** feature.

Settings:

- 1 — **V/I**
- 2 — RR
- 3 — RX
- 5 — **EOI** (Keypad)
- 6 — **RS485**
- 7 — Communication Option Board
- 8 — RX2 Option (AI1)
- 9 — **Option V/I**
- 10 — UP/DOWN Frequency
- 11 — Pulse Input (Option)
- 12 — Pulse Input (Motor CPU)
- 13 — Binary/BCD Input (Option)

**Direct Access Number — F004**

Parameter Type — **Selection List**

Factory Default — **RR**

Changeable During Run — **No**

---

**FM Output Terminal Function**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **FM** analog output terminal. The **FM** output terminal produces an output current or voltage that is proportional to the magnitude of the function assigned to this terminal (select current or voltage at [F681](#)). The available assignments for this output terminal are listed in [Table 7 on pg. 253](#).

***Note:** To read **voltage** at this terminal connect a 100 – 500Ω resistor from the **FM** (+) terminal to the **CC** (-) terminal. Using a voltmeter read the voltage across the 100 – 500Ω resistor.*

*To read **current** at this terminal connect a 100 – 500Ω resistor from the **FM** (+) terminal through a series Ammeter to the **CC** (-) terminal.*

*The **FM** analog output has a maximum resolution of 1/1024 and a maximum load rating of 500 ohms.*

**FM Terminal Setup Parameters**

- [F005](#) — Set FM Function
- [F006](#) — Calibrate FM Terminal
- [F681](#) — Voltage/Current Output Switching Selection
- [F682](#) — Output Response Polarity Selection
- [F683](#) — Set Zero Level

---

**FM Output Terminal Adjustment**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to calibrate the **FM** analog output.

To calibrate the **FM** analog output, connect a meter (current or voltage) as described at [F005](#).

With the ASD running at a known value (e.g., output frequency), adjust this parameter until the assigned function produces the desired DC level output at the **FM** output terminal.

See [F005](#) for more information on this setting.

---

**Direct Access Number — F005**

Parameter Type — **Selection List**

Factory Default — **Output Frequency**

Changeable During Run — **Yes**

---

**Direct Access Number — F006**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

---

**Type Reset**

Program ⇒ Utilities

This feature assists the user when performing fault analysis or by allowing a quick system setup change when required. Performing a **Type Reset** results in one of the following user-selected post-Reset configurations.

Settings:

- 0 — None.
- 1 — 50 Hz Setting — Sets the Maximum and Upper Limit Frequencies to 50 Hz.
- 2 — 60 Hz Setting — Sets the Maximum and Upper Limit Frequencies to 60 Hz.
- 3 — Reset to Factory Settings — Restores factory settings.
- 4 — Clear Past Trips — Clears four most-recent trips from the Monitor screen.
- 5 — Clear Run Timer — Sets the Run Timer to zero.
- 6 — Initialize Typeform — Restores factory settings and includes the analog terminals.
- 7 — \*Save User Settings — Stores user settings to the EOI memory.
- 8 — Restore User Settings — Restores user settings from the EOI memory.
- 9 — Clear Cumulative Fan Timer — Clears the part-replacement alarm.
- 10 — Accel/Decel Time Setting 0.01 – 600.00 Seconds — Display resolution.
- 11 — Accel/Decel Time Setting 0.1 – 6000.0 Seconds — Display resolution.
- 12 — Set EOI Memory to Default.

**Note:** User settings that are stored in the memory of the EOI are not saved via the **Save User Settings** selection. The unsaved functions include the items listed in the section titled [Battery Backup](#) on pg. 28.

---

**Forward/Reverse Run Selection**

Program ⇒ Fundamental ⇒ Standard Mode Selection

While operating in the **Hand** mode, this parameter sets the direction of motor rotation.

From the **Frequency Command** screen press the **ESC** key. At the subsequent **EOI Command** screen select the **Direction** field and change the setting. Press the **Rotary Encoder** and the new setting will be in effect.

This setting will not override parameter [F311](#) (Forward/Reverse Disable).

If either direction is disabled via parameter [F311](#), the disabled direction will not be recognized if commanded by the keypad. If both directions are disabled via parameter [F311](#), the direction command from the keypad will determine the direction of the motor rotation.

Settings:

- 0 — Forward
- 1 — Reverse
- 2 — Forward (EOI-Switchable F/R)
- 3 — Reverse (EOI-Switchable F/R)

**Direct Access Number — F007**Parameter Type — **Selection List**Factory Default — **None**Changeable During Run — **No**

---

**Direct Access Number — F008**Parameter Type — **Selection List**Factory Default — **Forward**Changeable During Run — **Yes**

**Acceleration Time 1**

Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings

This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** for the **1 Acceleration** profile. The Accel/Decel pattern may be set using [F502](#). The minimum Accel/Decel time may be set using [F508](#).

**Note:** *An acceleration time shorter than that which the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the acceleration times.*

**Acceleration**

The acceleration rate of a motor is determined by several factors: applied power, applied load, and the physical properties of the motor (winding parameters, motor size, etc.). The ASD will control the first of these factors: input power. The settings of the ASD will control the frequency and amplitude of the applied voltage to the motor.

Under most operating conditions, as the output frequency of the ASD goes up so does the output voltage (linear acceleration). The ASD has the ability to modify the relationship between frequency and voltage automatically to produce smoother operation or increased (starting) torque (See [F502](#)).

**Deceleration Time 1**

Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings

This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **1 Deceleration** profile. The Accel/Decel pattern may be set using [F502](#).

When operating with the **Automatic Accel/Decel** enabled ([F000](#)) the minimum accel/decel time may be set using [F508](#).

**Note:** *A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the deceleration times.*

**Maximum Frequency**

Program ⇒ Fundamental ⇒ Frequency Settings

This setting determines the absolute maximum frequency that the ASD can output.

**Accel/Decel** times are calculated based on the **Maximum Frequency** setting.

The **Maximum Frequency** is not limited by this setting while operating in the **Drooping Control** mode (See [F320](#) for more information on this setting).

**Note:** *This setting may not be lower than the **Upper-Limit Frequency** ([F012](#)) setting.*

**Direct Access Number — F009**

Parameter Type — **Numerical**

Factory Default — **(ASD-Dependent)**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

**Direct Access Number — F010**

Parameter Type — **Numerical**

Factory Default — **(ASD-Dependent)**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

**Direct Access Number — F011**

Parameter Type — **Numerical**

Factory Default — **66.0**

Changeable During Run — **No**

Minimum — **Upper Limit** ([F012](#))

Maximum — 299.0

Units — Hz


<p><b>Upper-Limit Frequency</b></p> <p>Program ⇒ Fundamental ⇒ Frequency Settings</p> <p>This parameter sets the highest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD may output frequencies higher than the <b>Upper-Limit Frequency</b> (but, lower than the <b>Maximum Frequency</b>) when operating in the <b>PID Control</b> mode, <b>Torque Control</b> mode, or the <b>Vector Control</b> modes (sensorless or feedback).</p> <p><i>Note:</i> This setting may not be higher than the <b>Maximum Frequency</b> (F011) setting.</p>	<p><b>Direct Access Number</b> — F012</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>66.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0 (F013)</p> <p>Maximum — <b>Max. Freq.</b> (F011)</p> <p>Units — Hz</p>
<p><b>Lower-Limit Frequency</b></p> <p>Program ⇒ Fundamental ⇒ Frequency Settings</p> <p>This parameter sets the lowest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD will output frequencies lower than the <b>Lower-Limit Frequency</b> when accelerating to the lower-limit or decelerating to a stop. Frequencies below the <b>Lower-Limit</b> may also be output when operating in the <b>PID Control</b> mode, <b>Torque Control</b> mode, or the <b>Vector Control</b> modes (sensorless or feedback).</p>	<p><b>Direct Access Number</b> — F013</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Upper-Limit</b> (F012)</p> <p>Units — Hz</p>
<p><b>Base Frequency 1</b></p> <p>Program ⇒ Fundamental ⇒ Motor Set 1</p> <p>The <b>Base Frequency 1</b> setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The <b>Base Frequency Voltage 1</b> parameter is set at F409.</p> <p>For proper motor operation, the <b>Base Frequency</b> should be set for the nameplated frequency of the motor.</p>	<p><b>Direct Access Number</b> — F014</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Upper-Limit</b> (F012)</p> <p>Units — Hz</p>
<p><b>V/f Pattern</b></p> <p>Program ⇒ Fundamental ⇒ Frequency Settings</p> <p>This function establishes the relationship between the output frequency and the output voltage.</p> <p><b>Bolded</b> selections use the motor tuning parameters of the ASD to properly configure the ASD for the motor being used. If <b>Load Reactors</b> or <b>Long Lead Filters</b> are used, or if the capacity of the ASD is greater than the motor, manual tuning of the motor parameters may be required for optimum performance.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — Constant Torque</li> <li>1 — Voltage Decrease Curve</li> <li>2 — <b>Automatic Torque Boost</b></li> <li>3 — <b>Sensorless Vector Control (Speed)</b></li> <li>4 — <b>Sensorless Vector Control (Speed/Torque Switching)</b></li> <li>5 — V/f 5-point Curve (Go to F190 to configure the V/f 5-Point Settings)</li> <li>6 — PM Drive (Permanent Magnet)</li> <li>7 — <b>PG Feedback Vector Control (Speed)</b></li> <li>8 — <b>PG Feedback Vector Control (Speed/Torque Switching)</b></li> </ul> <p><i>Note:</i> When operating in the <b>Vector Control</b> mode the carrier frequency should be set to 2.2 kHz or above.</p>	<p><b>Direct Access Number</b> — F015</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Automatic Torque Boost</b></p> <p>Changeable During Run — <b>No</b></p>

## Manual Torque Boost 1

Program ⇒ Fundamental ⇒ Motor Set 1

The **Manual Torque Boost 1** function is used to increase the low frequency torque for high-inertia loads by increasing the output voltage at frequencies below ½ of the **Base Frequency 1** (F014) setting.

The value programmed as a boost percentage establishes an output voltage vs. output frequency relationship to be used to start the motor or to provide smoother operation.



**Note:** Setting an excessive **Torque Boost** level may cause nuisance tripping and mechanical stress to loads.

**Direct Access Number — F016**

**Parameter Type — Numerical**

**Factory Default — (ASD-Dependent)**

**Changeable During Run — Yes**

**Minimum — 0.0**

**Maximum — 30.0**

**Units — %**

## Motor Overload Protection Configuration

Program ⇒ Protection ⇒ Overload

This parameter is used to protect the motor from an over-current condition. The type of motor being used and the **Overload Stall** setting is selected here to better match the application.

This parameter setting may extend the **Over-Voltage Stall** time settings.

This parameter may be affected by the setting of the **Power Running Stall Continuous Trip Detection Time** (F452).

Parameter F452 (Power Running Stall Continuous Trip Detection Time) setting may affect the performance of this parameter setting.

**Direct Access Number — F017**

**Parameter Type — Selection List**

**Factory Default — O/L Trip w/o Stall**

**Changeable During Run — Yes**

Settings:

- 0 — Overload Trip without Stall
- 1 — Overload Trip with Stall
- 2 — No Overload without Stall
- 3 — Stall Only
- 4 — V/f Motor-Overload without Stall
- 5 — V/f Motor-Overload with Stall
- 6 — V/f Motor-No Overload without Stall
- 7 — V/f Motor-Stall Only

## Preset Speed 1

Program ⇒ Frequency ⇒ Preset Speeds

Up to fifteen (15) output frequency values that fall within the **Lower-Limit** and the **Upper-Limit** range may be programmed into the ASD and output as a **Preset Speed**. This parameter assigns an output frequency to binary number 0001 and is identified as **Preset Speed 1**. The binary number is applied to **S1 – S4** of the **Terminal Board** to output the **Preset Speed**.

Perform the following setup to allow the system to receive **Preset Speed** control input at the **S1 – S4** terminals:

1. Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.
2. Program ⇒ Terminal ⇒ Input Terminals ⇒ **S1** (set to **Preset Speed 1**; LSB of 4-bit count). Repeat for **S2 – S4** (MSB of 4-bit count) as **Preset Speed 2 – 4**, respectively (all **Normally Open**).
3. Program ⇒ Frequency ⇒ Preset Speeds ⇒ **Preset Speed 1** (set an output frequency as **Preset Speed 1**; repeat for **Preset Speeds 2 – 15** as required).
4. Program ⇒ Pattern Run ⇒ Operation Mode ⇒ Preset Speed Operation Mode ⇒ **Enabled/Disabled**.

Select **Enabled** to use the direction, accel/decel, and torque settings of the **Preset Speed** being run. The torque settings used will be as defined in **F170 – F181** and as selected via the associated discrete input terminals **V/f Switching 1 and 2** in **Table 6 on pg. 249**.

Select **Disabled** to use the speed setting only of the **Preset Speed** being run.

5. Place the system in the **Hand** mode (Hand/Auto LED Off).
6. Provide a **Run** command (connect F and/or R to CC).

Connect **S1** to **CC** to run **Preset Speed 1** (**S1** to **CC** = 0001 binary).

With **S1 – S4** configured to output **Preset Speeds** (**F115 – F118**), 0001 – 1111 may be applied to **S1 – S4** of the **Terminal Board** to run the associated **Preset Speed**. If bidirectional operation is required, **F** and **R** must be connected to **CC**, and **Preset Speed Operation Mode** must be set to **Enabled** at **F560**.

With **S1** being the least significant bit of a binary count, the **S1 – S4** settings will produce the programmed speed settings as indicated in the **Preset Speed Truth Table** to the right.

**Preset Speeds** are also used in the **Pattern Run** mode.

**Direct Access Number — F018**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower-Limit** (**F013**)

Maximum — **Upper-Limit** (**F012**)

Units — Hz

**Preset Speed Truth Table**

Preset	S4 MSB	S3	S2	S1 LSB	Output
1	0	0	0	1	F018
2	0	0	1	0	F019
3	0	0	1	1	F020
4	0	1	0	0	F021
5	0	1	0	1	F022
6	0	1	1	0	F023
7	0	1	1	1	F024
8	1	0	0	0	F287
9	1	0	0	1	F288
10	1	0	1	0	F289
11	1	0	1	1	F290
12	1	1	0	0	F291
13	1	1	0	1	F292
14	1	1	1	0	F293
15	1	1	1	1	F294
<i>Note: 1 = Terminal connected to CC.</i>					

## Preset Speed 2

Program ⇒ Frequency ⇒ Preset Speeds

This parameter assigns an output frequency to binary number 0010 and is identified as **Preset Speed 2**. The binary number is applied to **S1 – S4** of the **Terminal Board** to output the **Preset Speed** (See **F018** for more information on this parameter).

**Direct Access Number — F019**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower-Limit** (**F013**)

Maximum — **Upper-Limit** (**F012**)

Units — Hz



<b>Preset Speed 3</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 0011 and is identified as <b>Preset Speed 3</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F020</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 4</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 0100 and is identified as <b>Preset Speed 4</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F021</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 5</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 0101 and is identified as <b>Preset Speed 5</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F022</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 6</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 0110 and is identified as <b>Preset Speed 6</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F023</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 7</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 0111 and is identified as <b>Preset Speed 7</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F024</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz

## Automatic Function Selection

Program ⇒ Utilities ⇒ Display Parameters

This parameter setting is used to configure multiple parameters with the setting of only one parameter. From the selection below multiple parameters may be set as indicated in the table.

Once set, the selected configuration is placed in effect and remains in effect until this parameter is changed or the individual settings are changed.

Set this parameter to **Disable** to set these parameters individually.

**Note:** After performing the desired selection the EOI display returns to **Disabled** though the selected function has been carried out (i.e., without this, if selection **1** is performed, **F004** and **F207** would hold the **RR** terminal setting regardless of attempts to change the settings individually).

Settings:

- 0 — Disabled
- 1 — RR
- 2 — V/I
- 3 — RR or V/I (V/I) Switched via Terminal Board
- 4 — Keypad = Frequency/Terminal Board = Command
- 5 — Keypad = Frequency and Command

		User Settings					
		0	1	2	3	4	5
Related Parameters	Default Settings	Disabled	RR	V/I	RR or V/I via TB	Keypad/ Freq. CMD/TB	Keypad Freq/CMD
Command Mode F003	Terminal Board	N/C				Terminal Board	Keypad
Frequency Mode 1 F004	RR	N/C	RR	N/C	RR	Keypad	
S3 Terminal F117	Preset Speed 3	N/C			Freq. Ref. Priority	N/C	
Frequency Priority F200	Terminal Board	N/C	Terminal Board				
V/I Setup F201	0.0%	N/C		20.0%		N/C	
Frequency Mode 2 F207	V/I	N/C	RR	V/I		Keypad	
N/C = No Change — the setting remains as it was before setting parameter F040.							

Direct Access Number — **F040**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

### Low-Speed Signal Output Frequency

Program ⇒ Terminal ⇒ Reach Settings

The **Low-Speed Signal Output Frequency** parameter sets an ASD output frequency threshold that activates the assigned discrete output terminal for the duration that the ASD output speed is equal to or less than this setting.

**Direct Access Number — F100**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Upper Limit (F012)**

Units — Hz

### Speed Reach Frequency

Program ⇒ Terminal ⇒ Reach Settings

The **Speed Reach Frequency** sets a frequency threshold that, when reached or is within the bandwidth specified by parameter **F102**, activates the assigned discrete output terminal for the duration that the ASD output is within the **F102** bandwidth.

**Direct Access Number — F101**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Upper Limit (F012)**

Units — Hz

### Speed Reach Detection Band

Program ⇒ Terminal ⇒ Reach Settings

This parameter sets the bandwidth of the **Speed Reach Frequency (F101)** setting.

**Direct Access Number — F102**

Parameter Type — **Numerical**

Factory Default — **2.50**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Upper Limit (F012)**

Units — Hz

### Forward/Reverse Run Priority Selection

Program ⇒ Terminal ⇒ Input Special Functions

The **Forward/Reverse Priority Selection** determines the operation of the ASD if the **F** and **R** control terminals are activated simultaneously.

Settings:

0 — Reverse

1 — Suspend

The waveforms shown depict the motor response for all combinations of the **F** and **R** terminal settings if the **Reverse** option is chosen.

The **Suspend** setting will decelerate the motor to a stop regardless of the rotation direction when both the **F** and **R** control terminals are activated.


**Direct Access Number — F105**

Parameter Type — **Selection List**

Factory Default — **Suspend**

Changeable During Run — **No**

Simultaneous F and R activation.



---

**Input Terminal Priority**

Program ⇒ Terminal ⇒ Input Special Functions

This parameter is used to allow the **Jog** and **DC Injection Braking** input signals to control the ASD when received via the **Terminal Board** even though the system is in the **Hand** mode.

With this parameter enabled, a **Jog** command or a **DC Injection Braking** command received from the **Terminal Board** will receive priority over commands from the **EOI**.

See [F260](#) for more information on using the **Jog** function.

See [F250 – F252](#) for more information on **DC Injection Braking**.

Settings:

- 0 — Disabled
- 1 — Enabled

**Direct Access Number — F106**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

---

**16-Bit Binary/BCD Input**

Program ⇒ Terminal ⇒ Input Special Functions

The extended terminal function is used with the **Expansion IO Card Option** (P/N ETB004Z).

This parameter defines the format of the binary or BCD data when using the option card.

**Note:** *The **Expansion IO Card Option 2** option board is required to use this terminal.*

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

Settings:

- 0 — None
- 1 — 12-Bit Binary
- 2 — 16-Bit Binary
- 3 — 3-Digit BCD
- 4 — 4-Digit BCD
- 5 — Inverted 12-Bit Binary
- 6 — Inverted 16-Bit Binary
- 7 — Inverted 3-Digit BCD
- 8 — Inverted 4-Digit BCD

Selections using 16-bit binary or 4-digit BCD will require the configuration of terminals S1-S4 on the **Terminal Board** as binary bits 0 – 3 ([F115 – F118](#)). The **Frequency Mode 1** ([F004](#)) parameter must be set to **Binary/BCD**.

For proper scaling of the binary or BCD input, parameters [F228 – F231](#) must be configured.

**Direct Access Number — F107**

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **No**

<b>Option V/I Terminal Voltage/Current Selection</b> Program ⇒ Frequency ⇒ V/I Settings  This parameter is used to set the <b>AI2</b> input terminal to receive either current or voltage as a control signal.  <i>Note: The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.</i>  See the <b>Expansion IO Card Option 2</b> instruction manual (P/N 58686) for more information on the function of this terminal.  Settings: 0 — Voltage Input 1 — Current Input	<b>Direct Access Number — F109</b> <b>Parameter Type — Selection List</b> <b>Factory Default — Voltage Input</b> <b>Changeable During Run — No</b>
<b>Always ON Terminal 1</b> Program ⇒ Terminal ⇒ Input Terminals ⇒ ON  This parameter is used to set the functionality of the virtual discrete input terminal <b>ON</b> . As a virtual terminal, the <b>ON</b> control terminal exists only in memory and is considered to always be in its <b>True</b> (connected to CC) state.  It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.  This parameter sets the programmable <b>ON</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F110</b> <b>Parameter Type — Selection List</b> <b>Factory Default — Unassigned</b> <b>Changeable During Run — No</b>
<b>Input Terminal 1 (F) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>F</b> discrete input terminal. In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>F</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F111</b> <b>Parameter Type — Selection List</b> <b>Factory Default — Forward</b> <b>Changeable During Run — No</b>
<b>Input Terminal 2 (R) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>R</b> discrete input terminal. In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>R</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F112</b> <b>Parameter Type — Selection List</b> <b>Factory Default — Reverse</b> <b>Changeable During Run — No</b>
<b>Input Terminal 3 (ST) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>ST</b> (Standby) discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>ST</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F113</b> <b>Parameter Type — Selection List</b> <b>Factory Default — Standby</b> <b>Changeable During Run — No</b>

<b>Input Terminal 4 (RES) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>RES</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>RES</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F114</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Reset</b> Changeable During Run — <b>No</b>
<b>Input Terminal 5 (S1) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>S1</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>S1</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F115</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Preset Speed 1</b> Changeable During Run — <b>No</b>
<b>Input Terminal 6 (S2) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>S2</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>S2</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F116</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Preset Speed 2</b> Changeable During Run — <b>No</b>
<b>Input Terminal 7 (S3) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>S3</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>S3</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F117</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Preset Speed 3</b> Changeable During Run — <b>No</b>
<b>Input Terminal 8 (S4) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>S4</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This parameter sets the programmable <b>S4</b> terminal to one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .	<b>Direct Access Number — F118</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Preset Speed 4</b> Changeable During Run — <b>No</b>

---

**Input Terminal 9 (LI1) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI1** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI1** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

**Note:** *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

---

**Direct Access Number — F119**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Input Terminal 10 (LI2) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI2** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI2** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

**Note:** *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

---

**Direct Access Number — F120**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Input Terminal 11 (LI3) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI3** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI3** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

**Note:** *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

---

**Direct Access Number — F121**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Input Terminal 12 (LI4) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI4** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI4** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

**Note:** *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

---

**Direct Access Number — F122**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Input Terminal 13 (LI5) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI5** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI5** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

**Note:** *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

---

**Direct Access Number — F123**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Input Terminal 14 (LI6) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI6** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI6** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

**Note:** *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

---

**Direct Access Number — F124**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**



---

**Input Terminal 15 (LI7) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI7** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI7** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

***Note:** The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

---

**Direct Access Number — F125**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Input Terminal 16 (LI8) Function**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI8** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI8** terminal to one of the user-selectable functions listed in [Table 6 on pg. 249](#).

***Note:** The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

---

**Direct Access Number — F126**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Output Terminal 1 (OUT1) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT1** discrete output terminals **O1A** and **O1B**.

The **O1A** and **O1B** (OUT1) output terminals change states (open or close) as a function of a user-selected event. See [Table 9 on pg. 255](#) for listing the possible assignments for the **OUT1** terminals.

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

---

**Direct Access Number — F130**Parameter Type — **Selection List**Factory Default — **External Device 1**Changeable During Run — **No**

---

**Output Terminal 2 (OUT2) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT2** discrete output terminals **O2A** and **O2B**.

The **O2A** and **O2B** (OUT2) output terminals change states (open or close) as a function of a user-selected event. See [Table 9 on pg. 255](#) for listing the possible assignments for the **OUT2** terminals.

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

---


**Direct Access Number — F131**Parameter Type — **Selection List**Factory Default — **External Device 2**Changeable During Run — **No**

**Output Terminal 3 (FL) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **FL** output terminals to one of the user-selectable functions listed in [Table 9 on pg. 255](#).

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

**Direct Access Number — F132**Parameter Type — **Selection List**Factory Default — **Fault (All)**Changeable During Run — **No****Output Terminal 4 (OUT3) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT3** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT3** terminal to one of the user-selectable functions listed in [Table 9 on pg. 255](#).

**Note:** The *Expansion IO Card Option 1* option board (P/N ETB003Z) is required to use this terminal.

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

**Direct Access Number — F133**Parameter Type — **Selection List**Factory Default — **Always OFF**Changeable During Run — **No****Output Terminal 5 (OUT4) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT4** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT4** terminal to one of the user-selectable functions listed in [Table 9 on pg. 255](#).

**Note:** The *Expansion IO Card Option 1* option board (P/N ETB003Z) is required to use this terminal.

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

**Direct Access Number — F134**Parameter Type — **Selection List**Factory Default — **Always OFF**Changeable During Run — **No**

---

**Output Terminal 6 (R1) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **R1** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **R1** terminal to one of the user-selectable functions listed in [Table 9 on pg. 255](#).

**Note:** *The **Expansion IO Card Option 1** option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.

---

**Direct Access Number — F135**Parameter Type — **Selection List**Factory Default — **Always OFF**Changeable During Run — **No**

---

**Output Terminal 7 (OUT5) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT5** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT5** terminal to one of the user-selectable functions listed in [Table 9 on pg. 255](#).

**Note:** *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

---

**Direct Access Number — F136**Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

---

**Output Terminal 8 (OUT6) Function**

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT6** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT6** terminal to one of the user-selectable functions listed in [Table 9 on pg. 255](#).

**Note:** *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

---

**Direct Access Number — F137**Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

### Output Terminal 9 (R2) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **R2** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **R2** terminal to one of the user-selectable functions listed in [Table 9 on pg. 255](#).

**Note:** The *Expansion IO Card Option 2* option board (P/N ETB004Z) is required to use this terminal.

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

Direct Access Number — F138

Parameter Type — Selection List


Factory Default — Always Off

Changeable During Run — No

### Input Terminal 1 (F) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **F** terminal input by the programmed value.



The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F140

Parameter Type — Numerical

Factory Default — 8.0

Changeable During Run — No

Minimum — 2.0

Maximum — 200.0

Units — mS

### Input Terminal 2 (R) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **R** terminal input by the programmed value (See waveforms at [F140](#)).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F141

Parameter Type — Numerical

Factory Default — 8.0

Changeable During Run — No

Minimum — 2.0

Maximum — 200.0

Units — mS

### Input Terminal 3 (ST) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **ST** terminal input by the programmed value (See waveforms at [F140](#)).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F142

Parameter Type — Numerical

Factory Default — 8.0

Changeable During Run — No

Minimum — 2.0

Maximum — 200.0

Units — mS

<b>Input Terminal 4 (RES) Response Time</b> Program ⇒ Terminal ⇒ Input Terminal Delays  This parameter delays the response of the ASD to any change in the <b>RES</b> terminal input by the programmed value (See waveforms at <a href="#">F140</a> ).  The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.	<b>Direct Access Number — F143</b> Parameter Type — <b>Numerical</b> Factory Default — <b>8.0</b> Changeable During Run — <b>No</b> Minimum — 2.0 Maximum — 200.0 Units — mS
<b>Input Terminal 5 – 12 Response Time</b> Program ⇒ Terminal ⇒ Input Terminal Delays  This parameter delays the response of the ASD to any change in the <b>5 – 12</b> terminal inputs by the programmed value (See waveforms at <a href="#">F140</a> ).  The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.	<b>Direct Access Number — F144</b> Parameter Type — <b>Numerical</b> Factory Default — <b>8.0</b> Changeable During Run — <b>No</b> Minimum — 2.0 Maximum — 200.0 Units — mS
<b>Input Terminal 13 – 20 Response Time</b> Program ⇒ Terminal ⇒ Input Terminal Delays  This parameter delays the response of the ASD to any change in the <b>13 – 20</b> terminal inputs by the programmed value (See waveforms at <a href="#">F140</a> ).  The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.	<b>Direct Access Number — F145</b> Parameter Type — <b>Numerical</b> Factory Default — <b>8.0</b> Changeable During Run — <b>No</b> Minimum — 2.0 Maximum — 200.0 Units — mS
<b>Input Terminal 17 (B12) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>B12</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This setting assigns the functionality of the programmable <b>B12</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .  See the <b>My Function Instruction Manual</b> (P/N E6581335) for more information on the function of this terminal.	<b>Direct Access Number — F164</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Unassigned</b> Changeable During Run — <b>No</b>
<b>Input Terminal 18 (B13) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>B13</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This setting assigns the function of the programmable <b>B13</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .  See the <b>My Function Instruction Manual</b> (P/N E6581335) for more information on the function of this terminal.	<b>Direct Access Number — F165</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Unassigned</b> Changeable During Run — <b>No</b>

<b>Input Terminal 19 (B14) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>B14</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This setting assigns the function of the programmable <b>B14</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .  See the <b>My Function Instruction Manual</b> (P/N E6581335) for more information on the function of this terminal.	<b>Direct Access Number — F166</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Unassigned</b> Changeable During Run — <b>No</b>
<b>Input Terminal 20 (B15) Function</b> Program ⇒ Terminal ⇒ Input Terminals  This parameter is used to set the functionality of the <b>B15</b> discrete input terminal.  In addition, this input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  This setting assigns the function of the programmable <b>B15</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 6 on pg. 249</a> .  See the <b>My Function Instruction Manual</b> (P/N E6581335) for more information on the function of this terminal.	<b>Direct Access Number — F167</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Unassigned</b> Changeable During Run — <b>No</b>
<b>Output Terminal 10 (R3) Function</b> Program ⇒ Terminal ⇒ Output Terminals  This parameter sets the functionality of the <b>R3</b> output terminal to any one of the user-selectable functions listed in <a href="#">Table 9 on pg. 255</a> .  In addition, the output terminals must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  See the instruction manual for the <b>16-Bit BIN/BCD</b> option for more information on the function of this terminal.	<b>Direct Access Number — F168</b> Parameter Type — <b>Selection List</b> Factory Default — <b>OFF</b> Changeable During Run — <b>No</b>
<b>Output Terminal 11 (R4) Function</b> Program ⇒ Terminal ⇒ Output Terminals  This parameter sets the functionality of the <b>R4</b> output terminal to any one of the user-selectable functions listed in <a href="#">Table 9 on pg. 255</a> .  In addition, the output terminals must be specified as <b>Normally Open</b> or <b>Normally Closed</b> .  See the instruction manual for the <b>16-Bit BIN/BCD</b> option for more information on the function of this terminal.	<b>Direct Access Number — F169</b> Parameter Type — <b>Selection List</b> Factory Default — <b>OFF</b> Changeable During Run — <b>No</b>

<p><b>Base Frequency 2</b></p> <p>Program ⇒ Motor ⇒ Motor Set 2</p> <p>The <b>Base Frequency 2</b> setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The <b>Base Frequency Voltage 2</b> parameter is set at <a href="#">F171</a>.</p> <p>This parameter is used only when the parameters for <b>Motor Set 2</b> are configured and selected. <b>Motor Set 2</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a>).</p> <p>For proper motor operation, the <b>Base Frequency</b> should be set for the nameplated frequency of the motor.</p>	<p><b>Direct Access Number — F170</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 25.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p><b>Base Frequency Voltage 2</b></p> <p>Program ⇒ Motor ⇒ Motor Set 2</p> <p>The <b>Base Frequency Voltage 2</b> setting is the <b>Motor 2</b> output voltage at the <b>Base Frequency</b> (<a href="#">F170</a>). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Compensation</b> setting (<a href="#">F307</a>).</p> <p>This parameter is used only when the parameters for <b>Motor Set 2</b> are configured and selected. <b>Motor Set 2</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a>).</p>	<p><b>Direct Access Number — F171</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-Dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 50.0</p> <p>Maximum — 660.0</p> <p>Units — Volts</p>
<p><b>Manual Torque Boost 2</b></p> <p>Program ⇒ Motor ⇒ Motor Set 2</p> <p>The <b>Manual Torque Boost 2</b> function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the <b>Base Frequency 2</b> setting (<a href="#">F170</a>).</p> <p>See parameter <a href="#">F016</a> (Manual Torque Boost 1) for an explanation of torque boost.</p> <p>This parameter is used only when the parameters for <b>Motor Set 2</b> are configured and selected. <b>Motor Set 2</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a>).</p>	<p><b>Direct Access Number — F172</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-Dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 30.0</p> <p>Units — %</p>
<p><b>Motor Overload Protection Level 2</b></p> <p>Program ⇒ Motor ⇒ Motor Set 2</p> <p>The <b>Motor 2 Overload Protection Level</b> parameter specifies the motor overload current level for <b>Motor Set 2</b>. This value is entered as either a percentage of the full load rating of the ASD or as the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to <b>Amps</b> (A/V) or it may be set as a percentage of the ASD rating. The nameplated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (See <a href="#">F701</a> to change the display unit).</p> <p>The <b>Motor 2 Overload Protection Level</b> setting will be displayed in <b>Amps</b> if the <b>EOI</b> display units are set to <b>A/V</b> rather than <b>%</b>.</p>	<p><b>Direct Access Number — F173</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10</p> <p>Maximum — 100</p> <p>Units — %</p>

<b>Base Frequency 3</b> Program ⇒ Motor ⇒ Motor Set 3  The <b>Base Frequency 3</b> setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The <b>Base Frequency Voltage 3</b> parameter is set at <a href="#">F175</a> .  This parameter is used only when the parameters for <b>Motor Set 3</b> are configured and selected. <b>Motor Set 3</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a> ).  For proper motor operation, the <b>Base Frequency</b> should be set for the nameplated frequency of the motor.	<b>Direct Access Number — F174</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.0</b> Changeable During Run — <b>No</b> Minimum — 25.0 Maximum — 299.0 Units — Hz
<b>Base Frequency Voltage 3</b> Program ⇒ Motor ⇒ Motor Set 3  The <b>Base Frequency Voltage 3</b> setting is the <b>Motor 3</b> output voltage at the <b>Base Frequency</b> ( <a href="#">F174</a> ). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.  The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Compensation</b> setting ( <a href="#">F307</a> ).  This parameter is used only when the parameters for <b>Motor Set 3</b> are configured and selected. <b>Motor Set 3</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a> ).	<b>Direct Access Number — F175</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 50.0 Maximum — 660.0 Units — Volts
<b>Manual Torque Boost 3</b> Program ⇒ Motor ⇒ Motor Set 3  The <b>Manual Torque Boost 3</b> function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the <b>Base Frequency 3</b> setting ( <a href="#">F174</a> ).  See parameter <a href="#">F016</a> (Manual Torque Boost 1) for an explanation of torque boost.  This parameter is used only when the parameters for <b>Motor Set 3</b> are configured and selected. <b>Motor Set 3</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a> ).	<b>Direct Access Number — F176</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 30.0 Units — %
<b>Motor Overload Protection Level 3</b> Program ⇒ Motor ⇒ Motor Set 3  The <b>Motor 3 Overload Protection Level</b> parameter specifies the motor overload current level for <b>Motor Set 3</b> . This value is entered as either a percentage of the full load rating of the ASD or as the FLA of the motor.  The unit of measurement for this parameter may be set to <b>Amps</b> (A/V) or it may be set as a percentage of the ASD rating. The nameplated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (See <a href="#">F701</a> to change the display unit).  The <b>Motor 3 Overload Protection Level</b> setting will be displayed in <b>Amps</b> if the <b>EOI</b> display units are set to <b>A/V</b> rather than <b>%</b> .	<b>Direct Access Number — F177</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100.0</b> Changeable During Run — <b>Yes</b> Minimum — 10 Maximum — 100 Units — %



<b>Base Frequency 4</b> Program ⇒ Motor ⇒ Motor Set 4  The <b>Base Frequency 4</b> setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The <b>Base Frequency Voltage 4</b> parameter is set at <a href="#">F179</a> .  This parameter is used only when the parameters for <b>Motor Set 4</b> are configured and selected. <b>Motor Set 4</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a> ).  For proper motor operation, the <b>Base Frequency</b> should be set for the nameplated frequency of the motor.	<b>Direct Access Number — F178</b>  Parameter Type — <b>Numerical</b> Factory Default — <b>60.0</b> Changeable During Run — <b>No</b> Minimum — 25.00 Maximum — 299.0 Units — Hz
<b>Base Frequency Voltage 4</b> Program ⇒ Motor ⇒ Motor Set 4  The <b>Base Frequency Voltage 4</b> is the <b>Motor 4</b> output voltage at the <b>Base Frequency</b> ( <a href="#">F178</a> ). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.  The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Compensation</b> setting ( <a href="#">F307</a> ).  This parameter is used only when the parameters for <b>Motor Set 4</b> are configured and selected. <b>Motor Set 4</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a> ).	<b>Direct Access Number — F179</b>  Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 50.0 Maximum — 660.0 Units — Volts
<b>Manual Torque Boost 4</b> Program ⇒ Motor ⇒ Motor Set 4  The <b>Manual Torque Boost 4</b> function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the <b>4 Base Frequency</b> setting ( <a href="#">F178</a> ).  See parameter <a href="#">F016</a> (Manual Torque Boost 1) for an explanation of torque boost.  This parameter is used only when the parameters for <b>Motor Set 4</b> are configured and selected. <b>Motor Set 4</b> may be selected by a properly configured input terminal (See <a href="#">Table 6 on pg. 249</a> ).	<b>Direct Access Number — F180</b>  Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 30.0 Units — %
<b>Motor Overload Protection Level 4</b> Program ⇒ Motor ⇒ Motor Set 4  The <b>Motor 4 Overload Protection Level</b> parameter specifies the motor overload current level for <b>Motor Set 4</b> . This value is entered as either a percentage of the full load rating of the ASD or as the FLA of the motor.  The unit of measurement for this parameter may be set to <b>Amps</b> (A/V) or it may be set as a percentage of the ASD rating. The nameplated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (See <a href="#">F701</a> to change the display unit).  The <b>Motor 4 Overload Protection Level</b> setting will be displayed in <b>Amps</b> if the <b>EOI</b> display units are set to <b>A/V</b> rather than <b>%</b> .	<b>Direct Access Number — F181</b>  Parameter Type — <b>Numerical</b> Factory Default — <b>100.0</b> Changeable During Run — <b>Yes</b> Minimum — 10 Maximum — 100 Units — %

### V/f 5-Point Setting Frequency 1

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Frequency 1** setting establishes the frequency that is to be associated with the voltage setting of **F191** (V/f 5-Point Setting Voltage 1).

The V/f 5-Point settings define a volts per hertz relationship for the startup output of the ASD.

To enable this function, set the **V/f Pattern (F015)** selection to the **V/f 5-Point Curve** setting.

**V/f Curves** may be useful in starting high inertia loads such as rotary drum vacuum filters.

**Direct Access Number — F190**

**Parameter Type — Numerical**


**Factory Default — 0.00**

**Changeable During Run — No**

**Minimum — 0.00**

**Maximum — Max. Freq. (F011)**

**Units — Hz**



### V/f 5-Point Setting Voltage 1

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Voltage 1** establishes the output voltage level that is to be associated with the frequency setting of **F190** (V/f 5-Point Setting Frequency 1).


The **F701** parameter setting will determine if the on-screen selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating.

If using **Voltage** as a unit of measure and with no voltage correction (**F307** Disabled), the limit of the on-screen display value for this parameter is 200 volts for the 230-volt ASD and 400 volts for the 460-volt ASD.

The actual output voltage is scaled to the maximum EOI display values (e.g., a 100-volt EOI display corresponds to a 115-volt actual output for the 230-volt ASD — ½ of the full display range).

If using **%** as a unit of measure and with no voltage correction (**F307** Disabled), the ASD output voltage will be the percentage setting times 230 for the 230-volt unit (or % times 460 volts for the 460-volt unit).

See **F190** for additional information on this setting.



Direct Access Number — **F191**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **No**

Minimum — 0.0

Maximum — 100.0

Units — V or % (**F701**)

### V/f 5-Point Setting Frequency 2

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Frequency 2** sets the frequency to be associated with the voltage setting of parameter **F193** (V/f 5-Point Setting Voltage 2).

See **F190** and **F191** for additional information on this setting.

Direct Access Number — **F192**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **No**

Minimum — 0.00

Maximum — **Max. Freq.** (**F011**)

Units — Hz

<b>V/f 5-Point Setting Voltage 2</b> Program ⇒ Special ⇒ V/f 5-Point Setting  The <b>V/f 5-Point Setting Voltage 2</b> establishes the output voltage level that is to be associated with the frequency setting of <b>F192</b> (V/f 5-Point Setting Frequency 2).  The <b>F701</b> parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %.  See <b>F190</b> and <b>F191</b> for additional information on this setting.	<b>Direct Access Number — F193</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>No</b> Minimum — 0.0 Maximum — 100.0 Units — V or % ( <b>F701</b> )
<b>V/f 5-Point Setting Frequency 3</b> Program ⇒ Special ⇒ V/f 5-Point Setting  The <b>V/f 5-Point Setting Frequency 3</b> sets the frequency to be associated with the voltage setting of parameter <b>F195</b> (V/f 5-Point Setting Voltage 3). See <b>F190</b> and <b>F191</b> for additional information on this setting.	<b>Direct Access Number — F194</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>No</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>V/f 5-Point Setting Voltage 3</b> Program ⇒ Special ⇒ V/f 5-Point Setting  The <b>V/f 5-Point Setting Voltage 3</b> establishes the output voltage level that is to be associated with the frequency setting of <b>F194</b> (V/f 5-Point Setting Frequency 3).  The <b>F701</b> parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %.  See <b>F190</b> and <b>F191</b> for additional information on this setting.	<b>Direct Access Number — F195</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>No</b> Minimum — 0.0 Maximum — 100.0 Units — V or % ( <b>F701</b> )
<b>V/f 5-Point Setting Frequency 4</b> Program ⇒ Special ⇒ V/f 5-Point Setting  The <b>V/f 5-Point Setting Frequency 4</b> sets the frequency to be associated with the voltage setting of parameter <b>F197</b> (V/f 5-Point Setting Voltage 4). See <b>F190</b> and <b>F191</b> for additional information on this setting.	<b>Direct Access Number — F196</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>No</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>V/f 5-Point Setting Voltage 4</b> Program ⇒ Special ⇒ V/f 5-Point Setting  The <b>V/f 5-Point Setting Voltage 4</b> establishes the output voltage level that is to be associated with the frequency setting of <b>F196</b> (V/f 5-Point Setting Frequency 4).  The <b>F701</b> parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %.  See <b>F190</b> and <b>F191</b> for additional information on this setting.	<b>Direct Access Number — F197</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>No</b> Minimum — 0.0 Maximum — 100.0 Units — V or % ( <b>F701</b> )

**V/f 5-Point Setting Frequency 5**

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Frequency 5** sets the frequency to be associated with the voltage setting of parameter **F199** (V/f 5-Point Setting Voltage 5).

See **F190** and **F191** for additional information on this setting.

**Direct Access Number — F198**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **No**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

**V/f 5-Point Setting Voltage 5**

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Voltage 5** establishes the output voltage level that is to be associated with the frequency setting of **F198** (V/f 5-Point Setting Frequency 5).

The **F701** parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating.

The default setting is %.

See **F190** and **F191** for additional information on this setting.

**Direct Access Number — F199**Parameter Type — **Numerical**Factory Default — **0.0**Changeable During Run — **No**

Minimum — 0.0

Maximum — 100.0

Units — V or % (**F701**)**Frequency Priority Selection**

Program ⇒ Fundamental ⇒ Standard Mode Selection

Either **Frequency Mode 1** or **Frequency Mode 2** may control the output frequency of the ASD. This parameter determines which of the two will control the output frequency and the conditions in which control will be switched from one to the other.

**Note:** *Frequency Mode is abbreviated as FMODE.*

The **Frequency Mode 1** or **Frequency Mode 2** selection specifies the source of the input frequency command signal. These selections are performed at **F004** and **F207**, respectively.


If **FMODE changed by Terminal Board** is selected here, the ASD will follow the control of the discrete input terminal assigned the function of **Frequency Priority**. The discrete terminal **Frequency Priority** will toggle control to and from **Frequency Mode 1** and **Frequency Mode 2** with each activation/deactivation.

If **FMODE (F208)** is selected here, the ASD will follow the control of the **Frequency Mode 1** setting for the duration that the commanded frequency of the **Frequency Mode 1** setting is greater than the setting of **F208**.

If the commanded frequency of the **Frequency Mode 1** setting is less than or equal to the setting of **F208** the ASD will follow the setting of **Frequency Mode 2**.

Settings:

- 0 — FMODE changed by Terminal Board (Frequency Mode)
- 1 — FMODE (**F208**) (Frequency Mode)

**Direct Access Number — F200**Parameter Type — **Selection List**Factory Default — **FMODE (changed by TB)**Changeable During Run — **Yes**

If the frequency command of Frequency Mode 1 is greater than the F208 setting, Frequency Mode 1 has priority over Frequency Mode 2.

If the frequency command of Frequency Mode 1 is equal to or less than the F208 setting, Frequency Mode 2 has priority.

## V/I Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the isolated **V/I** input terminal when the **V/I** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **V/I** input level that is associated with the **V/I Input Point 1 Frequency** setting when operating in the **Speed** control mode or is associated with the **V/I Input Point 1 Rate** setting when operating in the **Torque Control** mode.

## V/I Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **V/I** input terminal:

- Set **SW301** of the **Terminal Board** to **Voltage** or **Current** (See [Figure 9](#) on pg. 24).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **V/I**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.

## Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **V/I** input terminal:

- Set **V/I Input Point 1 Frequency** ([F202](#)).
- Set **V/I Input Point 1 Setting** ([F201](#)) — the input analog signal level that corresponds to the frequency setting at **V/I Input Point 1 Frequency**.
- Set **V/I Input Point 2 Frequency** ([F204](#)).
- Set **V/I Input Point 2 Setting** ([F203](#)) — the input analog signal level that corresponds to the frequency setting at **V/I Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **V/I** input voltage or current changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter value is entered as 0% to 100% of the **V/I** input signal range.

The **V/I** input is commonly used for a 4 – 20 mA current loop signal where 4 mA equals 20% of a 20 mA signal. Set this parameter to 20% for 4 – 20 mA current loop signal applications.

**Note:** When using the isolated **V/I** input terminal the **IICC** terminal must be used as the return (negative) connection.

**Note:** If using **P24** to power a transducer that is to be used to supply the **V/I** input signal, it may be necessary to connect **IICC** to **CCA**.

Direct Access Number — **F201**

Parameter Type — **Numerical**


Factory Default — **0**

Changeable During Run — **Yes**

Minimum — **0**

Maximum — **100**

Units — **%**



<b>V/I Input Point 1 Frequency</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the gain and bias of the <b>V/I</b> input terminal when the <b>V/I</b> terminal is used as the control input while operating in the <b>Speed Control</b> mode.  This parameter sets <b>V/I Input Point 1 Frequency</b> and is the frequency that is associated with the setting of <b>V/I Input Point 1 Setting</b> when operating in the <b>Speed Control</b> mode.  See <b>V/I Input Point 1 Setting</b> (F201) for more information on this setting.	<b>Direct Access Number — F202</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>V/I Input Point 2 Setting</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the gain and bias of the <b>V/I</b> input terminal when the <b>V/I</b> terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This parameter sets the <b>V/I</b> input level that is associated with <b>V/I Input Point 2 Frequency</b> when operating in the <b>Speed</b> control mode or is associated with the <b>V/I Input Point 1 Rate</b> when operating in the <b>Torque Control</b> mode.  This value is entered as 0% to 100% of the <b>V/I</b> input signal range.  See <b>V/I Input Point 1 Setting</b> (F201) for more information on this setting when used for <b>Speed</b> control.  See <b>V/I Input Point 1 Rate</b> (F203) for more information on this setting when used for <b>Torque Control</b> .	<b>Direct Access Number — F203</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 100 Units — %
<b>V/I Input Point 2 Frequency</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the gain and bias of the <b>V/I</b> input terminal when the <b>V/I</b> terminal is used as the control input while operating in the <b>Speed Control</b> mode.  This parameter sets <b>V/I Input Point 2 Frequency</b> and is the frequency that is associated with the setting of <b>V/I Input Point 2 Setting</b> when operating in the <b>Speed Control</b> mode.  See <b>V/I Input Point 1 Setting</b> (F201) for more information on this setting.	<b>Direct Access Number — F204</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz

## V/I Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the isolated V/I input terminal when the V/I terminal is used as the control input while operating in the **Torque Control** mode.

## V/I Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the V/I input terminal:

- Set **SW301** of the **Terminal Board** to **Voltage** or **Current** (See [Figure 9](#) on [pg. 24](#)).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **V/I**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.

## Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the V/I input terminal:

- Set **V/I Input Point 1 Rate** (**F205**).
- Set **V/I Input Point 1 Setting** (**F201**) — the input analog signal level that corresponds to the torque setting at **V/I Input Point 1 Rate**.
- Set **V/I Input Point 2 Rate** (**F206**).
- Set **V/I Input Point 2 Setting** (**F203**) — the input analog signal level that corresponds to the torque setting at **V/I Input Point 2 Rate**.
- Provide a **Run** command (**F** and/or **R**).

Torque Control is accomplished by establishing an associated V/f output pattern for a given V/I input level.

Once set, as the V/I input voltage changes or the V/I current changes, the output torque of the ASD will vary in accordance with the above settings.

This parameter sets **V/I Input Point 1 Rate** and is the output torque value that is associated with the setting of **V/I Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

**Note:** When using the isolated V/I input terminal the **IICC** terminal must be used as the return (negative) connection.

Direct Access Number — **F205**

Parameter Type — **Numerical**


Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %





**V/I Input Point 2 Rate**

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **V/I** input terminal when the **V/I** terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **V/I** input level.

This parameter sets **V/I Input Point 2 Rate** and is the output torque value that is associated with the setting of **V/I Input Point 2 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

See **V/I Input Point 1 Rate (F205)** for more information on this setting.

**Direct Access Number — F206**

Parameter Type — **Numerical**

Factory Default — **100.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %

**Frequency Mode 2**

Program ⇒ Fundamental ⇒ Standard Mode Selection

This parameter is used to set the source of the frequency command signal to be used as **Frequency Mode 2** in the event that **Frequency Mode 1** is disabled or if **Frequency Mode 2** is set up as the primary control parameter.

See [F004](#) and [F200](#) for additional information on this setting.

Settings:

- 1 — V/I
- 2 — RR
- 3 — RX
- 5 — EOI (Keypad)
- 6 — RS485
- 7 — Communication Option Board
- 8 — RX2 Option (AI1)
- 9 — Option V/I
- 10 — UP/DOWN Frequency (Terminal Board)
- 11 — Pulse Input (Option)
- 12 — Pulse Input (Motor CPU)
- 13 — Binary/BCD Input (Option)

**Direct Access Number — F207**

Parameter Type — **Selection List**

Factory Default — **V/I**

Changeable During Run — **Yes**

**Frequency Mode Priority Switching Frequency**

Program ⇒ Fundamental ⇒ Standard Mode Selection

This parameter establishes a threshold frequency that will be used as a reference when determining when to switch the output frequency control source from the **Frequency Mode 1** setting to the **Frequency Mode 2** setting.

See [F200](#) for additional information on this setting.

**Direct Access Number — F208**

Parameter Type — **Numerical**

Factory Default — **0.10**

Changeable During Run — **Yes**

Minimum — 0.10

Maximum — **Max. Freq. (F011)**

Units — Hz

---

**Analog Input Filter**

Program ⇒ Frequency ⇒ Analog Filter

Analog filtering is applied after the analog reference signal is converted to a digital signal. The type of filtering used is **Rolling Average** over time.

Settings:

- 0 — None (1 mS)
- 1 — Small (8 mS)
- 2 — Medium (16 mS)
- 3 — Large (32 mS)
- 4 — Huge (64 mS)

The analog input signal is sampled and converted to a digital signal. With no filtering applied, the resulting digital value is scaled for use by the microprocessor of the ASD.

If the filtering selection **Small** is selected, the ASD averages the last **8 mS** of sampled signal and converted (digital) values. The rolling average is updated (every 4  $\mu$ S) and scaled for use by the microprocessor.

This holds true for the **Medium**, **Large**, and **Huge** selections providing a larger sample to produce the average for use by the microprocessor.

False responses to electrical noise are eliminated with no loss in bandwidth because the value used by the ASD is the average value of several samples.

**Direct Access Number — F209**

**Parameter Type — Selection List**

**Factory Default — None**

**Changeable During Run — Yes**

### RR Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RR** input level that is associated with the **RR Input Point 1 Frequency** setting when operating in the **Speed** control mode or is associated with the **RR Input Point 1 Rate** setting when operating in the **Torque Control** mode.

### Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RR** input terminal:

- Set **RR Input Point 1 Frequency** (F211).
- Set **RR Input Point 1 Setting** (F210) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 1 Frequency**.
- Set **RR Input Point 2 Frequency** (F213).
- Set **RR Input Point 2 Setting** (F212) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 2 Frequency**.

### RR Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RR** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RR**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.
- Provide a **Run** command (F and/or R).

Once set, as the **RR** input voltage changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter value is entered as 0% to 100% of the **RR** input signal range.

Direct Access Number — F210

Parameter Type — Numerical


Factory Default — 0

Changeable During Run — Yes

Minimum — 0

Maximum — 100

Units — %



### RR Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RR Input Point 1 Frequency** and is the frequency that is associated with the setting of **RR Input Point 1 Setting** when operating in the **Speed Control** mode.

See **RR Input Point 1 Setting** (F210) for more information on this setting.

Direct Access Number — F211

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — **Max. Freq.** (F011)

Units — Hz

---

**RR Input Point 2 Setting**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RR** input level that is associated with **RR Input Point 2 Frequency** when operating in the **Speed** control mode or is associated with the **RR Input Point 1 Rate** when operating in the **Torque Control** mode.

This value is entered as 0% to 100% of the **RR** input signal range.

See **RR Input Point 1 Setting** (F210) for more information on this setting when used for **Speed** control.

See **RR Input Point 1 Rate** (F214) for more information on this setting when used for **Torque Control**.

---

**Direct Access Number — F212**Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

---

**RR Input Point 2 Frequency**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RR Input Point 2 Frequency** and is the frequency that is associated with the setting of **RR Input Point 2 Setting** when operating in the **Speed Control** mode.

See **RR Input Point 1 Setting** (F210) for more information on this setting.

---

**Direct Access Number — F213**Parameter Type — **Numerical**Factory Default — **60.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

## RR Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

### RR Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RR** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RR**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.

### Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RR** input terminal:

- Set **RR Input Point 1 Rate** (F214).
- Set **RR Input Point 1 Setting** (F210) — the input analog signal level that corresponds to the torque setting at **RR Input Point 1 Rate**.
- Set **RR Input Point 2 Rate** (F215).
- Set **RR Input Point 2 Setting** (F212) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 2 Rate**.
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RR** input level.

Once set, as the **RR** input voltage changes, the output torque of the ASD will vary in accordance with the above settings.

This parameter sets **RR Input Point 1 Rate** and is the output torque value that is associated with the setting of **RR Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

Direct Access Number — F214

Parameter Type — Numerical


Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — 250.00

Units — %



## RR Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

**Torque Control** is accomplished by establishing an associated **V/f** output pattern for a given **RR** input level.

This parameter sets **RR Input Point 2 Rate** and is the output torque value that is associated with the setting of **RR Input Point 2 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

See **RR Input Point 1 Rate** (F214) for more information on this setting.

Direct Access Number — F215

Parameter Type — Numerical

Factory Default — 100.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — 250.00

Units — %

## RX Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RX** input level that is associated with **RX Input Point 1 Frequency** when operating in the **Speed Control** mode or is associated with the **RX Input Point 1 Rate** when operating in the **Torque Control** mode.

## RX Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RX** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RX**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.

## Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RX** input terminal:

- Set **RX Input Point 1 Frequency** (F217).
- Set **RX Input Point 1 Setting** (F216) — the input analog signal level that corresponds to the speed setting at **RX Input Point 1 Frequency**.
- Set **RX Input Point 2 Frequency** (F219).
- Set **RX Input Point 2 Setting** (F218) — the input analog signal level that corresponds to the speed setting at **RX Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **RX** input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter value is entered as -100% to +100% of the **RX** input signal range.

See parameter F474 and F475 for information on fine-tuning this terminal response.

Direct Access Number — F216

Parameter Type — Numerical


Factory Default — 0

Changeable During Run — Yes

Minimum — -100

Maximum — +100

Units — %



## RX Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RX Input Point 1 Frequency** and is the frequency that is associated with the setting of **RX Input Point 1 Setting** when operating in the **Speed Control** mode.

See **RX Input Point 1 Setting** (F216) for more information on this setting.

Direct Access Number — F217

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

---

**RX Input Point 2 Setting**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RX** input level that is associated with **RX Input Point 2 Frequency** when operating in the **Speed** control mode or is associated with the **RX Input Point 2 Rate** when operating in the **Torque Control** mode.

This value is entered as -100% to +100% of the **RX** input signal range.

See **RX Input Point 1 Setting** (F216) for more information on this setting when used for **Speed** control.

See **RX Input Point 1 Rate** (F220) for more information on this setting when used for **Torque Control**.

---

**Direct Access Number — F218**Parameter Type — **Numerical**Factory Default — **+100**Changeable During Run — **Yes**

Minimum — -100.0

Maximum — +100.0

Units — %

---

**RX Input Point 2 Frequency**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RX Input Point 2 Frequency** and is the frequency that is associated with the setting of **RX Input Point 2 Setting** when operating in the **Speed Control** mode.

See **RX Input Point 1 Setting** (F216) for more information on this setting.

---

**Direct Access Number — F219**Parameter Type — **Numerical**Factory Default — **60.00**Changeable During Run — **Yes**

Minimum — 0.00.

Maximum — **Max. Freq.** (F011)

Units — Hz

## RX Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

## RX Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RX** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RX**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.

## Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RX** input terminal:

- Set **RX Input Point 1 Rate** (F220).
- Set **RX Input Point 1 Setting** (F216) — the input analog signal level that corresponds to the torque setting at **RX Input Point 1 Rate**.
- Set **RX Input Point 2 Rate** (F221).
- Set **RX Input Point 2 Setting** (F218) — the input analog signal level that corresponds to the speed setting at **RX Input Point 2 Rate**.
- Provide a **Run** command (F and/or R).

**Torque Control** is accomplished by establishing an associated **V/f** output pattern for a given **RX** input level.

Once set, as the **RX** input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter sets **RX Input Point 1 Rate** and is the output torque value that is associated with the setting of **RX Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

Direct Access Number — F220

Parameter Type — Numerical


Factory Default — 0.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %



## RX Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

**Torque Control** is accomplished by establishing an associated **V/f** output pattern for a given **RX** input level.

This parameter sets **RX Input Point 2 Rate** and is the output torque value that is associated with the setting of **RX Input Point 2 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See **RX Input Point 1 Rate** (F220) for more information on this setting.

Direct Access Number — F221

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %



## RX2 (AI1) Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

**Note:** The *Expansion IO Card Option 1* option board (P/N ETB003Z) is required to use this terminal.

This parameter sets the **RX2** (AI1) input level that is associated with **RX2** (AI1) **Input Point 1 Frequency** when operating in the **Speed Control** mode or is associated with the **RX2** (AI1) **Input Point 1 Rate** when operating in the **Torque Control** mode.

## RX2 (AI1) Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RX2** (AI1) input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RX2**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.

## Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RX2** (AI1) input terminal:

- Set **RX2** (AI1) **Input Point 1 Frequency** (F223).
- Set **RX2** (AI1) **Input Point 1 Setting** (F222) — the input analog signal level that corresponds to the speed setting at **RX2** (AI1) **Input Point 1 Frequency**.
- Set **RX2** (AI1) **Input Point 2 Frequency** (F225).
- Set **RX2** (AI1) **Input Point 2 Setting** (F224) — the input analog signal level that corresponds to the speed setting at **RX** **Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **RX2** (AI1) input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter value is entered as -100% to +100% of the **RX2** (AI1) input signal range.

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal. See parameter F476 and F477 for information on fine-tuning this terminal response.

Direct Access Number — F222

Parameter Type — Numerical


Factory Default — 0

Changeable During Run — Yes

Minimum — -100

Maximum — +100

Units — %



<b>RX2 (AI1) Input Point 1 Frequency</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the gain and bias of the <b>RX2</b> (AI1) input terminal when the <b>RX2</b> (AI1) terminal is used as the control input while operating in the <b>Speed Control</b> mode.  This parameter sets <b>RX2 (AI1) Input Point 1 Frequency</b> and is the frequency that is associated with the setting of <b>RX2 (AI1) Input Point 1 Setting</b> when operating in the <b>Speed Control</b> mode.  See <b>RX2 (AI1) Input Point 1 Setting</b> (F222) for more information on this setting.	<b>Direct Access Number — F223</b> <b>Parameter Type — Numerical</b> <b>Factory Default — 0.00</b> <b>Changeable During Run — Yes</b> <b>Minimum — 0.00</b> <b>Maximum — Max. Freq. (F011)</b> <b>Units — Hz</b>
<b>RX2 (AI1) Input Point 2 Setting</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the gain and bias of the <b>RX2</b> (AI1) input terminal when the <b>RX2</b> (AI1) terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This parameter sets the <b>RX2 (AI1) input level</b> that is associated with <b>RX2 (AI1) Input Point 2 Frequency</b> when operating in the <b>Speed</b> control mode or is associated with the <b>RX2 (AI1) Input Point 2 Rate</b> when operating in the <b>Torque Control</b> mode.  This value is entered as -100% to +100% of the <b>RX2 (AI1) input signal range</b> .  See <b>RX2 (AI1) Input Point 1 Setting</b> (F222) for more information on this setting when used for <b>Speed</b> control.  See <b>RX2 (AI1) Input Point 1 Rate</b> (F226) for more information on this setting when used for <b>Torque Control</b> .	<b>Direct Access Number — F224</b> <b>Parameter Type — Numerical</b> <b>Factory Default — +100</b> <b>Changeable During Run — Yes</b> <b>Minimum — -100</b> <b>Maximum — +100</b> <b>Units — %</b>
<b>RX2 (AI1) Input Point 2 Frequency</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the gain and bias of the <b>RX2</b> (AI1) input terminal when the <b>RX2</b> (AI1) terminal is used as the control input while operating in the <b>Speed Control</b> mode.  This parameter sets <b>RX2 (AI1) Input Point 2 Frequency</b> and is the frequency that is associated with the setting of <b>RX2 (AI1) Input Point 2 Setting</b> when operating in the <b>Speed Control</b> mode.  See <b>RX2 (AI1) Input Point 1 Setting</b> (F222) for more information on this setting.	<b>Direct Access Number — F225</b> <b>Parameter Type — Numerical</b> <b>Factory Default — 60.00</b> <b>Changeable During Run — Yes</b> <b>Minimum — 0.00</b> <b>Maximum — Max. Freq. (F011)</b> <b>Units — Hz</b>

**RX2 (AI1) Input Point 1 Rate**

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Torque Control** mode.

**Note:** The *Expansion IO Card Option 1* option board (P/N ETB003Z) is required to use this terminal.

Direct Access Number — F226

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %

**RX2 (AI1) Input Torque Control Setup**

Perform the following setup to allow the system to receive **Torque Control** input at the **RX2** (AI1) input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RX2**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.
- Provide a **Run** command (F and/or R).

**Torque Control**

Perform the following setup to allow the system to perform **Torque Control** from the **RX2** (AI1) input terminal:

- Set **RX2** (AI1) **Input Point 1 Rate** (F226).
- Set **RX2** (AI1) **Input Point 1 Setting** (F222) — the input analog signal level that corresponds to the speed setting at **RX2** (AI1) **Input Point 1 Rate**.
- Set **RX2** (AI1) **Input Point 2 Rate** (F227).
- Set **RX2** (AI1) **Input Point 2 Setting** (F224) — the input analog signal level that corresponds to the speed setting at **RX** **Input Point 2 Rate**.
- Provide a **Run** command (F and/or R).


**Torque Control** is accomplished by establishing an associated **V/f** output pattern for a given **RX2** (AI1) input level.

Once set, as the **RX2** (AI1) input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter sets **RX2** (AI1) **Input Point 1 Rate** and is the output torque value that is associated with the setting of **RX2** (AI1) **Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See the **Expansion IO Card Option 1** instruction manual (P/N 58685) for more information on the function of this terminal.



**RX2 (AI1) Input Point 2 Rate**

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Torque Control** mode.

**Torque Control** is accomplished by establishing an associated **V/f** output pattern for a given **RX2** (AI1) input level.

This parameter sets **RX2** (AI1) **Input Point 2 Rate** and is the output torque value that is associated with the setting of **RX2** (AI1) **Input Point 2 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See **RX2** (AI1) **Input Point 1 Rate** (F226) for more information on this setting.

**Direct Access Number — F227**

**Parameter Type — Numerical**

**Factory Default — 100.00**

**Changeable During Run — Yes**

**Minimum — -250.00**

**Maximum — +250.00**

**Units — %**

## BIN Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **BIN** input terminals when the **BIN** terminals are used as the control input while operating in the **Speed Control** mode.

The discrete input terminals of the **Terminal Board** are used as the **BIN** terminals.

## BIN Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **BIN** input terminals:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **Binary/BCD**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Block**.
- Program ⇒ Terminal ⇒ **Input Terminals**; select and set the desired discrete input terminals to **Binary Bit(s) 0 – 7** (or 0 – MSB). The binary input byte will control the speed of the motor.
- Program ⇒ Terminal ⇒ **Input Terminals**; select and set a discrete input terminal to **Binary Data Write**. Activation of the **Binary Data Write** terminal will transfer the status of the **Binary Bit(s) 0 – 7** (or 0 – MSB) to the control board for speed control.

## Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **BIN** input terminals:

- Set **BIN Input Point 1 Frequency** (F229).
- Set the **BIN** input value (% of 255<sub>D</sub>) (F228) that represents **BIN Input Point 1 Frequency**.
- Set **BIN Input Point 2 Frequency** (F231).
- Set the **BIN** input value (% of 255<sub>D</sub>) (F230) that represents **BIN Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

**Note:** 255<sub>D</sub> is the decimal equivalent of the 8-bit **BIN** byte with all input terminals set to 1 (255 decimal = 11111111 binary).

Once set, as the **BIN** input signal changes are transferred to the control board, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **BIN Input Point 1 Setting** and is entered as 0% to 100% of the of the range represented by the **BIN** binary input byte 11111111 (255<sub>D</sub>) or the binary bit(s) 0 – MSB.

Direct Access Number — F228

Parameter Type — Numerical


Factory Default — 0

Changeable During Run — Yes

Minimum — 0

Maximum — 100

Units — %



**BIN Input Point 1 Frequency**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **BIN** input terminals when the **BIN** terminals are used as the control input.

This parameter sets **BIN Input Point 1 Frequency** and is the frequency that is associated with the setting of **BIN Input Point 1 Setting**.

See **BIN Input Point 1 Setting (F228)** for further information on this setting.

**Direct Access Number — F229**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0

Maximum — **Max. Freq. (F011)**

Units — Hz

**BIN Input Point 2 Setting**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **BIN** input terminals when the **BIN** terminals are used as the control input.

This parameter sets the **BIN** input signal that is associated with **BIN Input Point 2 Frequency**.

This value is entered as 0% to +100% of the **BIN** input signal range.

See **BIN Input Point 1 Setting (F228)** for further information on this setting.

**Direct Access Number — F230**

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

**BIN Input Point 2 Frequency**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **BIN** input terminals when the **BIN** terminal are used as the control input.

This parameter sets **BIN Input Point 2 Frequency** and is the frequency that is associated with the setting of **BIN Input Point 2 Setting**.

See **BIN Input Point 1 Setting (F228)** for further information on this setting.

**Direct Access Number — F231**

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Maximum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

## PG Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **PG** input terminal of the option board when a shaft-mounted encoder is used as the control input while operating in the **Speed Control** mode.

**Note:** See Instruction Manual P/N 58687 for more information on the **PG Option Board**.

## PG Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **PG** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **Pulse Input** (option).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Command Mode Selection** ⇒ (any setting).
- Provide a **Run** command (F and/or R).

## Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **PG** input terminals:

- Set **PG Point 1 Frequency** (F235).
- Set the **PG** input value (F234) that represents **PG Point 1 Frequency**.
- Set **PG Point 2 Frequency** (F237).
- Set the **PG** input value (F236) that represents **PG Point 2 Frequency**.

Once set, as the **PG** input pulse count rate changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets the **PG** input pulse count that represents **Reference Setpoint 1** (frequency). The range of values for this parameter is 0% to 100% of the **PG** input pulse count range.

**Note:** Further application-specific **PG** settings may be performed from the following path: Program ⇒ Feedback ⇒ **PG Settings**.

Direct Access Number — F234

Parameter Type — Numerical


Factory Default — 0.0

Changeable During Run — Yes

Minimum — 0

Maximum — 100.0

Units — %



## PG Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **PG** input terminals when the **PG** terminal is used as the control input.

This parameter sets **PG Point 1 Frequency** and is the frequency that is associated with the setting of **PG Point 1 Setting**.

See **PG Point 1 Setting** (F234) for further information on this setting.

Direct Access Number — F235

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

<b>PG Input Point 2 Setting</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the direction and speed of the <b>PG</b> input terminals when the <b>PG</b> terminals are used as the control input. This parameter sets the <b>PG</b> input signal that is associated with <b>PG Point 2 Frequency</b> . This value is entered as 0% to 100% of the <b>PG</b> input signal range. See <b>PG Point 1 Setting (F234)</b> for further information on this setting.	<b>Direct Access Number — F236</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 100 Units — %
<b>PG Input Point 2 Frequency</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to set the direction and speed of the <b>PG</b> input terminals when the <b>PG</b> terminal are used as the control input. This parameter sets <b>PG Point 2 Frequency</b> and is the frequency that is associated with the setting of <b>PG Point 2 Setting</b> . See <b>PG Point 1 Setting (F234)</b> for further information on this setting.	<b>Direct Access Number — F237</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>Start Frequency</b> Program ⇒ Special ⇒ Frequency Control  The output of the ASD will remain at 0.0 Hz until the programmed speed value exceeds this setting during startup. Once exceeded during startup, the output frequency of the ASD will accelerate to the programmed setting. Output frequencies below the <b>Start Frequency</b> will not be output from the ASD during startup. However, once reaching the <b>Start Frequency</b> , speed values below the <b>Start Frequency</b> may be output from the ASD. If the setting of this parameter results in an over-current condition at startup, reduce the setting of this parameter to a value less than the rated slippage of the motor. If zero-speed torque is required, set this parameter and <a href="#">F243</a> to 0.0 Hz. This setting will override the setting of <a href="#">F244</a> if this setting has a higher value. This parameter setting is used during a <b>Jog</b> as the <b>Lower-Limit Frequency</b> (See <a href="#">F260</a> ).	<b>Direct Access Number — F240</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.10</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 10.00 Units — Hz
<b>Run Frequency</b> Program ⇒ Special ⇒ Frequency Control  This parameter establishes a center frequency ( <b>Run Frequency</b> ) of a frequency band. Parameter <a href="#">F242</a> provides a plus-or-minus value for the <b>Run Frequency</b> ; thus, establishing a frequency band. During acceleration, the ASD will not output a signal to the motor until the lower level of the band is reached. During deceleration, the ASD will continue to output the programmed deceleration signal to the motor until the lower level of the band is reached; at which time the output will go to 0.0 Hz.	<b>Direct Access Number — F241</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz



<b>Run Frequency Hysteresis</b> Program ⇒ Special ⇒ Frequency Control  This parameter provides a plus-or-minus value for the <b>Run Frequency</b> setting (F241).	<b>Direct Access Number — F242</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 30.0 Units — Hz
<b>End Frequency</b> Program ⇒ Special ⇒ Frequency Control  This parameter sets the lowest frequency that the ASD will recognize during deceleration before the ASD goes to 0.0 Hz.	<b>Direct Access Number — F243</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 30.0 Units — Hz
<b>0 Hz Dead Band Signal</b> Program ⇒ Special ⇒ Special Parameters  This parameter sets an output frequency threshold that, until the commanded frequency surpasses this setting, the ASD will output 0.0 Hz to the motor. This setting will override the <b>Start Frequency</b> setting (F240) if this setting has a higher value.	<b>Direct Access Number — F244</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 5.00 Units — Hz
<b>DC Injection Braking Start Frequency</b> Program ⇒ Protection ⇒ DC Braking During deceleration this is the frequency at which <b>DC Injection Braking</b> will start.  <b>DC Injection Braking</b> <b>DC Injection Braking</b> is a braking system used with 3-phase motors. Unlike conventional brakes, there is no physical contact between the rotating shaft and a stationary brake pad or drum. When braking is required, the ASD outputs a DC current that is applied to the windings of the motor to quickly brake the motor. The braking current stops when the time entered in F252 times out. The intensity of the DC current used while braking determines how fast the motor will come to a stop and may be set at F251. The intensity setting is entered as a percentage of the full load current of the ASD. <b>DC Injection Braking</b> is also used to preheat the motor or to keep the rotor from spinning freely when the motor is off by providing a pulsating DC current into the motor at the <b>Carrier Frequency</b> . This feature may be enabled at F254.	<b>Direct Access Number — F250</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 120.00 Units — Hz
<b>DC Injection Braking Current</b> Program ⇒ Protection ⇒ DC Braking  This parameter sets the percentage of the rated current of the ASD that will be used for <b>DC Injection Braking</b> . A larger load will require a higher setting.	<b>Direct Access Number — F251</b> Parameter Type — <b>Numerical</b> Factory Default — <b>50</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 100 Units — %

<b>DC Injection Braking Time</b> Program ⇒ Protection ⇒ DC Braking  This parameter setting is used to set the on-time duration of the <b>DC Injection Braking</b> .	<b>Direct Access Number — F252</b> Parameter Type — <b>Numerical</b> Factory Default — <b>1.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 20.0 Units — Seconds
<b>Forward/Reverse DC Injection Braking Priority</b> Program ⇒ Protection ⇒ DC Braking  This parameter setting determines if <b>DC Injection Braking</b> is to be used during a change in the direction of the motor.  Settings: 0 — Disabled 1 — Enabled	<b>Direct Access Number — F253</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>
<b>Motor Shaft Fixing Control</b> Program ⇒ Protection ⇒ DC Braking  This parameter <b>Enables/Disables</b> a continuous DC injection at half of the amperage setting of <a href="#">F251</a> into a stopped motor. This feature is useful in preheating the motor or to keep the rotor from spinning freely.  <b>Motor Shaft Stationary Control</b> starts after the DC injection brake stops the motor and continues until <b>ST – CC</b> is opened, power is turned off, an <b>Emergency Off</b> command is received, or this parameter is changed.  Enabling this feature will also require a non-zero entry at <a href="#">F250</a> .  Settings: 0 — Disabled 1 — Enabled	<b>Direct Access Number — F254</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>
<b>0 Hz Command Output</b> Program ⇒ Special ⇒ Special Parameters  This parameter is used to set the go-to-zero method to be used by the ASD in the event that the ASD is commanded to go to zero Hz.  Settings: 0 — Standard (DC Injection Braking) 1 — 0 Hz Command	<b>Direct Access Number — F255</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Standard (DC Injection Braking)</b> Changeable During Run — <b>No</b>
<b>Time Limit For Lower-Limit Frequency Operation</b> Program ⇒ Fundamental ⇒ Frequency Settings  This parameter sets the time that the ASD is allowed to operate below the <b>Lower-Limit</b> setting before an alarm and subsequent fault is incurred.	<b>Direct Access Number — F256</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 600.0 Units — Seconds

---

## Jog Run Frequency

Program ⇒ Frequency ⇒ **Jog Settings**

This parameter sets the output frequency of the ASD during a **Jog. Jogging** is the term used to describe turning on the motor for small increments of time and is used when precise positioning of motor-driven equipment is required.

The **Jog** function is initiated via the **Terminal Board** or using **Communications** (See the **Communications** manual-P/N 53840 for further information on using **Communications** for **Jogging**).

To perform a **Jog**, set this parameter (F260) to the desired **Jog** frequency.

Select a **Jog Stop** method (F261).

## Jog Run Using the Terminal Board

To initiate a **Jog** from the **Terminal Board** perform the following:

1. Assign an unused discrete input terminal to the **Jog** setting.
2. Assign a discrete input terminal to the **F** (Forward) function (and Reverse if required) (See [Table 6 on pg. 249](#)).
3. Provide a **Forward** (and/or **Reverse**) command from the **Terminal Board**.
4. Place the system in the **Auto** mode (Hand/Auto LED is off).
5. Activate the **Jog** terminal of [Step 1](#).

The system will run at the [F260](#) speed for the duration of the terminal activation and will stop using the [F261](#) method upon terminal deactivation.

---

## Jog Stop Pattern

Program ⇒ Frequency ⇒ Jog Settings

This parameter sets the stopping method used while operating in the **Jog** mode.

**Note:** *This parameter setting is used for the **Jog** operation only. The **Emergency Off** stopping method setting of parameter [F603](#) has priority over this setting and changes made here do not affect the function or setting of parameter [F603](#).*

Settings:

- 0 — Deceleration Stop
- 1 — Coast Stop
- 2 — DC Injection Braking Stop

---

**Direct Access Number — F260**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 20.0

Units — Hz

---

**Direct Access Number — F261**

Parameter Type — **Selection List**

Factory Default — **Deceleration Stop**

Changeable During Run — **Yes**

---

**EOI (Panel) Operation Jog Mode**

Program ⇒ Frequency ⇒ Jog Settings

This parameter enables the **Jog** command to be received from the **EOI**. When disabled the **Jog** command received from the **EOI** is ignored.

**Jog** commands may also be received from the **Terminal Board**. Priority as to which is allowed to override the other is selected at [F106](#).

The priority selection at [F106](#) enables the selected source for **Jog** control and disables the other. The [F106](#) setting overrides the [F262](#) parameter setting.

Settings:

- 0 — Disabled
- 1 — Enabled

**Direct Access Number — F262**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

## UP/DOWN Frequency (up) Response Time

No Path — Direct Access Only

This parameter functions in conjunction with the parameter settings of [F265](#), [F266](#), [F267](#), [F268](#), and [F269](#). The purpose of these settings is to set up the ASD to allow an externally-supplied discrete input signal to control the output frequency of the ASD.

This method uses the discrete input terminal settings **UP/DOWN Frequency (up)** and **UP/DOWN Frequency (down)** to change the ASD speed. Activation of either terminal increases or decreases the output frequency at the **Accel 1** or **Decel 1** rates, respectively.

Depending on the **Delay** setting, the **UP/DOWN Frequency (up/down)** terminal may perform **1)** the increase/decrease function for the duration of activation or **2)** the **UP/DOWN Frequency (up/down)** terminal may act as a momentary contact that loads a new commanded frequency upon activation.

In either case, to activate-and-hold will continue the up or down function until reaching the **Upper-Limit Frequency** or the **Lower-Limit Frequency**, respectively. At which point further activation will be ignored.

See [Figure 36](#) on pg. 135 for more information on the **UP/DOWN Frequency** function.

## Setup Requirements

[F003](#) — Selects the **Command** control source; set to **Terminal Block**.

[F004](#) — Selects the **Frequency Control Mode 1** control source; set to **UP/DOWN Frequency**.

[F207](#) — Selects the **Frequency Control Mode 2** control source; set to **UP/DOWN Frequency** if used.

Set one unused discrete input terminal to **UP/DOWN Frequency (up)** and one unused discrete input terminal to **UP/DOWN Frequency (down)**.

[F264](#) — Sets the system-response delay to the initial activation of the discrete input terminal **UP/DOWN Frequency (up)**. Also sets the response delay of subsequent terminal activations of the **UP/DOWN Frequency (up)** terminal during an activate-and-hold.

[F265](#) — Sets the frequency increase amount for each activation of the **UP/DOWN Frequency (up)** terminal activation. The rate of the frequency increase is set at **Acceleration Time 1** ([F009](#)).

[F266](#) — Sets the system-response delay to the initial activation of the discrete input terminal **UP/DOWN Frequency (down)**. Also sets the activation delay of subsequent terminal activations of the **UP/DOWN Frequency (down)** terminal during an activate-and-hold.

[F267](#) — Sets the frequency decrease amount for each activation of the **UP/DOWN Frequency (down)** terminal activation. The rate of the frequency decrease is set at **Deceleration Time 1** ([F010](#)).

[F268](#) — At power up or after a reset, this parameter setting is used to provide a starting frequency for the **UP/DOWN Frequency** function.

[F269](#) — At power down while running, and when enabled, this parameter writes the running frequency into the [F268](#) location and, upon a system restart, uses this setting as the startup frequency.

Provide a **Run** command (F or R). The motor will run at the [F268](#) setting.

Direct Access Number — **F264**

Parameter Type — **Numerical**

Factory Default — **0.1**


Changeable During Run — **Yes**

Minimum — 0.0


Maximum — 10.0

Units — Seconds

### Up/Down Frequency (up) Mode




### Up/Down Frequency (down) Mode



<b>UP/DOWN Frequency (up) Frequency Step</b> No Path — Direct Access Only  This parameter sets the frequency increase amount for each activation of the <b>UP/DOWN Frequency (up)</b> terminal activation. The rate of the frequency increase is set at Acceleration Time 1 (F009).  See F264 for more information on this parameter.	<b>Direct Access Number — F265</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.10</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>UP/DOWN Frequency (down) Response Time</b> No Path — Direct Access Only  This parameter sets the system-response delay to the initial activation of the discrete input terminal <b>UP/DOWN Frequency (down)</b> . Also sets the activation delay of subsequent terminal activations of the <b>UP/DOWN Frequency (down)</b> terminal during an activate-and-hold.  See F264 for more information on this parameter.	<b>Direct Access Number — F266</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.1</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 10.0 Units — Seconds
<b>UP/DOWN Frequency (down) Frequency Step</b> No Path — Direct Access Only  This parameter sets the frequency decrease amount for each activation of the <b>UP/DOWN Frequency (down)</b> terminal activation. The rate of the frequency decrease is set at Deceleration Time 1 (F010).  See F264 for more information on this parameter.	<b>Direct Access Number — F267</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.10</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>Initial UP/DOWN Frequency</b> No Path — Direct Access Only  At power up or after a reset, this parameter setting is used to provide a starting frequency for the <b>UP/DOWN Frequency</b> function.  See F269 for more information on this parameter setting.	<b>Direct Access Number — F268</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Initial UP/DOWN Frequency Rewriting</b> No Path — Direct Access Only  At power down, and when enabled, this parameter writes the running frequency into the F268 location and, upon a system restart, uses this setting as the startup frequency.  Disable this parameter and set parameter F268 to the desired startup frequency if the same starting frequency is required at each startup.  <b>Note:</b> <i>This parameter setting may be different at each startup when enabled.</i>  Settings: 0 — Disabled 1 — Enabled (overwrite F268 at Power Off or Reset)	<b>Direct Access Number — F269</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Enabled</b> Changeable During Run — <b>Yes</b>

Figure 36. UP/Down Frequency Operation Control Timing Diagram.



### Jump Frequency 1

Program ⇒ Special ⇒ Jump Frequencies

In conjunction with parameter [F271](#), this parameter establishes a user-defined frequency range: the **Jump Frequency** and a plus-or-minus value.

During acceleration, the output frequency of the ASD will hold at the lower level of the **Jump Frequency** range until the programmed acceleration ramp reaches the upper level of the **Jump Frequency** range. At which time the output frequency of the ASD will accelerate to the upper level of the **Jump Frequency** range and continue upward as programmed.

During deceleration, the output frequency of the ASD will hold at the upper level of the **Jump Frequency** range until the programmed deceleration ramp reaches the lower level of the **Jump Frequency** range. At which time the output frequency of the ASD will decelerate to the lower level of the **Jump Frequency** range and continue downward as programmed.

Once set up and enabled, it is on in all control modes.

User-selected frequencies may be jumped to avoid the negative effects of mechanical resonance.

**Direct Access Number — F270**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

<b>Jump Frequency 1 Bandwidth</b> Program ⇒ Special ⇒ Jump Frequencies  This parameter establishes a plus-or-minus value for <b>Jump Frequency 1</b> (See <a href="#">F270</a> ).	<b>Direct Access Number — F271</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 30.00 Units — Hz
<b>Jump Frequency 2</b> Program ⇒ Special ⇒ Jump Frequencies  Same as <b>Jump Frequency 1</b> ( <a href="#">F270</a> ) and is used when multiple frequencies are to be jumped (See the plus-or-minus value setting at <a href="#">F273</a> ). When multiple jump frequencies overlap, the system will recognize the lowest and the highest frequencies as one jump range.	<b>Direct Access Number — F272</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>Jump Frequency 2 Bandwidth</b> Program ⇒ Special ⇒ Jump Frequencies  This parameter establishes a plus-or-minus value for <b>Jump Frequency 2</b> ( <a href="#">F272</a> ).	<b>Direct Access Number — F273</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 30.0 Units — Hz
<b>Jump Frequency 3</b> Program ⇒ Special ⇒ Jump Frequencies  Same as <b>Jump Frequency 1</b> ( <a href="#">F270</a> ) and is used when multiple frequencies are to be jumped (See the plus-or-minus value setting at <a href="#">F275</a> ).  When multiple jump frequencies overlap, the system will recognize the lowest and the highest frequencies as one jump range.	<b>Direct Access Number — F274</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>Jump Frequency 3 Bandwidth</b> Program ⇒ Special ⇒ Jump Frequencies  This parameter establishes a plus-or-minus value for <b>Jump Frequency 3</b> ( <a href="#">F274</a> ).	<b>Direct Access Number — F275</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 30.0 Units — Hz
<b>Preset Speed 8</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 1000 and is identified as <b>Preset Speed 8</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F287</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz



<b>Preset Speed 9</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 1001 and is identified as <b>Preset Speed 9</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F288</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 10</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 1010 and is identified as <b>Preset Speed 10</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F289</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 11</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 1011 and is identified as <b>Preset Speed 11</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F290</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 12</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 1100 and is identified as <b>Preset Speed 12</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F291</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 13</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 1101 and is identified as <b>Preset Speed 13</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F292</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Preset Speed 14</b> Program ⇒ Frequency ⇒ Preset Speeds  This parameter assigns an output frequency to binary number 1110 and is identified as <b>Preset Speed 14</b> . The binary number is applied to <b>S1 – S4</b> of the <b>Terminal Board</b> to output the <b>Preset Speed</b> (See <a href="#">F018</a> for more information on this parameter).	<b>Direct Access Number — F293</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz

**Preset Speed 15**

Program ⇒ Frequency ⇒ Preset Speeds

This parameter assigns an output frequency to binary number 1111 and is identified as **Preset Speed 15**. The binary number is applied to **S1 – S4** of the **Terminal Board** to output the **Preset Speed** (See [F018](#) for more information on this parameter).

**Direct Access Number — F294**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**Minimum — **Lower-Limit (F013)**Maximum — **Upper-Limit (F012)**

Units — Hz

**PWM Carrier Frequency**

Program ⇒ Special ⇒ Carrier Frequency

This parameter sets the frequency of the pulse width modulation signal applied to the motor.

**Note:** When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.

**Note:** If the PWM carrier frequency is set at 2.0 kHz or above, it cannot be decreased below 2.0 kHz while running. If the PWM carrier frequency is set at 1.9 kHz or below, it cannot be increased above 2.0 kHz while running. Either change requires that the ASD be stopped and restarted for the changes to take effect.

**Direct Access Number — F300**Parameter Type — **Numerical**Factory Default — **2.200**Changeable During Run — **No**

Minimum — 1.0

Maximum — **(ASD-Dependent)**

Units — kHz

**Auto Restart Selection**

Program ⇒ Protection ⇒ Retry/Restart

This parameter **Enables/Disables** the ability of the ASD to start into a spinning motor when the **ST – CC** connection opens momentarily and is then closed (Break/Make ST) or after a power interruption (momentary power failure).

Settings:

- 0 — Off
- 1 — Enabled (at Power Failure)
- 2 — Enabled (at Make-Break ST-CC)
- 3 — Enabled (at Make-Break ST-CC or Power Failure)
- 4 — Enabled (at Run)

**Direct Access Number — F301**Parameter Type — **Selection List**Factory Default — **Off**Changeable During Run — **No**

## Regenerative Power Ridethrough Mode

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

This parameter determines the motor control response of the ASD in the event of a momentary power outage or under-voltage condition.

During a **Ridethrough**, regenerative energy is used to maintain the control circuitry settings for the duration of the **Ridethrough**; it is not used to drive the motor. The motor(s) of the system are stopped and then restarted automatically if so configured.

In a multiple-motor application, there will be a requirement to synchronize the stopping and restarting of the motors as not to cause breakage in the product being processed by the motors stopping/starting at different times (e.g., wire spools, bobbin winder for textile machines, etc.). Parameters [F317](#) and [F318](#) must be set up to synchronize motor operation as to avoid breakage in these types of applications.

**Note:** If used to restart the motors, the Retry setup of [F301](#) is required.

**Note:** The **Jog** function will not operate while in the **Synchronized Decel/Accel** mode.

Settings:

- 0 — Off
- 1 — Ridethrough On
- 2 — Decel Stop
- 3 — Synchronized ACC/DEC (TB)
- 4 — Synchronized ACC/DEC (TB + Power Off)

## Ridethrough Setup Requirements

1. Select the **Ridethrough Mode** at [F302](#).
2. Select the **Ridethrough Time** at [F310](#).
3. Select the **Synchronized Stop/Start Times** at [F317/F318](#) (if required).

**Note:** [F317](#) and [F318](#) are not functional while operating in the **Torque** or **Position** control modes, or for the **Jog Run** function ([F260](#)).

4. Set a discrete input terminal to **Power Failure Synchronized Signal** and activate the terminal to enable the **Synchronized Accel/Decel** function.
5. Select the **Ridethrough Control Level** at [F629](#).

Direct Access Number — **F302**

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **Yes**

## Retry Selection

Program ⇒ Protection ⇒ Retry/Restart

After a trip has occurred, this parameter sets the number of times that an automatic system restart is attempted for a qualified trip.

The trip conditions listed below will **NOT** initiate the automatic **Retry/Restart** function:

- Input Phase Loss (Input Phase Failure)
- Output Phase Loss (Output Phase Failure)
- Output Current Protection Fault
- Output Current Detector Error
- Load Side Over-Current at Start
- Earth Fault (Ground Fault)
- Over-Current During Acceleration
- Arm Over-Current at Start-Up
- DBR Resistor Over-Current
- Low-Current
- Voltage Drop In Main Circuit
- EEPROM Data Fault (EEPROM Fault)
- Flash Memory/Gate Array/RAM-ROM Fault
- CPU Fault
- Emergency Off (EMG)
- Communication Error
- Option Fault
- Sink/Source Setting Error
- Over-Speed Error
- Over-Torque
- Key Error
- External Thermal Error
- Externally-Controlled Interrupt

See the section titled [System Setup Requirements on pg. 8](#) for more information on this setting.

**Direct Access Number — F303**

Parameter Type — **Numerical**

Factory Default — **00**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 10

---

## Dynamic Braking Selection

Program ⇒ Protection ⇒ Dynamic Braking

This parameter **Enables/Disables** the **Dynamic Braking** system.

Settings:

- 0 — Off
- 1 — On with Overload Detection
- 2 — On without Overload Detection

**Dynamic Braking** uses the transistor **IGBT7** to dissipate the bus voltage when required.

**IGBT7** is a standard item on the 25 HP and below P9 ASD 230-volt systems and is standard on the 400 HP and below for the 460-volt systems.

**IGBT7** is optional for all remaining systems.

## Dynamic Braking

**Dynamic Braking** is used to prevent over-voltage faults during rapid deceleration or constant speed run on cyclic overhauling applications.

Dynamic Braking dissipates regenerated energy in the form of heat. When using a DBR use thermal protection.

The resistive load is connected across terminals **PA** and **PB** (non-polarized). Using a low-value, high-wattage resistance as a load for the generated current, the resistive load dissipates the induced energy.

**Dynamic Braking** helps to slow the load quickly; it cannot act as a holding brake.

The **Dynamic Braking** function may be set up and enabled by connecting a braking resistor from terminal **PA** to **PB** of the ASD and providing the proper information at [F304](#), [F308](#), and [F309](#).

See the section titled [Dynamic Braking Protection on pg. 283](#) for more information on using the DBR system and for assistance in selecting the appropriate resistor for a given application.

Direct Access Number — **F304**

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

---

## Over-Voltage Limit Operation

Program ⇒ Protection ⇒ Stall

This parameter enables the **Over-Voltage Limit** function. This feature is used to set the upper DC bus voltage threshold that, once exceeded, will cause an **Over-Voltage Stall**.

An **Over-Voltage Stall** increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an **Over-Voltage Trip**.

If the over-voltage threshold level setting of parameter [F626](#) is exceeded for over 4 mS, an **Over-Voltage Trip** will be incurred.

Parameter [F452](#) (Power Running Stall Continuous Trip Detection Time) setting may affect the performance of this parameter setting.

**Note:** *This parameter setting may increase deceleration times.*

Settings:

- 0 — Enabled (Over-voltage Stall)
- 1 — Disabled
- 2 — Enabled (Forced Shorted Deceleration)
- 3 — Enabled (Forced Dynamic Braking Deceleration)

Direct Access Number — **F305**

Parameter Type — **Selection List**

Factory Default — **(ASD-Dependent)**

Changeable During Run — **Yes**

---

**Supply Voltage Correction**

Program ⇒ Protection ⇒ Base Frequency Voltage

This parameter **Enables/Disables** the **Voltage Compensation** function.

When **Enabled**, this function provides a constant V/f ratio during periods of input voltage fluctuations.

Settings:

- 0 — Disabled (Output Voltage Unlimited)
- 1 — Enabled (Supply Voltage Compensation)
- 2 — Disabled (Output Voltage Limited)
- 3 — Enabled (Supply Voltage Compensation w/Output Voltage Limited)

---

**Dynamic Braking Resistance**

Program ⇒ Protection ⇒ Dynamic Braking

This parameter is used to input the resistive value of the **Dynamic Braking Resistor** being used.

Light-duty and heavy-duty resistors vary from a few ohms to several hundred ohms. The appropriate resistance size will be typeform- and application-specific.

See the section titled [Dynamic Braking Protection on pg. 283](#) for more information on using the DBR system and for assistance in selecting the appropriate resistor for a given application.

**Note:** *Using a resistor value that is too low may result in system damage.*

---

**Continuous Dynamic Braking Capacity**

Program ⇒ Protection ⇒ Dynamic Braking

This parameter is used to input the wattage of the **Dynamic Braking Resistor**.

See the section titled [Dynamic Braking Protection on pg. 283](#) for more information on using the DBR system.

**Note:** *Using a resistor with a wattage rating that is too low may result in system damage.*

---

**Ridethrough Time**

Program ⇒ Protection ⇒ Retry/Restart

In the event of a momentary power outage, this parameter determines the length of the **Ridethrough** time.

The **Ridethrough** will be maintained for the number of seconds set using this parameter.

See parameter [F302](#) for more information on the Ridethrough function.

**Note:** *The actual **Ridethrough Time** is load-dependent.*

**Direct Access Number — F307**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

---

**Direct Access Number — F308**

Parameter Type — **Numerical**

Factory Default — **(ASD-Dependent)**

Changeable During Run — **No**

Minimum — 0.5

Maximum — 1000.0

Units —  $\Omega$

---

**Direct Access Number — F309**

Parameter Type — **Numerical**

Factory Default — **(ASD-Dependent)**

Changeable During Run — **No**

Minimum — 0.01

Maximum — 600.00

Units — kW

---

**Direct Access Number — F310**

Parameter Type — **Numerical**

Factory Default — **2.0**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 320.0

Units — Seconds

**Forward Run/Reverse Run Disable**

Program ⇒ Frequency ⇒ Forward/Reverse Disable

This parameter **Enables/Disables** the **Forward Run** or **Reverse Run** mode.

If either direction is disabled, commands received for the disabled direction will not be recognized.

If both directions are disabled, the received direction command will determine the direction of the motor rotation.

Settings:

- 0 — Off
- 1 — Disable Reverse Run
- 2 — Disable Forward Run

Direct Access Number — F311

Parameter Type — Selection List

Factory Default — Off

Changeable During Run — No

**Random Mode**

Program ⇒ Protection ⇒ Retry/Restart

This parameter adjusts the carrier frequency randomly. This feature is effective in minimizing the negative effects of mechanical resonance.

Settings:

- 0 — Disabled
- 1 — Enabled

Direct Access Number — F312

Parameter Type — Selection List

Factory Default — Disabled

Changeable During Run — No

**Carrier Frequency Control Mode**

Program ⇒ Special ⇒ Carrier Frequency

This parameter provides for the automatic decrease of the carrier frequency.

Select **1** to decrease the **Carrier Frequency** setting as a function of an increased current requirement.

Selection **2** or **3** may also include an output voltage drop as a function of an increased current requirement. The **Carrier Frequency** should be set below 4 kHz.

Settings:

- 0 — No Decrease and No Limit
- 1 — Valid Decrease and No Limit
- 2 — No Decrease and Limit Small Pulse
- 4 — Valid Decrease and Limit Small Pulse

Direct Access Number — F316

Parameter Type — Selection List

Factory Default — Valid Decrease and No Limit

Changeable During Run — Yes

**Synchronized Deceleration Time**

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

In the event that the **Ridethrough** function activates in a multiple-motor application it will be necessary to manage the stopping motors synchronously as not to damage the product being processed (e.g., wire spools, bobbin winder for textile machines, etc.).

This parameter is used to minimize the product breakage during a momentary power outage. This function stops multiple machines simultaneously or makes them reach their respective command frequencies simultaneously by regulating their deceleration times.

See parameter [F302](#) for more information on this setting.

Direct Access Number — F317

Parameter Type — Numerical

Factory Default — 2.0

Changeable During Run — Yes

Minimum — 0.1

Maximum — 6000.0

Units — Seconds

---

**Synchronized Acceleration Time**

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

In the event that the **Ridethrough** function activates in a multiple-motor application it will be necessary to manage the accelerating motors synchronously as not to damage the product being processed (e.g., wire spools, bobbin winder for textile machines, etc.).

This parameter is used to minimize the product breakage during a momentary power outage. This function orchestrates the acceleration of multiple machines simultaneously or makes them reach their respective command frequencies simultaneously by regulating their acceleration times.

See parameter [F302](#) for more information on this setting.

**Direct Access Number — F318**

 Parameter Type — **Numerical**

 Factory Default — **2.0**

 Changeable During Run — **Yes**

Minimum — 0.10

Maximum — 6000

Units — Seconds

---

**Drooping Gain**

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the effective 100% output torque level while operating in the **Drooping Control** mode. This value is the upper torque limit of the motor being driven by a given ASD while operating in the **Drooping Control** mode.

**Note:** *The maximum frequency output is not limited by the setting of [F011](#) while operating in the **Drooping Control** mode.*

**Direct Access Number — F320**

 Parameter Type — **Numerical**

 Factory Default — **0.0**

 Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 100.0

Units — %

**Drooping**

**Drooping Control**, also called **Load Share**, is used to share the load among two or more mechanically coupled motors. Unlike **Stall**, which reduces the output frequency in order to limit the load once the load reaches a preset level, **Drooping** can decrease or increase the V/f setting of a motor to maintain a balance between the output torque levels of mechanically coupled motors.

Because of variances in gearboxes, sheaves, belts, motors, and since the speed of the motor is constrained by the mechanical system, one motor may experience more load than its counterpart and may become overloaded.

**Drooping Control** allows the overloaded motor to slow down, thus shedding load and encouraging a lightly-loaded motor to pick up the slack. The goal of **Drooping Control** is to have the same torque ratios for mechanically coupled motors.

---

**Speed at 0% Drooping Gain**

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the motor speed when at the 0% output torque gain while operating in the **Drooping Control** mode. This function determines the lowest speed that **Drooping** will be in effect for motors that share the same load.

**Direct Access Number — F321**

 Parameter Type — **Numerical**

 Factory Default — **0.00**

 Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 320.0

Units — Hz

---

**Speed at [F320](#) Drooping Gain**

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the motor speed when at the 100% output torque gain while operating in the **Drooping Control** mode. This function determines the speed of the individual motors at the 100% **Drooping Gain** setting for motors that share the same load.

**Direct Access Number — F322**

 Parameter Type — **Numerical**

 Factory Default — **0.00**

 Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 320.0

Units — Hz



<b>Drooping Insensitive Torque</b> Program ⇒ Feedback ⇒ Drooping Control  This parameter defines a torque range in which the <b>Drooping Control</b> settings will be ignored and the programmed torque settings will be followed.	<b>Direct Access Number — F323</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 100.0 Units — %
<b>Drooping Output Filter</b> Program ⇒ Feedback ⇒ Drooping Control  This parameter is used to set the rate of output change allowed when operating in the <b>Drooping Control</b> mode. Jerky operation may be reduced by increasing this setting.	<b>Direct Access Number — F324</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 200.0 Units — Radians/Second
<b>Braking Mode Selection</b> Program ⇒ Torque ⇒ Torque Control  This parameter is primarily used with lifting systems to allow for enough torque to be produced after receiving a <b>Run</b> command before releasing the brake. Without this feature the load would drop for a period once the brake was released. This parameter enables this function by setting the system operating mode.  Settings: 0 — Disabled 1 — Forward Direction 2 — Reverse Direction 3 — Same Direction	<b>Direct Access Number — F341</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>
<b>Torque Bias Input Selection</b> Program ⇒ Torque ⇒ Torque Control  Once enabled at parameter <a href="#">F341</a> , this parameter sets the source of the input signal that will set the torque level used to provide the <b>Braking Mode Selection</b> function of parameter <a href="#">F341</a> .  Settings: 0 — Disabled 1 — V/I 2 — RR 3 — RX 4 — EOI (Keypad) 5 — RS485 2-Wire 6 — RS485 4-Wire 7 — Communication Option Board 8 — RX2 Option (A11)	<b>Direct Access Number — F342</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>

<b>Panel Torque Bias</b> Program ⇒ Torque ⇒ Torque Control  Once enabled at parameter F341, this parameter establishes the torque bias setting to which the setting of F342 will either add to or subtract from to produce the final torque value used to carry out the <b>Braking Mode Selection</b> function of parameter F341.	<b>Direct Access Number — F343</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100.00</b> Changeable During Run — <b>Yes</b> Minimum — -250.00 Maximum — +250.00 Units — %
<b>Panel Torque Gain</b> Program ⇒ Torque ⇒ Torque Control  Once enabled at parameter F341, this parameter sets the sensitivity of the torque control source selected at F342 for the <b>Braking Mode Selection</b> function of parameter F341.	<b>Direct Access Number — F344</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 100.00 Units — %
<b>Release Time</b> Program ⇒ Torque ⇒ Torque Control  Once enabled at parameter F341, this parameter sets the time that the brake will hold after the requirements of the <b>Braking Mode Selection</b> function of parameter F341 have been met.	<b>Direct Access Number — F345</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.05</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 2.50 Units — Seconds
<b>Creeping Frequency</b> Program ⇒ Torque ⇒ Torque Control  Once enabled at parameter F341, and while running, upon receiving a <b>Stop</b> command this parameter sets an output frequency to be provided for the duration of the time setting of parameter F347.	<b>Direct Access Number — F346</b> Parameter Type — <b>Numerical</b> Factory Default — <b>3.00</b> Changeable During Run — <b>Yes</b> Minimum — F240 Setting Maximum — 20.0 Units — Hz
<b>Creeping Time</b> Program ⇒ Torque ⇒ Torque Control  Once the <b>Creep</b> function of F346 is activated, this parameter determines the duration of activation of the <b>Creep</b> function.	<b>Direct Access Number — F347</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.10</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 2.50 Units — Seconds

**Braking Time Learning Function**

Program ⇒ Torque ⇒ Torque Control

This parameter is used to establish approximate settings for parameters [F343](#), [F345](#), [F346](#), and [F347](#).

**Note:** *Setting this parameter should be done using a light load only.*

Set this parameter to **Brake Signal Learning**. Provide a Run command. The aforementioned parameters will receive approximate values. Application-specific adjustments may be required when finished.

Settings:

- 0 — Disabled
- 1 — Enabled

**Direct Access Number — F348**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes****Accel/Decel Suspend**

Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings

To maintain a constant speed setting while running, this parameter may be used to suspend speed changes for a user-set length of time.

The **Accel/Decel Suspend** function is enabled by setting this parameter to either **Terminal Board Input** or to [F350 – F353](#).

Selecting **Terminal Board Input** at this parameter requires that a discrete input terminal be set to **Dwell Signal** (See [Table 6 on pg. 249](#) for a listing of available settings). Upon activation of the **Dwell Signal** terminal the output frequency remains at the at-activation speed for the duration of the activation. When deactivated the programmed accel or decel ramp resumes.

Selecting [F350 – F353](#) at this parameter requires that the acceleration and/or the deceleration **Suspend Frequency** and **Suspend Time** settings be completed at [F350](#), [F351](#), [F352](#), and [F353](#). Upon reaching the frequency setting of [F350](#) (Accel) or [F352](#) (Decel), the Accel/Decel ramp will cease and the output frequency will hold at the threshold frequency setting for the time setting of [F351](#) for acceleration or [F353](#) for deceleration.

Settings:

- 0 — Off
- 1 — [F350 – F353](#) Settings
- 2 — Terminal Board Input

**Direct Access Number — F349**Parameter Type — **Selection List**Factory Default — **Off**Changeable During Run — **Yes****Acceleration Suspend Frequency**

Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings

When **Enabled** at [F349](#), this parameter is used to set the frequency at which the **Acceleration Suspend** function will activate.

During acceleration, this parameter sets the frequency at which acceleration will stop and the motor will run at the setting of this parameter for the time setting of [F351](#).

**Direct Access Number — F350**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

<b>Acceleration Suspend Time</b> Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings  When <b>Enabled</b> at <a href="#">F349</a> , this parameter is used to set the duration of activation of the <b>Acceleration Suspend</b> function when initiated by reaching the <b>Acceleration Suspend Frequency</b> setting ( <a href="#">F350</a> ).  Once this parameter times out the acceleration rate will resume from the point of suspension.	<b>Direct Access Number — F351</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 10.0 Units — Seconds
<b>Deceleration Suspend Frequency</b> Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings  When <b>Enabled</b> at <a href="#">F349</a> , this parameter is used to set the frequency at which the <b>Deceleration Suspend</b> function will activate.  During deceleration, this parameter sets the frequency at which deceleration will stop and the motor will run at the setting of this parameter for the time setting of <a href="#">F353</a> .	<b>Direct Access Number — F352</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (<a href="#">F011</a>)</b> Units — Hz
<b>Deceleration Suspend Time</b> Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings  When <b>Enabled</b> at <a href="#">F349</a> , this parameter is used to set the duration of activation of the <b>Deceleration Suspend</b> function when initiated by reaching the <b>Deceleration Suspend Frequency</b> setting ( <a href="#">F352</a> ).  Once this parameter times out the deceleration rate will resume from the point of suspension.	<b>Direct Access Number — F353</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 10.0 Units — Seconds

## Commercial Power/ASD Output Switching

Program ⇒ Terminal ⇒ Line Power Switching

This parameter **Enables/Disables** the **Commercial Power/ASD Output Switching** function.

When enabled, the system may be set up to discontinue using the output of the ASD and to switch to the commercial power if 1) a trip is incurred, 2) a user-set ASD frequency is reached, or 3) if initiated by a discrete input terminal.

Once set up with the proper switching frequency and hold times, the system will switch to commercial power upon reaching the **F355** frequency criterion.

Switching may also be accomplished manually by activating the discrete input terminal **Commercial Power ASD Switching**. Terminal activation forces the ASD output speed to accelerate to the **F355** switching frequency, resulting in the ASD-to-commercial power switching.

Deactivation of the discrete input terminal starts the hold-time counter setting (**F356**) for ASD-to-commercial power switching. Once timed out the motor resumes normal commercial power operation.

Settings:

- 0 — Off
- 1 — Switch at Trip
- 2 — Switch at Switching Frequency
- 3 — Switch at Trip or Switching Frequency

### Switching Setup Requirements

**F354** — Enable the switching function.

**F355** — Set the switching frequency.

**F356** — (Speed) Hold -time before applying ASD output after the switching criteria has been met.

**F357** — (Speed) Hold -time before applying commercial power after the switching criteria has been met.


**F358** — (Speed) Hold -time of applying commercial power after the switching criteria has been met.

Set a discrete input terminal to **Commercial Power ASD Switching**.

Set **OUT1** and **OUT2** to **Commercial Power/ASD Switching 1** and **2**, respectively.

**Note:** Ensure that the switching directions are the same and that **F311** is set to **Permit All**.

**Note:** The **OUT1** and **OUT2** outputs assigned to **Commercial Power/ASD Switching Output** are used to actuate the re-routing contactors.



<b>Commercial Power/ASD Switching Frequency</b> Program ⇒ Terminal ⇒ Line Power Switching  When enabled at <a href="#">F354</a> and with a properly configured discrete output terminal, this parameter sets the frequency at which the <b>At Frequency Powerline Switching</b> function engages.  The <b>At Frequency Powerline Switching</b> function commands the system to discontinue using the output of the ASD and to switch to commercial power once reaching the frequency set here.  See parameter <a href="#">F354</a> for more information on this setting.	<b>Direct Access Number — F355</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>ASD-Side Switching Delay</b> Program ⇒ Terminal ⇒ Line Power Switching  This parameter determines the amount of time that the ASD will wait before outputting a signal to the motor once the switch-to-ASD-output criteria has been met.  See parameter <a href="#">F354</a> for more information on this setting.	<b>Direct Access Number — F356</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>Yes</b> Minimum — 0.10 Maximum — 10.00 Units — Seconds
<b>Commercial Power Switching Delay</b> Program ⇒ Terminal ⇒ Line Power Switching  This parameter determines the amount of time that the ASD will wait before allowing commercial power to be applied to the motor once the switch-to-commercial-power criteria has been met.  See parameter <a href="#">F354</a> for more information on this setting.	<b>Direct Access Number — F357</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.62</b> Changeable During Run — <b>Yes</b> Minimum — <b>(ASD-Dependent)</b> Maximum — 10.00 Units — Seconds
<b>Commercial Power Switching Freq. Hold Time</b> Program ⇒ Terminal ⇒ Line Power Switching  This parameter determines the amount of time that the connection to commercial power is maintained once the switch-to-ASD-output criteria has been met.  See parameter <a href="#">F354</a> for more information on this setting.	<b>Direct Access Number — F358</b> Parameter Type — <b>Numerical</b> Factory Default — <b>2.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.10 Maximum — 10.00 Units — Seconds
<b>PID Control Switching</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter is used to set the PID control mode. Selecting <b>Process PID</b> uses the upper and lower-limit settings of parameters <a href="#">F367</a> and <a href="#">F368</a> . Selecting <b>Speed PID</b> uses the upper and lower-limit settings of parameters <a href="#">F370</a> and <a href="#">F371</a> .  Settings: 0 — PID Off 1 — Process PID 2 — Speed PID 3 — Easy Positioning PID (Not Used with the P9 ASD)	<b>Direct Access Number — F359</b> Parameter Type — <b>Selection List</b> Factory Default — <b>PID Off</b> Changeable During Run — <b>No</b>

<b>PID Feedback Signal</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter <b>Enables/Disables PID</b> feedback control. When enabled, this parameter determines the source of the motor control feedback.  Settings: 0 — PID Control Disabled 1 — V/I 2 — RR 3 — RX 4 — RX2 Option (AI1) 5 — Option V/I (AI2) 6 — PG Feedback Option  <b>Proportional-Integral-Derivative (PID)</b> — A closed-loop control technique that seeks error minimization by reacting to three values: One that is proportional to the error, one that is representative of the error, and one that is representative of the rate of change of the error.	<b>Direct Access Number</b> — F360 <b>Parameter Type</b> — Selection List <b>Factory Default</b> — V/I <b>Changeable During Run</b> — Yes
<b>PID Feedback Delay Filter</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter determines the delay in the ASD output response to the motor control feedback signal (signal source is selected at <a href="#">F360</a> ).	<b>Direct Access Number</b> — F361 <b>Parameter Type</b> — Numerical <b>Factory Default</b> — 0.1 <b>Changeable During Run</b> — Yes <b>Minimum</b> — 0.0 <b>Maximum</b> — 25.0
<b>PID Feedback Proportional (P) Gain</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter determines the degree that the <b>Proportional</b> function affects the output signal. The larger the value entered here, the quicker the ASD responds to changes in feedback.	<b>Direct Access Number</b> — F362 <b>Parameter Type</b> — Numerical <b>Factory Default</b> — 0.10 <b>Changeable During Run</b> — Yes <b>Minimum</b> — 0.01 <b>Maximum</b> — 100.0
<b>PID Feedback Integral (I) Gain</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter determines the degree that the <b>Integral</b> function affects the output signal. The smaller the value here, the more pronounced the effect of the integral function on the output signal.	<b>Direct Access Number</b> — F363 <b>Parameter Type</b> — Numerical <b>Factory Default</b> — 0.01 <b>Changeable During Run</b> — Yes <b>Minimum</b> — 0.01 <b>Maximum</b> — 100.00
<b>PID Deviation Upper-Limit</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter determines the maximum amount that the feedback may increase the output signal.	<b>Direct Access Number</b> — F364 <b>Parameter Type</b> — Numerical <b>Factory Default</b> — 60.00 <b>Changeable During Run</b> — Yes <b>Minimum</b> — 0.00 <b>Maximum</b> — 60.00 <b>Units</b> — Hz

<b>PID Deviation Lower-Limit</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter determines the maximum amount that the feedback may decrease the output signal.	<b>Direct Access Number — F365</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 60.00 Units — Hz
<b>PID Feedback Differential (D) Gain</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter determines the degree that the <b>Differential</b> function affects the output signal. The larger the value entered here, the more pronounced the affect of the differential function for a given feedback signal level.	<b>Direct Access Number — F366</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 2.55
<b>Process Upper-Limit</b> Program ⇒ Feedback ⇒ Feedback Settings  Selecting <b>Process PID</b> at parameter <a href="#">F359</a> allows for this parameter setting to function as the <b>Upper-Limit</b> while operating in the <b>PID Control</b> mode.	<b>Direct Access Number — F367</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.00</b> Changeable During Run — <b>No</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Process Lower-Limit</b> Program ⇒ Feedback ⇒ Feedback Settings  Selecting <b>Process PID</b> at parameter <a href="#">F359</a> allows for this parameter setting to function as the <b>Lower-Limit</b> while operating in the <b>PID Control</b> mode.	<b>Direct Access Number — F368</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>No</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>PID Control Delay</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter is used to delay the start of PID control at start up. During the wait time set here, the ASD will follow the frequency control input of the process value and the feedback input will be ignored until this setting times out. At which time the PID setup assumes control.	<b>Direct Access Number — F369</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 2400 Units — Seconds
<b>PID Output Upper-Limit</b> Program ⇒ Feedback ⇒ Feedback Settings  Selecting <b>Speed PID</b> at parameter <a href="#">F359</a> allows for this parameter setting to function as the <b>Upper-Limit</b> while operating in the <b>PID Control</b> mode.	<b>Direct Access Number — F370</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.00</b> Changeable During Run — <b>No</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz



<b>PID Output Lower-Limit</b> Program ⇒ Feedback ⇒ Feedback Settings  Selecting <b>Speed PID</b> at parameter <a href="#">F359</a> allows for this parameter setting to function as the <b>Lower-Limit</b> while operating in the <b>PID Control</b> mode.	<b>Direct Access Number — F371</b> Parameter Type — <b>Numerical</b> Factory Default — <b>4.00</b> Changeable During Run — <b>Yes</b> Minimum — <b>Lower-Limit (F013)</b> Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Process Increasing Rate</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter is used to limit the rate that the output of the ASD may increase for a given difference in the speed reference and the PID feedback value.	<b>Direct Access Number — F372</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 600.0 Units — Seconds
<b>Process Decreasing Rate</b> Program ⇒ Feedback ⇒ Feedback Settings  This parameter is used to limit the rate that the output of the ASD may decrease for a given difference in the speed reference and the PID feedback value.	<b>Direct Access Number — F373</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 600.0 Units — Seconds
<b>Number of PG Input Pulses</b> Program ⇒ Feedback ⇒ PG Settings  This parameter is used to set the number of pulses output from a shaft-mounted encoder that is used to indicate one revolution of rotation (360°) of the motor or of the motor-driven equipment.	<b>Direct Access Number — F375</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 12 Maximum — 9999
<b>Number of PG Input Phases</b> Program ⇒ Feedback ⇒ PG Settings  This parameter determines the type of information that is supplied by the phase encoder.  Settings: 1 — Single Phase 2 — Two Phase	<b>Direct Access Number — F376</b> Parameter Type — <b>Selection List</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b>

**PG Disconnection Detection**

Program ⇒ Feedback ⇒ PG Settings

This parameter **Enables/Disables** the system's monitoring of the PG connection status when using encoders with line driver outputs.

**Note:** *The PG Vector Feedback Board option is required to use this feature.*

Settings:

- 0 — Disabled
- 1 — Enabled with Filter
- 3 — Enabled (Detect momentary power fail)

**Direct Access Number — F377**Parameter Type — **Selection List**Factory Default — **(ASD-Dependent)**Changeable During Run — **No****VLP Application Operating Mode**

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

While operating in the **VLP** mode, this parameter sets the system response to the received feedback from the **V/I** terminal.

Select **Direct Acting** to produce an increase in the ASD output with a decrease in the feedback signal.

Select **Reverse Acting** to produce a decrease in the ASD output with an decrease in the feedback signal.

Settings:

- 0 — Direct Acting (Positive Gradient)
- 1 — Reverse Acting (Negative Gradient)

**Direct Access Number — F380**Parameter Type — **Selection List**Factory Default — **Direct Acting**Changeable During Run — **No****Simple Positioning Completion Range**

Program ⇒ Feedback ⇒ PG Settings

While operating in the **Positioning Control** mode, this parameter sets the range of accuracy for a **Stop** command initiated via the terminal board.

If the setting is too low the stop may be too abrupt.

**Direct Access Number — F381**Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **Yes**Minimum — **1**Maximum — **4000****VLP Sleep Timer**

Virtual Linear Pump ⇒ Sleep Timer Enable

During a properly configured **VLP** operation, this parameter **Enables/Disables** the ability of the ASD to terminate the output signal to the motor upon operating for a user-set amount of time within the **VLP Minimum Zone**.

See [F383](#) and [F480](#) for more information on this parameter.

**Direct Access Number — F382**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes****WARNING**

**The Sleep Timer function may result in the unexpected Start or Stop of the motor. Signs to this effect are to be posted at the location of the motor/pump.**

Settings:

- 0 — Disabled
- 1 — Enabled

**VLP Sleep Timer Delay**

Virtual Linear Pump ⇒ Sleep Timer Setting

During a properly configured **VLP** operation, and once enabled at [F382](#), this parameter establishes the time that system operation will be allowed to operate within the **VLP Minimum Zone** before the ASD output to the motor is terminated.

See [F382](#) for more information on this parameter.

**Direct Access Number — F383**Parameter Type — **Numerical**Factory Default — **300**Changeable During Run — **Yes**

Minimum — 1

Maximum — 63335


Units — Seconds

**Direct Operation VLP Command Value**

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

During a properly configured **VLP** operation while operating in the **Direct** mode and using the EOI for system control, this parameter establishes the **VLP** level.

This parameter setting is effective **ONLY** while operating in the **Direct** mode and while receiving a command from the EOI. The end value of this parameter setting appears in the **Frequency Command** screen as shown below.

**Direct Access Number — F384**Parameter Type — **Numerical**Factory Default — **0.0**Changeable During Run — **Yes**

Minimum — 10

Maximum — 165

**VLP Auto Start-Stop Mode**

Virtual Linear Pump ⇒ Auto Start-Stop Mode Enable

During a properly configured **VLP** operation, this parameter **Enables/Disables** the ability of the system to receive transducer input to manage system starts and stops as it pertains to the process variable.

This parameter is also used to select the ASD response (Stop or Start) upon meeting the criteria of [F388](#) and [F389](#) settings.

**On Forward** = Run ASD while measured signal is  $\leq$  [F388](#) setting and stop ASD upon reaching [F389](#) setting.

**On Reverse** = Run ASD while measured signal is  $\geq$  [F389](#) setting and stop ASD upon reaching [F388](#) setting.

Settings:

- 0 — Off
- 1 — On Forward
- 2 — On Reverse

**Direct Access Number — F385**Parameter Type — **Selection List**Factory Default — **Off**Changeable During Run — **Yes****WARNING**

The Auto Start-Stop operating mode may result in the unexpected Start or Stop of the motor. Signs to this effect are to be posted at the location of the motor/pump.

<p><b>VLP Auto Start-Stop Delay Timer</b></p> <p>Virtual Linear Pump ⇒ Auto Start-Stop Delay Timer</p> <p>During a properly configured <b>VLP</b> operation, this parameter establishes the time that the <b>Start-Stop</b> criteria of <a href="#">F388</a> and <a href="#">F389</a> must be maintained to activate the <b>Auto Start-Stop</b> function.</p> <p>This feature is used to minimize system responses to rapid fluctuations in the feedback signal.</p> <p>See <a href="#">F385</a> for more information on this parameter.</p>	<p><b>Direct Access Number — F387</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>5.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6553.5</p> <p>Units — Seconds</p>
<p><b>VLP Auto Start-Stop Lower Threshold</b></p> <p>Virtual Linear Pump ⇒ Auto Start-Stop Threshold Setting</p> <p>During a properly configured <b>VLP</b> operation while in the <b>On Forward</b> or <b>On Reverse</b> modes (<a href="#">F385</a>), this parameter establishes the lower level of the <b>Auto Start-Stop</b> threshold.</p> <p>See <a href="#">F385</a> for further information on this parameter.</p> <p>The unit of measure for this parameter may be one of the following types — the type is selected while running the <b>VLP Wizard</b>.</p> <ul style="list-style-type: none"> <li>• PSI</li> <li>• GPM</li> <li>• Inches of Water Column</li> <li>• Feet of Water Column</li> <li>• CFM</li> <li>• °C</li> <li>• °F</li> <li>• Custom</li> </ul> <p>(Custom selection allows for three character spaces to be populated from the 26 alphabet and 13 special characters)</p>	<p><b>Direct Access Number — F388</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>Application-Specific</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — <a href="#">F403</a> Setting</p> <p>Maximum — <a href="#">F393</a> Setting</p> <p>Units — Selectable at VLP Setup Wizard</p>
<p><b>VLP Auto Start-Stop Upper Threshold</b></p> <p>Virtual Linear Pump ⇒ Auto Start-Stop Threshold Setting</p> <p>During a properly configured <b>VLP</b> operation while in the <b>On Forward</b> or <b>On Reverse</b> modes (<a href="#">F385</a>), this parameter establishes the upper level of the <b>Auto Start-Stop</b> threshold.</p> <p>See <a href="#">F385</a> for further information on this parameter.</p> <p>The unit of measure for this parameter may be one of the following types — the type is selected while running the <b>VLP Wizard</b>.</p> <ul style="list-style-type: none"> <li>• PSI</li> <li>• GPM</li> <li>• Inches of Water Column</li> <li>• Feet of Water Column</li> <li>• CFM</li> <li>• °C</li> <li>• °F</li> <li>• Custom</li> </ul> <p>(Custom selection allows for three character spaces to be populated from the 26 alphabet and 13 special characters)</p>	<p><b>Direct Access Number — F389</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>300.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — <a href="#">F403</a> Setting</p> <p>Maximum — <a href="#">F393</a> Setting</p> <p>Units — Selectable at VLP Setup Wizard</p>

---

**Virtual Linear Pump Mode Switch**

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

This parameter is enabled for use by completing the **VLP Setup Wizard**.

During a properly configured **VLP** operation, this parameter establishes if feedback is used or not.

Select the command source or the feedback source for operating in the **Direct** or **Process** modes, respectively, at F396. The default selection for each may be used.

**Note:** If F396 is set to use **V/I** as the command source **DO NOT** set this parameter to **Process Hold**. Doing so will result in an error message (V/I cannot be used for both functions).

**Note:** The selected setting for this parameter will be retained when the **VLP** function is turned on or off using a discrete input terminal set to **VLP Enable/Disable**.

Settings:

- 0 — Disabled
- 1 — Direct Mode (No Feedback Used)
- 2 — Process Hold (V/I Feedback Used)
- 255 — Setup

---

**Direct Access Number — F390**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **No**

---

**Virtual Linear Pump Application Type**

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

During a properly configured **VLP** operation, this parameter establishes the process variable measurement type.

Settings:

- 0 — Pressure
- 1 — Flow
- 2 — Level

---

**Direct Access Number — F391**Parameter Type — **Selection List**Factory Default — **Pressure**Changeable During Run — **No**

---

**Virtual Linear Pump Transducer Output Type/Range**

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

During a properly configured **VLP** operation, this parameter establishes the transducer output signal type and range for **VLP** operation.

**Note:** This parameter is scaled at F201 – F204 for either selection and requires no user intervention.

Settings:

- 0 — 0 – 20 mA
- 1 — 4 – 20 mA
- 2 — 0 – 10 V
- 3 — 0 – 5 V

---

**Direct Access Number — F392**Parameter Type — **Selection List**

Factory Default — 0 – 20 mA

Changeable During Run — **No**


<b>Virtual Linear Pump Transducer Maximum Reading</b> Program ⇒ Virtual Linear Pump ⇒ VLP Settings  During a properly configured <b>VLP</b> operation, this parameter establishes the maximum level of the transducer range for <b>VLP</b> operation.	<b>Direct Access Number — F393</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — -3276.7 Maximum — 3276.7
<b>Virtual Linear Pump Transducer Minimum Reading</b> Program ⇒ Virtual Linear Pump ⇒ VLP Settings  During a properly configured <b>VLP</b> operation, this parameter establishes the minimum level of the transducer range for <b>VLP</b> operation.	<b>Direct Access Number — F403</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — -3276.7 Maximum — 3276.7
<b>Virtual Linear Pump Minimum</b> Program ⇒ Virtual Linear Pump ⇒ VLP Settings  During a properly configured <b>VLP</b> operation, this parameter establishes the minimum setpoint within the <b>VLP</b> operating domain.	<b>Direct Access Number — F394</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 10 Maximum — 165
<b>Virtual Linear Pump Maximum</b> Program ⇒ Virtual Linear Pump ⇒ VLP Settings  During a properly configured <b>VLP</b> operation, this parameter establishes the maximum setpoint within the <b>VLP</b> operating domain.	<b>Direct Access Number — F395</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 10 Maximum — 165
<b>Virtual Linear Pump Command Source</b> Program ⇒ Virtual Linear Pump ⇒ VLP Settings  During <b>Direct</b> mode or the <b>Process Hold</b> mode operation, this parameter sets the <b>VLP</b> command source.  <i><b>Note:</b> If <b>Process Hold</b> is selected at <a href="#">F390</a>, selecting <b>V/I</b> here will result in an error message.</i>  Settings: 0 — EOI 1 — *V/I 2 — RR 3 — Communication Board	<b>Direct Access Number — F396</b> Parameter Type — <b>Selection List</b> Factory Default — <b>EOI</b> Changeable During Run — <b>No</b>

### Process Hold Operation VLP Command Value via the EOI

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

During a properly configured **VLP** operation while operating in the **Process Hold** mode and using the EOI for system control, this parameter establishes the **VLP** level.

This parameter setting is effective **ONLY** while operating in the **Process Hold** mode and while receiving a command via the EOI. The end value of this parameter setting appears in the **Frequency Command** screen as shown below.



Direct Access Number — F397

Parameter Type — Numerical

Factory Default — 0.0

Changeable During Run — Yes

Minimum — F403 Setting

Maximum — F393 Setting

### Virtual Linear Pump Low Frequency Limit

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

During a properly configured **VLP** operation, this parameter establishes the **VLP Low Frequency Limit**.

Direct Access Number — F398

Parameter Type — Numerical

Factory Default — 15

Changeable During Run — Yes

Minimum — 1.00

Maximum — 60.00

Units — Hz

### Autotuning 1

Program ⇒ Motor ⇒ Vector Motor Model

This parameter sets the **Autotune** command status.

Selecting **Reset Motor Defaults** for this parameter sets parameters F410, F411, F412, and F413 to the factory default settings.

If selecting **Autotune on Run Command**, **Autotune Initiated by Input Terminal**, or **Autotune of Detail Parameters** for this parameter set the **Base Frequency**, **Base Frequency Voltage**, and the **Motor Rated Revolutions** to the nameplated values of the motor to achieve the best possible **Autotune** precision.

Settings:

- 0 — Autotune Disabled
- 1 — Reset Motor Defaults
- 2 — Enable Autotune on Run Command
- 3 — Autotuning by Input Terminal Signal (See Table 6 on pg. 249)
- 4 — Motor Constant Auto Calculation

Direct Access Number — F400

Parameter Type — Selection List

Factory Default — Autotune Disabled

Changeable During Run — No

<b>Slip Frequency Gain</b> Program ⇒ Motor ⇒ Vector Motor Model  This parameter provides a degree of slip compensation for a given load. A higher setting here decreases the slip allowed for a given load/ASD output ratio.	<b>Direct Access Number — F401</b> Parameter Type — <b>Numerical</b> Factory Default — <b>70</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 150 Units — %
<b>Autotuning 2</b> Program ⇒ Motor ⇒ Vector Motor Model  This parameter introduces a thermal element into the autotuning equation and is used to automatically adjust the <b>Autotune</b> parameter values as a function of increases in the temperature of the motor.  Settings: 0 — Off 1 — Self-Cooled Motor Tuning 2 — Forced Air Cooled Motor Tuning	<b>Direct Access Number — F402</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Off</b> Changeable During Run — <b>No</b>
<b>Virtual Linear Pump Transducer Minimum Reading</b> Program ⇒ Virtual Linear Pump ⇒ VLP Settings  During a properly configured <b>VLP</b> operation, this parameter establishes the minimum level of the transducer range for <b>VLP</b> operation.	<b>Direct Access Number — F403</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — -32767 Maximum — 32767



---

**Time-Based Alternation Emergency Timer**

Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation

During **Time-Based Alternation** operation, in the event that the Lead ASD trips or loses the transducer input signal, this parameter sets a counter time that, upon such an event, will start a count down to zero.

Upon reaching zero, two actions will occur:

- 1) The Lag 1 ASD will accelerate to the setting of **F395** at the **Accel Time 1** rate — **F009**.

If the Lag1 ASD is tripped, another timer count down begins and upon reaching zero, the next available ASD will accelerate to the setting of **F395**.

- 2) The system will check the load requirement of the Lag1 ASD (or the next available ASD).

If the Lag 1 ASD load is zero, the ASD will stop.

If a non-zero load is detected, the Lag1 ASD will continue to run in accordance with the user-set **VLP** settings.

**Time-Based Alternation**

**Time-Based Alternation** (TBA) is used to provide a more evenly distributed run-time of the system pumps of a multi-pump system. This is accomplished by alternating which system pump plays the Lead role.

Permanently assigning one pump as the Lead pump invariably results in the Lead pump being over worked and it will require more maintenance. The **TBA** algorithm allows the user to set the time that each pump within the system is to be assigned the Lead pump function and which are assigned the function of being the Lag pump(s).

Upon completion of the user-set time, the system changes the Lead pump assignment to the next pump number (**F434**).

The **VLP** feature allows the Lag pumps to assist the Lead pump when required as the load exceeds the ability of the lead pump.

---

**Motor Rated Capacity**

Program ⇒ Motor ⇒ Vector Motor Model

This parameter is used to set the (nameplated) rated capacity of the motor being used.

---

**Motor Rated Current**

Program ⇒ Motor ⇒ Vector Motor Model

This parameter is used to set the (nameplated) current rating of the motor being used.

**Direct Access Number — F404**

Parameter Type — **Numerical**

Factory Default — **60**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 65535

Units — Minutes

---

**Direct Access Number — F405**

Parameter Type — **Numerical**

Factory Default — **11.0**

Changeable During Run — **No**

Minimum — 0.1

Maximum — 500.00

Units — kW

---

**Direct Access Number — F406**

Parameter Type — **Numerical**

Factory Default — **20.3**

Changeable During Run — **No**

Minimum — 0.1

Maximum — 2000.0

Units — Amps

<b>Motor Rated RPM</b> Program ⇒ Motor ⇒ Vector Motor Model  This parameter is used input the (nameplated) rated speed of the motor.	<b>Direct Access Number — F407</b> Parameter Type — <b>Numerical</b> Factory Default — <b>1730</b> Changeable During Run — <b>No</b> Minimum — 100 Maximum — 60000 Units — RPM
<b>Base Frequency Voltage 1</b> Program ⇒ Vector ⇒ Vector Motor Model  The <b>Motor 1 Base Frequency Voltage 1</b> is the <b>Motor 1</b> output voltage at the <b>Base Frequency (F014)</b> . Regardless of the programmed value, the output voltage cannot be higher than the input voltage.  The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Correction</b> setting ( <b>F307</b> ).	<b>Direct Access Number — F409</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 50.0 Maximum — 660.0 Units — Volts
<b>Motor Constant 1 (Torque Boost)</b> Program ⇒ Motor ⇒ Vector Motor Model  This parameter sets the primary resistance of the motor. Increasing this value can prevent a drop in the torque of the motor at low speeds. Increasing this value excessively can result in nuisance overload tripping.	<b>Direct Access Number — F410</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 30.0 Units — %
<b>Motor Constant 2 (No-Load Current)</b> Program ⇒ Motor ⇒ Vector Motor Model  This parameter is used to set the current level required to excite the motor. Specifying a value that is too high for this parameter may result in hunting (erratic motor operation).	<b>Direct Access Number — F411</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 10 Maximum — 90 Units — %
<b>Motor Constant 3 (Leak Inductance)</b> Program ⇒ Motor ⇒ Vector Motor Model  This parameter is used to set the leakage inductance of the motor. A larger setting here results in higher output torque at high speeds.	<b>Direct Access Number — F412</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 0 Maximum — 200 Units — %
<b>Motor Constant 4 (Rated Slip)</b> Program ⇒ Motor ⇒ Vector Motor Model  This parameter is used to set the secondary resistance of the motor. An increase in this parameter setting results in an increase of compensation for motor slip.	<b>Direct Access Number — F413</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 0.01 Minimum — 25.00 Units — %

**Exciting Strengthening Coefficient**

Program ⇒ Special ⇒ Special Parameters

This parameter is used to increase the magnetic flux of the motor at low-speed.  
This feature is useful when increased torque at low speeds is required.

**Direct Access Number — F415**Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **No**

Minimum — 100

Maximum — 130

Units — %

**Stall Prevention Factor 1**

Program ⇒ Protection ⇒ Stall

This parameter is to be adjusted in the event that the motor stalls when operated above the base frequency.

If a momentary heavy load occurs the motor may stall before the load current reaches the stall prevention level setting of [F601](#).

A drop in the supply voltage may cause fluctuations of the load current or may cause motor vibration. A gradual adjustment of this parameter may alleviate this condition.

Start with a setting of 85 at these parameters and gradually adjust them from there one at a time until the desired results are produced.

Adjustments to this parameter may increase the load current of the motor and subsequently warrant an adjustment at the **Motor Overload Protection Level** setting.

**Direct Access Number — F416**Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **No**

Minimum — 10

Maximum — 250

### Time-Based Alternation

Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation

This parameter is enabled for use by completing the **VLP Setup Wizard**.

**Time-Based Alternation** operation is enable by setting this parameter (F417) to an operating mode and assigning a discrete input terminal to the **TBA HOA Switch** function and activating the terminal.

During **Time-Based Alternation** operation, and while running in the **VLP** mode, this parameter **Enables/Disables** the ability of the system to receive transducer input to manage system starts and stops as it pertains to the process variable.

This parameter is also used to select the Lead ASD response (Stop or Start) upon meeting the criteria of F388 and F389 settings.

**Forward Auto** = Run the ASD while the measured signal is ≤ F388 setting, and stop the ASD upon reaching the F389 setting.

**Reverse Auto** = Run the ASD while the measured signal is ≥ F389 setting, and stop the ASD upon reaching the F388 setting.

Settings:

- 0 — Off
- 1 — Forward Auto
- 2 — Reverse Auto



## WARNING

The Time-Based Alternation operating mode may result in the unexpected Start or Stop of the motor. Signs to this effect are to be posted at the location of the motor/pump.

**Direct Access Number — F417**

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **Yes**

The active TBA ASD is indicated by the **Run** symbol (Forward shown).

0	100%
SET: 0.00 Hz	
VLP Technology Avg:	0%
V/I Input:	0.00%
F R ST RES S1 S2 S3 S4	OUT1 OUT2 FL

The inactive TBA ASDs are indicated by the **Pause** symbol (Pause shown).

0	100%
SET: 0.00 Hz	
VLP Technology Avg:	0%
V/I Input:	0.00%
F R ST RES S1 S2 S3 S4	OUT1 OUT2 FL

### Time-Based Alternation Period

Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation

During **Time-Based Alternation** operation, this parameter sets the time that the Lead ASD and Lag ASD assignments are valid until changed as a function of the **Time-Based Alternation** settings.

**Direct Access Number — F418**

Parameter Type — **Numerical**

Factory Default — **1 Minute**

Changeable During Run — **No**

Minimum — 1 Minute

Maximum — 41 Days 15 Hours

### Torque Command

Program ⇒ Torque ⇒ Torque Control

When operating in the **Torque Control** mode, this parameter allows the user to select the source of the torque command signal.

Settings:

- 1 — V/I
- 2 — RR
- 3 — RX
- 4 — EOI (Keypad) (F725 Setting)
- 5 — RS485 2-Wire
- 6 — RS485 4-Wire
- 7 — Communication Option Board
- 8 — RX2 Option (A11)

**Direct Access Number — F420**

Parameter Type — **Selection List**

Factory Default — **RX**

Changeable During Run — **Yes**

---

**Tension Torque Bias Input**

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Tension Torque Bias** input function.This feature is enabled by selecting a **Tension Torque Bias** input signal source.

Settings:

- 0 — Disabled
- 1 — V/I
- 2 — RR
- 3 — RX
- 4 — EOI (Keypad)
- 5 — RS485 2-Wire
- 6 — RS485 4-Wire
- 7 — Communication Option Board
- 8 — RX2 Option (AI1)

**Direct Access Number — F423**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

---

**Load Sharing Gain Input**

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Load Sharing Gain** input function.This feature is enabled by selecting a **Load Sharing Gain** input signal source.

Settings:

- 0 — Disabled
- 1 — V/I
- 2 — RR
- 3 — RX
- 4 — EOI (Keypad)
- 5 — RS485 2-Wire
- 6 — RS485 4-Wire
- 7 — Communication Option Board
- 8 — RX2 Option (AI1)

**Direct Access Number — F424**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

---

**Forward Speed Limit Input**

Program ⇒ Torque ⇒ Torque Speed Limiting

This parameter **Enables/Disables** the **Forward Speed Limit Input** control function. When enabled and operating in the **Torque Control** mode, the forward speed limit is controlled by the input selected here.

If **Setting** is selected, the value set at [F426](#) is used as the **Forward Speed Limit** input.

Settings:

- 0 — Disabled
- 1 — V/I
- 2 — RR
- 3 — RX
- 4 — [F426](#) (Setting)

**Direct Access Number — F425**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

<b>Forward Speed Limit Level</b> Program ⇒ Torque ⇒ Torque Control  This parameter provides a value to be used as the <b>Forward Speed Limit</b> setting if <b>F426</b> is selected at <b>F425</b> .	<b>Direct Access Number — F426</b> Parameter Type — <b>Numerical</b> Factory Default — <b>80.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Reverse Speed Limit Input</b> Program ⇒ Torque ⇒ Torque Control  This parameter <b>Enables/Disables</b> the <b>Reverse Speed Limit Input</b> control function. When enabled and operating in the <b>Torque Control</b> mode, the reverse speed limit is controlled by the terminal selected here. If <b>Setting</b> is selected, the value set at <b>F428</b> is used as the <b>Reverse Speed Limit</b> input.  Settings: 0 — Disabled 1 — V/I 2 — RR 3 — RX 4 — <b>F428</b> (Setting)	<b>Direct Access Number — F427</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>
<b>Reverse Speed Limit Input Level</b> Program ⇒ Torque ⇒ Torque Control  This parameter provides a value to be used as the <b>Reverse Speed Limit</b> setting if <b>F428</b> is selected at <b>F427</b> .	<b>Direct Access Number — F428</b> Parameter Type — <b>Numerical</b> Factory Default — <b>80.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Upper-Limit (F012)</b> Units — Hz
<b>Speed Limit (torque=0) Center Value Reference</b> Program ⇒ Torque ⇒ Torque Speed Limiting  The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the <b>Torque Control</b> mode. This parameter sets the input signal source or value that will be used to control the allowable speed variance.  Settings: 0 — Disabled 1 — V/I 2 — RR 3 — RX 4 — <b>F431</b> (Setting)	<b>Direct Access Number — F430</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>

<b>Speed Limit (torque=0) Center Value</b> Program ⇒ Torque ⇒ Torque Speed Limiting  This parameter provides a value to be used as the <b>Speed Limit (torque=0) Center Value Reference</b> setting if <a href="#">F431</a> is selected at <a href="#">F430</a> .	<b>Direct Access Number — F431</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>Speed Limit (torque=0) Band</b> Program ⇒ Torque ⇒ Torque Speed Limiting  The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the <b>Torque Control</b> mode. This parameter sets a plus-or-minus value (range) for the <b>Speed Limit Torque Level (F431)</b> .	<b>Direct Access Number — F432</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>Time-Based Alternation Pump Number</b> Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation  During <b>Time-Based Alternation</b> operation, this parameter is used to assign an identifying number to an ASD/pump combination.  The identifying number is used to assign the virtual priority Lead and Lag assignments.  The maximum number is limited to the user-assigned number at parameter <a href="#">F437</a> .  <i><b>Note:</b> This parameter is not associated with nor affected by the setting of <a href="#">F802</a>.</i>	<b>Direct Access Number — F434</b> Parameter Type — <b>Selection List</b> Factory Default — <b>1</b> Changeable During Run — <b>Yes</b> Minimum — 1 Maximum — F437 Setting
<b>Rotation in Specified Direction ONLY</b> Program ⇒ Torque ⇒ Torque Speed Limiting  This parameter <b>Enables/Disables</b> the <b>Forward Run</b> or <b>Reverse Run</b> mode.  If either direction is disabled, commands received for the disabled direction will not be recognized.  If both directions are disabled, the received direction command will determine the direction of the motor rotation.  Settings 0 — Disabled 1 — Enabled	<b>Direct Access Number — F435</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>No</b>
<b>Time-Based Alternation Total Number of ASDs</b> Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation  This parameter lists the number of ASDs registered within the system. This parameter setting is used as the <b>Maximum</b> setting for parameter <a href="#">F434</a> .	<b>Direct Access Number — F437</b> Parameter Type — <b>Numerical</b> Factory Default — <b>2</b> Changeable During Run — <b>Yes</b> Minimum — 2 Maximum — 32

<b>Time-Based Alternation Process Hold Mode Response Time</b> Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation  During <b>Time-Based Alternation</b> operation, while running in the <b>Process Hold</b> mode, this parameter sets the time that the system may operate within the maximum or minimum <b>VLP</b> zones before turning the ASD on or off, respectively.	<b>Direct Access Number — F438</b> Parameter Type — <b>Numerical</b> Factory Default — <b>7.5</b> Changeable During Run — <b>No</b> Minimum — 0.0 Maximum — 6553.5 Units — Seconds
<b>Time-Based Alternation Direct Mode Response Time</b> Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation  During <b>Time-Based Alternation</b> operation, while running in the <b>Direct</b> mode, this parameter sets the time that the system may operate within the maximum or minimum <b>VLP</b> zones before turning the ASD on or off, respectively.	<b>Direct Access Number — F439</b> Parameter Type — <b>Numerical</b> Factory Default — <b>1000</b> Changeable During Run — <b>No</b> Minimum — 0 Maximum — 65535 Units — Seconds
<b>Power Running Torque Limit 1</b> Program ⇒ Torque ⇒ Torque Limit Settings  This parameter determines the source of the control signal for the positive torque limit setting.  If <b>Setting</b> is selected, the value set at <a href="#">F441</a> is used as the <b>Power Running Torque Limit 1</b> input.  Settings: 1 — V/I 2 — RR 3 — RX 4 — <a href="#">F441</a> (Setting)	<b>Direct Access Number — F440</b> Parameter Type — <b>Selection List</b> Factory Default — <a href="#">F441</a> (Setting) Changeable During Run — <b>Yes</b>
<b>Power Running Torque Limit 1 Level</b> Program ⇒ Torque ⇒ Torque Limit Settings  This parameter provides a value for the <b>Power Running Torque Limit 1</b> setting if <a href="#">F441</a> is selected at parameter <a href="#">F440</a> . This value provides the positive torque upper-limit for the 1 motor.	<b>Direct Access Number — F441</b> Parameter Type — <b>Numerical</b> Factory Default — <b>250.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
<b>Regenerative Braking Torque Limit 1</b> Program ⇒ Torque ⇒ Torque Limit Settings  This parameter determines the source of the <b>Regenerative Torque Limit</b> control signal.  If <b>Setting</b> is selected, the value set at <a href="#">F443</a> is used for this parameter.  Settings: 1 — V/I 2 — RR 3 — RX 4 — <a href="#">F443</a> (Setting)	<b>Direct Access Number — F442</b> Parameter Type — <b>Selection List</b> Factory Default — <a href="#">F443 Setting</a> Changeable During Run — <b>Yes</b>



<b>Regenerative Braking Torque Limit 1 Level</b> Program ⇒ Torque ⇒ Torque Limit Settings  This parameter provides a value to be used as the <b>Regeneration Torque Limit 1</b> if <b>F443</b> is selected at parameter <b>F442</b> . Set this parameter to <b>250%</b> to disable this function.	<b>Direct Access Number — F443</b> Parameter Type — <b>Numerical</b> Factory Default — <b>250.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 249.9 Units — %
<b>Power Running Torque Limit 2 Level</b> Program ⇒ Torque ⇒ Manual Torque Limit Settings  This parameter is used to set the positive torque upper-limit for the 2 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles. Set this parameter to <b>250%</b> to disable this function.	<b>Direct Access Number — F444</b> Parameter Type — <b>Numerical</b> Factory Default — <b>250.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
<b>Regenerative Braking Torque Limit 2 Level</b> Program ⇒ Torque ⇒ Manual Torque Limit Settings  This parameter is used to set the negative torque upper-limit for the 2 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles. Set this parameter to <b>250%</b> to disable this function.	<b>Direct Access Number — F445</b> Parameter Type — <b>Numerical</b> Factory Default — <b>250.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
<b>Power Running Torque Limit 3 Level</b> Program ⇒ Torque ⇒ Manual Torque Limit Settings  This parameter is used to set the positive torque upper-limit for the 3 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles. Set this parameter to <b>250%</b> to disable this function.	<b>Direct Access Number — F446</b> Parameter Type — <b>Numerical</b> Factory Default — <b>250.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
<b>Regenerative Braking Torque Limit 3 Level</b> Program ⇒ Torque ⇒ Manual Torque Limit Settings  This parameter is used to set the negative torque upper-limit for the 3 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles. Set this parameter to <b>250%</b> to disable this function.	<b>Direct Access Number — F447</b> Parameter Type — <b>Numerical</b> Factory Default — <b>250.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
<b>Power Running Torque Limit 4 Level</b> Program ⇒ Torque ⇒ Manual Torque Limit Settings  This parameter is used to set the positive torque upper-limit for the 4 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles. Set this parameter to <b>250%</b> to disable this function.	<b>Direct Access Number — F448</b> Parameter Type — <b>Numerical</b> Factory Default — <b>250.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %

<p><b>Regenerative Braking Torque Limit 4 Level</b></p> <p>Program ⇒ Torque ⇒ Manual Torque Limit Settings</p> <p>This parameter is used to set the negative torque upper-limit for the 4 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p> <p>Set this parameter to <b>250%</b> to disable this function.</p>	<p><b>Direct Access Number — F449</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0 (Disabled)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p><b>VLP Low Suction/No-Flow Cut Off Fault Disposition</b></p> <p>Program ⇒ Virtual Linear Pump ⇒ Low Suction/No-Flow Cut Off</p> <p>This parameter is used in conjunction with the setting of parameter <a href="#">F483</a>.</p> <p>If <b>On (Physical Switch)</b> or <b>On (Electronic Switch)</b> is selected at parameter <a href="#">F483</a>, then this parameter selection sets the disposition of the system in the event of a <b>Low Suction/No-Flow Cut Off</b> condition that exists for the duration of the parameter <a href="#">F484</a> setting.</p> <p>If <b>Off</b> is selected at parameter <a href="#">F483</a>, then this parameter selection is ignored.</p> <p>If Alarm i</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — Trip</li> <li>1 — Alarm</li> <li>2 — Alarm and Restart at <a href="#">F484</a> Interval</li> </ul>	<p><b>Direct Access Number — F450</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Trip</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Accel/Decel Operation After Torque Limit</b></p> <p>Program ⇒ Torque ⇒ Torque Limit Settings</p> <p>In a Crane/Hoist application that is operating using a mechanical brake, this parameter is used to minimize the delay between the brake release and the output torque reaching a level that can sustain the load.</p> <p>This setting may reference time or the operating speed of the motor.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — In Sync with Accel/Decel</li> <li>1 — In Sync with Minimum Time</li> </ul>	<p><b>Direct Access Number — F451</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>In Sync with Accel/Decel</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Power Running Stall Continuous Trip Detection Time</b></p> <p>Program ⇒ Protection ⇒ Stall</p> <p>This parameter is used to extend the <b>Over-Voltage Stall</b> (<a href="#">F305</a>) and the <b>Over-Current Stall</b> (<a href="#">F017</a>) time settings.</p>	<p><b>Direct Access Number — F452</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 1.0</p> <p>Units — Seconds</p>

<b>Stall Prevention During Regeneration</b> Program ⇒ Protection ⇒ Stall  This function of this parameter is to disable the <b>Over-Voltage Stall (F305)</b> and the <b>Over-Current Stall (F017)</b> function during regeneration <u>only</u> . Application-specific conditions may occur that warrant disabling the <b>Stall</b> function during regeneration.  Settings: 0 — Disabled (Stall During Regenerative Braking) 1 — Enabled (No Stall During Regenerative Braking)	<b>Direct Access Number — F453</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Enabled</b> Changeable During Run — <b>Yes</b>
<b>Time-Based Alternation Direct Mode Emergency Setpoint</b> Program ⇒ Virtual Linear Pump ⇒ VLP Time-Based Alternation  During <b>Time-Based Alternation</b> operation, while running in the <b>Direct</b> mode, this parameter sets the <b>VLP</b> setpoint.	<b>Direct Access Number — F456</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — <a href="#">F394</a> Setting Maximum — <a href="#">F395</a> Setting Units — %
<b>Current Control Proportional Gain</b> Program ⇒ Feedback ⇒ PG Settings  This parameter sets the sensitivity of the ASD when monitoring the output current to control speed. The larger the value entered here, the more sensitive the ASD is to changes in the received feedback.	<b>Direct Access Number — F458</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 0.0 Maximum — 100.0
<b>Speed Loop Proportional Gain</b> Program ⇒ Feedback ⇒ PG Settings  During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control. The larger the value entered here, the larger the change in the output speed for a given received feedback signal.	<b>Direct Access Number — F460</b> Parameter Type — <b>Numerical</b> Factory Default — <b>12</b> Changeable During Run — <b>No</b> Minimum — 1 Maximum — 9999
<b>Speed Loop Stabilization Coefficient</b> Program ⇒ Feedback ⇒ PG Settings  During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control. The larger the value entered here, the quicker the response to changes in the received feedback.	<b>Direct Access Number — F461</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100</b> Changeable During Run — <b>Yes</b> Minimum — 1 Maximum — 9999
<b>Load Moment of Inertia 1</b> Program ⇒ Feedback ⇒ PG Settings  This parameter is used for calculating accel/decel torque when compensating for load inertia while operating in the <b>Drooping Control</b> mode.	<b>Direct Access Number — F462</b> Parameter Type — <b>Numerical</b> Factory Default — <b>35</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 100

<b>Second Speed Loop Proportional Gain</b> Program ⇒ Feedback ⇒ PG Settings  During closed-loop operation, this parameter sets the sensitivity of the ASD when monitoring the output speed for control.  The larger the value entered here, the more sensitive the ASD is to changes in the received feedback.	<b>Direct Access Number — F463</b> Parameter Type — <b>Numerical</b> Factory Default — <b>12</b> Changeable During Run — <b>No</b> Minimum — 1 Maximum — 9999
<b>Second Speed Loop Stabilization Coefficient</b> Program ⇒ Feedback ⇒ PG Settings  During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control.  The larger the value entered here, the quicker the response to changes in the received feedback.	<b>Direct Access Number — F464</b> Parameter Type — <b>Numerical</b> Factory Default — <b>1</b> Changeable During Run — <b>Yes</b> Minimum — 1 Maximum — 9999
<b>Load Moment of Inertia 2</b> Program ⇒ Feedback ⇒ PG Settings  This parameter is used for calculating accel/decel torque when compensating for load inertia while operating in the <b>Drooping Control</b> mode.	<b>Direct Access Number — F465</b> Parameter Type — <b>Numerical</b> Factory Default — <b>35</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 100
<b>Speed PID Switching Frequency</b> Program ⇒ Feedback ⇒ Feedback Settings  While running, this parameter establishes the threshold speed setting that is used to determine if PID control may engage or remain engaged if active.	<b>Direct Access Number — F466</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>V/I Input Bias</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine-tune the bias of the <b>V/I</b> input terminals.  <b>Note:</b> See note on <a href="#">pg. 50</a> for more information on the <b>V/I</b> terminal.  This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.  This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.	<b>Direct Access Number — F470</b> Parameter Type — <b>Numerical</b> Factory Default — <b>141</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255

<b>V/I Input Gain</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the gain of the <b>V/I</b> input terminals.  <i>Note:</i> See note on <a href="#">pg. 50</a> for more information on the <b>V/I</b> terminal.  This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.  This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	<b>Direct Access Number — F471</b> Parameter Type — <b>Numerical</b> Factory Default — <b>129</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255
<b>RR Input Bias</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the bias of the <b>RR</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.  This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.	<b>Direct Access Number — F472</b> Parameter Type — <b>Numerical</b> Factory Default — <b>128</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255
<b>RR Input Gain</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the gain of the <b>RR</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.  This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	<b>Direct Access Number — F473</b> Parameter Type — <b>Numerical</b> Factory Default — <b>154</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255
<b>RX Input Bias</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the bias of the <b>RX</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.  This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.	<b>Direct Access Number — F474</b> Parameter Type — <b>Numerical</b> Factory Default — <b>127</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255

<b>RX Input Gain</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the gain of the <b>RX</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.  This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	<b>Direct Access Number — F475</b> Parameter Type — <b>Numerical</b> Factory Default — <b>127</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255
<b>RX2 (AI1) Input Bias</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the bias of the <b>RX2 (AI1)</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.  This is accomplished by setting the input source to zero and adjusting this setting to provide a zero output from the ASD.	<b>Direct Access Number — F476</b> Parameter Type — <b>Numerical</b> Factory Default — <b>128</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255
<b>RX2 (AI1) Input Gain</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the gain of the <b>RX2 (AI1)</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.  This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	<b>Direct Access Number — F477</b> Parameter Type — <b>Numerical</b> Factory Default — <b>128</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255
<b>AI2 (Option V/I) Input Bias</b> Program ⇒ Frequency ⇒ Speed Reference Setpoints  This parameter is used to fine tune the gain of the <b>Optional AI2</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> mode or the <b>Torque Control</b> mode.  This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.  This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	<b>Direct Access Number — F478</b> Parameter Type — <b>Numerical</b> Factory Default — <b>128</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255

---

**AI2 (Option V/I) Input Gain**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to fine tune the gain of the **Optional AI2** input terminal when this terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.

This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.

**Direct Access Number — F479**

**Parameter Type — Numerical**

**Factory Default — 128**

**Changeable During Run — Yes**

**Minimum — 0**

**Maximum — 255**

**VLP External Device Delay Timer**

Virtual Linear Pump ⇒ External Device Delay Timer

During a properly configured **VLP** operation, this parameter establishes the time that the **VLP** operating level must remain within the **VLP Maximum Zone** or the **VLP Minimum Zone** to activate/deactivate the **Sleep Timer (F382)** or an auxiliary pump.

See **Figures 31** and **32** for more information on the **VLP Maximum Zone** and **VLP Minimum Zone**.

**Increasing Load**

If the **VLP** operating level of the Lead Pump is within the **VLP Maximum Zone**, and the **External Device Delay Timer** times out, **OUT1** will change states and activate an auxiliary pump (Lag1).

Should the **VLP** operating level return to the **VLP Maximum Zone** for a duration in excess of the **External Device Delay Timer**, **OUT2** will change states and activate the second auxiliary pump (Lag2).

**Decreasing Load**

If operating in the **VLP Minimum Zone**, and the **External Device Delay Timer** times out while **OUT2** is activated, **OUT2** will change states and deactivate the second auxiliary pump (Lag2).

Should the system return to the **VLP Minimum Zone** for a duration in excess of the **External Device Delay Timer**, **OUT1** will change states and deactivate the auxiliary pump (Lag1).

**Note:** Set the **Sleep Timer Delay (F383)** to two (2) times the **VLP External Device Delay Timer** (if using the **Sleep Timer** function) as not to place the primary ASD in the sleep mode with Lag1 and/or Lag2 running.

**Note:** Set **OUT1** and **OUT2** to **External Device 1** and **2**, respectively, as required.

**Direct Access Number — F480**Parameter Type — **Numerical**Factory Default — **5**Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6553.5

Units — Seconds

Auxiliary Pump Activation Sequence				
PUMP ID	IF @	AND	THEN	OR
Lead Pump	Max Zone	Counter Time = 0	Activate OUT1	
Lag1 Pump	Max Zone	Counter Time = 0	Activate OUT2	
Lag2 Pump	Max Zone	Counter Time = 0	Run Continuous	
Lag2 Pump	Min Zone	Counter Time = 0	Deactivate OUT2	
Lag1 Pump	Min Zone	Counter Time = 0	Deactivate OUT1	
Lead Pump	Min Zone	Counter Time = 0	—	Sleep if enabled

**Note:** The number of pumps used may be increased by using the optional expansion board (Primary pump plus auxiliary pumps).



<b>VLP Low Band Threshold</b> Virtual Linear Pump ⇒ Low Band Threshold  During a properly configured <b>VLP</b> operation, this parameter establishes the upper limit of the <b>VLP Minimum Zone</b> . See <a href="#">F480</a> for more information on this parameter.	<b>Direct Access Number — F481</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 30
<b>VLP High Band Threshold</b> Virtual Linear Pump ⇒ High Band Threshold  This parameter sets the lower limit of the <b>VLP Maximum Zone</b> . See <a href="#">F480</a> for more information on this parameter.	<b>Direct Access Number — F482</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 30
<b>VLP Low Suction/No-Flow Cut Off Pressure Mode</b> Virtual Linear Pump ⇒ Low Suction Pressure Mode  This parameter is used to halt the ASD in the event of the loss of feed water to the pump or if there is a closed output valve at the pump output. A low-pressure suction switch may be used to detect the loss of feed water by opening or closing a circuit in the event of feed water loss. The switch state change would result in the activation of a discrete input terminal (set to <b>Low Suction/No Flow Protection</b> ) resulting in an <b>AbFL</b> trip. Either a closed output valve or a suction pressure loss will result in the ASD running at the <b>Upper-Limit Frequency</b> indefinitely. To monitor the <b>Upper-Limit Frequency</b> run time for either condition, set <a href="#">F484</a> for the time that the ASD may output the <b>Upper-Limit Frequency</b> continuously before the system initiates an <b>AbFL</b> trip. Set this parameter to <b>On (Physical Switch)</b> if using a discrete input terminal for detection. Set this parameter to <b>On (Electronic Switch)</b> if using the <b>Upper Limit</b> run-time for detection — set the run-time limit at <a href="#">F484</a> .  <i><b>Note:</b> The <b>On (Electronic Switch)</b> setting allows for the availability of the <b>Trip (0)</b> and <b>Alarm (1)</b> selections at <a href="#">F450</a> ONLY.</i>  Settings: 0 — Off 1 — On (Physical Switch) 2 — On (Electronic Switch; <a href="#">F484</a> Setting)	<b>Direct Access Number — F483</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Off</b> Changeable During Run — <b>Yes</b>

### Low Suction Pressure Delay Timer

Virtual Linear Pump ⇒ Low Suction Pressure Delay Timer

This parameter has three functions.

1. It is used to set the time that the ASD will be allowed to run at the **Upper-Limit Frequency** continuously before the system is turned off.  
This condition is used as an indication of loss of feed water or a closed output valve. See [F483](#) for more information on this function.
2. It is used to set the time that a **Low Suction/No Flow** condition is allowed to continue before a shut down.
3. It is used to set the time that must lapse before a system restart is attempted after a system shut down due to a **Low Suction/No Flow** condition. See [F450](#) for more information on this function.

**Direct Access Number — F484**

Parameter Type — **Numerical**

Factory Default — **10**

Changeable During Run — **Yes**

Minimum — **1**

Maximum — **255**

Units — **Seconds**

### Sealing Water/Vacuum Prime Enable

Virtual Linear Pump ⇒ Sealing Water/Vacuum Prime Enable

This parameter **Enables/Disables** seal water detection.

On larger or older pumps external sealing water is required at start up. Until adequately supplied with sealing water the ASD will not start.

An external sealing water pump is required to supply sealing water and is enabled via an ASD output contactor set to [Sealing Water](#).

Normal ASD operations are allowed once an adequate water supply is detected at the seal, as detected by a pump-mounted reed switch that is connected to a discrete input terminal of the ASD.

Set the discrete input terminal to [Sealing Water](#).

Settings:

0 — Disabled

1 — Enabled

**Direct Access Number — F485**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

### Direct Operation VLP Command Value via Communications

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

During a properly configured **VLP** operation while operating in the **Direct** mode and using communications for system control, this parameter establishes the **VLP** level.

This parameter setting is effective **ONLY** while operating in the **Direct** mode and while receiving a command via communications. The end value of this parameter setting appears in the **Frequency Command** screen as shown below.

**Direct Access Number — F486**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **10**

Maximum — **165**


0 ————— 100%	
SET: 0.00 Hz	
VLP Technology Avg:	0%
V/I Input:	0.00%
F R ST RES S1 S2 S3 S4	
OUT1 OUT2 FL	

### Process Hold Operation VLP Command Value via Communications

Program ⇒ Virtual Linear Pump ⇒ VLP Settings

During a properly configured **VLP** operation while operating in the **Process Hold** mode and using communications for system control, this parameter establishes the **VLP** level.

This parameter setting is effective **ONLY** while operating in the **Process Hold** mode and while receiving a command via communications. The end value of this parameter setting appears in the **Frequency Command** screen as shown below.



Direct Access Number — F487

Parameter Type — Numerical

Factory Default — 0.0

Changeable During Run — Yes

Minimum — F403 Setting

Maximum — F393 Setting

### Permanent Magnet (PM) Motor Constant 1

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact the TIC Customer Support Center for information on this parameter.

Direct Access Number — F498

Parameter Type — Numerical

Factory Default — 100

Changeable During Run — Yes

Minimum — 0

Maximum — 100

Units — %

### Permanent Magnet (PM) Motor Constant 2

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact the TIC Customer Support Center for information on this parameter.

Direct Access Number — F499

Parameter Type — Numerical

Factory Default — 100

Changeable During Run — Yes

Minimum — 0

Maximum — 100

Units — %

### Acceleration Time 2

Program ⇒ Special ⇒ Acc/Dec 1 – 4 Settings

This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** for the **2 Acceleration** profile. The Accel/Decel pattern may be set using F502. The minimum Accel/Decel time may be set using F508.

This setting may be adjusted to stabilize unstable **VLP** operation.

This setting is also used to determine the acceleration rate of the **UP/DOWN Frequency Functions**.

**Note:** An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel, Stall, and Ridethrough** settings may lengthen the acceleration times.

Direct Access Number — F500

Parameter Type — Numerical

Factory Default — (ASD-Dependent)

Changeable During Run — Yes

Minimum — 0.1

Maximum — 6000.0

Units — Seconds

**Deceleration Time 2**

Program ⇒ Fundamental ⇒ Accel/Decel 1 Settings

This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **2 Deceleration** profile. The Accel/Decel pattern may be set using [F502](#). The minimum Accel/Decel time may be set using [F508](#).

This setting may be adjusted to stabilize unstable **VLP** operation.

This setting is also used to determine the deceleration rate of the **UP/DOWN Frequency Functions**.

***Note:** A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the deceleration times.*

**Direct Access Number — F501**

Parameter Type — **Numerical**

Factory Default — **(ASD-Dependent)**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

## Acceleration/Deceleration Pattern 1

Program  $\Rightarrow$  Special  $\Rightarrow$  Accel/Decel 1 – 4 Settings


This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the **1 Accel/Decel** parameters (See F009 and F010).

Settings:


- 0 — Linear
- 1 — S-Pattern 1
- 2 — S-Pattern 2

The figures below provide a profile of the available accel/decel patterns.


**Linear** acceleration and deceleration is the default pattern and is used on most applications.



**S-pattern 1** is used for applications that require quick acceleration and deceleration. This setting is also popular for applications that require shock absorption at the start of acceleration or deceleration.



**S-pattern 2** decreases the rate of change above the base frequency for acceleration and deceleration.



---

**Acc/Dec Pattern 2**

Program ⇒ Special ⇒ Accel/Decel 1 – 4 Settings

This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the **2 Accel/Decel** parameter.

Settings:

- 0 — Linear
- 1 — S-Pattern 1
- 2 — S-Pattern 2

**Direct Access Number — F503**

Parameter Type — **Selection List**

Factory Default — **Linear**

Changeable During Run — **Yes**

**Acc/Dec Pattern 1 – 4**

Program ⇒ Special ⇒ Acc/Dec Special

Four Acceleration times and four Deceleration times may be set up and run individually. **Accel/Decel Time 1 – 4** may be selected using this parameter setting or switched via threshold frequencies, or by discrete input terminal.

This parameter is used to select one of the four configured accel/decel profiles to be used.

Settings:

- 1 — Acc/Dec 1
- 2 — Acc/Dec 2
- 3 — Acc/Dec 3
- 4 — Acc/Dec 4

Each Accel/Decel selection is comprised of an **Acceleration Time**, **Deceleration Time**, and a **Pattern** selection. Selection 1, 2, and 3 have a **Switching Frequency** setting. The **Switching Frequency** is used as a threshold frequency that, once reached, the ASD switches to the next higher **Acc/Dec** selection (i.e., 1 to 2, 2 to 3, or 3 to 4). **Switching Frequency** settings are also used during deceleration. A switching frequency setting is not required for **Acc/Dec 4**.

**Acc/Dec 1** is set up using parameters **F009** (Acc Time), **F010** (Dec Time), **F502** (Pattern), and **F505** (Switching Frequency).

**Acc/Dec 2** is set up using parameters **F500** (Acc Time), **F501** (Dec Time), **F503** (Pattern), and **F513** (Switching Frequency).

**Acc/Dec 3** is set up using parameters **F510** (Acc Time), **F511** (Dec Time), **F512** (Pattern), and **F517** (Switching Frequency).

**Acc/Dec 4** is set up using parameters **F514** (Acc Time), and **F515** (Dec Time), **F516** (Pattern).

This parameter (**F504**) is used to manually select **Acc/Dec 1 – 4**.

To switch using the **Terminal Board**, assign the functions **Acc/Dec Switching 1** and **Acc/Dec Switching 2** to two discrete input terminals. Activation combinations of the two terminals result in the **Acc/Dec 1 – 4** selections as shown in **Table 5**.

**Figure 37** shows the setup requirements and the resulting output frequency response when using **Switching Frequency** settings to control the **Acc/Dec** response of the ASD output.

While operating using **S-Pattern 1** the system performance may be further enhanced by the adjustment of parameters **F506 – F509**. These settings provide for upper and lower **Acc/Dec** limit adjustments. These settings are used to extend or shorten the upper or lower **Acc/Dec** curve.

**Note:** If operating from the **Hand mode**, press **Esc** from the **Frequency Command** screen to access this parameter.

Direct Access Number — **F504**

Parameter Type — **Selection List**


Factory Default — **1**

Changeable During Run — **Yes**

Table 5. Using combinations of discrete terminal activations Accel/Decel profiles 1 – 4 may be selected.

Acc/Dec Switching Truth Table		
A/D SW 1	A/D SW 2	Acc/Dec # Out
0	0	1
0	1	2
1	0	3
1	1	4
1 = Discrete terminal activation.		

Figure 37. Using Acc/Dec Switching.



- 1 — Accel time 1 (**F009** setting)
- 2 — Accel time 2 (**F500** setting)
- 3 — Accel time 3 (**F510** setting)
- 4 — Accel time 4 (**F514** setting)
- 5 — Decel time 4 (**F515** setting)
- 6 — Decel time 3 (**F511** setting)
- 7 — Decel time 2 (**F501** setting)
- 8 — Decel time 1 (**F010** setting)

**Accel/Decel Switching Frequency 1**

Program ⇒ Special ⇒ Accel/Decel Special

This parameter sets the frequency at which the acceleration control is switched from the **Accel 1** profile to the **Accel 2** profile during a multiple-acceleration profile configuration.

Direct Access Number — **F505**

Parameter Type — **Numerical**

Factory Default — **30.00**

Changeable During Run — **Yes**

Minimum — **0.00**

Maximum — **Max. Freq. (F011)**

Units — **Hz**

<b>S-Pattern Acceleration Lower-Limit Adjustment</b> Program ⇒ Special ⇒ Accel/Decel Special  During an <b>S-Pattern 1</b> or <b>2</b> sequence, this parameter settings modifies the acceleration rate for the lower part of the acceleration curve by the percentage set here.  This function is commonly used with transportation and lifting applications. See parameter <a href="#">F502 on pg. 181</a> for more information on this setting.	<b>Direct Access Number — F506</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 50 Units — %
<b>S-Pattern Acceleration Upper-Limit Adjustment</b> Program ⇒ Special ⇒ Accel/Decel Special  During an <b>S-Pattern 1</b> or <b>2</b> sequence, this parameter settings modifies the acceleration rate for the upper part of the acceleration curve by the percentage set here.  This function is commonly used with transportation and lifting applications. See parameter <a href="#">F502 on pg. 181</a> for more information on this setting.	<b>Direct Access Number — F507</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 50 Units — %
<b>S-Pattern Deceleration Lower-Limit Adjustment</b> Program ⇒ Special ⇒ Accel/Decel Special  During an <b>S-Pattern 1</b> or <b>2</b> sequence, this parameter settings modifies the deceleration rate for the lower part of the deceleration curve by the percentage set here.  This function is commonly used with transportation and lifting applications. See parameter <a href="#">F502 on pg. 181</a> for more information on this setting.	<b>Direct Access Number — F508</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 50 Units — %
<b>S-Pattern Deceleration Upper-Limit Adjustment</b> Program ⇒ Special ⇒ Accel/Decel Special  During an <b>S-Pattern 1</b> or <b>2</b> sequence, this parameter settings modifies the deceleration rate for the upper part of the deceleration curve by the percentage set here.  This function is commonly used with transportation and lifting applications. See parameter <a href="#">F502 on pg. 181</a> for more information on this setting.	<b>Direct Access Number — F509</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 50 Units — %
<b>Acceleration Time 3</b> Program ⇒ Special ⇒ Accel/Decel 1 – 4 Settings  This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the <b>Maximum Frequency</b> for the <b>3 Acceleration</b> profile. The Accel/Decel pattern may be set using <a href="#">F502</a> . The minimum Accel/Decel time may be set using <a href="#">F508</a> .  <b>Note:</b> <i>An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. <b>Automatic Accel/Decel</b>, <b>Stall</b>, and <b>Ridethrough</b> settings may lengthen the acceleration times.</i>	<b>Direct Access Number — F510</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000 Units — Seconds



<p><b>Deceleration Time 3</b></p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4 Settings</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from the <b>Maximum Frequency</b> to 0.0 Hz for the <b>3 Deceleration</b> profile.</p> <p>The Accel/Decel pattern may be set using <a href="#">F502</a>. The minimum Accel/Decel time may be set using <a href="#">F508</a>.</p> <p><b>Note:</b> <i>A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. <b>Automatic Accel/Decel</b>, <b>Stall</b>, and <b>Ridethrough</b> settings may lengthen the deceleration times.</i></p>	<p><b>Direct Access Number — F511</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-Dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p><b>Acceleration/Deceleration Pattern 3</b></p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4 Settings</p> <p>This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the <b>3 Accel/Decel</b> parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — Linear</li> <li>1 — S-Pattern 1</li> <li>2 — S-Pattern 2</li> </ul>	<p><b>Direct Access Number — F512</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Linear</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Acceleration/Deceleration Switching Frequency 2</b></p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>This parameter sets the frequency at which the acceleration control is switched from the <b>Accel 2</b> profile to the <b>Accel 3</b> profile during a multiple-acceleration profile configuration.</p>	<p><b>Direct Access Number — F513</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Max. Freq. (F011)</b></p> <p>Units — Hz</p>
<p><b>Acceleration Time 4</b></p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4 Settings</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the <b>Maximum Frequency</b> for the <b>4 Acceleration</b> profile. The Accel/Decel pattern may be set using <a href="#">F502</a>. The minimum Accel/Decel time may be set using <a href="#">F508</a>.</p> <p><b>Note:</b> <i>An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. <b>Automatic Accel/Decel</b>, <b>Stall</b>, and <b>Ridethrough</b> settings may lengthen the acceleration times.</i></p>	<p><b>Direct Access Number — F514</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-Dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>

**Deceleration Time 4**

Program ⇒ Special ⇒ Accel/Decel 1 – 4 Settings

This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **4 Deceleration** profile. The Accel/Decel pattern may be set using [F502](#). The minimum Accel/Decel time may be set using [F508](#).

**Note:** A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel, Stall, and Ridethrough** settings may lengthen the deceleration times.

**Direct Access Number — F515**Parameter Type — **Numerical**Factory Default — **(ASD-Dependent)**Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

**Acceleration/Deceleration Pattern 4**

Program ⇒ Special ⇒ Accel/Decel 1 – 4 Settings

This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the **4 Accel/Decel** parameter.

Settings:

0 — Linear

1 — S-Pattern 1

2 — S-Pattern 2

**Direct Access Number — F516**Parameter Type — **Selection List**Factory Default — **Linear**Changeable During Run — **Yes****Acceleration/Deceleration Switching Frequency 3**

Program ⇒ Special ⇒ Accel/Decel Special

This parameter sets the frequency at which the acceleration control is switched from the **Accel 3** profile to the **Accel 4** profile during a multiple-acceleration profile configuration.

**Direct Access Number — F517**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

**Pattern Operation Selection**

Program ⇒ Pattern Run ⇒ Pattern Run

**Pattern Run** operation is enabled by selecting **Seconds** or **Minutes** as a unit of measure for the **Operation Time** setting for the selected **Preset Speeds**.

See Parameter [F523](#) for more information on **Selections** and **Group Speeds** setup.

Settings:

0 — Disabled

1 — Enabled (Units in Seconds)

2 — Enabled (Units in Minutes)

**Direct Access Number — F520**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **No****Pattern Operation Mode**

Program ⇒ Pattern Run ⇒ Pattern Run

This parameter sets the start condition of subsequent **Pattern Runs** after the initial **Pattern Run** has been terminated or has completed its programming.

Settings:

0 — Reset After Stop

1 — Continue After Stop

**Direct Access Number — F521**Parameter Type — **Selection List**Factory Default — **Reset After Stop**Changeable During Run — **No**

---

**Pattern 1 Repeat**

Program ⇒ Pattern Run ⇒ Pattern Run

This parameter sets the number of times to repeat the **Pattern Group 1**.

Settings:

- 1 = Once Then Stop
- 2 – 254 = Number of Repeats
- 255 = Infinite (Forever)

**Direct Access Number — F522**

Parameter Type — **Numerical**

Factory Default — **255 (Infinite)**

Changeable During Run — **No**

Minimum — 1

Maximum — 255 (Infinite)

Units — Repetitions

## Pattern Group 1 Selection 1

Program ⇒ Pattern Run ⇒ Speeds

Groups of configured **Preset Speeds** may be selected and run from this screen. The execution of grouped **Preset Speeds** in this manner is called a **Pattern Run**.

One to eight user-selected **Preset Speeds** may be run sequentially for a user-set number of repetitions. The group of user-selected **Preset Speeds** is called a **Pattern Group**. The **Pattern Run** function executes the user-set **Pattern Group**.

**Pattern Group 1** is comprised of up to 8 **Selections** with each **Selection** being 1 of 15 possible **Preset Speed** settings. **Skip** may be selected to ignore a **Selection**.

This parameter allows the user to choose one configured **Preset Speed** that is to be used as **Selection 1** (of 8) for **Pattern Group 1**. See F018 for information on configuring the individual **Preset Speeds**. Parameters F524 – F530 may be set up for subsequent **Selections 2 – 8**.

One **Preset Speed** number (1 – 15) or **Skip** is selected for **Selection 1** (F523). The number of times to repeat **Pattern Group 1** is selected at F522. Set this value to 255 to run forever.

Setup **Pattern Group 2** at F531 – F539 if more **Preset Speed** entries are required.

### Pattern Run Setup (for Pattern Group 1)

- From Program ⇒ Pattern Run ⇒ **Speeds**, select the **Preset Speeds** that are to be used as the **Pattern Group 1** set of **Selections**. Select a speed from the 1 – 15 configured presets; 1 speed number per **Selection**. Set any unused **Selections** to **Skip**.
- From Program ⇒ Pattern Run ⇒ Pattern Run ⇒ **Pattern Operation Selection**, enable the **Pattern Run** mode of operation by selecting **Seconds** or **Minutes** as the unit of measure for the **Operation Time** setting.
- From Program ⇒ Pattern Run ⇒ **Operation Time**, set the run-time for each **Preset Speed** selected in step 1.
- Configure two unused discrete input terminals for **Pattern Operation Group 1** and **Pattern Operation Trigger Signal**.

**Note:** Activation of the **Pattern Operation Group 1** discrete input terminal is required to enable **Pattern Group 1** for use.  
Activation of the **Pattern Operation Trigger Signal** discrete input terminal starts the **Pattern Group 1** pattern run.

- From Program ⇒ Pattern Run ⇒ Pattern Run ⇒ **Pattern 1 Repeat**, set to the number of times that **Pattern Group 1** is to be run. Set to 255 to run forever.
- From Program ⇒ Pattern Run ⇒ Pattern Run ⇒ **Pattern Operation Mode**, set the end-of-pattern command to **Reset** or **Continue**.
- From the **Hand** mode (**Hand/Auto** light is off), initiate a **Run** command (i.e., **F** and/or **R** terminal **On**).
- Connect the **Pattern Operation Group 1** input terminal to **CC**.
- Connect the **Pattern Operation Trigger Signal** input terminal to **CC** and the **Pattern Run** will start and continue as programmed.
- Open the **Pattern Operation Trigger Signal** connection to **CC** to stop the **Pattern Run** before its conclusion if required.

Direct Access Number — F523

Parameter Type — Selection List

Factory Default — Skip

Changeable During Run — No

Minimum — Skip

Maximum — 15

Units — Preset Speed Number

Pattern Group 1								
	Selection							
	F523	F524	F525	F526	F527	F528	F529	F530
	1	2	3	4	5	6	7	8
Preset Speed Number	Skip	Skip	Skip	Skip	Skip	Skip	Skip	Skip
	1	1	1	1	1	1	1	1
	2	2	2	2	2	2	2	2
	3	3	3	3	3	3	3	3
	4	4	4	4	4	4	4	4
	5	5	5	5	5	5	5	5
	6	6	6	6	6	6	6	6
	7	7	7	7	7	7	7	7
	8	8	8	8	8	8	8	8
	9	9	9	9	9	9	9	9
	10	10	10	10	10	10	10	10
	11	11	11	11	11	11	11	11
	12	12	12	12	12	12	12	12
	13	13	13	13	13	13	13	13
	14	14	14	14	14	14	14	14
	15	15	15	15	15	15	15	15

**Pattern Group 1 Selection 2**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **2 Selection** to be included in **Pattern Group 1**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F524**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 1 Selection 3**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **3 Selection** to be included in **Pattern Group 1**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F525**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 1 Selection 4**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **4 Selection** to be included in **Pattern Group 1**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F526**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 1 Selection 5**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **5 Selection** to be included in **Pattern Group 1**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F527**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No**

**Pattern Group 1 Selection 6**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **6 Selection** to be included in **Pattern Group 1**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F528**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 1 Selection 7**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **7 Selection** to be included in **Pattern Group 1**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F529**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 1 Selection 8**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **8 Selection** to be included in **Pattern Group 1**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F530**Parameter Type — **Numerical**Factory Default — **Skip**Changeable During Run — **No****Pattern 2 Repeat**

Program ⇒ Pattern Run ⇒ Pattern Run

This parameter sets the number of times to repeat the **Pattern Group 2**.

**Direct Access Number — F531**Parameter Type — **Numerical**Factory Default — **255 (Infinite)**Changeable During Run — **No**

Minimum — 1

Maximum — 255 (Infinite)

Units — Repetitions

**Pattern Group 2 Selection 1**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **1** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F532**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 2 Selection 2**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **2** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F533**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 2 Selection 3**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **3** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F534**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 2 Selection 4**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **4** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F535**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No**

**Pattern Group 2 Selection 5**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **5** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F536**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 2 Selection 6**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **6** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F537**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 2 Selection 7**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **7** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F538**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No****Pattern Group 2 Selection 8**

Program ⇒ Pattern Run ⇒ Speeds

This parameter allows the user to select 1 of 15 configured **Preset Speeds** as the number **8** selection to be included in the **Group 2 Selection**.

Skip may be selected to ignore this **Selection**.

Setting

0 — Skip

1 – 15 Preset Speed Number

See [F523](#) for more information on this parameter.

**Direct Access Number — F539**Parameter Type — **Selection List**Factory Default — **Skip**Changeable During Run — **No**



<b>Speed 1 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 1</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F540</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 2 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 2</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F541</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 3 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 3</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F542</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 4 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 4</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F543</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 5 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 5</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F544</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 6 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 6</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F545</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting

<b>Speed 7 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 7</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F546</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 8 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 8</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F547</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 9 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 9</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F548</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 10 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 10</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F549</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 11 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 11</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F550</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 12 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 12</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F551</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting

<b>Speed 13 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 13</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F552</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 14 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 14</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F553</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Speed 15 Operation Time</b> Program ⇒ Pattern Run ⇒ Operation Time  This parameter sets the run-time for <b>Preset Speed 15</b> . This time is effective when used with <b>Group Speeds</b> and non- <b>Group Speeds</b> . If the <b>Auto-Restart</b> function is activated, the search time required for the <b>Auto-Restart</b> function will be subtracted from the <b>Operation Time</b> setting; resulting in a shorter run time.	<b>Direct Access Number — F554</b> Parameter Type — <b>Numerical</b> Factory Default — <b>5.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.1 Maximum — 6000.0 Units — <a href="#">F520</a> Setting
<b>Preset Speed Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  This parameter is used to set the <b>Preset Speed</b> operating mode. Select <b>Disabled</b> at this parameter to use the speed command only for <b>Preset Speed</b> operation. Select <b>Enabled</b> at this parameter to apply the control settings of <a href="#">F561 – F575</a> to the associated <b>Preset Speed</b> while operating in the <b>Preset Speed</b> mode.  Settings: 0 — Disabled (Preset Speed Only) 1 — Enabled (Full Preset Speed Mode)	<b>Direct Access Number — F560</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>No</b>

## Preset Speed 1 Operation Mode

Program ⇒ Pattern Run ⇒ Operation Mode

This parameter is enabled at [F560](#) and is used to set the speed, torque, and direction of **Preset Speed 1**.

This screen is comprised of 4 fields that are labeled as follows: **Direction, Acc/Dec Group, V/f Group, and Torque Limit Group**. Scroll to the field of interest and press the scroll knob (Enter). Using the scroll knob, set the value and press the scroll knob (Enter).


Parameters [F562](#) – [F575](#) are used to set the functions listed here for **Preset Speeds 2 – 15**.

When using communications write the appropriate byte to location [F561](#) as indicated below.

Settings:

- 0 — Forward Run
- 1 — Reverse Run
- 2 — Accel/Decel Switching 1
- 4 — Accel/Decel Switching 2
- 8 — V/f Switching Signal 1
- 16 — V/f Switching Signal 2
- 32 — Torque Limit Switching Signal 1
- 64 — Torque Limit Switching Signal 2

Writing the following data to location [F561](#) via communications results in: Forward Run, A/D SW 2, V/f SW 3, Torque Lim SW 4.



## Preset Speed 2 Operation Mode

Program ⇒ Pattern Run ⇒ Operation Mode

Same as **Preset Speed 1 Operation Mode** (See [F561](#)).

**Direct Access Number — F562**

Parameter Type — **Selection List**

Factory Default — **Forward Run**

Changeable During Run — **No**

## Preset Speed 3 Operation Mode

Program ⇒ Pattern Run ⇒ Operation Mode

Same as **Preset Speed 1 Operation Mode** (See [F561](#)).

**Direct Access Number — F563**

Parameter Type — **Selection List**

Factory Default — **Forward Run**

Changeable During Run — **No**

<b>Preset Speed 4 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F564</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 5 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F565</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 6 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F566</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 7 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F567</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 8 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F568</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 9 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F569</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 10 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F570</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 11 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F571</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 12 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F572</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 13 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F573</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>

<b>Preset Speed 14 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F574</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Preset Speed 15 Operation Mode</b> Program ⇒ Pattern Run ⇒ Operation Mode  Same as <b>Preset Speed 1 Operation Mode</b> (See <a href="#">F561</a> ).	<b>Direct Access Number — F575</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Forward Run</b> Changeable During Run — <b>No</b>
<b>Motor Overload Protection Level 1</b> Program ⇒ Fundamental ⇒ Motor Set 1  This parameter specifies the motor overload current level for <b>Motor Set 1</b> . This value is entered as either a percentage of the full load rating of the ASD or as a percentage of the FLA of the motor.  The unit of measurement for this parameter may be set to <b>A/V</b> (Amps) or it may be set as a percentage of the ASD rating. The nameplated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (See <a href="#">F701</a> to change the display unit).  <b>Motor Overload Protection Level 1</b> settings will be displayed in <b>Amps</b> if the <b>EOI</b> display units are set to <b>A/V</b> rather than <b>%</b> .	<b>Direct Access Number — F600</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100</b> Changeable During Run — <b>Yes</b> Minimum — 10 Maximum — 100.0 Units — <b>%</b>
<b>Stall Prevention Level</b> Program ⇒ Protection ⇒ Stall  This parameter specifies the output current level at which the output frequency is reduced in an attempt to prevent a trip. The over-current level is entered as a percentage of the maximum rating of the ASD.  <i><b>Note:</b> The <b>Motor Overload Protection</b> parameter must be enabled at <a href="#">F017</a> to use this feature.</i>	<b>Direct Access Number — F601</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>Yes</b> Minimum — 10 Maximum — 165 Units — <b>%</b>
<b>Retain Trip Record at Power Down</b> Program ⇒ Protection ⇒ Trip Settings  This parameter <b>Enables/Disables</b> the <b>Trip Record Retention</b> setting. When enabled, this feature logs the trip event and retains the trip information when the system powers down. The trip information may be viewed from the (Program ⇒ Utilities ⇒) <b>Trip History</b> screen or the <b>Monitor</b> screen.  When disabled, the trip information will be cleared when the system powers down.  Settings: 0 — Disabled 1 — Enabled	<b>Direct Access Number — F602</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>

---

**Emergency Off Mode Settings**

Program ⇒ Protection ⇒ Emergency Off Settings

This parameter determines the method used to stop the motor in the event that an **Emergency Off** command is received and the system is configured to use this feature.

This setting may also be associated with the **FL** terminals to allow the **FL** relay to change states when an **EOFF** condition occurs by setting the **FL** terminal to **Fault FL (all)** (See [F132](#)).

**Note:** *A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.*

Settings:

- 0 — Coast Stop
- 1 — Deceleration Stop
- 2 — DC Injection Braking Stop
- 3 — Deceleration Stop (Decel 4 setting; [F515](#))

---

**Emergency Off DC Injection Application Time**

Program ⇒ Protection ⇒ Emergency Off Settings

When **DC Injection** is selected at [F603](#) this parameter determines the time that the **DC Injection Braking** is applied to the motor.

---

**ASD Output Phase Failure Detection**

Program ⇒ Protection ⇒ Phase Loss

This parameter **Enables/Disables** the monitoring of each phase of the 3-phase output signal (U, V, or W) of the ASD. If either line is missing, inactive, or not of the specified level for one second or more, the ASD incurs a trip.

**Note:** *Autotune checks for phase failures regardless of this setting.*

Settings:

- 0 — Disabled (No Detection)
- 1 — Enabled (Run at Startup and Retry)
- 2 — Enabled (Every Run Command and Retry)
- 3 — Enabled (During Run)
- 4 — Enabled (At Startup and During Run)
- 5 — Enabled (Detects an ALL-PHASE Failure ONLY - Will Not Trip, Restarts At Reconnect)

**Direct Access Number — F603**

Parameter Type — **Selection List**

Factory Default — **Coast Stop**

Changeable During Run — **No**

---

**Direct Access Number — F604**

Parameter Type — **Numerical**

Factory Default — **1.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 20.0

Units — Seconds

---

**Direct Access Number — F605**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**



<p><b>Overload Reduction Starting Frequency</b></p> <p>Program ⇒ Protection ⇒ Overload</p> <p>This parameter is primarily used with V/f motors. It is used to reduce the starting frequency at which the <b>Overload Reduction</b> function begins and is useful during extremely low-speed motor operation.</p> <p>During very low-speed operation the cooling efficiency of the motor decreases. Lowering the start frequency of the <b>Overload Reduction</b> function aides in minimizing the generated heat and precluding an <b>Overload</b> trip.</p> <p>This function is useful in loads such as fans, pumps, and blowers that have the square reduction torque characteristic.</p> <p>Set parameter <a href="#">F607</a> to the desired <b>Overload Time Limit</b>.</p>	<p><b>Direct Access Number — F606</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>6.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 30.00</p> <p>Units — Hz</p>
<p><b>Motor 150% Overload Time Limit</b></p> <p>Program ⇒ Protection ⇒ Overload</p> <p>This parameter establishes a time that the motor may operate at 150% of its rated current before tripping. This setting applies the time/150% reference to the individual settings of each motor (e.g., this setting references 150% of the <a href="#">F600</a> setting for the 1 motor).</p> <p>The unit will trip sooner than the time entered here if the overload is greater than 150%.</p>	<p><b>Direct Access Number — F607</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>300</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10</p> <p>Maximum — 2400</p> <p>Units — Seconds</p>
<p><b>ASD Input Phase Failure Detection</b></p> <p>Program ⇒ Protection ⇒ Phase Loss</p> <p>This parameter enables the 3-phase input power phase loss detection feature. A loss of either input phase (R, S, or T) results in a trip.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — Disabled</li> <li>1 — Enabled</li> </ul>	<p><b>Direct Access Number — F608</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Enabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Low-Current Detection Current Hysteresis Width</b></p> <p>Program ⇒ Protection ⇒ Low-Current Settings</p> <p>During a momentary low-current condition, this parameter provides a current threshold level to which the low-current condition must return within the time setting of <a href="#">F612</a> or a <b>Low-Current Trip</b> will be incurred.</p>	<p><b>Direct Access Number — F609</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>10</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 1</p> <p>Maximum — 20</p> <p>Units — %</p>
<p><b>Low-Current Trip</b></p> <p>Program ⇒ Protection ⇒ Low-Current Settings</p> <p>This parameter <b>Enables/Disables</b> the low-current trip feature.</p> <p>When enabled, the ASD will trip on a low-current fault if the output current of the ASD falls below the level defined at <a href="#">F611</a> and remains there for the time set at <a href="#">F612</a>.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — Disabled</li> <li>1 — Enabled</li> </ul>	<p><b>Direct Access Number — F610</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>



<b>Low-Current Detection Threshold</b> Program ⇒ Protection ⇒ Low-Current Settings  With the <b>Low-Current Trip (F610)</b> parameter is enabled, this function sets the low-current trip threshold.  The threshold value is entered as a percentage of the maximum rating of the ASD.	<b>Direct Access Number — F611</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 100 Units — %
<b>Low-Current Trip Threshold Time</b> Program ⇒ Protection ⇒ Low-current Settings  With the <b>Low-Current Trip (F610)</b> parameter is enabled, this function sets the time that the low-current condition must exist to cause a trip.	<b>Direct Access Number — F612</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255 Units — Seconds
<b>Short Circuit Detection At Start</b> Program ⇒ Protection ⇒ Special Protection Parameters  This parameter determines when the system will perform an <b>Output Short Circuit</b> test.  <i><b>Note:</b> Selection 3 is recommended for high-speed motor applications. Because of the low impedance of high-speed motors the standard-pulse setting may result in a motor malfunction.</i>  Settings: 0 — Every Start (Standard Pulse) 1 — Power On or Reset (Standard Pulse) 2 — Every Start (Short Pulse) 3 — Power On or Reset (Short Pulse)	<b>Direct Access Number — F613</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Every Start</b> (Standard Pulse) Changeable During Run — <b>No</b>
<b>Over-Torque Trip</b> Program ⇒ Protection ⇒ Over-Torque Parameters  This parameter <b>Enables/Disables</b> the <b>Over-Torque Tripping</b> function. When enabled, the ASD trips if an output torque value greater than the setting of <b>F616</b> or <b>F617</b> exists for a time longer than the setting of <b>F618</b> . When disabled, the ASD does not trip due to over-torque conditions.  <i><b>Note:</b> A discrete output terminal may be activated when an over-torque alarm occurs if so configured (See <b>F130</b>).</i>  Settings: 0 — Disabled 1 — Enabled	<b>Direct Access Number — F615</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>Yes</b>

<b>Over-Torque Detection Level (Positive Torque)</b> Program ⇒ Protection ⇒ Over-Torque Parameters  This parameter sets the torque threshold level that is used as a setpoint for over-torque tripping during positive torque. This setting is a percentage of the maximum rated torque of the ASD.  This function is enabled at <a href="#">F615</a> .	<b>Direct Access Number — F616</b> Parameter Type — <b>Numerical</b> Factory Default — <b>200.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.00 Units — %
<b>Over-Torque Detection Level (Negative Torque)</b> Program ⇒ Protection ⇒ Over-Torque Parameters  This parameter sets the torque threshold level that is used as a setpoint for over-torque tripping during negative torque (regen). This setting is a percentage of the maximum rated torque of the ASD.  This function is enabled at <a href="#">F615</a> .	<b>Direct Access Number — F617</b> Parameter Type — <b>Numerical</b> Factory Default — <b>200.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.00 Units — %
<b>Over-Torque Detection Time</b> Program ⇒ Protection ⇒ Over-Torque Parameters  This parameter sets the amount of time that the over-torque condition may exceed the tripping threshold level set at <a href="#">F616</a> and <a href="#">F617</a> before a trip occurs.  This function is enabled at <a href="#">F615</a> .	<b>Direct Access Number — F618</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.50</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 10.0 Units — Seconds
<b>Over-Torque Detection Hysteresis</b> Program ⇒ Protection ⇒ Over-Torque Parameters  During a momentary over-torque condition, this parameter provides a torque threshold level to which the over-torque condition must return within the time setting of <a href="#">F618</a> or an <b>Over-Torque Trip</b> will be incurred.	<b>Direct Access Number — F619</b> Parameter Type — <b>Numerical</b> Factory Default — <b>10.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 100.00 Units — %
<b>Cooling Fan Control</b> Program ⇒ Protection ⇒ Special Protection Parameters  This parameter sets the cooling fan run-time command.  Settings: 0 — Automatic 1 — Always On	<b>Direct Access Number — F620</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Automatic</b> Changeable During Run — <b>Yes</b>
<b>Cumulative Operation Time Alarm</b> Program ⇒ Protection ⇒ Special Protection Parameters  This parameter sets a run-time value that, once exceeded, closes a discrete output contact. The output signal may be used to control external equipment or used to engage a brake.  Associate the <b>Total-Operation-Hours Alarm</b> setting of <a href="#">Table 9 on pg. 255</a> to a discrete output contactor.  <b>Note:</b> The time displayed is 1/10th of the actual time (0.1 hr. = 1.0 hr.).	<b>Direct Access Number — F621</b> Parameter Type — <b>Numerical</b> Factory Default — <b>610.0</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 999.9 Units — Hours (X 10)

<b>Abnormal Speed Detection Time</b> Program ⇒ Protection ⇒ Abnormal Speed Settings  This parameter sets the time that an over-speed condition must exist to cause a trip. This parameter functions in conjunction with the settings of <a href="#">F623</a> and <a href="#">F624</a> .	<b>Direct Access Number — F622</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.01</b> Changeable During Run — <b>Yes</b> Minimum — 0.01 Maximum — 100.00 Units — Seconds
<b>Over-Speed Detection Frequency Upper Band</b> Program ⇒ Protection ⇒ Abnormal Speed Settings  This parameter sets the upper level of the <b>Base Frequency</b> range that, once exceeded, will cause an <b>Over-Speed Detected</b> alert. This parameter functions in conjunction with the settings of <a href="#">F622</a> and <a href="#">F624</a> .	<b>Direct Access Number — F623</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 (Disabled) Maximum — 30.00 Units — Hz
<b>Over-Speed Detection Frequency Lower Band</b> Program ⇒ Protection ⇒ Abnormal Speed Settings  This parameter sets the lower level of the <b>Base Frequency</b> range that, once the output speed falls below this setting, will cause a <b>Speed Drop Detected</b> alert. This parameter functions in conjunction with the settings of <a href="#">F622</a> and <a href="#">F623</a> .	<b>Direct Access Number — F624</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 (Disabled) Maximum — 30.00 Units — Hz
<b>Over-Voltage Limit Operation Level</b> Program ⇒ Protection ⇒ Stall  This parameter sets the upper DC bus voltage threshold that, once exceeded, will cause an <b>Over-Voltage Stall</b> . An <b>Over-Voltage Stall</b> increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an <b>Over-Voltage Trip</b> . If the over-voltage condition persists for over 4 mS, an <b>Over-Voltage Trip</b> will be incurred. This parameter is enabled at <a href="#">F305</a> .  <i>Note: This parameter setting may increase deceleration times.</i>	<b>Direct Access Number — F626</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>Yes</b> Minimum — 100 Maximum — 150 Units — %
<b>Under-Voltage Trip</b> Program ⇒ Protection ⇒ Under-Voltage/Ridethrough  This parameter <b>Enables/Disables</b> the <b>Under-Voltage Trip</b> function. With this parameter <b>Enabled</b> , the ASD will trip if the under-voltage condition persists for a time greater than the <a href="#">F628</a> setting. A user-selected contact may be actuated if so configured. If <b>Disabled</b> the ASD will stop and not trip; the <b>FL</b> contact is not activated.  Settings: 0 — Disabled 1 — Enabled	<b>Direct Access Number — F627</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>No</b>

<b>Under-Voltage Trip Detection Time</b> Program ⇒ Protection ⇒ Under-Voltage/Ridethrough This parameter sets the time that the under-voltage condition must exist to cause an <b>Under-Voltage Trip</b> . This parameter is enabled at <a href="#">F627</a> .	<b>Direct Access Number — F628</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.03</b> Changeable During Run — <b>No</b> Minimum — 0.01 Maximum — 10.00 Units — Seconds
<b>Regenerative Power Ridethrough Control Level</b> Program ⇒ Protection ⇒ Under-Voltage/Ridethrough This parameter is activated during regeneration. It is used to set the low end of the DC bus voltage threshold that, once the bus voltage drops below this setting, activates the setting of <a href="#">F302</a> (Ridethrough Mode). Activation may be the result of a momentary power loss or an excessive load on the bus voltage. During a <b>Ridethrough</b> , regenerative energy is used to maintain the control circuitry settings for the duration of the <b>Ridethrough</b> ; it is not used to drive the motor. The motor(s) of the system are stopped and then restarted automatically or may continue seamlessly if so configured. See <a href="#">F302</a> for more information on this parameter. <i>Note: This parameter setting may increase deceleration times.</i>	<b>Direct Access Number — F629</b> Parameter Type — <b>Numerical</b> Factory Default — <b>(ASD-Dependent)</b> Changeable During Run — <b>No</b> Minimum — 55 Maximum — 100 Units — %
<b>Brake Answer Delay Time</b> Program ⇒ Protection ⇒ Special Protection Parameters This parameter is used in conjunction with the discrete input terminal setting <b>Brake Answerback Input</b> (See <a href="#">Table 6 on pg. 249</a> for more information on this feature). After activating the discrete input terminal <b>Braking Request</b> , the setting of this parameter starts a count-down timer in which 1) a <b>Brake Answerback Input</b> response must be received or 2) the brake must release before the timer expires. Should this timer setting expire before the <b>Brake Answerback Input</b> is returned or the brake releases, a <b>Brake Fault</b> (E-11) is incurred. Otherwise, the brake releases and normal motor operations resume.	<b>Direct Access Number — F630</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 0.0 (Disabled) Maximum — 10.0 Units — Seconds
<b>ASD Overload</b> Program ⇒ Protection ⇒ Overload This parameter is used to protect the ASD from an over-current condition. The standard overload rating of the P9 ASD is 120% operation for 60 seconds. This setting allows for the overload protection to be switched from the standard overload detection means (Thermal Detection <u>and</u> Overload) to thermal detection only. Settings: 0 — Thermal Detection + Overload 1 — Thermal Detection Only The <b>Thermal Detection Only</b> selection is used when multiple devices are installed horizontally as described on <a href="#">pg. 15</a> .	<b>Direct Access Number — F631</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Thermal Detection + Overload</b> Changeable During Run — <b>No</b>

<b>V/I Analog Input Broken Wire Detection Level</b> Program ⇒ Terminal ⇒ Input Special Functions  This parameter is enabled by providing a non-zero value here. This function monitors the <b>V/I</b> input signal and if the <b>V/I</b> input signal falls below the level specified here and remains there for a period in excess of 0.3 seconds a trip will be incurred (E-18).  This value is entered as 0% to 100% of the <b>V/I</b> input signal range.	<b>Direct Access Number — F633</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b> Minimum — 1 Maximum — 100 Units — %
<b>Annual Average Ambient Temperature</b> Program ⇒ Special ⇒ Special Parameters  This parameter is used in conjunction with a discrete output terminal setting to notify the operator of the remaining useful life of critical components of the ASD system.  With a discrete output terminal set to <b>Part Replacement Alarm</b> (See <a href="#">Table 9 on pg. 255</a> ) and the calculation derived from the parameter setting, maintenance scheduling may be enhanced.  Settings: 1 — Under 10° C (50° F) 2 — Under 20° C (68° F) 3 — Under 30° C (86° F) 4 — Under 40° C (104° F) 5 — Under 50° C (122° F) 6 — Under 60° C (140° F)	<b>Direct Access Number — F634</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Under 30°</b> Changeable During Run — <b>No</b>
<b>Rush Relay Current Activation Time</b> Program ⇒ Special ⇒ Special Parameters⇒ Rush Relay Current Activation Time  At system startup, this parameter sets a time-delay for the start of the <b>Rush Relay</b> activation in an attempt to allow the DC bus voltage to reach the normal operating level before outputting a signal to the motor.	<b>Direct Access Number — F635</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>No</b> Minimum — 0.0 Maximum — 2.5 Units — Seconds
<b>PTC1 Thermal Selection</b> Program ⇒ Special ⇒ Special Parameters⇒ PTC1 Thermal Selection  This parameter <b>Enables/Disables</b> the optional external thermal detection circuit of the <b>Expansion IO Card Option 1</b> . A thermistor is connected from <b>TH1+</b> to <b>TH1-</b> of <b>TB3</b> on the <b>Expansion IO Card Option 1</b> .  Should the thermistor resistance reading fall below 50Ω because of an over-temperature condition or exceed 3000Ω because of an open circuit an <b>External Thermal Fault</b> (OH2) will be incurred.  <i><b>Note:</b> While this parameter is <b>Enabled</b>, the system cannot be restarted until the thermistor value recovers to the level of 1.8 kΩ from an over-temperature condition. An <b>Auto-Restart</b> will not be initiated subsequent to an <b>External Thermal Trip</b> (OH2). A manual restart will be required in the event of an <b>OH2</b> trip.</i>  Settings: 0 — Disabled 1 — Detect Disconnect	<b>Direct Access Number — F637</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Disabled</b> Changeable During Run — <b>No</b>

**PTC2 Thermal Selection**

Program ⇒ Special ⇒ Special Parameters⇒ PTC2 Thermal Selection

This parameter **Enables/Disables** the optional external thermal detection circuit of the **Expansion IO Card Option 2**. A thermistor is connected from **TH1+** to **TH1-** of **TB4** on the **Expansion IO Card Option 2**.

Should the thermistor resistance reading fall below 50Ω because of an over-temperature condition or exceed 3000Ω because of an open circuit an **External Thermal Fault** (OH2) will be incurred.

**Note:** While this parameter is **Enabled**, the system cannot be restarted until the thermistor value recovers to the level of 1.8 kΩ from an over-temperature condition. An **Auto-Restart** will not be initiated subsequent to an **External Thermal Trip** (OH2). A manual restart will be required in the event of an **OH2** trip.

Settings:

- 0 — Disabled
- 1 — Detect Disconnect

**Direct Access Number — F638**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

**Braking Resistance Overload Time (10x rated torque)**

Program ⇒ Protection ⇒ Dynamic Braking

This parameter sets the time that the braking resistor is allowed to sustain and overload condition before a trip is incurred.

This feature is useful for applications that have a fluctuating load or for loads that require a long deceleration time.

**Direct Access Number — F639**

Parameter Type — **Numerical**

Factory Default — **5.0**

Changeable During Run — **No**

Minimum — 0.1

Maximum — 600.0

Units — Seconds

**Step-Out Current Detection Level**

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact the TIC Customer Support Center for information on this parameter.

**Direct Access Number — F640**

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 10

Maximum — 150

Units — %

**Step-Out Current Detection Time**

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact the TIC Customer Support Center for information on this parameter.

**Direct Access Number — F641**

Parameter Type — **Numerical**

Factory Default — **00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 25.0

Units — Seconds

---

### V/I Analog Input Loss Response

Program ⇒ Terminal ⇒ Input Special Functions

This parameter is used to provide a system disposition in the event of the loss of the **V/I** input signal.

The system will either trip, run the speed set at [Preset Speed 14](#), or run at the [F456](#) setting in the **Direct** mode.

**Note:** *[Preset Speed 14](#) must be configured to use the preset speed selection.*

Settings:

- 0 — Trip
- 1 — Preset Speed 14
- 2 — Direct Mode Speed Setpoint (Run at [F456](#) setting)

**Direct Access Number** — F644

**Parameter Type** — Selection List

**Factory Default** — Trip

**Changeable During Run** — No

---

### Adding Input Selection

Program ⇒ Feedback ⇒ Override Control

This parameter **Enables/Disables** the feature that allows for the external adjustment of the **Output Frequency**.

Selecting either of the input methods listed enables this feature. The selected input is used as a modifier of the programmed **Output Frequency**.

Settings:

- 0 — Disabled
- 1 — V/I
- 2 — RR
- 3 — RX
- 5 — EOI (Keypad)
- 6 — RS485 (2-Wire)
- 7 — Communication Option Board
- 8 — RX2 Option (AI1)
- 9 — Option V/I
- 10 — UP/DOWN Frequency (Terminal Board)
- 11 — Pulse Input (Option)
- 12 — Pulse Input (Motor CPU)
- 13 — Binary/BCD Input (Option)

**Direct Access Number** — F660

**Parameter Type** — Selection List

**Factory Default** — Disabled

**Changeable During Run** — Yes

---

### Multiplying Input Selection

Program ⇒ Feedback ⇒ Override Control

This parameter **Enables/Disables** the feature that allows for the external adjustment of the commanded frequency.

Selecting either of the input methods listed enables this feature. The selected input is used as a multiplier of the commanded frequency.

If **Setting (F729)** is selected, the % value entered at parameter [F729](#) is used as the multiplier of the commanded frequency.

Settings:

- 0 — Disabled
- 1 — V/I
- 2 — RR
- 3 — RX
- 4 — Setting ([F729](#))
- 5 — RX2 Option (AI1)

**Direct Access Number** — F661

**Parameter Type** — Selection List

**Factory Default** — Disabled

**Changeable During Run** — Yes

**AM Output Terminal Function**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **AM** analog output terminal. The **AM** analog output terminal produces an output current that is proportional to the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 7 on pg. 253](#).

**Note:** To read **current** at this terminal connect a 100 – 500Ω resistor from the **AM** (+) terminal through the series Ammeter to the **CC** (-) terminal.

**AM Terminal Setup Parameters**

[F670](#) — Set AM Function

[F671](#) — Calibrate AM Terminal

[F685](#) — Output Response Polarity Selection

[F686](#) — Set Zero Level

**Direct Access Number** — **F670**

**Parameter Type** — **Selection List**

**Factory Default** — **Output Current**

**Changeable During Run** — **Yes**

**AM Output Terminal Adjustment**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to calibrate the **AM** analog output.

To calibrate the **AM** analog output, connect an ammeter as described at parameter [F670](#).

With the ASD is running at a known value (e.g., output frequency), adjust this parameter until the associated function of parameter [F670](#) produces the desired DC level output at the **AM** output terminal.

See [F670](#) for more information on this setting.

**Direct Access Number** — **F671**

**Parameter Type** — **Numerical**

**Factory Default** — **512**

**Changeable During Run** — **Yes**

**Minimum** — 1

**Maximum** — 1280

**MON1 Terminal Meter Selection**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **MON1** analog output terminal. The available assignments for this output terminal are listed in [Table 7 on pg. 253](#).

The **MON1** analog output terminal produces an output voltage or current that is proportional to the magnitude of the function assigned to this terminal.

**Note:** The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

**MON1 Terminal Setup Parameters**

[F672](#) — MON1 Output Function

[F673](#) — MON1 Terminal Meter Adjustment

[F688](#) — MON1 Voltage/Current Output Switching

[F689](#) — MON1 Output Gradient Characteristic

[F690](#) — MON1 Bias Adjustment Set Zero Level

**Direct Access Number** — **F672**

**Parameter Type** — **Selection List**

**Factory Default** — **Output Voltage**

**Changeable During Run** — **Yes**



**MON1 Terminal Adjustment**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the gain of the **MON1** output terminal and is used in conjunction with the settings of parameter [F672](#).

See parameter [F672](#) for more information on this setting.

**Direct Access Number — F673**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

**MON2 Terminal Meter Selection**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **MON2** analog output terminal. The available assignments for this output terminal are listed in [Table 7 on pg. 253](#).

The **MON2** analog output terminal produces an output voltage or current that is proportional to the magnitude of the function assigned to this terminal.

**Note:** *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2** instruction manual (P/N 58686) for more information on the function of this terminal.

**Direct Access Number — F674**

Parameter Type — **Selection List**

Factory Default — **Output Frequency**

Changeable During Run — **Yes**

**MON2 Terminal Setup Parameters**

[F674](#) — MON2 Output Function

[F675](#) — MON2 Terminal Meter Adjustment

[F691](#) — MON2 Voltage/Current Output Switching

[F692](#) — MON2 Output Gradient Characteristic

[F693](#) — MON2 Bias Adjustment Set Zero Level

**MON2 Terminal Adjustment**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the gain of the **MON2** output terminal and is used in conjunction with the settings of parameter [F674](#).

See parameter [F674](#) for more information on this setting.

**Direct Access Number — F675**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

**FP Terminal Assignment**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter sets the functionality of the **FP** output terminal to any one of the user-selectable functions listed in [Table 7 on pg. 253](#).

As the assigned function changes in magnitude or frequency, the pulse count of the **FP** output terminal pulse train changes in direct proportion to changes in the assigned function.

**Note:** *The duty cycle of the output pulse train remains at 65 ±5.0 μS.*

This parameter is used in conjunction with parameter [F677](#).

**Direct Access Number — F676**

Parameter Type — **Selection List**

Factory Default — **Output Frequency**

Changeable During Run — **Yes**

<b>FP Terminal Frequency</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter scales the <b>FP</b> output terminal by setting the pulses-per-second output signal of the <b>FP</b> terminal. See <a href="#">F676</a> for more information on this parameter.	<b>Direct Access Number — F677</b> Parameter Type — <b>Numerical</b> Factory Default — <b>3.84</b> Changeable During Run — <b>Yes</b> Minimum — 1.00 Maximum — 43.20 Units — Pulses/Second
<b>FM Voltage/Current Output Switching</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter is used to select the type of output signal provided at the <b>FM</b> terminal (i.e., voltage or current). The output voltage and current range is 0 – 10 VDC and 0 – 20 mA, respectively. See <a href="#">F005</a> for more information on this setting.  Settings: 0 — 0 – 10 V 1 — 0 – 20 mA	<b>Direct Access Number — F681</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0–10V</b> Changeable During Run — <b>No</b>
<b>FM Output Gradient Characteristic</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter sets the output response polarity of the <b>FM</b> output terminal. The <b>FM</b> output terminal response may be set to respond inversely (-) or directly (+) to the input signal. See <a href="#">F005</a> for more information on this setting.  Settings: 0 — Minus (Negative Gradient) 1 — Plus (Positive Gradient)	<b>Direct Access Number — F682</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Plus</b> Changeable During Run — <b>Yes</b>
<b>FM Bias Adjustment</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the <b>FM</b> terminal. Set the function of <a href="#">F005</a> to zero and then set this parameter to zero for proper operation. See <a href="#">F005</a> for more information on this setting.	<b>Direct Access Number — F683</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — -10.0 Maximum — +100.0 Units — %
<b>AM Output Gradient Characteristic</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter sets the output response polarity of the <b>AM</b> output terminal. The <b>AM</b> output terminal response may be set to respond inversely (-) or directly (+) to the input signal. See <a href="#">F670</a> for more information on this setting.  Settings: 0 — Minus (Negative Gradient) 1 — Plus (Positive Gradient)	<b>Direct Access Number — F685</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Plus</b> Changeable During Run — <b>Yes</b>

<b>AM Bias Adjustment</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the <b>AM</b> terminal.  Set the function set at <a href="#">F670</a> to zero and then set this parameter to zero for proper operation.  See <a href="#">F670</a> for more information on this setting.	<b>Direct Access Number — F686</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — -10.0 Maximum — +100.0 Units — %
<b>MON 1 Voltage/Current Output Switching</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter is used to set the output signal type of the <b>MON1</b> output terminal.  Settings 0 — -10 V – +10 V 1 — 0 – 10 V 2 — 0 – 20 mA	<b>Direct Access Number — F688</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 – 10V</b> Changeable During Run — <b>Yes</b>
<b>MON 1 Output Gradient Characteristic</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter sets the output response polarity of the <b>MON1</b> output terminal. The <b>MON1</b> output terminal response may be set to respond inversely (-) or directly (+) to the input signal.  See parameter <a href="#">F672</a> for more information on this setting.  Settings: 0 — Minus (Negative Gradient) 1 — Plus (Positive Gradient)	<b>Direct Access Number — F689</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Plus</b> Changeable During Run — <b>Yes</b>
<b>MON 1 Bias Adjustment</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the <b>MON1</b> terminal.  Set the assigned function of parameter <a href="#">F672</a> to zero and then set this parameter to a zero output.  See parameter <a href="#">F672</a> for more information on this setting.	<b>Direct Access Number — F690</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — -10.0 Maximum — 100.0 Units — %
<b>MON 2 Voltage/Current Output Switching</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter is used to set the output signal type of the <b>MON2</b> output terminal.  See parameter <a href="#">F674</a> for more information on this setting.  Settings 0 — -10 V – +10 V 1 — 0 – 10 V 2 — 0 – 20 mA	<b>Direct Access Number — F691</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 – 10V</b> Changeable During Run — <b>Yes</b>

<b>MON 2 Output Gradient Characteristic</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter sets the output response polarity of the <b>MON2</b> output terminal. The <b>MON2</b> output terminal response may be set to respond inversely (-) or directly (+) to the input signal.  See parameter <a href="#">F672</a> for more information on this setting.  Settings: 0 — Minus (Negative Gradient) 1 — Plus (Positive Gradient)	<b>Direct Access Number — F692</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Plus</b> Changeable During Run — <b>Yes</b>
<b>MON 2 Bias Adjustment</b> Program ⇒ Terminal ⇒ Analog Output Terminals  This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the <b>MON2</b> terminal. Set the assigned function of parameter <a href="#">F674</a> to zero and then set this parameter to a zero output. See parameter <a href="#">F674</a> for more information on this setting.	<b>Direct Access Number — F693</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.0</b> Changeable During Run — <b>Yes</b> Minimum — -10.0 Maximum — 100.0 Units — %
<b>Parameter Write Lock Out</b> Program ⇒ Utilities ⇒ Prohibition  This parameter <b>Enables/Disables</b> the <b>Run</b> and <b>Stop</b> keys.  Settings: 0 — Enabled 1 — Disabled	<b>Direct Access Number — F700</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Enabled</b> Changeable During Run — <b>Yes</b>
<b>Display Units for Current and Voltage</b> Program ⇒ Utilities ⇒ Display Parameters  This parameter sets the unit of measurement for current and voltage values displayed on the EOI.  Settings: 0 — % 1 — A/V	<b>Direct Access Number — F701</b> Parameter Type — <b>Selection List</b> Factory Default — % Changeable During Run — <b>Yes</b>
<b>Display Unit Multiplication Factor</b> Program ⇒ Utilities ⇒ Display Parameters  This parameter provides a multiplier for the displayed speed value shown on the EOI of the ASD. This parameter may be used to display the rate that a commodity is being processed by the driven load in process units (i.e., units/time).  <b>Example:</b> <i>An output frequency of 100 Hz would be displayed as 50 Hz if using a multiplier of 0.5 for this parameter.</i>  <b>Note:</b> <i>PID frequency-limiting parameters are not affected by this setting (i.e., <a href="#">F364</a>, <a href="#">F365</a>, <a href="#">F367</a>, and <a href="#">F368</a>).</i>	<b>Direct Access Number — F702</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00 (OFF)</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00

**Display Unit Selection**

Program ⇒ Utilities ⇒ Display Parameters

This parameter is used in conjunction with [F702](#) to set the method in which the frequency is displayed on the EOI.

The multiplier setting of [F702](#) will be applied to the display of all frequencies if all frequencies are selected at this parameter.

The multiplier setting of [F702](#) will be applied to parameters [F364](#), [F365](#), [F367](#), and [F368](#) ONLY if **PID Process Data** is selected at this parameter.

Settings:

- 0 — All Frequencies
- 1 — PID Process Data

**Direct Access Number — F703**

Parameter Type — **Selection List**

Factory Default — **All Frequencies**

Changeable During Run — **Yes**

**Display Gradient Characteristic**

Program ⇒ Utilities ⇒ Display Parameters

The ASD-displayed response to output speed changes will be displayed as directly proportional or inversely proportional as a function of this parameter setting.

Selecting **Negative Gradient** displays an increased output speed as going more negative.

Selecting **Positive Gradient** displays an increased output speed as going more positive.

Settings:

- 0 — Minus (Negative Gradient)
- 1 — Plus (Positive Gradient)

**Direct Access Number — F705**

Parameter Type — **Selection List**

Factory Default — **Plus**

Changeable During Run — **Yes**

**Display Bias**

Program ⇒ Utilities ⇒ Display Parameters

In conjunction with the setting of [F702](#), this parameter sets the bias of the EOI speed display.

The frequency entered here will be multiplied by the setting of [F702](#) and then displayed as the zero value on the EOI display.

**Direct Access Number — F706**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

**Change Step Selection 1**

Program ⇒ Utilities ⇒ Display Parameters

In conjunction with the parameter setting of [F708](#), this parameter sets the amount that the output speed will increase or decrease for each speed command change entered from the EOI using the **Rotary Encoder**.

**Direct Access Number — F707**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

## Change Step Selection 2

Program ⇒ Utilities ⇒ Display Parameters

The parameter is used to modify the degree that the setting of **F707** affects the output speed changes that are input from the EOI using the **Rotary Encoder**.

Selecting a zero value here disables this parameter and the resulting non-zero value of parameter setting **F707** is output from the ASD.

Selecting a non-zero value here provides a dividend that will be used in the following equation resulting in the actual output frequency applied to the motor.

$$\text{OutputFrequencyDisplayed} = \text{InternallyCommandedFrequency} \times \frac{\text{F708}}{\text{F707}}$$

Direct Access Number — **F708**

Parameter Type — **Numerical**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 255

## Operation Command Clear Selection When ST Off

Program ⇒ Special ⇒ Operation Panel Parameters

Upon deactivation of the **ST** terminal while operating in the **Hand** mode, the ASD output to the motor will cease — this parameter setting is used to allow for the reactivation of the motor without user intervention upon the reactivation of the **ST** terminal.

Upon reactivation of the **ST** terminal in this condition the ASD will resume the Run condition and the motor will start (1 — Retain Run Command).

This feature may be **Disabled** and the Run command must be re-initiated by the user for ASD operation (0 — Clear Panel Run Command).

Direct Access Number — **F719**

Parameter Type — **Selection List**

Factory Default — **Retain Panel Run Command**

Changeable During Run — **Yes**



# DANGER

**WHEN ENABLED THE ASD WILL RESUME THE RUN CONDITION WHEN THE ST TERMINAL IS REACTIVATED.**

Settings:

0 — Clear Panel Run Command

1 — Retain Panel Run Command

## Panel Stop Pattern

Program ⇒ Special ⇒ Operation Panel Parameters

While operating in the **Hand** mode this parameter determines the method used to stop the motor when the stop command is issued via the EOI.

The **Deceleration Stop** selection enables the **Dynamic Braking** system that is set up at **F304** or the **DC Injection Braking** system that is set up at **F250**, **F251**, and **F252**.

The **Coast Stop** setting allows the motor to stop at the rate allowed by the inertia of the load.

Settings:

0 — Deceleration Stop

1 — Coast Stop

**Note:** The **Stop Pattern** setting has no effect on the **Emergency Off** settings of **F603**. This parameter may also be accessed by pressing the **ESC** key from the **Frequency Command** screen.

Direct Access Number — **F721**

Parameter Type — **Selection List**

Factory Default — **Deceleration Stop**

Changeable During Run — **Yes**

<b>Panel Torque Command</b> Program ⇒ Special ⇒ Operation Panel Parameters  This function is not used with the P9 ASD. The <b>Torque Command</b> selection is performed at <a href="#">F420</a> .	<b>Direct Access Number — F725</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — -250.00 Maximum — +250.00
<b>Panel Tension Torque Bias</b> Program ⇒ Special ⇒ Operation Panel Parameters  This function is not used with the P9 ASD. The <b>Tension Torque Bias</b> selection is performed at <a href="#">F423</a> .	<b>Direct Access Number — F727</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — -250.00 Maximum — +250.00 Units — %
<b>Panel Load Sharing Gain</b> Program ⇒ Special ⇒ Operation Panel Parameters  This function is not used with the P9 ASD. The <b>Load Sharing Gain</b> selection is performed at <a href="#">F424</a> .	<b>Direct Access Number — F728</b> Parameter Type — <b>Numerical</b> Factory Default — <b>100.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 250.00 Units — %
<b>Panel Override Multiplication Gain</b> Program ⇒ Special ⇒ Operation Panel Parameters  This parameter provides a value to be used in the event that <b>Setting</b> ( <a href="#">F729</a> ) is selected for the <b>Frequency Override Multiplying Input</b> ( <a href="#">F661</a> ).	<b>Direct Access Number — F729</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0.00</b> Changeable During Run — <b>Yes</b> Minimum — -100.00 Maximum — 100.00 Units — %
<b>Panel Frequency Lock Out</b> Program ⇒ Special ⇒ Operation Panel Parameters  This parameter is model-specific and has no function on the P9 ASD system.  Settings: 0 — Unlocked 1 — Locked	<b>Direct Access Number — F730</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Unlocked</b> Changeable During Run — <b>Yes</b>
<b>Panel Emergency Off Lock Out</b> Program ⇒ Special ⇒ Operation Panel Parameters  This parameter is model-specific and has no function on the P9 ASD system.  Settings: 0 — Unlocked 1 — Locked	<b>Direct Access Number — F734</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Unlocked</b> Changeable During Run — <b>No</b>

<b>Panel Reset Lock Out</b> Program ⇒ Special ⇒ Operation Panel Parameters  This parameter is model-specific and has no function on the P9 ASD system.  Settings: 0 — Unlocked 1 — Locked	<b>Direct Access Number — F735</b>  Parameter Type — <b>Selection List</b> Factory Default — <b>Unlocked</b> Changeable During Run — <b>Yes</b>
<b>Command Mode/Frequency Mode Change Lock Out</b> Program ⇒ Utilities ⇒ Prohibition  This parameter is model-specific and has no function on the P9 ASD system.  Settings: 0 — Unlocked 1 — Locked	<b>Direct Access Number — F736</b>  Parameter Type — <b>Selection List</b> Factory Default — <b>Locked</b> Changeable During Run — <b>Yes</b>
<b>Lock Out All Keys</b> Program ⇒ Utilities ⇒ Prohibition  This parameter is model-specific and has no function on the P9 ASD system.  Settings: 0 — Unlocked 1 — Locked	<b>Direct Access Number — F737</b>  Parameter Type — <b>Selection List</b> Factory Default — <b>Unlocked</b> Changeable During Run — <b>Yes</b>
<b>Trace Selection</b> Program ⇒ Utilities ⇒ Trace  In conjunction with parameter <a href="#">F741 – F745</a> , this parameter is used to monitor and store 4 ASD output waveform data points. The data may be read and stored as a function of a trip (At Trip) or it may be initiated by the activation of a discrete terminal activation (At Trigger).  Set a discrete input terminal to <b>Trace Back Trigger Signal</b> and activate the terminal to initiate the <b>At Trigger</b> read/store function.  <a href="#">Table 10 on pg. 256</a> lists the items that may be selected for the data read/store function along with the associated communication number for each selection.  The duration of the read/store cycle for the selected items is set at parameter <a href="#">F741</a> .  To acquire and store the data a communications device and a PC are required. The P9 ASD supports the following communications protocols: RS485 (MODBUS-RTU) Toshiba Protocol, USB Toshiba Protocol, CC-Link, ProfiBus, and DeviceNet (Refer to the manual of each protocol type for more information).  Trace data may be viewed graphically via Program ⇒ Utilities ⇒ <b>View Trace Data</b> .  Settings: 0 — None (Disabled) 1 — At Trip 2 — At Trigger	<b>Direct Access Number — F740</b>  Parameter Type — <b>Selection List</b> Factory Default — <b>At Trip</b> Changeable During Run — <b>Yes</b>



<b>Trace Cycle</b> Program ⇒ Utilities ⇒ Trace This parameter sets the record time for the <b>Trace Data</b> events selected at <a href="#">F742</a> – <a href="#">F745</a> . See <a href="#">F740</a> for more information on this parameter setting. Settings: 0 — 4 mS 1 — 20 mS 2 — 100 mS 3 — 1 Second 4 — 10 Seconds	<b>Direct Access Number</b> — <b>F741</b> <b>Parameter Type</b> — <b>Selection List</b> <b>Factory Default</b> — <b>100 mS</b> <b>Changeable During Run</b> — <b>Yes</b>
<b>Trace Data 1</b> Program ⇒ Utilities ⇒ Trace This parameter is used to select the <b>Trace Data 1</b> item from <a href="#">Table 10 on pg. 256</a> to be read and stored in accordance with the setup of parameters <a href="#">F740</a> and <a href="#">F741</a> . See <a href="#">F740</a> for more information on this parameter setting.	<b>Direct Access Number</b> — <b>F742</b> <b>Parameter Type</b> — <b>Selection List</b> <b>Factory Default</b> — <b>Output Frequency</b> <b>Changeable During Run</b> — <b>Yes</b>
<b>Trace Data 2</b> Program ⇒ Utilities ⇒ Trace This parameter is used to select the <b>Trace Data 2</b> item from <a href="#">Table 10 on pg. 256</a> to be read and stored in accordance with the setup of parameters <a href="#">F740</a> and <a href="#">F741</a> . See <a href="#">F740</a> for more information on this parameter setting.	<b>Direct Access Number</b> — <b>F743</b> <b>Parameter Type</b> — <b>Selection List</b> <b>Factory Default</b> — <b>Freq. Reference</b> <b>Changeable During Run</b> — <b>Yes</b>
<b>Trace Data 3</b> Program ⇒ Utilities ⇒ Trace This parameter is used to select the <b>Trace Data 3</b> item from <a href="#">Table 10 on pg. 256</a> to be read and stored in accordance with the setup of parameters <a href="#">F740</a> and <a href="#">F741</a> . See <a href="#">F740</a> for more information on this parameter setting.	<b>Direct Access Number</b> — <b>F744</b> <b>Parameter Type</b> — <b>Selection List</b> <b>Factory Default</b> — <b>Output Current</b> <b>Changeable During Run</b> — <b>Yes</b>
<b>Trace Data 4</b> Program ⇒ Utilities ⇒ Trace This parameter is used to select the <b>Trace Data 4</b> item from <a href="#">Table 10 on pg. 256</a> to be read and stored in accordance with the setup of parameters <a href="#">F740</a> and <a href="#">F741</a> . See <a href="#">F740</a> for more information on this parameter setting.	<b>Direct Access Number</b> — <b>F745</b> <b>Parameter Type</b> — <b>Selection List</b> <b>Factory Default</b> — <b>DC Voltage</b> <b>Changeable During Run</b> — <b>Yes</b>

<p><b>Baud Rate (RS485 2-Wire)</b></p> <p>Program ⇒ Communications ⇒ Communication Settings</p> <p>This parameter plays a role in the setup of the communications network by establishing the <b>Baud Rate</b> of the communications link.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — 9600</li> <li>1 — 19200</li> <li>2 — 38400</li> </ul>	<p><b>Direct Access Number — F800</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>19200</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Units — bps</p>
<p><b>Parity (RS485 2- and 4-Wire)</b></p> <p>Program ⇒ Communications ⇒ Communication Settings</p> <p>This parameter plays a role in the setup of the communications network by establishing the <b>Parity</b> setting of the communications link.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>0 — No Parity</li> <li>1 — Even Parity</li> <li>2 — Odd Parity</li> </ul>	<p><b>Direct Access Number — F801</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Even Parity</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>ASD Number</b></p> <p>Program ⇒ Communications ⇒ Communication Settings</p> <p>This parameter plays a role in the setup of the communications network by assigning an identification (ID) number to each ASD in the communications network.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p>	<p><b>Direct Access Number — F802</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 247</p>
<p><b>Communications Time-Out Time (RS485 2- and 4-wire)</b></p> <p>Program ⇒ Communications ⇒ Communication Settings</p> <p>This parameter plays a role in the setup of the communications network by setting the time that no activity may exist over the communications link before the link is severed (Time Out).</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p>	<p><b>Direct Access Number — F803</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0 (Off)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0 (Off)</p> <p>Maximum — 100</p> <p>Units — Seconds</p>

**Communications Time-Out Action (RS485 2- and 4-wire)**

Program ⇒ Communications ⇒ Communication Settings

This parameter plays a role in the setup of the communications network by determining the action to be taken in the event of a time-out (Time-Out Action).

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

(Settings Are For 2-Wire/4-Wire)

- 0 — No Action/No Action
- 1 — Alarm/No Action
- 2 — Trip/No Action
- 3 — No Action/Alarm
- 4 — Alarm/Alarm
- 5 — Trip/Alarm
- 6 — No Action/Trip
- 7 — Alarm/Trip
- 8 — Trip/Trip

Direct Access Number — **F804**

Parameter Type — **Selection List**

Factory Default — **Trip/Trip**

Changeable During Run — **Yes**

**Send Delay (RS485 2-Wire)**

Program ⇒ Communications ⇒ Communication Settings

This parameter sets the **RS485** (2-wire) response delay time.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Direct Access Number — **F805**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 2.00

Units — Seconds

**ASD-to-ASD Communications (RS485 2-wire)**

Program ⇒ Communications ⇒ Communication Settings

The function of this parameter is 2-fold:

- 1) In a Master/Follower configuration and while communicating via RS485 2-wire, this parameter sets the ASD as the Master or the Follower.
- 2) This parameter determines the function of the ASD while operating as the Master or the Follower. If operating as the Master ASD, an output parameter of the Master ASD is used to control the Follower ASDs and is set here.

If operating as a Follower ASD, the ASD response if an error is incurred is set here.

**Note:** Select a Follower function here if [F826](#) is configured as a **Master Output** controller for any other ASD in the system. Otherwise, an **EOI** failure will result.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- 0 — Follower (Decel Stop If Error Detected)
- 1 — Follower (Continues Operation If Error Detected)
- 2 — Follower (Emergency Off If Error Detected)
- 3 — Master (Frequency Command)
- 4 — Master (Output Frequency)
- 5 — Master (Torque Reference)
- 6 — Master (Output Torque)

**Direct Access Number — F806**

Parameter Type — **Selection List**

Factory Default — **Follower (Decel Stop)**

Changeable During Run — **Yes**

**Frequency Point Selection**

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the communications reference for scaling.

See [F811](#) — [F814](#) for more information on this setting.

**Note:** Scaling the communications signal is not required for all applications.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- 0 — Disabled
- 1 — RS485 (2-Wire — NOT USED)
- 2 — RS485 (4-Wire)
- 3 — Communication Option Board

**Direct Access Number — F810**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

### Point 1 Setting

Program ⇒ Communications ⇒ Communication Reference Adjust

When enabled at [F810](#), this parameter is used to allow the user to set the gain and bias of the speed control input to the ASD when the speed control signal is received via the source selected at [F810](#).

#### Gain and Bias Settings

When operating in the **Speed Control** mode and using one of the control sources from **Settings** above, the settings that determine the gain and bias properties of the input signal are:

- **Communications Reference Speed Setpoint 1** (frequency) ([F812](#)),
- the communications input signal value that represents **Communications Reference Speed Setpoint 1** (frequency): [F811](#),
- **Communications Reference Speed Setpoint 2** (frequency) ([F814](#)), and
- the communications input signal value that represents **Communications Reference Speed Setpoint 2** (frequency): [F813](#).

Once set, as the input signal value changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets the **Communications Reference** input value that represents **Communications Reference Speed Setpoint 1** (frequency). This value is entered as 0 to 100% of the **Communications Reference** input value range.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

**Direct Access Number — F811**

**Parameter Type — Numerical**


**Factory Default — 0**

**Changeable During Run — Yes**

**Minimum — 0**

**Maximum — 100**

**Units — %**



### Point 1 Frequency

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Communications Reference** speed control input.

See [F811](#) for more information on this setting.

This parameter sets **Communications Reference Speed Setpoint 1**.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

**Direct Access Number — F812**

**Parameter Type — Numerical**

**Factory Default — 0.00**

**Changeable During Run — Yes**

**Minimum — 0.00**

**Maximum — Max. Freq. (F011)**

**Units — Hz**

### Point 2 Setting

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Communications Reference** speed control input.

See [F811](#) for more information on this setting.

This parameter sets the **Communications Reference** input value that represents **Communications Reference Speed Setpoint 2** (frequency). This value is entered as 0 to 100% of the **Communications Reference** input value range.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

**Direct Access Number — F813**

**Parameter Type — Numerical**

**Factory Default — 100**

**Changeable During Run — Yes**

**Minimum — 0**

**Maximum — 100**

**Units — %**

<b>Point 2 Frequency</b> Program ⇒ Communications ⇒ Communication Reference Adjust  This parameter is used to set the gain and bias of the <b>Communications Reference</b> speed control input. See <a href="#">F811</a> for more information on this setting. This parameter sets the <b>Communications Reference Speed Setpoint 2</b> . Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.	<b>Direct Access Number — F814</b> Parameter Type — <b>Numerical</b> Factory Default — <b>60.00</b> Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — <b>Max. Freq. (F011)</b> Units — Hz
<b>Baud Rate (RS485)</b> Program ⇒ Communications ⇒ Communication Settings  This parameter sets the RSRS485 baud rate.  Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.  Settings: 0 — 9600 bps 1 — 19200 bps 2 — 38400 bps	<b>Direct Access Number — F820</b> Parameter Type — <b>Selection List</b> Factory Default — <b>19200</b> Changeable During Run — <b>Yes</b>
<b>RS485 Send Delay (4-Wire RS485)</b> Program ⇒ Communications ⇒ Communication Settings  This parameter sets the <b>RS485</b> response delay time.  Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.	<b>Direct Access Number — F825</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 2.00 Units — Seconds

**ASD-to-ASD Communications (RS485)**

Program ⇒ Communications ⇒ Communication Settings

The function of this parameter is 2-fold:

- 1) In a Master/Follower configuration and while communicating via RS485 4-wire, this parameter sets the ASD as the Master or the Follower.
- 2) This parameter determines the function of the ASD while operating as the Master or the Follower. If operating as the Master ASD, an output parameter of the Master ASD is used to control the Follower ASDs and is set here. If operating as a Follower ASD, the ASD response if an error is incurred is set here.

**Note:** *Select a Follower function here if **F806** is configured as a **Master Output** controller for any other ASD in the system. Otherwise, an **EOI** failure will result.*

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- 0 — Follower (Decel Stop if Error Detected)
- 1 — Follower (Continues Operation if Error Detected)
- 2 — Follower (Emergency Off if Error Detected)
- 3 — Master (Frequency Command)
- 4 — Master (Output Frequency)
- 5 — Master (Torque Reference)
- 6 — Master (Output Torque)

**Direct Access Number — F826**

Parameter Type — **Selection List**

Factory Default — **Follower (Decel Stop)**

Changeable During Run — **Yes**

**RS485 Protocol Selection**

Program ⇒ Communications ⇒ Communication Settings

This parameter sets the communications protocol for ASD-to-ASD communications.

Settings:

- 0 — Toshiba
- 1 — Modbus
- 2 — BACnet

**Direct Access Number — F829**

Parameter Type — **Selection List**

Factory Default — **Toshiba**

Changeable During Run — **Yes**

**Communications Option (DeviceNet/Profibus) Setting 1**

Program ⇒ Communications ⇒ Communication Settings

While using the DeviceNet/Profibus communications protocol, this parameter allows the user to select the read and write information communicated between the ASD and the Host.

Read information may include the ASD fault status, ASD speed, ASD MAC ID, etc. Write information may include Enable/Disable DeviceNet commands, Forward run, ACC/DEC command, etc.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for more information on this parameter.

Settings:

- 0 – 7

**Direct Access Number — F830**

Parameter Type — **Selection List**

Factory Default — **0**

Changeable During Run — **Yes**

**Communications Option (DeviceNet/Profibus) Setting 2**

Program ⇒ Communications ⇒ Communication Settings

While using the DeviceNet/Profibus communications protocol, parameters [F831](#) – [F836](#) allow the user to select the ASD memory location that holds the Command/Frequency/Monitoring instructions to be applied to the ASD for **Communications Option Settings 2 – 7**, respectively.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for more information on this parameter.

Settings:

- 0 — Disabled
- 1 — FA06 (ALCAN Command 1)
- 2 — FA23 (ALCAN Command 2)
- 3 — FA07 (ALCAN Frequency Command, 0.01 Hz)
- 4 — FA33 (Torque Command, 0.01%)
- 5 — FA50 (Terminal Output)
- 6 — FA51 (Analog Output Data from Comm. [FM])
- 7 — FA52 (Analog Output Data from Comm. [AM])
- 8 — [F601](#) (Stall Prevention Level, %)
- 9 — [F441](#) (Power Running Torque Limit 1 Level, 0.01%)
- 10 — [F443](#) (Regen. Braking Torque Limit 1 Level, 0.01%)
- 11 — [F460](#) (Speed Loop Proportional Gain)
- 12 — [F461](#) (Speed Loop Stabilization Coefficient)

Direct Access Number — **F831**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 3**

Program ⇒ Communications ⇒ Communication Settings

Same as [F831](#). See [F831](#) for information on this parameter

Direct Access Number — **F832**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 4**

Program ⇒ Communications ⇒ Communication Settings

Same as [F831](#). See [F831](#) for information on this parameter

Direct Access Number — **F833**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 5**

Program ⇒ Communications ⇒ Communication Settings

Same as [F831](#). See [F831](#) for information on this parameter

Direct Access Number — **F834**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 6**

Program ⇒ Communications ⇒ Communication Settings

Same as [F831](#). See [F831](#) for information on this parameter

Direct Access Number — **F835**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 7**

Program ⇒ Communications ⇒ Communication Settings

Same as [F831](#). See [F831](#) for information on this parameter

Direct Access Number — **F836**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes**



**Communications Option (DeviceNet/Profibus) Setting 8**

Program ⇒ Communications ⇒ Communication Settings

While using the DeviceNet/Profibus communications protocol, parameters [F841](#) – [F846](#) allow the user to select the ASD memory location that holds the Command/Frequency/Monitoring instructions to be applied to the ASD for **Communications Option Settings 8 – 13**, respectively.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for more information on this parameter.

Settings:

- 0 — Disabled
- 1 — FD01 (ASD Status 1)
- 2 — FD00 (Output Frequency, 0.01 Hz)
- 3 — FD03 (Output Current, 0.01%)
- 4 — FD05 (Output Voltage, 0.01%)
- 5 — FC91 (ASD Alarm)
- 6 — FD22 (PID Feedback Value, 0.01 Hz)
- 7 — FD06 (Input Terminal Status)
- 8 — FD07 (Output Terminal Status)
- 9 — FE36 V/I
- 10 — FE35 (RR Input)
- 11 — FE37 (RX Input)
- 12 — FD04 (Input Voltage [DC Detection], 0.01%)
- 13 — FD16 (Real-Time Speed Feedback)
- 14 — FD18 (Torque, 0.01%)
- 15 — FE60 (My Monitor)
- 16 — FE61 (My Monitor)
- 17 — FE62 (My Monitor)
- 18 — FE63 (My Monitor)
- 19 — F880 (Free Notes)
- 20 — FD29 (Input Power, 0.01 kW)
- 21 — FD30 (Output Power, 0.01 kW)
- 22 — FE14 (Cumulative Operation Time, 0.01=1 Hour)
- 23 — FE40 (FM Terminal Output Monitor)
- 24 — FE41 (AM Terminal Output Monitor)

**Direct Access Number — F841**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 9**

Program ⇒ Communications ⇒ Communication Settings

Same as [F841](#). See [F841](#) for information on this parameter.

**Direct Access Number — F842**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 10**

Program ⇒ Communications ⇒ Communication Settings

Same as [F841](#). See [F841](#) for information on this parameter.

**Direct Access Number — F843**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 11**

Program ⇒ Communications ⇒ Communication Settings

Same as [F841](#). See [F841](#) for information on this parameter.

**Direct Access Number — F844**Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes**

<b>Communications Option (DeviceNet/Profibus) Setting 12</b> Program ⇒ Communications ⇒ Communication Settings  Same as F841. See F841 for information on this parameter.	<b>Direct Access Number — F845</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0000h</b> Changeable During Run — <b>Yes</b>
<b>Communications Option (DeviceNet/Profibus) Setting 13</b> Program ⇒ Communications ⇒ Communication Settings  Same as F841. See F841 for information on this parameter.	<b>Direct Access Number — F846</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0000h</b> Changeable During Run — <b>Yes</b>
<b>Disconnection Detection Extended Time</b> Program ⇒ Communications ⇒ Communication Settings  This parameter is used to set the length of time that no communications activity may exist before the communications link is disconnected.	<b>Direct Access Number — F850</b> Parameter Type — <b>Numerical</b> Factory Default — 0.0 Changeable During Run — <b>Yes</b> Minimum — 0.0 Maximum — 100.0 Units — Seconds
<b>ASD Operation at Disconnect</b> Program ⇒ Communications ⇒ Communication Settings  This parameter is used to set the P9 ASD action to be carried out in the event of the loss of communications.  Settings: 0 — Stop and Terminate Communication 1 — Do Nothing (Continue Programmed Operation) 2 — Deceleration Stop 3 — Coast Stop 4 — Emergency Off 5 — Preset Speed (Setting of F852)	<b>Direct Access Number — F851</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Stop and Terminate Communication</b> Changeable During Run — <b>Yes</b>
<b>Preset Speed Operation Selection</b> Program ⇒ Communications ⇒ Communication Settings  This parameter setting is used to set the <b>Preset Speed</b> selection to be used if <b>Preset Speed</b> is selected at parameter F851.  Settings: 0 — Disabled 1 – 15 — Preset Speed Number	<b>Direct Access Number — F852</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (Disabled) Changeable During Run — <b>Yes</b>
<b>Communications Option Station Address Monitor</b> Program ⇒ Communications ⇒ Communication Settings  This parameter is used in the setup of the communications network by reading the Media Access Code (MAC) address of the ASD that is connected to a node of the communications system.  The MAC Address is set via DIP switches of the optional device.  See the <b>DeviceNet Option Instruction Manual</b> (P/N 58683) for more information on this parameter.	<b>Direct Access Number — F853</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (Disabled) Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 255

---

**Communications Option Speed Switch Monitor DeviceNet/CC-Link**

Program ⇒ Communications ⇒ Communication Settings

This parameter is used in the setup of the communications network by reading the hardware-specific settings of the option card being used with the ASD.

If using the **DEV002Z** Devicenet card, this parameter reads the hardware switch SW300 setting of the Devicenet card. SW300 sets the baud rate and the MAC address of the option card that is connected to a node of the communications system.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for more information on this parameter or see the Instruction manual for the option being used with the P9 ASD.

**Direct Access Number — F854**

Parameter Type — **Hardware Selectable**

Factory Default — **Option-Specific**

Changeable During Run — **No**

Minimum — 0

Maximum — 255

---

**Block Write Data 1**

Program ⇒ Communications ⇒ Communication Settings

This parameter plays a role in the setup of the communications network by establishing the type of data to be written to the ASD of the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- 0 — None
- 1 — FA00 (Command 1)
- 2 — FA20 (Command 2)
- 3 — FA01 (Frequency)
- 4 — FA50 (TB Output)
- 5 — FA51 (Analog Output)

**Direct Access Number — F870**

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **Yes**

---

**Block Write Data 2**

Program ⇒ Communications ⇒ Communication Settings

This parameter plays a role in the setup of the communications network by establishing the type of data to be written to the ASD of the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- 0 — None
- 1 — FA00 (Command 1)
- 2 — FA20 (Command 2)
- 3 — FA01 (Frequency)
- 4 — FA50 (TB Output)
- 5 — FA51 (Analog Output)

**Direct Access Number — F871**

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **Yes**

**Block Read Data 1**

Program ⇒ Communications ⇒ Communication Settings

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD using the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- 0 — None
- 1 — Status Information
- 2 — Output Frequency
- 3 — Output Current
- 4 — Output Voltage
- 5 — Alarm Information
- 6 — PID Feedback Value
- 7 — Input Terminal Status
- 8 — Output Terminal Status
- 9 — V/I
- 10 — RR
- 11 — RX
- 12 — DC Voltage
- 13 — PG Feedback
- 14 — Torque
- 15 — My Monitor 1
- 16 — My Monitor 2
- 17 — My Monitor 3
- 18 — My Monitor 4
- 19 — Free Memo

**Direct Access Number — F875**

Parameter Type — **Selection List**

Factory Default — 0 (None)

Changeable During Run — **Yes**

**Block Read Data 2**

Program ⇒ Communications ⇒ Communication Settings

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.

See parameter [F875](#) for more information on this setting.

**Direct Access Number — F876**

Parameter Type — **Selection List**

Factory Default — None

Changeable During Run — **Yes**

**Block Read Data 3**

Program ⇒ Communications ⇒ Communication Settings

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.

See parameter [F875](#) for more information on this setting.

**Direct Access Number — F877**

Parameter Type — **Selection List**

Factory Default — None

Changeable During Run — **Yes**

<b>Block Read Data 4</b> Program ⇒ Communications ⇒ Communication Settings  This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.  See parameter <a href="#">F875</a> for more information on this setting.	<b>Direct Access Number — F878</b> Parameter Type — <b>Selection List</b> Factory Default — None Changeable During Run — <b>Yes</b>
<b>Block Read Data 5</b> Program ⇒ Communications ⇒ Communication Settings  This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.  See parameter <a href="#">F875</a> for more information on this setting.	<b>Direct Access Number — F879</b> Parameter Type — <b>Selection List</b> Factory Default — None Changeable During Run — <b>Yes</b>
<b>Free Notes</b> Program ⇒ Communications ⇒ Communication Settings  This is an unused parameter that has allocated memory space. The space may be used at the discretion of the user. This space may be used to store information or a note to be transferred using communications.	<b>Direct Access Number — F880</b> Parameter Type — <b>Numerical</b> Factory Default — <b>0</b> Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 65534
<b>Network Option Reset Settings</b> Program ⇒ Communications ⇒ Communication Settings  This parameter plays a role in the setup of the communications network by establishing the targets of a Reset command received via the communications link.  Settings: 0 — Reset ASD only 1 — Reset Option Board and ASD	<b>Direct Access Number — F899</b> Parameter Type — <b>Selection List</b> Factory Default — <b>Reset ASD only</b> Changeable During Run — <b>Yes</b>
<b>Input Function Target 1</b> Program ⇒ My Function ⇒ My Function Unit 1  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 1</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 1</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F900</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 1</b> Program ⇒ My Function ⇒ My Function Unit 1  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F901</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)

<b>Input Function Target 2</b> Program ⇒ My Function ⇒ My Function Unit 1  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 2</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 2</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F902</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 2</b> Program ⇒ My Function ⇒ My Function Unit 1  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F903</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 3</b> Program ⇒ My Function ⇒ My Function Unit 1  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 3</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 3</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F904</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Output Function Assigned</b> Program ⇒ My Function ⇒ My Function Unit 1  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the <b>Output Function Assigned</b> terminal.  This setting assigns the function of the programmable <b>Output Function Assigned</b> data location to one of the functions listed in the <b>Input Setting</b> field of <a href="#">Table 8 on pg. 254</a> .  Settings: 0 – 3099  See the <b>My Function Instruction Manual</b> (P/N E6581335) and <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F905</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>

<b>Input Function Target 1</b> Program ⇒ My Function ⇒ My Function Unit 2  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 1</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 1</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F906</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 1</b> Program ⇒ My Function ⇒ My Function Unit 2  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F907</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 2</b> Program ⇒ My Function ⇒ My Function Unit 2  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 2</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 2</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F908</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 2</b> Program ⇒ My Function ⇒ My Function Unit 2  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F909</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 3</b> Program ⇒ My Function ⇒ My Function Unit 2  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 3</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 3</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F910</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>

<p><b>Output Function Assigned</b></p> <p>Program ⇒ My Function ⇒ My Function Unit 2</p> <p>This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the <b>Output Function Assigned</b> terminal.</p> <p>This setting assigns the function of the programmable <b>Output Function Assigned</b> data location to one of the functions listed in the <b>Input Setting</b> field of <a href="#">Table 9 on pg. 255</a>.</p> <p>Settings:</p> <p>0 – 3099</p> <p>See the <b>My Function Instruction Manual</b> (P/N E6581335) and <a href="#">F977</a> for more information on this parameter.</p>	<p><b>Direct Access Number — F911</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>0 (Disabled)</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Input Function Target 1</b></p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 1</b> terminal.</p> <p>This setting assigns the function of the programmable <b>Input Function Target 1</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a>, <a href="#">Table 9 on pg. 255</a>, or <a href="#">Table 11 on pg. 257</a>.</p> <p>See <a href="#">F977</a> for more information on this parameter.</p>	<p><b>Direct Access Number — F912</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>0 (Disabled)</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Input Function Command 1</b></p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.</p> <p><a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a>.</p>	<p><b>Direct Access Number — F913</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — 0 (NOP)</p>
<p><b>Input Function Target 2</b></p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 2</b> terminal.</p> <p>This setting assigns the function of the programmable <b>Input Function Target 2</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a>, <a href="#">Table 9 on pg. 255</a>, or <a href="#">Table 11 on pg. 257</a>.</p> <p>See <a href="#">F977</a> for more information on this parameter.</p>	<p><b>Direct Access Number — F914</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>0 (Disabled)</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Input Function Command 2</b></p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.</p> <p><a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a>.</p>	<p><b>Direct Access Number — F915</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — 0 (NOP)</p>



<b>Input Function Target 3</b> Program ⇒ My Function ⇒ My Function Unit 3  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 3</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 3</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F916</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Output Function Assigned</b> Program ⇒ My Function ⇒ My Function Unit 3  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the <b>Output Function Assigned</b> terminal.  This setting assigns the function of the programmable <b>Output Function Assigned</b> data location to one of the functions listed in the <b>Input Setting</b> field of <a href="#">Table 9 on pg. 255</a> .  Settings: 0 – 3099  See the <b>My Function Instruction Manual</b> (P/N E6581335) and <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F917</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>My Function Percent Data 1</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Percent Data 1</b> .  The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .  Once the assigned output value reaches the threshold setting of this parameter the output value is transferred to <b>My Function Out 1</b> .  See the <b>My Function Instruction Manual</b> (P/N E6581335) and <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F918</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Percent Data 2</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Percent Data 2</b> .  The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F919</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %

<b>My Function Percent Data 3</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Percent Data 3</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F920</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Percent Data 4</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Percent Data 4</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F921</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Percent Data 5</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Percent Data 5</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F922</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Frequency Data 1</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Frequency Data 1</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F923</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Frequency Data 2</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Frequency Data 2</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F924</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Frequency Data 3</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Frequency Data 1</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F925</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %

<b>My Function Frequency Data 4</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Frequency Data 4</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F926</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Frequency Data 5</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the trigger threshold level of the analog signal of the <b>My Function Frequency Data 5</b> . The analog signal is selected using the <b>Input Setting</b> number from <a href="#">Table 9 on pg. 255</a> .	<b>Direct Access Number — F927</b> Parameter Type — <b>Numerical</b> Factory Default — 0.00 Changeable During Run — <b>Yes</b> Minimum — 0.00 Maximum — 200.00 Units — %
<b>My Function Time Data 1</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the response delay of the <b>My Function Time Data 1</b> terminal. The applied discrete input signal must be present at the input terminal of the P9 ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	<b>Direct Access Number — F928</b> Parameter Type — <b>Numerical</b> Factory Default — 0.01 Changeable During Run — <b>Yes</b> Minimum — 0.01 Maximum — 600.00 Units — Seconds
<b>My Function Time Data 2</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the response delay of the <b>My Function Time Data 2</b> terminal. The applied discrete input signal must be present at the input terminal of the P9 ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	<b>Direct Access Number — F929</b> Parameter Type — <b>Numerical</b> Factory Default — 0.01 Changeable During Run — <b>Yes</b> Minimum — 0.01 Maximum — 600.00 Units — Seconds
<b>My Function Time Data 3</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the response delay of the <b>My Function Time Data 3</b> terminal. The applied discrete input signal must be present at the input terminal of the P9 ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	<b>Direct Access Number — F930</b> Parameter Type — <b>Numerical</b> Factory Default — 0.01 Changeable During Run — <b>Yes</b> Minimum — 0.01 Maximum — 600.00 Units — Seconds

<b>My Function Time Data 4</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the response delay of the <b>My Function Time Data 4</b> terminal. The applied discrete input signal must be present at the input terminal of the P9 ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	<b>Direct Access Number — F931</b> Parameter Type — <b>Numerical</b> Factory Default — 0.01 Changeable During Run — <b>Yes</b> Minimum — 0.01 Maximum — 600.00 Units — Seconds
<b>My Function Time Data 5</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the response delay of the <b>My Function Time Data 5</b> terminal. The applied discrete input signal must be present at the input terminal of the P9 ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	<b>Direct Access Number — F932</b> Parameter Type — <b>Numerical</b> Factory Default — 0.01 Changeable During Run — <b>Yes</b> Minimum — 0.01 Maximum — 600.00 Units — Seconds
<b>My Function Count Data 1</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the pulse-count threshold value used to trigger the discrete output <b>COUNT1 (ON Timer)</b> . <b>COUNT1 (ON Timer)</b> outputs a 1 upon reaching the threshold setting of this parameter.	<b>Direct Access Number — F933</b> Parameter Type — <b>Numerical</b> Factory Default — 0 Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 9999 Units — Pulses
<b>My Function Count Data 2</b> Program ⇒ My Function ⇒ My Function Data  This parameter is used to set the pulse-count threshold value used to trigger the discrete output <b>COUNT2 (ON Timer)</b> . <b>COUNT2 (ON Timer)</b> outputs a 1 upon reaching the threshold setting at this parameter.	<b>Direct Access Number — F934</b> Parameter Type — <b>Numerical</b> Factory Default — 0 Changeable During Run — <b>Yes</b> Minimum — 0 Maximum — 9999 Units — Pulses
<b>Input Function Target 1</b> Program ⇒ My Function ⇒ My Function Unit 4  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 1</b> terminal. This setting assigns the function of the programmable <b>Input Function Target 1</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> . See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F935</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>

<b>Input Function Command 1</b> Program ⇒ My Function ⇒ My Function Unit 4  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F936</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 2</b> Program ⇒ My Function ⇒ My Function Unit 4  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 2</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 2</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F937</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 2</b> Program ⇒ My Function ⇒ My Function Unit 4  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F938</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 3</b> Program ⇒ My Function ⇒ My Function Unit 4  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 3</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 3</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F939</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Output Function Assigned</b> Program ⇒ My Function ⇒ My Function Unit 4  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the <b>Output Function Assigned</b> terminal.  This setting assigns the function of the programmable <b>Output Function Assigned</b> data location to one of the functions listed in the <b>Input Setting</b> field of <a href="#">Table 9 on pg. 255</a> .  Settings: 0 – 3099  See the <b>My Function Instruction Manual</b> (P/N E6581335) and <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F940</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>

<b>Input Function Target 1</b> Program ⇒ My Function ⇒ My Function Unit 5  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 1</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 1</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F941</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 1</b> Program ⇒ My Function ⇒ My Function Unit 5  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F942</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 2</b> Program ⇒ My Function ⇒ My Function Unit 5  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 2</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 2</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F943</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 2</b> Program ⇒ My Function ⇒ My Function Unit 5  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F944</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 3</b> Program ⇒ My Function ⇒ My Function Unit 5  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 3</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 3</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F945</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>

**Output Function Assigned**

Program ⇒ My Function ⇒ My Function Unit 5

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 9 on pg. 255](#).

Settings:

0 – 3099

See the **My Function Instruction Manual** (P/N E6581335) and [F977](#) for more information on this parameter.

**Direct Access Number — F946**Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes****Input Function Target 1**

Program ⇒ My Function ⇒ My Function Unit 6

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 1** terminal.

This setting assigns the function of the programmable **Input Function Target 1** terminal to any one of the user-selectable functions listed in [Table 8 on pg. 254](#), [Table 9 on pg. 255](#), or [Table 11 on pg. 257](#).

See [F977](#) for more information on this parameter.

**Direct Access Number — F947**Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes****Input Function Command 1**

Program ⇒ My Function ⇒ My Function Unit 6

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/reset function.

[Table 12 on pg. 259](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

**Direct Access Number — F948**Parameter Type — **Selection List**

Factory Default — 0 (NOP)

**Input Function Target 2**

Program ⇒ My Function ⇒ My Function Unit 6

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 2** terminal.

This setting assigns the function of the programmable **Input Function Target 2** terminal to any one of the user-selectable functions listed in [Table 8 on pg. 254](#), [Table 9 on pg. 255](#), or [Table 11 on pg. 257](#).

See [F977](#) for more information on this parameter.

**Direct Access Number — F949**Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes****Input Function Command 2**

Program ⇒ My Function ⇒ My Function Unit 6

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/reset function.

[Table 12 on pg. 259](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

**Direct Access Number — F950**Parameter Type — **Selection List**

Factory Default — 0 (NOP)

**Input Function Target 3**

Program ⇒ My Function ⇒ My Function Unit 6

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 3** terminal.

This setting assigns the function of the programmable **Input Function Target 3** terminal to any one of the user-selectable functions listed in [Table 8 on pg. 254](#), [Table 9 on pg. 255](#), or [Table 11 on pg. 257](#).

See [F977](#) for more information on this parameter.

**Direct Access Number — F951**

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

**Output Function Assigned**

Program ⇒ My Function ⇒ My Function Unit 6

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 9 on pg. 255](#).

Settings:

0 – 3099

See the **My Function Instruction Manual** (P/N E6581335) and [F977](#) for more information on this parameter.

**Direct Access Number — F952**

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

**Input Function Target 1**

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 1** terminal.

This setting assigns the function of the programmable **Input Function Target 1** terminal to any one of the user-selectable functions listed in [Table 8 on pg. 254](#), [Table 9 on pg. 255](#), or [Table 11 on pg. 257](#).

See [F977](#) for more information on this parameter.

**Direct Access Number — F953**

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

**Input Function Command 1**

Program ⇒ My Function ⇒ My Function Unit 7

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/reset function.

[Table 12 on pg. 259](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

**Direct Access Number — F954**

Parameter Type — **Selection List**

Factory Default — **0 (NOP)**



<b>Input Function Target 2</b> Program ⇒ My Function ⇒ My Function Unit 7  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 2</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 2</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F955</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Input Function Command 2</b> Program ⇒ My Function ⇒ My Function Unit 7  This parameter is used to assign a user-selected logical operator to two user-selected <b>Input Function Target</b> variables, enable a counter/timer function, or perform a hold/reset function.  <a href="#">Table 12 on pg. 259</a> lists the available selections. Their use and selection requirements are described in an example at <a href="#">F977</a> .	<b>Direct Access Number — F956</b> Parameter Type — <b>Selection List</b> Factory Default — 0 (NOP)
<b>Input Function Target 3</b> Program ⇒ My Function ⇒ My Function Unit 7  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the programmable <b>Input Function Target 3</b> terminal.  This setting assigns the function of the programmable <b>Input Function Target 3</b> terminal to any one of the user-selectable functions listed in <a href="#">Table 8 on pg. 254</a> , <a href="#">Table 9 on pg. 255</a> , or <a href="#">Table 11 on pg. 257</a> .  See <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F957</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>
<b>Output Function Assigned</b> Program ⇒ My Function ⇒ My Function Unit 7  This parameter plays a role in the setup of the <b>My Function</b> feature by selecting the functionality of the <b>Output Function Assigned</b> terminal.  This setting assigns the function of the programmable <b>Output Function Assigned</b> data location to one of the functions listed in the <b>Input Setting</b> field of <a href="#">Table 9 on pg. 255</a> .  Settings: 0 – 3099  See the <b>My Function Instruction Manual</b> (P/N E6581335) and <a href="#">F977</a> for more information on this parameter.	<b>Direct Access Number — F958</b> Parameter Type — <b>Selection List</b> Factory Default — <b>0 (Disabled)</b> Changeable During Run — <b>Yes</b>

**Analog Input Function Target 11**

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Analog Input Function Target 11** terminal.

The function selected at [F961](#) may be adjusted using the input analog control signal selected here.

Settings:

- 0 — Disabled (None)
- 1 — V/I
- 2 — RR
- 3 — RX
- 4 — Optional RX2+, RX2-
- 5 — Optional V/I

**Direct Access Number — F959**

Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

**Analog Function Assigned Object 11**

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality to which the adjustment of [F959](#) is applied.

Settings:

- 0 — Disabled (None)
- 1 — Acceleration Rate
- 2 — Upper-Limit Frequency
- 3 — Acceleration Multiplication Factor
- 4 — Deceleration Multiplication Factor
- 5 — Manual Torque Boost
- 6 — Over-Current Stall ([F601](#))
- 7 — Thermal Protection
- 8 — Speed Loop Proportional Gain ([F460](#))
- 9 — Drooping Gain ([F320](#))
- 10 — PID Proportional Gain ([F362](#))

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Analog Function Assigned Object** parameter.

**Direct Access Number — F961**

Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

**Analog Input Function Target 21**

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Analog Input Function Target 21** terminal.

The function selected at [F964](#) may be adjusted using the input analog control signal selected here.

Settings:

- 0 — Disabled (None)
- 1 — V/I
- 2 — RR
- 3 — RX
- 4 — Optional RX2+, RX2-
- 5 — Optional V/I

**Direct Access Number — F962**

Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

**Analog Function Assigned Object 21**

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality to which the adjustment of [F962](#) is applied.

Settings:

- 0 — Disabled (None)
- 1 — Acceleration Rate
- 2 — Upper-Limit Frequency
- 3 — Acceleration Multiplication Factor
- 4 — Deceleration Multiplication Factor
- 5 — Manual Torque Boost
- 6 — Over-Current Stall ([F601](#))
- 7 — Thermal Protection
- 8 — Speed Loop Proportional Gain ([F460](#))
- 9 — Drooping Gain ([F320](#))
- 10 — PID Proportional Gain ([F362](#))

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Analog Function Assigned Object** parameter.

**Direct Access Number — F964**Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes****Monitor Output Function 11**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Average** value as selected at parameter [F966](#).

Select the **Monitor Display Input Setting** number from [Table 11 on pg. 257](#) to output the corresponding function.

Use the Communication Number if operating using communications.

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

**Direct Access Number — F965**Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes****Monitor Output Function Command 11**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F965](#) selection to be recorded and output as a monitored function.

Settings:

- 0 — Normal
- 1 — Peak
- 2 — Minimum

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

**Direct Access Number — F966**Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

---

**Monitor Output Function 21**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Average** value as selected at parameter [F968](#).

Select the **Monitor Display Input Setting** number from [Table 11 on pg. 257](#) to output the corresponding function.

Use the Communication Number if operating using communications.

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

---

**Direct Access Number — F967**Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

---

**Monitor Output Function Command 21**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F967](#) selection to be recorded and output as a monitored function.

Settings:

- 0 — Normal
- 1 — Peak
- 2 — Minimum

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

---

**Direct Access Number — F968**Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

---

**Monitor Output Function 31**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Average** value as selected at parameter [F970](#).

Select the **Monitor Display Input Setting** number from [Table 11 on pg. 257](#) to output the corresponding function.

Use the **Communication Number** if operating using communications.

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

---

**Direct Access Number — F969**Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

**Monitor Output Function Command 31**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F969](#) selection to be recorded and output as a monitored function.

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

Settings:

- 0 — Normal
- 1 — Peak
- 2 — Minimum

**Direct Access Number — F970**Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes****Monitor Output Function 41**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter [F972](#).

Select the **Monitor Display Input Setting** number from [Table 11 on pg. 257](#) to output the corresponding function.

Use the Communication Number if operating using communications.

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

**Direct Access Number — F971**Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes****Monitor Output Function Command 41**

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F971](#) selection to be recorded and output as a monitored function.

Settings:

- 0 — Normal
- 1 — Peak
- 2 — Minimum

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **Monitor Output Function** parameter.

**Direct Access Number — F972**Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

---

**Virtual Input Terminal 1 Selection**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 1**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** (connected to CC) state.

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 1** terminal to one of the functions that are listed in [Table 6 on pg. 249](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

---

**Virtual Input Terminal 2 Selection**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 2**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** (connected to CC) state.

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 2** terminal to one of the functions that are listed in [Table 6 on pg. 249](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

---

**Virtual Input Terminal 3 Selection**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 3**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** (connected to CC) state.

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 3** terminal to one of the functions that are listed in [Table 6 on pg. 249](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

---

**Virtual Input Terminal 4 Selection**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 4**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** (connected to CC) state.

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 4** terminal to one of the functions that are listed in [Table 6 on pg. 249](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

---

**Direct Access Number — F973**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Direct Access Number — F974**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Direct Access Number — F975**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Direct Access Number — F976**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

## My Function Selection

Program ⇒ My Function

This parameter **Enables/Disables** the configured **My Function** feature of the P9 ASD.

Settings:

- 0 — None (Disabled)
- 1 — My Function with Terminal Board Signal (discrete terminal activation)
- 2 — My Function Always On

## My Function

The **My Function** feature is configured using the settings of [F900](#) to [F977](#) and is used to enhance the programmability of the P9 ASD by performing two programmable functions: 1) the Combined Terminal Function, and 2) Logic Operations.

### Combined Terminal Function

Assigning more than one function to a discrete output terminal provides two advantages: it effectively expands the number of input terminals, and reduces the number of cables required to support the input/output functions (e.g., assigning ST and F to one terminal). Using **Virtual Terminals 1 – 4** ([F973](#) – [F976](#)) are required to use this function.

In the example below, the **ST** terminal assignment and the **F** terminal assignment will be combined as one terminal to illustrate this feature. However, any two of the discrete output terminal assignments listed in [Table 9 on pg. 255](#) may be combined in this manner.

### Setup (Example)

1. Disable the **My Function** parameter at [F977](#) to prevent the system from starting upon completion of the setup.
2. Assign the **ST** function to the **S1** terminal ([F115](#)).
3. Assign the **F** function to **Virtual Input Terminal 1** ([F973](#)).
4. Set **Input Function Target 1** to **5** ([F900](#)). This setting assigns **S1** as the control input terminal.
5. Set **Output Function Assigned** to **21** ([F905](#)). This setting is a command that writes the **F115** selection (S1) to **Virtual Input Terminal 1**, activating both.
6. Enable the **My Function** parameter at [F977](#) by selecting **My Function Always On** or selecting **My Function With TB Signal**.

If set to **My Function Always On**, the combination of **ST** and **F** are always On (both are connected to CC only during the S1 activation).

If set to **My Function With TB Signal**, set a discrete input terminal to **My Function Run Signal** and connect it to **CC** to enable **My Function**. Connect **S1** to **CC** to activate the **ST+F** function. A disconnection at either terminal will terminate the **My Function** programming (discrete input terminal **My Function Run Signal** is Anded with discrete input terminal **S1**).

Connect **S1** to **CC** and the **F-to-CC** + the **ST-to-CC** functions will be carried out using only **S1**.

With the aforementioned setup completed, provide a **Frequency Command** ([F004](#)) and the motor will run at the commanded frequency.

Continued on next page.

Direct Access Number — [F977](#)

Parameter Type — **Selection List**

Factory Default — **None** (Disabled)

Changeable During Run — **No**



## DANGER

This parameter must always be set to **None** at the start of the **My Function** setup and remain set to **None** until all of the **My Function** parameter settings have been confirmed as being correct.

If enabled for normal operation using settings **1** or **2**, the motor may start and engage the driven equipment unexpectedly upon receiving a **Run** signal during the **My Function** setup.

### Combined Terminal Function

Output terminals may also be combined to produce one output response to multiple conditions using the computational operators of [Table 12 on pg. 259](#). Assigning more than one function to a discrete output terminal provides two advantages: it effectively expands the number of input terminals, and reduces the number of cables required to support the input/output functions (e.g., assigning Low-Speed Detection and Low Current Detection to one output terminal). Using **Virtual Terminals 1 – 4** ([F973 – F976](#)) are required to use this function.

In the example below, the **Low-Speed Signal** (detection) terminal assignment and the **Low Current Detection** terminal assignment will be combined as one terminal output to illustrate this feature. However, any two of the discrete output terminal assignments may listed in [Table 9 on pg. 255](#) may be combined in this manner.

#### Setup (example)

1. Disable the **My Function** parameter at [F977](#) to prevent the system from starting upon completion of the setup.
2. From Program ⇒ Direct Access ⇒ Unknown Numbers, select **Enabled**.
3. Set the **OUT1** terminal ([F130](#)) to **My Function Output 1** (222).
4. Set **Input Function Target 1** ([F900](#)) to **1004** (Low-Speed Signal detection). See [Table 9 on pg. 255](#) for a complete listing of available settings.
5. Set **Input Function Target 2** ([F902](#)) to **1026** (Low Current Alarm). See [Table 9 on pg. 255](#) for a complete listing of available settings.
6. Set **Input Function Command 1** ([F901](#)) to **AND** (3). This setting assigns an operator to the **Input Function Target 1** and the **Input Function Target 2** settings.
7. Set **Output Function Assigned** ([F905](#)) to **1222**. This setting will transfer the results of the logical AND to **My Function Output 1** (OUT1).
8. Enable the **My Function** parameter at [F977](#) by selecting **My Function Always On**.

With the aforementioned setup completed in the example, once the **Low-Speed Signal** AND the **Low Current Alarm** are active, the **OUT1** terminal is activated for the duration of the **Low-Speed/Low Current** condition.

See the **My Function Instruction Manual** (P/N E6581335) for a complete description of the setup requirements and operational information of the **My Function** parameter.

### Direct Access Number — F977

Parameter Type — **Selection List**

Factory Default — **None** (Disabled)

Changeable During Run — **No**



## DANGER

This parameter must always be set to **None** at the start of the **My Function** setup and remain set to **None** until all of the **My Function** parameter settings have been confirmed as being correct.

If enabled for normal operation using settings **1** or **2**, the motor may start and engage the driven equipment unexpectedly upon receiving a **Run** signal during the **My Function** setup.



Table 6. Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions																			
NO	NC																				
<b>Note:</b> NO/NC = Normally Open/Normally Closed. NO/NC selection numbers are used when making system changes via communications.																					
0	1	<b>Unassigned</b> — No operation.																			
2	3	<b>Forward</b> — Provides a <b>Forward</b> run command.																			
4	5	<b>Reverse</b> — Provides a <b>Reverse</b> run command.																			
6	7	<b>Standby</b> — Enables the <b>Forward</b> and <b>Reverse</b> operation commands.																			
8	9	<b>Reset</b> — Resets the device and any active faults.																			
10	11	<b>Preset Speed 1</b> — <b>Preset Speed 1</b> is used as the <b>LSB</b> of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																			
12	13	<b>Preset Speed 2</b> — <b>Preset Speed 2</b> is used as the second bit of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																			
14	15	<b>Preset Speed 3</b> — <b>Preset Speed 3</b> is used as the third bit of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																			
16	17	<b>Preset Speed 4</b> — <b>Preset Speed 4</b> is used as the <b>MSB</b> of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																			
18	19	<b>Jog</b> — This terminal activates a <b>Jog</b> for the duration of the activation. The <b>Jog</b> settings may be configured at <a href="#">F260</a> – <a href="#">F262</a> .																			
20	21	<b>Emergency Off</b> — Terminates the output signal from the ASD and may apply a brake if so configured. The braking method may be selected at <a href="#">F603</a> .																			
22	23	<b>DC Braking</b> — The ASD outputs a DC current that is injected into the windings of the motor to quickly brake the motor.																			
24	25	<b>Accel/Decel Switching 1/Accel/Decel Switching 2</b> — Activating combinations of discrete input terminals <b>Accel/Decel Switching 1</b> and <b>2</b> allow for the selection of Accel/Decel profiles 1 – 4 as shown below. See <a href="#">F504</a> for more information on this terminal setting.																			
		<table><tr><th colspan="2">A/D SW Terminal</th><th rowspan="2">A/D Profile Selection</th></tr><tr><th>#1</th><th>#2</th></tr><tr><td>0</td><td>0</td><td>1</td></tr><tr><td>0</td><td>1</td><td>2</td></tr><tr><td>1</td><td>0</td><td>3</td></tr><tr><td>1</td><td>1</td><td>4</td></tr><tr><td colspan="2">1=Terminal Activated</td><td></td></tr></table>		A/D SW Terminal		A/D Profile Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated
A/D SW Terminal		A/D Profile Selection																			
#1	#2																				
0	0	1																			
0	1	2																			
1	0	3																			
1	1	4																			
1=Terminal Activated																					
26	27	The settings of the A/D selections 1 – 4 are performed at <a href="#">F009/F010</a> , <a href="#">F500/F501</a> , <a href="#">F510/F511</a> , and <a href="#">F514/F515</a> , respectively.																			
		<b>Accel/Decel</b> profiles are comprised of the <b>Accel/Decel</b> settings, <b>Pattern</b> , and <b>Switching Frequency</b> .																			
28	29	<b>V/f Switching 1/V/f Switching 2</b> — Activating combinations of discrete input terminals <b>V/f Switching 1</b> and <b>2</b> allow for the selection of a V/f switching profile as listed below.																			
		<table><tr><th colspan="2">V/f Switching Terminal</th><th rowspan="2">V/f Selection</th></tr><tr><th>#1</th><th>#2</th></tr><tr><td>0</td><td>0</td><td>1</td></tr><tr><td>0</td><td>1</td><td>2</td></tr><tr><td>1</td><td>0</td><td>3</td></tr><tr><td>1</td><td>1</td><td>4</td></tr><tr><td colspan="2">1=Terminal Activated</td><td></td></tr></table>		V/f Switching Terminal		V/f Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated
V/f Switching Terminal		V/f Selection																			
#1	#2																				
0	0	1																			
0	1	2																			
1	0	3																			
1	1	4																			
1=Terminal Activated																					
30	31	The 1 – 4 settings of the V/f Switching selections are performed at parameters <a href="#">F170</a> – <a href="#">F181</a> .																			

Table 6. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions																					
NO	NC																						
<b>Note:</b> NO/NC = Normally Open/Normally Closed. NO/NC selection numbers are used when making system changes via communications.																							
32	33	<b>Torque Limit Switching 1/Torque Limit Switching 2</b> — Activating combinations of discrete input terminals <b>Torque Limit Switching 1</b> and <b>2</b> allow for the selection of a torque limit switching profile as listed below.																					
34	35	<table><tr><th colspan="2">Torque Limit Switching Terminal</th><th rowspan="2">Torque Limit Selection</th></tr><tr><th>#1</th><th>#2</th></tr><tr><td>0</td><td>0</td><td>1</td></tr><tr><td>0</td><td>1</td><td>2</td></tr><tr><td>1</td><td>0</td><td>3</td></tr><tr><td>1</td><td>1</td><td>4</td></tr><tr><td colspan="2">1=Terminal Activated</td><td></td></tr></table>		Torque Limit Switching Terminal		Torque Limit Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated		
		Torque Limit Switching Terminal		Torque Limit Selection																			
		#1	#2																				
		0	0	1																			
		0	1	2																			
		1	0	3																			
1	1	4																					
1=Terminal Activated																							
36	37	<b>PID Off</b> — Turns off <b>PID</b> control.																					
38	39	<b>Pattern Operation Group 1</b> — Initiates the <b>Pattern 1 Pattern Run</b> .																					
40	41	<b>Pattern Operation Group 2</b> — Initiates the <b>Pattern 2 Pattern Run</b> .																					
42	43	<b>Pattern Operation Continuation</b> — Initiates a continuation of the last <b>Pattern Run</b> from its stopping point.																					
44	45	<b>Pattern Operation Trigger</b> — Initiates the first <b>Preset Speed</b> of a <b>Pattern Run</b> and initiates each subsequent enabled <b>Preset Speed</b> with continued activations.																					
46	47	<b>External Over-Heat</b> — Causes an <b>Over-Heat Trip</b> (OH).																					
48	49	<b>Hand Priority</b> (cancels serial priority) — Overrides any serial control and returns the <b>Command</b> and <b>Frequency</b> control to the settings of <b>F003</b> and <b>F004</b> .																					
50	51	<b>Hold</b> (3-Wire Stop) — Decelerates the motor to a stop.																					
52	53	<b>PID Differentiation/Integration Clear</b> — Clears the PID value.																					
54	55	<b>PID Forward/Reverse Switching</b> — Toggles the gradient characteristic of the feedback response of the <b>V/I</b> terminal during PID-controlled operation.																					
56	57	<b>Forced Continuous Operation</b> — Ignore PID control settings for the duration of activation.																					
58	59	<b>Specified Speed Operation</b> — Runs speed as commanded by the <b>Frequency Mode</b> setting.																					
60	61	<b>Dwell Signal</b> — Used in conjunction with the <b>Acceleration/Deceleration Suspend</b> function ( <b>F349</b> ) — suspends the Accel/Decel function for the duration of the activation.																					
62	63	<b>Power Failure Synchronized Signal</b> — Activates the <b>Synchronized Accel/Decel</b> function of the <b>Regenerative Power Ridethrough</b> feature. See <b>F302</b> for more information on this terminal setting.																					
64	65	<b>My Function Run</b> — Activates the configured <b>My Function</b> feature. See <b>F977</b> for more information on this parameter.																					
66	67	<b>Autotuning Signal</b> — Initiates the <b>Autotune</b> function. Set <b>F400</b> to <b>Autotuning by Input Terminal Signal</b> .																					
68	69	<b>Speed Gain Switching</b> — Toggles the ASD operating mode from and to <b>Speed Control</b> and <b>Torque Control</b> . <b>Speed Control</b> operation references parameter settings <b>F460</b> and <b>F461</b> . <b>Torque Control</b> operation references parameter settings <b>F462</b> and <b>F463</b> .																					
70	71	<b>Servo Lock</b> — Holds the motor at 0 Hz until a <b>Run</b> command is received.																					
72	73	<b>Simple Positioning</b> — While operating in the <b>Positioning Control</b> mode, activation initiates the <b>Stop</b> command. See <b>F381</b> for more information on this terminal setting.																					
74	75	<b>kWH Display Clear</b> — Clears the kWH meter display.																					
76	77	<b>Trace Back Trigger</b> — Initiates the data Read/Store function of the <b>Trace Selection</b> parameter. See <b>F740</b> for more information on this feature.																					
78	79	<b>Light-Load High-Speed Disable</b> — Terminates the Light-Load High-Speed operation.																					

Table 6. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions
NO	NC	
<i>Note: NO/NC = Normally Open/Normally Closed. NO/NC selection numbers are used when making system changes via communications</i>		
86	87	<b>Binary Write</b> — Writes the status of the discrete input terminals to the control board during binary input speed control.
88	89	<b>UP/DOWN Frequency (up)</b> — Increases the speed of the motor for the duration of activation until reaching the <b>Upper-Limit</b> setting or increases the speed of the motor in steps (See <a href="#">F264</a> for more information on this feature).
90	91	<b>UP/DOWN Frequency (down)</b> — Decreases the speed of the motor for the duration of activation until reaching the <b>Lower-Limit</b> setting or decreases the speed of the motor in steps (See <a href="#">F264</a> for more information on this feature).
92	93	<b>UP/DOWN Frequency (clear)</b> — While operating in the <b>Up/Down Frequency</b> speed control mode this terminal initiates a 0 Hz output command. If operating with an activated <b>UP/DOWN Frequency</b> (up or down) terminal, the output goes to the <b>Lower-Limit</b> ( <a href="#">F013</a> ) setting.
98	99	<b>Forward/Reverse</b> — Operates in conjunction with another terminal being set to the <b>Run/Stop</b> (100/101) function. When configured to <b>Run (Run/Stop to CC)</b> , the activation/deactivation of this terminal changes the direction of the motor.
100	101	<b>Run/Stop</b> — This terminal enables the motor to run when activated and disables the motor when deactivated.
102	103	<b>Commercial Power/ASD Switching</b> — Initiates the <b>ASD-to-Commercial Power</b> switching function. See parameter <a href="#">F354</a> for more information on this feature.
104	105	<b>Frequency Reference Priority Switching</b> — Toggles frequency control to and from the settings of <a href="#">F004</a> and <a href="#">F207</a> .
106	107	<b>V/I Terminal Priority</b> — Assigns <b>Speed</b> control to the <b>V/I Terminal</b> and overrides the <a href="#">F004</a> setting.
108	109	<b>Command Terminal Board Priority</b> — Assigns <b>Command</b> control to the <b>Terminal Board</b> and overrides the <a href="#">F003</a> setting.
110	111	<b>Edit Enable</b> — Allows for the override of the lock out parameter setting ( <a href="#">F700</a> ) allowing for parameter editing.
112	113	<b>Control Switching</b> — Toggles the system to and from the speed control and the torque control modes.
122	123	<b>Fast Deceleration</b> — Using dynamic braking (if enabled and supported), stops the motor at the fastest rate allowed by the load.
124	125	<b>Preliminary Excitation</b> — Applies an excitation current to the motor (holds shaft stationary) for the duration of the activation.
126	127	<b>Brake Request</b> — Initiates the brake release command. This setting requires that another discrete input terminal be set to <b>Brake Answerback Input</b> to complete the brake release command and to convey the status of the braking system to the user or to a dependent subsystem.  Once the braking release function is initiated, the <b>Trouble Internal Timer</b> begins to count down ( <b>Trouble Internal Timer</b> value is set at <a href="#">F630</a> ). Should the count-down timer expire before the brake releases or before the <b>Brake Answerback Input</b> is returned, fault <b>E-11</b> will occur. Otherwise, the brake releases the motor and normal motor operations resume.  The <b>Braking Release</b> function is primarily used at startup; but, may be used when the brake is applied while the motor is running.
130	131	<b>Brake Answerback Input</b> — This setting is required when the <b>Braking Request</b> function is used. The function of this input terminal is to receive the returned the status of the braking system. The returned status is either <b>Released</b> or <b>Not Released</b> .  If <b>Released</b> is returned within the time setting of <a href="#">F630</a> , normal system function resumes.  If <b>Not Released</b> is returned or if the <a href="#">F630</a> time setting times out before either signal is returned, then fault <b>E-11</b> occurs.  The returned signal may also be used to notify the user or control a dependent subsystem.
134	135	<b>Traverse Permission Signal</b> — Enables/Disables the Traverse function.
136	137	<b>Start-Stop HOA</b> — Activates the <b>Auto Start-Stop</b> operating mode in accordance with the settings of <a href="#">F385</a> .
138	139	<b>Low Suction/No Flow Protection</b> — Will not allow the ASD to start if activated, or terminates the ASD output upon activation (if running) in the event of the loss of feed water or a closed output valve at the pump output.

Table 6. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions
NO	NC	
<i><b>Note:</b> NO/NC = Normally Open/Normally Closed. NO/NC selection numbers are used when making system changes via communications</i>		
140	141	<b>Sealing Water</b> — Once an adequate water supply is detected at the pump seal via a reed switch, activation enables the ASD for normal operations.
142	143	<b>VLP Enable/Disable</b> — Activation enables the <b>VLP</b> function for normal <b>VLP</b> operation. The <b>VLP</b> function is disabled when the terminal is not active.
144	145	<b>ON Float</b> — Activation runs the ASD at the setting of <a href="#">F456</a> .
146	147	<b>OFF Float</b> — Activation has a dual function: 1) Changes the operating mode from <b>Process Hold</b> to <b>Direct</b> . 2) Turns off the ASD.
148	149	<b>Trigger Float</b> — Activation changes the operating mode from <b>Process Hold</b> to <b>Direct</b> .
150	151	<b>Alarm Float</b> — This input is typically connected to a float switch that, when activated, annunciates that the fluid level is now critical. The discrete output terminals <b>OUT1</b> and/or <b>OUT2</b> may be associated with the activation (set <b>OUT1/OUT2</b> to <b>TBA Alarm Float</b> to activate an auxiliary system — i.e., aux pump, relief valve, audible/visual alarm, etc.).
152	153	<b>TBA HOA Switch</b> — Activation enables <b>Time-Based Alternation</b> operation. Operates in conjunction with the setting of <a href="#">F417</a> .

Table 7. Output Terminal Assignments for the **FP**, **AM**, **FM**, **MON1**, and **MON2** Output Terminals.

Output Meter Terminal Assignments and Display Item Selections			
Selection/ Comm Number	Terminal Assignment Name	Selection/ Comm Number	Terminal Assignment Name
0	Output Frequency	30	100% Meter Adjust Value
1	Frequency Reference	31	Data from Communications
2	Output Current	32	185% Meter Adjust Value
3	DC Bus Voltage	33	250% Meter Adjust Value
4	Output Voltage	34	Input Watt Hour
5	Compensated Frequency	35	Output Watt Hour
6	Speed Feedback (Real Time)	45	Gain Display
7	Speed Feedback (1 Sec Filter)	46	My Function Monitor 1 Without Sign
8	Torque	47	My Function Monitor 2 Without Sign
9	Torque Command	48	My Function Monitor 3 With Sign
11	Torque Current	49	My Function Monitor 4 With Sign
12	Excitation Current	50	Signed Output Frequency
13	PID Feedback Value	51	Signed Frequency Reference
14	Motor Overload Ratio	52	Signed Compensated Frequency
15	ASD Overload Ratio	53	Signed Speed Feedback (Real Time)
16	DBR Overload Ratio	54	Signed Speed Feedback (1 Sec Filter)
17	DBR Load Ratio	55	Signed Torque
18	Input Power	56	Signed Torque Command
19	Output Power	58	Signed Torque Current
23	Option V/I Input	59	Signed PID Feedback Value
24	RR Input	60	Signed RX Input
25	V/I Input	61	Signed RX2 Option (AI1) Input
26	RX Input	62	Signed 100% Meter Adjust Value
27	RX2 Option (AI1) Input	63	Signed 185% Meter Adjust Value
28	FM Output	64	Signed 250% Meter Adjust Value
29	AM Output		

Table 8. My Function Input Function Target Selections.

Selection/ Communications Number	Terminal Assignment	Selection/ Communications Number	Terminal Assignment
0	Unassigned	17	B12
1	Forward	18	B13
2	Reverse	19	B14
3	Standby	20	B15
4	Reset	21	Virtual Input Terminal 1
5	S1	22	Virtual Input Terminal 2
6	S2	23	Virtual Input Terminal 3
7	S3	24	Virtual Input Terminal 4
8	S4	25	Internal Terminal 1
9	LI1	26	Internal Terminal 2
10	LI2	27	Internal Terminal 3
11	LI3	28	Internal Terminal 4
12	LI4	29	Internal Terminal 5
13	LI5	30	Internal Terminal 6
14	LI6	31	Internal Terminal 7
15	LI7	32	Internal Terminal 8
16	LI8		

Table 9. Output Terminal Assignments, **My Function Input Setting** Assignments, and Parameter/Input Setting Numbers for the **FLA/B/C, O1A/O1B (OUT1), O2A/O2B (OUT2), OUT3 – OUT6, and R1 – R4.**

<b>Discrete Output Terminal Assignment Selections</b>					
<b>Input Setting</b>	<b>Param. Setting</b>	<b>Function</b>	<b>Input Setting</b>	<b>Param. Setting</b>	<b>Function</b>
1000	0	Lower-Limit Frequency	1096	96	Specified Data Output 3
1002	2	Upper-Limit Frequency	1098	98	Specified Data Output 4
1004	4	Low-Speed Signal	1100	100	Specified Data Output 5
1006	6	Acceleration/Deceleration Completion	1102	102	Specified Data Output 6
1008	8	Speed Reach Signal	1104	104	Specified Data Output 7
1010	10	Failure FL (All Trips)	1106	106	Light Load
1012	12	Failure FL (Except EF, OCL, EPHO, OL2)	1108	108	Heavy Load
1014	14	Over-Current (OC) Alarm	1110	110	Positive Torque Limit
1016	16	ASD Overload (OL1) Alarm	1112	112	Negative Torque Limit
1018	18	Motor Overload (OL2) Alarm	1114	114	External Rush Suppression Relay Activated
1020	20	Over-Heat Alarm	1118	118	Completion of Stop Positioning
1022	22	Over-Voltage Alarm	1120	120	L-STOP
1024	24	Main Circuit (MOFF) Under-Voltage Alarm	1122	122	Power Failure Synchronized Operation
1026	26	Low-Current Alarm	1124	124	Traverse in Progress
1028	28	Over-Torque Alarm	1126	126	Traverse Deceleration Active
1030	30	DBR Overload Alarm	1128	128	Part Replacement Alarm
1032	32	Emergency Off Active	1130	130	Over-Torque Alarm
1034	34	Retry Active	1132	132	Frequency Command ½ Selection
1036	36	Pattern Operation Switching Output	1134	134	Failure FL (Except Emergency Off)
1038	38	PID Deviation Limit	1136	136	External Device 1
1040	40	Run/Stop	1138	138	External Device 2
1042	42	Serious Failure (OCA, OCL, EF, Phase Failure, etc.)	1140	140	External Device 3
1044	44	Light failure (OL, OC1, 2, 3, OP)	1142	142	External Device 4
1046	46	Commercial Power/ASD Switching Output 1	1144	144	External Device 5
1048	48	Commercial power/ASD switching Output 2	1146	146	External Device 6
1050	50	Cooling Fan On/Off	1148	148	Sealing Water
1052	52	Jogging Operation Active (Jog Run Active)	1150	150	NPSH/No Flow Alarm
1054	54	Panel/Terminal Board Operation Switching	1154	154	TBA Active
1056	56	Cumulative Run-time Alarm	1156	156	TBA Alarm Float
1058	58	ProfiBus/DeviceNet/CC-Link Communication Error	1222	222	My Function Output 1
1060	60	Forward/Reverse Switching	1224	224	My Function Output 2
1062	62	Ready for Operation 1	1226	226	My Function Output 3
1064	64	Ready for Operation 2	1228	228	My Function Output 4
1068	68	Brake Release (BR)	1230	230	My Function Output 5
1070	70	Alarm Status Active	1232	232	My Function Output 6
1072	72	Forward Speed Limit (Torque Control)	1234	234	My Function Output 7
1074	74	Reverse Speed Limit (Torque Control)	1236	236	My Function Output 8
1076	76	ASD Healthy Output	1238	238	My Function Output 9
1078	78	RS485 Communication Error	1240	240	My Function Output 10
1080	80	Error Code Output 1	1242	242	My Function Output 11
1082	82	Error Code Output 2	1244	244	My Function Output 12
1084	84	Error Code Output 3	1246	246	My Function Output 13
1086	86	Error Code Output 4	1248	248	My Function Output 14
1088	88	Error Code Output 5	1250	250	My Function Output 15
1090	90	Error Code Output 6	1252	252	My Function Output 16
1092	92	Specified Data Output 1	1254	254	Always Off
1094	94	Specified Data Output 2			

Table 10. Trace Back Data Selections.

Selection Number	Comm. Number	Trace (Monitor) Function	Resolution/Unit
0	FD00	Output Frequency	0.01 Hz
1	FD02	Frequency Reference	0.01 Hz
2	FD03	Output Current	0.01%
3	FD04	DC Bus Voltage	0.01%
4	FD05	Output Voltage	0.01%
5	FD15	Compensated Frequency	0.01 Hz
6	FD16	Speed Feedback (Real Time)	0.01 Hz
7	FD17	Speed Feedback (1 Sec Filter)	0.01 Hz
8	FD18	Torque	0.01%
9	FD19	Torque Command	0.01%
11	FD20	Torque Current	0.01%
12	FD21	Excitation Current	0.01%
13	FD22	PID Feedback Value	0.01 Hz
14	FD23	Motor Overload Ratio	0.01%
15	FD24	ASD Overload Ratio	0.01%
16	FD25	DBR Overload Ratio	1%
17	FD28	DBR Load Ratio	1%
18	FD29	Input Power	0.01 kW
19	FD30	Output Power	0.01 kW
23	FE39	V/I Option (AI2)	1%
24	FE35	RR Input	0.01%
25	FE36	V/I Input	0.01%
26	FE37	RX Input	0.01%
27	FE38	RX2 Option (AI1)	1%
28	FE40	FM Output	0.01%
29	FE41	AM Output	0.01%
30	FE51	Signed 100% Meter Adjust Value	1%
31	FA51	Communication Data	N/A
32	FE50	Signed 185% Meter Adjust Value	1%
33	FE67	Signed 250% Meter Adjust Value	1%
34	FE76	Input Watt-Hour	0.01 kWhr
35	FE77	Output Watt-Hour	0.01 kWhr
45	0006/0671	FM/AM Gain Display	1
46	FE60	My Function Monitor 1 (Unsigned Value)	1
47	FE61	My Function Monitor 2 (Unsigned Value)	1
48	FE62	My Function Monitor 3 (Signed Value)	1
49	FE63	My Function Monitor 4 (Signed Value)	1



Table 11. **Input Function Target** Selections and the Associated Communications Number.

Input Setting/Communication Number				Function	Resolution/ Unit
FM/AM/FP Input Setting	Comm. Number	Monitor Display Input Setting	Comm. Number		
2000	FD00	3000	FE00	Output Frequency	0.01 Hz
2002	FD02	3002	FE02	Frequency Reference	0.01 Hz
2003	FD03	3003	FE03	Output Current	0.01%
2004	FD04	3004	FE04	DC Bus Voltage	0.01%
2005	FD05	3005	FE05	Output Voltage	0.01%
2015	FD15	3015	FE15	Compensated Frequency	0.01 Hz
2016	FD16	3016	FE16	Speed Feedback (Real Time) <i>(See Note 1)</i>	0.01 Hz
2017	FD17	3017	FE17	Speed Feedback (1 Sec Filter) <i>(See Note 1)</i>	0.01 Hz
2018	FD18	3018	FE18	Torque <i>(See Note 2)</i>	0.01%
2019	FD19	3019	FE19	Torque Command <i>(See Note 2)</i>	0.01%
2020	FD20	3020	FE20	Torque Current <i>(See Note 2)</i>	0.01%
2021	FD21	3021	FE21	Excitation Current	0.01%
2022	FD22	3022	FE22	PID Feedback Value	0.01 Hz
2023	FD23	3023	FE23	Motor Overload Ratio	0.01%
2024	FD24	3024	FE24	ASD Overload Ratio	0.01%
2025	FD25	3025	FE25	DBR Overload Ratio	1%
2028	FD28	3028	FE28	DBR Load Ratio	1%
2029	FD29	3029	FE29	Input Power	0.01 kW
2030	FD30	3030	FE30	Output Power	0.01 kW
		3031	FE31	Pattern Operation Group Number	0.1
		3032	FE32	Pattern Operation Cycles Remaining	1
		3033	FE33	Pattern Operation Preset Speed Number	1
		3034	FE34	Pattern Operation Preset Speed Time Remaining	0.1
2050	FD50			Light-Load High-Speed Load Torque Monitor 1	0.01%
2051	FD51			Light-Load High-Speed Load Torque Monitor 2	0.01%
		3035	FE35	RR Input	1%
		3036	FE36	V/I Input	1%
		3037	FE37	RX Input <i>(See Note 2)</i>	1%
		3038	FE38	RX2 Option (AI1) Input <i>(See Note 2)</i>	1%
		3039	FE39	RX2 Option (AI1) Input	1%
		3040	FE40	FM Output	1
		3041	FE41	AM Output	1
<b>Note 1:</b> If no PG feedback is used an estimated speed value is displayed.					
<b>Note 2:</b> My Function cannot process negative values — A negative value is processed by <b>My Function</b> as an absolute value.					

Table 11. (Continued) **Input Function Target** Selections and the Associated Communications Number.

Input Setting/Communication Number				Function	Resolution/ Unit
FM/AM/FP Input Setting	Comm. Number	Monitor Display Input Setting	Comm. Number		
3050	FE50			Communication Data Output 2	
3051	FE51			Communication Data Output 1	
3052	FE52			Communication Data Output 3	
3060	FE60			My Function Monitor 1 (Output of Unsigned Value)	
3061	FE61			My Function Monitor 2 (Output of Unsigned Value)	
3062	FE62			My Function Monitor 3 (Output of Signed Value)	
3063	FE63			My Function Monitor 4 (Output of Signed Value)	
		3066	FE66	Expansion I/O Card 1 CPU Version	0.01 kW
		3067	FE67	Expansion I/O Card 2 CPU Version	
		3076	FE76	Integral Input Power	
		3077	FE77	Integral Output Power	
		3084	FE84	16-Bit BIN/BCD Input Value	1

Table 12. My Function Operator Selections.

My Function Computational Selections		
Input Function Command	Function Name	Function Description
0	NOP (No Operation)	Disables the My Function feature.
1	ST	Execute data read/transfer.
2	STN	Execute inverted data read/transfer.
3	AND	Logical product of A AND B.
4	ANDN	Logical product of A AND $\overline{B}$ .
5	OR	Logical sum of A OR B.
6	ORN	Logical sum of A OR $\overline{B}$ .
7	EQ	Compares data — Outputs 1 if Equal; 0 if not Equal.
8	NE	Compares data — Outputs 0 if Equal; 1 if not Equal.
9	GT	Compares data — Outputs 1 if A>B; 0 if A≤B.
10	GE	Compares data — Outputs 1 if A≥B; 0 if A<B.
11	LT	Compares data — Outputs 1 if A<B; 0 if A≥B.
12	LE	Compares data — Outputs 1 if A≤B; 0 if A>B.
13	ASUB	Outputs absolute difference between A and B —  A-B
14	ON (Timer)	Enables the On response time delay settings of <b>My Function Time Data 1 – 5</b> ( <a href="#">F928 – F932</a> ) for <b>My Function Data</b> .
15	OFF (Timer)	Enables the Off response time delay settings of <b>My Function Time Data 1 – 5</b> ( <a href="#">F928 – F932</a> ) for <b>My Function Data</b> .
16	COUNT1 (Timer)	Outputs a 1 upon reaching the pulse count setting of <a href="#">F933</a> .
17	COUNT2 (Timer)	Outputs a 1 upon reaching the pulse count setting of <a href="#">F934</a> .
18	HOLD	Outputs the peak output value since powering up or since the last reset.
19	SET	Sets data.
20	RESET	Resets data.

# Alarms, Trips, and Troubleshooting

## Alarms and Trips

This section lists the available user-notification codes of the EOI display and provides information that assists the user in the event that a **Fault** is incurred. The **User Notification** codes are displayed as an indication that a system function or system condition is active (i.e., ATN, DB, and DBON). The code is displayed on the EOI for the duration of the activation.

If a user setting or an P9 ASD parameter has been exceeded, or if a data transfer function produces an unexpected result, a condition that is referred to as a **Fault** is incurred.

An **Alarm** is an indication that a **Fault** is imminent if existing operating conditions continue unchanged. An **Alarm** may be associated with an output terminal to notify the operator of the condition remotely, close a contact, or engage a brake. At the least, an **Alarm** will cause an alarm code to appear on the EOI display. [Table 14](#) lists the **Alarm** codes that may be displayed during operation of the P9 ASD.

In the event that the condition that caused the **Alarm** does not return to its normal operating level within a specified time, the ASD **Faults** and a **Trip** is incurred (**Fault** and **Trip** are sometimes used interchangeably).

A **Trip** is a safety feature (the result of a **Fault**) that disables the P9 ASD system and removes the 3-phase power from the motor in the event that a subsystem of the ASD is malfunctioning, or one or more of the variables listed below exceeds its normal range (time and/or magnitude).

- Current,
- Voltage,
- Speed,
- Temperature,
- Torque, or
- Load.

See [Table 15 on pg. 265](#) for a listing of the potential **Trips** and the associated probable causes.

The operating conditions at the time of the trip may be used to help determine the cause of the trip. Listed below are operating conditions that may be used to assist the operator in correcting the problem or that the P9 ASD operator should be prepared to discuss when contacting the TIC Customer Support Center for assistance.

- What trip information is displayed?
- Is this a new installation?
- Has the system ever worked properly and what are the recent modifications (if any)?
- What is the ASD and Motor size?
- What is the CPU version and revision level?
- What is the EOI version?
- Does the ASD trip when accelerating, running, decelerating, or when not running?
- Does the ASD reach the commanded frequency?
- Does the ASD trip without the motor attached?
- Does the ASD trip with an unloaded motor?

# User Notification Codes

The **User Notification** codes appear in the top right corner of the **Frequency Command** screen while the associated function is active.

**User Notification** codes notify the user of active functions that are usually only momentary under normal conditions and are active for the duration of activation only. User notification events are not error conditions and only convey active system functions to the user.

Table 13. User Notification Codes.

LED	Function	Description
Atn	Autotune active	Atn indicates that the <b>Autotune</b> function is active.
dbOn	DC Braking	This code conveys the <b>DC Injection</b> function being carried out. The display shows <b>db</b> when braking and shows <b>dbOn</b> when the motor shaft stationary function is being carried out.

# Alarms

Table 14 lists the alarm codes that may be displayed during operation of the P9 ASD. Each alarm code listed is accompanied by a description and a possible cause. In the event that the source of the malfunction cannot be determined, contact your TIC Sales Representative for further information on the condition and for an appropriate course of action.

The **Alarms** are listed in the top-down order that they are checked for activation. Only the first to be detected will be displayed on the **Frequency Command** screen.

Table 14. P9 ASD Alarms.

LED Screen	LCD Screen	Description	Possible Causes/Troubleshooting
RbFL	Low Suction/No Flow Cut Off	Running ASD producing no flow.	<ul style="list-style-type: none"> <li>Loss of suction pressure or closed pump output valve.</li> <li>Activated discrete input terminal set to <b>Low Suction/No Flow Protection</b>.</li> <li>ASD <b>Upper-Limit Frequency</b> run-time is equal to <b>F484</b> time setting.</li> </ul>
EN1	Comm1 Error	Internal communications error.	<ul style="list-style-type: none"> <li>Improperly programmed ASD.</li> <li>Improper communications settings.</li> <li>Improperly connected cables.</li> </ul>
EN2	Comm2 Error	External communications error.	
E	Emergency Off	Output signal from the ASD is terminated and a brake may be applied if so configured.	<ul style="list-style-type: none"> <li>Stop/Reset pressed twice at the EOI.</li> <li>EOFF command received remotely.</li> <li>ASD reset required.</li> </ul>
NOFF	Main Under-Voltage	Under-voltage condition at the 3-phase AC input to the ASD.	<ul style="list-style-type: none"> <li>Low 3-phase commercial voltage.</li> <li>PO-to-PA jumper not secured or missing.</li> <li>Typeform error.</li> <li>Loss of externally-supplied control power.</li> </ul>
OC	Over-Current	ASD output current greater than <b>F601</b> setting.	<ul style="list-style-type: none"> <li>Defective IGBT (U, V, or W).</li> <li>ASD output to the motor is connected incorrectly.</li> <li>ASD output phase-to-phase short.</li> <li>The ASD is starting into a spinning motor.</li> <li>Motor/machine jammed.</li> <li>Mechanical brake engaged while the ASD is starting or while running.</li> <li>Accel/Decel time is too short.</li> <li>Voltage Boost setting is too high.</li> <li>Load fluctuations.</li> <li>ASD operating at an elevated temperature.</li> <li>Disconnected/damaged cable while operating in the PG Feedback Vector Control mode.</li> </ul>

LED Screen	LCD Screen	Description	Possible Causes/Troubleshooting
* Reset ignored if active.			
*OH	Overheat	ASD ambient temperature excessive.	<ul style="list-style-type: none"> <li>ASD is operating at an elevated temperature.</li> <li>ASD is too close to heat-generating equipment.</li> <li>Cooling fan vent is obstructed (see <a href="#">Mounting the ASD on pg. 15</a>).</li> <li>Cooling fan is inoperative.</li> <li>Internal thermistor is disconnected.</li> </ul>
OU	Timer	Run-time counter exceeded.	<ul style="list-style-type: none"> <li><b>Type Reset</b> required; select <b>Clear run timer</b>.</li> </ul>
*OL1	ASD Overload	Load requirement in excess of the capability of the ASD.	<ul style="list-style-type: none"> <li>The carrier frequency is too high.</li> <li>An excessive load.</li> <li>Acceleration time is too short.</li> <li>DC damping rate is set too high.</li> <li>The motor is starting into a spinning load after a momentary power failure.</li> <li>The ASD is improperly matched to the application.</li> </ul>
OLN	Motor Overload	Load requirement in excess of the capability of the motor.	<ul style="list-style-type: none"> <li>V/f parameter improperly set.</li> <li>Motor is locked.</li> <li>Continuous operation at low speed.</li> <li>The load is in excess of what the motor can deliver.</li> <li>Disconnected/damaged cable while operating in the PG Feedback Vector Control mode.</li> </ul>
*OLr	Resistor Overload	Excessive current at the <b>Dynamic Braking Resistor</b> .	<ul style="list-style-type: none"> <li>Deceleration time is too short.</li> <li>DBR configuration improperly set.</li> </ul>
*OP	Over-Voltage	DC bus voltage exceeds specifications.  <i>Note: It is normal for the <b>OP</b> alarm to flash during decel when using the <b>Automatic Acc/Dec</b> setting at <b>F000</b>.</i>	<ul style="list-style-type: none"> <li>ASD attempting to start into a spinning motor after a momentary power loss.</li> <li>Incoming commercial power is above the specified range.</li> <li>Decel time is too short.</li> <li>Voltage spikes at the 3-phase input; install inductive filter.</li> <li>DBR required.</li> <li>DBR resistance value is too high.</li> <li>DBR function is turned off.</li> <li>Over-Voltage Stall feature is turned off.</li> <li>System is regenerating.</li> <li>Load instability.</li> <li>Disable the Ridethrough function (<b>F302</b>).</li> </ul>
OT	Over-Torque	Torque requirement is in excess of the setting of <b>F616</b> or <b>F617</b> for a time longer than the setting of <b>F618</b> .	<ul style="list-style-type: none"> <li>ASD is not correctly matched to the application.</li> <li><b>F616</b> or <b>F617</b> setting is too low.</li> <li>Obstructed load.</li> <li>Disconnected/damaged cable while operating in the PG Feedback Vector Control mode.</li> </ul>

LED Screen	LCD Screen	Description	Possible Causes/Troubleshooting
* Reset ignored if active.			
*P0FF	Control Under-Voltage	Under-voltage condition at the 5, 15, or the 24 VDC supply.	<ul style="list-style-type: none"> <li>Defective Control board.</li> <li>Excessive load on power supply.</li> <li>Low input voltage.</li> </ul>
Pt5t	Reference Point	Two speed-reference frequency setpoint values are too close to each other.	<ul style="list-style-type: none"> <li>Two speed reference frequency setpoints are too close to each other (increase the difference).</li> </ul>
UC	Under-Current	With the <b>Low-Current Trip (F610)</b> parameter enabled, the output current of the ASD is below the level defined at <b>F611</b> and remains there for a time longer than the setting of <b>F612</b> .	<ul style="list-style-type: none"> <li>Output current too low.</li> </ul>



# Trips/Faults

A **Trip** is an P9 ASD response to a **Fault** (though **Fault** and **Trip** are sometimes used interchangeably). A **Trip** is a safety feature that disables the ASD system in the event that a subsystem of the ASD is malfunctioning or a parameter setting has been exceeded.

Listed in [Table 15](#) are the **Faults** that may result in a **Trip** and the possible causes. When a **Trip** is incurred the system displays the **Fault** screen. The **Fault** screen identifies the active **Fault**.

Table 15. P9 ASD Fault Listing.

LED Screen	LCD Screen	Possible Causes/Troubleshooting
RbFL	Low Suction/No Flow Cut Off	<ul style="list-style-type: none"> <li>Loss of suction pressure or closed pump output valve.</li> <li>Activated discrete input terminal set to <b>Low Suction/No Flow Protection</b>.</li> <li>ASD <a href="#">Upper-Limit Frequency</a> run-time is equal to <a href="#">F484</a> time setting.</li> </ul>
E	Emergency Off	<ul style="list-style-type: none"> <li>Emergency Off command received via EOI or remotely.</li> </ul>
E-10	Sink/Source Setting Error	<ul style="list-style-type: none"> <li>Improperly positioned <b>Sink/Source</b> jumper on the Terminal board or on an option device (see J100 at the Terminal PCB of the ASD).</li> <li><b>Sink/Source</b> configuration is incorrect.</li> </ul>
E-11	Brake Sequence Response Error	<ul style="list-style-type: none"> <li><a href="#">F630</a> is set to a non-zero value.</li> <li>Braking sequence discrete input and output terminals are not set up properly.</li> </ul>
E-12	Encoder Signal-Loss Error	<ul style="list-style-type: none"> <li>ASD is configured to receive a signal from a shaft-mounted encoder and no signal is being received while running.</li> <li>Disconnection at the Encoder circuit.</li> <li>Motor is stopped and is generating torque via torque limit control.</li> <li>ASD is not configured properly.</li> </ul>
E-13	Speed Error	<ul style="list-style-type: none"> <li>Result of a motor speed that is greater than the commanded speed when using an encoder for speed control.</li> <li>Improper encoder connection or setup information.</li> <li>Defective encoder.</li> </ul>
E-17	Key Failure	<ul style="list-style-type: none"> <li>Same key input for 20 seconds or more.</li> </ul>
E-18	Analog (Terminal) Input Loss	<ul style="list-style-type: none"> <li>V/I signal loss.</li> <li>Terminal Board failure.</li> <li>P24 over-current condition.</li> <li><a href="#">F633</a> setting is too high.</li> </ul>
E-19	CPU Communication Error	<ul style="list-style-type: none"> <li>CPU data Transmit/Receive error.</li> </ul>
E-20	V/f Control Error	<ul style="list-style-type: none"> <li>Torque processing error.</li> <li>Make service call.</li> </ul>
E-21	CPU Processing Error	<ul style="list-style-type: none"> <li>Software processed incorrectly.</li> <li>Make service call.</li> </ul>
E-22	Logic Input Voltage Error	<ul style="list-style-type: none"> <li>Incorrect voltage applied to the discrete input terminals.</li> </ul>

LED Screen	LCD Screen	Possible Causes/Troubleshooting
E-23	Optional Expansion Input Terminal Board 1 Error	<ul style="list-style-type: none"> <li>Optional Expansion Input Terminal Board 1 is defective.</li> </ul>
E-24	Optional Expansion Input Terminal Board 2 Error	<ul style="list-style-type: none"> <li>Optional Expansion Input Terminal Board 2 is defective.</li> </ul>
E-25	Stop Positioning Retention Error	<ul style="list-style-type: none"> <li>Load movement while stopped.</li> <li>F381 setting is too low.</li> <li>Encoder malfunction.</li> <li>Creep speed is too high.</li> </ul>
E-26	CPU2 Fault	<ul style="list-style-type: none"> <li>CPU malfunction.</li> <li>Control board malfunction.</li> </ul>
E-50/E-51	Sink/Source Setting Error	<ul style="list-style-type: none"> <li>Improperly positioned <b>Sink/Source</b> jumper on the Terminal board or on an option device (see J100 at the Terminal PCB of the ASD).</li> <li><b>Sink/Source</b> configuration is incorrect.</li> </ul>
EEP1	EEPROM Fault	<ul style="list-style-type: none"> <li>EEPROM write malfunction.</li> <li>Make a service call.</li> </ul>
EEP2/EEP3	EEPROM Read Error	<ul style="list-style-type: none"> <li>EEPROM read malfunction.</li> <li>Make a service call.</li> </ul>
EF1/EF2	(Earth) Ground Fault	<ul style="list-style-type: none"> <li>Ground fault at the motor.</li> <li>Ground fault at the output of the ASD.</li> <li>Current leakage to <b>Earth Ground</b>.</li> </ul>
EPH1	Input Phase Failure	<ul style="list-style-type: none"> <li>3-phase input to the ASD is low or missing at the R, S, or T input terminals.</li> </ul>
EPH2	Output Phase Failure	<ul style="list-style-type: none"> <li>3-phase output from the ASD is low or missing at the U, V, or W output terminals or at the input to the motor.</li> </ul>
Err2	RAM Fault	<ul style="list-style-type: none"> <li>Internal RAM malfunction.</li> <li>Make a service call.</li> </ul>
Err3	ROM Fault	<ul style="list-style-type: none"> <li>Internal ROM malfunction.</li> <li>Make a service call.</li> </ul>
Err4	CPU Fault	<ul style="list-style-type: none"> <li>CPU malfunction.</li> <li>Control board malfunction.</li> <li>Make a service call.</li> </ul>
Err5	Communication Error	<ul style="list-style-type: none"> <li>Communication time out error.</li> <li>Communication malfunction.</li> <li>Improper or loose connection.</li> <li>Improper system settings.</li> </ul>
Err6	Gate Array Fault	<ul style="list-style-type: none"> <li>Main Gate Array is defective.</li> </ul>
Err7	Low -Current	<ul style="list-style-type: none"> <li>Improper Low- Current detection level settings at F609 – F612.</li> </ul>
Err8	Option Device Fault	<ul style="list-style-type: none"> <li>Check installation, connections, and option device manual.</li> </ul>

LED Screen	LCD Screen	Possible Causes/Troubleshooting
Err9	Flash Memory Fault	<ul style="list-style-type: none"> <li>Flash memory malfunction.</li> <li>Make a service call.</li> </ul>
EEn	Autotune Error	<ul style="list-style-type: none"> <li>No motor connected or improperly secured connection.</li> <li><b>Autotune</b> readings that are significantly inconsistent with the configuration information.</li> <li>A non-3-phase motor is being used.</li> <li>Incorrect settings at <b>F400</b>, <b>F413</b>, or <b>F416</b>.</li> <li>Using a motor that has a significantly smaller rating than the ASD.</li> <li>ASD output cabling is too small, too long, or is being housed in a cable tray with other cables that are producing an interfering EMF.</li> <li>Motor is running during the <b>Autotune</b> function.</li> </ul>
EEn1		<ul style="list-style-type: none"> <li><b>F402</b> adjustment required (Motor temperature is too high).</li> <li><b>F410</b> adjustment required (Motor Constant 1 improperly set).</li> </ul>
EEn2		<ul style="list-style-type: none"> <li><b>F402</b> adjustment required (Motor temperature is too high).</li> <li><b>F412</b> adjustment required (Motor Constant 3 improperly set).</li> <li>Motor shaft is rotating during <b>Autotune</b>.</li> </ul>
EEn3		<ul style="list-style-type: none"> <li>Autotune setting <b>F400</b> is set to Auto Calculation and there is a problem with the Motor Constant readings.</li> </ul>
EEnP	Typeform Error	<ul style="list-style-type: none"> <li>Firmware information (typeform) loaded into the <b>Gate Driver</b> board is inconsistent with the device in which the firmware is being used.</li> <li>The <b>Gate Driver</b> board has been replaced.</li> <li>The <b>Gate Driver</b> board is defective.</li> </ul>
nonE	No Errors	<ul style="list-style-type: none"> <li>No active faults.</li> </ul>
OC 1	Over-Current During Acceleration	<ul style="list-style-type: none"> <li>Improper V/f setting.</li> <li>Restart from a momentary power outage.</li> <li>The ASD is starting into a rotating motor.</li> <li>ASD/Motor not properly matched.</li> <li>Phase-to-phase short (<b>U</b>, <b>V</b>, or <b>W</b>).</li> <li><b>Accel</b> time too short.</li> <li><b>Voltage Boost</b> setting is too high.</li> <li>Motor/machine jammed.</li> <li>Mechanical brake engaged while the ASD is running.</li> <li>ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during acceleration. On ASDs that are greater than 100 HP, this fault occurs when the ASD current exceeds 320% of the rated FLA during acceleration.</li> </ul>

LED Screen	LCD Screen	Possible Causes/Troubleshooting
OC 1P	Overheat During Acceleration	<ul style="list-style-type: none"> <li>Cooling fan inoperative.</li> <li>Ventilation openings are obstructed.</li> <li>Internal thermistor is disconnected.</li> <li>Acceleration time is too short.</li> <li>Improper V/f setting.</li> <li>ASD or the motor is improperly matched to the application.</li> </ul>
OC2	Over-Current During Deceleration	<ul style="list-style-type: none"> <li>Phase-to-phase short (U, V, or W).</li> <li>Deceleration time is too short.</li> <li>Motor/machine jammed.</li> <li>Mechanical brake engaged while the ASD is running.</li> <li>ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during deceleration. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA during deceleration.</li> </ul>
OC2P	Overheat During Deceleration	<ul style="list-style-type: none"> <li>Cooling fan inoperative.</li> <li>Ventilation openings are obstructed.</li> <li>Internal thermistor is disconnected.</li> <li>Deceleration time is too short.</li> <li>DC Injection current is too high.</li> <li>ASD or the motor is improperly matched to the application.</li> </ul>
OC3	Over-Current During Run	<ul style="list-style-type: none"> <li>Load fluctuations.</li> <li>ASD is operating at an elevated temperature.</li> <li>ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during a fixed-speed run or if during a fixed-speed run the ASD overheats. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA on a fixed-speed run.</li> </ul>
OC3P	Overheat During Run	<ul style="list-style-type: none"> <li>Cooling fan inoperative.</li> <li>Ventilation openings are obstructed.</li> <li>Internal thermistor is disconnected.</li> <li>Improper V/f setting.</li> <li>ASD or the motor is improperly matched to the application.</li> </ul>
OCRA1 or OCL	U-Phase Over-Current	<ul style="list-style-type: none"> <li>Low impedance at the U lead of the ASD output.</li> </ul>
OCRA2 or OCL	V-Phase Over-Current	<ul style="list-style-type: none"> <li>Low impedance at the V lead of the ASD output.</li> </ul>
OCRA3 or OCL	W-Phase Over-Current	<ul style="list-style-type: none"> <li>Low impedance at the W lead of the ASD output.</li> </ul>
OCr	Dynamic Braking Resistor Over-Current	<ul style="list-style-type: none"> <li>ASD inability to discharge the bus voltage during regeneration.</li> <li>No dynamic braking resistor (DBR) installed.</li> <li>Deceleration time is too short.</li> <li>Improper DBR setup information.</li> <li>Defective IGBT7 (or IGBT7 ckt.).</li> <li>3-phase input voltage is above specification.</li> </ul>

LED Screen	LCD Screen	Possible Causes/Troubleshooting
OH	Overheat	<ul style="list-style-type: none"> <li>Cooling fan inoperative.</li> <li>Ventilation openings are obstructed.</li> <li>Internal thermistor is disconnected.</li> </ul>
OH2	External Overheat	<ul style="list-style-type: none"> <li>Excessive-heat signature received at the <b>TB3 – TH1(+)</b> and <b>TH1(-)</b> terminals. See <a href="#">F637</a> for setup information.</li> </ul>
OL 1	ASD Overload	<ul style="list-style-type: none"> <li>Acceleration time is too short.</li> <li>DC Injection current is too high.</li> <li>Improper V/f setting.</li> <li>Motor running during restart.</li> <li>ASD or the motor is improperly matched to the application.</li> </ul>
OL2	Motor Overload	<ul style="list-style-type: none"> <li>Improper V/f setting.</li> <li>Motor is locked.</li> <li>Continuous operation at low speed.</li> <li>Load requirement exceeds ability of the motor.</li> <li>Startup frequency setting adjustment required.</li> </ul>
OLr	Dynamic Braking Resistor Overload	<ul style="list-style-type: none"> <li>Deceleration time is too short.</li> <li>DBR setting adjustment required.</li> <li>Over-Voltage Stall setting adjustment required.</li> </ul>
OP 1	Over-Voltage During Acceleration	<ul style="list-style-type: none"> <li>Motor running during restart.</li> </ul>
OP2	Over-Voltage During Deceleration	<ul style="list-style-type: none"> <li>Deceleration time is too short.</li> <li>DBR value is too high.</li> <li>DBR required (DBR setup required).</li> <li>Stall protection is disabled.</li> <li>3-phase input voltage is out of specification.</li> <li>Input reactance required.</li> </ul>
OP3	Over-Voltage During Run	<ul style="list-style-type: none"> <li>Load fluctuations.</li> <li>3-Phase input voltage out of specification.</li> <li>DBR required (DBR setup required).</li> </ul>
OT	Over-Torque	<ul style="list-style-type: none"> <li>A torque requirement by the load in excess of the setting of <a href="#">F616</a> or <a href="#">F617</a> for a time longer than the setting of <a href="#">F618</a>.</li> <li>The ASD is improperly matched to the application.</li> <li>The load is obstructed.</li> </ul>
SEAL	Sealing Water Error	<ul style="list-style-type: none"> <li>Inadequate pump seal water.</li> <li>Loss of pump seal water.</li> </ul>
SOUL	Step-Out (for PM Motor Only)	<ul style="list-style-type: none"> <li>Motor shaft is locked.</li> <li>Output phase is open.</li> <li>Operating a reciprocating load.</li> </ul>
UP 1	Main Power Under-Voltage	<ul style="list-style-type: none"> <li>Input 3-phase voltage is too low.</li> <li>Momentary power failure longer than the time setting of <a href="#">F628</a>.</li> </ul>
UP2	Control Power Under-Voltage	<ul style="list-style-type: none"> <li>This fault is caused by an under-voltage condition at the 5, 15, or the 24 VDC supply.</li> <li>3-phase input voltage low.</li> </ul>

## Viewing Trip Information

In the event that the condition causing an **Alarm** does not return to the normal operating level within a specified time, the P9 ASD **Faults** and a **Trip** is incurred.

When a trip occurs, the resultant error information may be viewed either from the LED screen, LCD **Fault** screen (Table 15 on pg. 265), **Monitor** screen, or the **Trip History** screen (Program ⇒ Utilities ⇒ **Trip History**).

### Trip Record at Monitor Screen

The at-trip condition of the last 4 incurred trips may be viewed at the **Monitor** screen. The **Monitor** screen displays the records of up to four trips and catalogs each trip as **Past Trip 1** through **Past Trip 4** (see pg. 50). Once reset (**Type Reset**), the trip records are erased. If no trips have occurred since being powered up or since the last reset, **None** is displayed for each trip record.

The **Monitor** screen at-trip record is erased when the P9 ASD is reset.

**Note:** An improper P9 ASD setup may cause some trips — Save the existing parameter profile via Program\Utilities\Save/Restore Wizard and then reset the ASD to the **Factory Default** settings before pursuing a systemic malfunction (Program ⇒ Utilities ⇒ Type Reset ⇒ **Reset to Factory Settings**).

### Trip History

The **Trip History** screen records the system parameters for up to 20 trips. The recorded trips are numbered from zero to 19. Once the **Trip History** record reaches trip number 19, the oldest recorded trip will be deleted with each new record stored (first-in first-out). The **Trip #** field may be selected and scrolled through to view the recorded trip information for a given trip number. The monitored parameters are listed in Table 16 as **At-trip Recorded Parameters** (parameter readings at the time that the trip occurred).

In the event of a power loss or if the keypad has been removed from the ASD, the trip records and the real-time clock information are retained within the keypad for up to 4.5 years via **Battery Backup**.

Table 16. Trip History Record Parameters.

At-trip Recorded Parameters			
Trip records are comprised of the full list of monitored parameters (28).			
1) Trip Number	8) Frequency Reference	15) Feedback (1 sec.)	22) ASD Overload
2) Trip Type	9) Bus Voltage	16) Torque	23) DBR Overload
3) Time and Date	10) Discrete Input Status	17) Torque Reference	24) Motor Load
4) Frequency at Trip	11) OUT1/OUT2/FL Status	18) Torque Current	25) ASD Load
5) Output Current	12) Timer	19) Excitation Current	26) DBR Load
6) Output Voltage	13) Post Compensation Frequency	20) PID Value	27) Input Power
7) Direction	14) Feedback (inst.)	21) Motor Overload	28) Output Power

## Clearing a Trip

Once the cause of the trip has been corrected, performing a **Reset** re-enables the P9 ASD for normal operation.

The record of a trip may also be cleared using either of the following methods:


- Cycling power (trip info may be saved via **F602** if desired),
- Pressing the **Stop-Reset** key twice,
- Remotely via the communications channel,
- Momentarily connecting terminal **RES** to **CC** of the **Terminal Board**, or
- Via Program ⇒ Utilities ⇒ Type Reset ⇒ **Clear Past Trip** (clears Monitor screen records only).

# Enclosure and Conduit Plate Dimensions

The P9 ASD part numbering convention is shown below.

The enclosure dimensions for the available models (typeforms) are listed in [Tables 17](#) and [18](#). The conduit plates referenced are shown in [Figures 41](#), [42](#), and [43](#).

## P9 Part Numbering Convention.



**Note:** The Type 1 enclosed versions of these drives meet or exceed the specification **UL 50-1995, the Standard for Heating and Cooling Equipment**, and complies with the applicable requirements for installation in a compartment handling conditioned air.

## Enclosure Dimensions

Table 17. 230-Volt P9 ASD Systems.

Frame	Model Number VT130P9U	Enclosure Figure Number	A Width (in/mm)	B Height (in/mm)	C Depth (in/mm)	Mounting Hole Dimensions (in/mm)				Conduit Plate
						D	E	R1	R2	
2	2010	Figure 38	5.2/132	11.2/285	6.1/155	8.7/220	4.5/114	0.098/2.5	0.217/5.5	Figure 41-A
	2015									
	2025									
3	2035		6.1/155	12.4/315	6.6/168	9.8/249	5.4/138			
	2055									
4	2080		6.9/175	15.0/381		11.1/283	6.2/158		0.236/6.0	Figure 41-B
	2110									
5B	2160		9.1/231	19.3/490	7.6/193	15.2/386	8.3/210	0.118/3.0	0.276/7.0	Figure 41-D
	2220									
	2270									
6	2330	Figure 39	11.1/283	25.9/658	13.2/335	25.0/635	8.0/203	0.188/4.8	0.375/9.5	Figure 41-E
7B	2400		14.3/363	33.1/841	15.0/381	32.3/820				Figure 42-G
	2500									
	2600									
	2750									
9	210K	Figure 40	14.6/371	51.7/1313	17.6/447	50.2/1275	9.2/234	0.344/8.7	0.670/17	Figure 42-I
10	212K		15.7/399	53.1/1349		51.7/1313	9.9/252			Figure 42-J

Table 18. 460-Volt P9 ASD Systems.

Frame	Model Number VT130P9U	Enclosure Figure Number	A Width (in/mm)	B Height (in/mm)	C Depth (in/mm)	Mounting Hole Dimensions (in/mm)				Conduit Plate					
						D	E	R1	R2						
2	4015	Figure 38	5.2/132	11.2/285	6.1/155	8.7/220	4.5/114	0.098/2.5	0.217/5.5	Figure 41-A					
	4025														
	4035														
3	4055		6.1/155	12.4/315	6.6/168	9.8/249	5.4/138				0.236/6.0	Figure 41-B			
	4080														
4	4110		6.9/175	15.0/381		11.1/283	6.2/158		0.118/3.0	0.276/7.0			Figure 41-C		
5A	4160		8.3/211	15.1/384	7.6/193		7.5/190	Figure 41-D							
	4220														
5B	4270		9.1/231	19.3/490		15.2/386	8.3/210				Figure 42-H				
	4330														
6	4400	Figure 39	11.1/283	25.9/658	13.2/335	25.0/635	8.0/203		0.188/4.8	0.375/9.5		Figure 41-E			
7A	4500			30.8/782	14.3/363	29.7/754		Figure 41-F							
	4600			14.3/363	36.1/917	15.3/389		35.3/897				Figure 42-I			
8	4750		17.6/447								50.2/1275		9.2/234	0.344/8.7	0.670/17
	410K														
412K															
9	415K	Figure 40		14.6/371	51.7/1313	51.7/1313	9.9/252	Figure 42-J							
10	420K			15.7/399	53.1/1349				61.6/1565	Figure 42-K					
11	425K		15.0/381	63.1/1603	67.0/1701						13.8/351				
12	430K		18.9/480	68.5/1740		68.5/1740	21.3/541					Figure 43-L			
	435K														
13	440K	25.6/650	70.0/1778	Figure 43-M											



Figure 38. See [Tables 17](#) and [18](#) for Actual Dimensions.




Figure 39. See [Tables 17](#) and [18](#) for Actual Dimensions.





Figure 40. See [Tables 17](#) and [18](#) for Actual Dimensions.



# Conduit Plate Dimensions

Figure 41. See [Tables 17](#) and [18](#) for the associated device. Dimensions are in in/cm.

ØX = Concentric Knockouts for Diameter Sizes 0.5", 0.75", and 1.0" Conduit.






Figure 42. See [Tables 17](#) and [18](#) for the associated device. Dimensions are in in/cm.

ØX = Concentric Knockouts for Diameter Sizes 0.5", 0.75", and 1.0" Conduit.




G




Conduit Ø = Same as G

H




I




Conduit Ø = Same as I

J



Conduit Ø = Same as I


K



Conduit Ø = Same as I

L

Figure 43. See Table 18 for the associated device. Dimensions are in in/cm.



# Current/Voltage Specifications

Table 19. 230-Volt Chassis Standard Ratings Table.

Model Number VT130P9U	Typical Motor HP	100% Output Current Continuous	Overload Current 120% for 60 Seconds	Input Voltage 3-Ph 50/60 $\pm 2$ Hz	Output Voltage 3-Ph Variable Frequency
2010	0.75	3.2 A	3.84 A	200 – 240 VAC ( $\pm 10\%$ )	Input Voltage Level (Max.)
2015	1.0	4.2 A	5.04 A		
2025	2.0	6.8 A	8.16 A		
2035	3.0	9.6 A	11.5 A		
2055	5.0	15.2 A	18.2 A		
2080	7.5	22.0 A	26.0 A		
2110	10	28.0 A	34.0 A		
2160	15	42.0 A	50.0 A		
2220	20	54.0 A	65.0 A		
2270	25	68.0 A	82.0 A		
2330	30	80.0 A	96.0 A		
2400	40	104 A	125 A		
2500	50	130 A	156 A		
2600	60	154 A	185 A		
2750	75	192 A	230 A		
210K	100	248 A	298 A		
212K	125	312 A	374 A		

Table 20. 460-Volt Chassis Standard Ratings Table.

Model Number VT130P9U	Typical Motor HP	100% Output Current Continuous	Overload Current 120% for 60 Seconds	Input Voltage 3-Ph 50/60 ±2 Hz	Output Voltage 3-Ph Variable Frequency
4015	1.0	2.1 A	2.52 A	380 – 480 VAC (±10%)	Input Voltage Level (Max.)
4025	2.0	3.4 A	4.08 A		
4035	3.0	4.8 A	5.76 A		
4055	5.0	7.6 A	9.00 A		
4080	7.5	11.0 A	13.0 A		
4110	10	14.0 A	17.0 A		
4160	15	21.0 A	25.0 A		
4220	20	27.0 A	32.0 A		
4270	25	34.0 A	41.0 A		
4330	30	40.0 A	48.0 A		
4400	40	52.0 A	62.0 A		
4500	50	65.0 A	78.0 A		
4600	60	77.0 A	92.0 A		
4750	75	96.0 A	115 A		
410K	100	124 A	149 A		
412K	125	156 A	187 A		
415K	150	180 A	216 A		
420K	200	240 A	288 A		
425K	250	302 A	362 A		
430K	300	361 A	433 A		
435K	350	414 A	497 A		
440K	400	477 A	572 A		



# Cable/Terminal/Torque Specifications

Installation should conform to the **NEC Article 110 (NEC)** (Requirements for Electrical Installations), all regulations of the Occupational Safety and Health Administration, and any other applicable national, regional, or industry codes and standards.

**Note:** The following ratings are guidelines and shall not be the sole determining factor of the lug or wire size used with the P9 ASD. Application-specific applicables, wire insulation type, conductor material, and local and regional regulations are but a few of the considerations when selecting the actual lug and wire type to be used with the P9 ASD.

**Note:** Cable/Terminal specifications are based on the rated current of the P9 ASD and **Do Not** include the 10% Service Factor.

**Note:** Use only 75° C copper wire/cable for motor and power connections.

For further installation information see the section titled [Installation and Connections on pg. 14](#).

Table 21. 230-Volt P9 ASD Cable/Terminal/Torque Specifications.

Model Number VT130P9U	MCP Rating (Amps)	Wire/Cable Size		Lug Size Range		Terminal Board	Torque		
		AWG or kcmil						3Ø-Input	3Ø-Output
		Input/Output Power		Wire-Size/Lug-Capacity for Input/Output Power		TB1 – 4 Terminals			
		Recommended	Maximum	3Ø-Input	3Ø-Output	In-Lbs./Nm			
2010	15	14	10	14 to 8		20 (3-core shield)  Torque to 5.3/0.6	11.5/1.3		
2015									
2025									
2035	30	10	8	12 to 8			17.7/2.0		
2055									
2080	50	8	3	8 to 3			21/2.4		
2110									
2160									
2220	100	4	4/0	6 to 250	2 to 300		275/31	168/19	
2270	125	3							
2330	150	2							
2400	175	1/0	4/0	6 to 250	2 to 300		275/31	168/19	
2500	200	2/0							
2600	250	3/0							
2750	300	4/0							
210K	400	*3/0	*250	6 to 250			275/31		
212K	500	*250							

**Note:** (\*) Indicates that the item is one of a set of two parallel cables.

Table 22. 460-Volt P9 ASD Cable/Terminal/Torque Specifications.

Model Number VT130P9U	MCP Rating (Amps)	Wire/Cable Size		Lug Size Range		Terminal Board	Torque			
		AWG or kcmil						3Ø-Input	3Ø-Output	
		Input/Output Power		Wire-Size/Lug-Capacity for Input/Output Power		TB1 – 4 Terminals				
		Recommended	Maximum	3Ø-Input	3Ø-Output	In-Lbs./Nm				
4015	15	14	10	14 to 8		20 (3-core shield)  Torque to 5.3/0.6	11.5/1.3			
4025										
4035										
4055										
4080	20	12	8	12 to 8			17.7/2.0			
4110	30	10								
4160		50		8	4		10 to 4			
4220										
4270	75	4	3	8 to 3			21/2.4			
4330										
4400	100		2	12 to 1/0	4 to 1/0				50/5.7  53/6.0	
4500										
4600	125	2								
4750	175	1/0					4/0	6 to 250		
410K	200	2/0								
412K	250	4/0								
415K	300	*1/0	*4/0	6 to 250		275/31				
420K	400	*3/0	*250							
425K	500	*250								
430K	600	*300	*350					4 to 350		375/42.4
435K	700	*350								
440K	800	**250	**350	0 to 500	6 to 350					

**Note:** (\*) Indicates that the item is one of a set of two parallel cables.

**Note:** (\*\*) Indicates that the item is one of a set of three parallel cables.

# Dynamic Braking Protection

Thermal protection for the DBR circuit (see [Figure 44. on pg. 284](#)) or an input contactor that will open the 3-phase power input circuit (see [Figure 45. on pg. 284](#)) to the P9 ASD in the event that a DBR over-temperature condition occurs is a requirement. Should a DBR failure or a power source over-voltage condition occur, the DBR thermal protection circuitry will prevent hazardous DBR temperatures.

To use the **Dynamic Braking** function the following requirements must be met:

- **Enable** the DBR function,
- Select a **Resistance Value**, and
- Set the **Continuous Braking Wattage** value at [F304](#), [F308](#), and [F309](#), respectively.

Set the **Braking Resistance Overload Time** at parameter [F639](#) to establish how long the braking resistor is allowed to sustain the overload condition before a trip is incurred (the factory default setting is 5 seconds).

Light-duty and heavy-duty resistors vary from a few ohms to several hundred ohms. The appropriate resistance size will be typeform- and application-specific. Contact your TIC Sales Representative or the TIC Customer Support Center for more information on your specific DBR requirements.

Heavy-duty DBRs should be wired using the same gauge wire as the motor leads. Light-duty DBRs may use one wire size smaller (AWG or kcmil) than the motor leads.

Because the heat generated by the DBR will affect the cooling capacity of the heat sink, the resistor pack should be mounted above or to the side of the ASD — **Never below the ASD**. Maintain a minimum of six inches between the resistor pack and the ASD unit.

The total wire length from the ASD to the DBR should not exceed 10 feet.

The wiring from the ASD to the DBR should be twisted approximately two twists per foot throughout the length of the wire.

If EMI/RFI noise is of concern, the DBR wiring should be 3-core screened cable. The screen should connect to the ASD enclosure and the resistor enclosure.

## CAUTION

Though the in-line DBR fuse and the thermal relay are designed into the system to prevent a catastrophic DBR over-current condition, they are both intended to be used as backup protection **ONLY**.

A proper typeform-specific and application-specific system setup that includes using the appropriate **Dynamic Braking Resistor and Overload** settings will be required.

Figure 44.





Figure 45.



# Short Circuit Protection Recommendations

Table 23. 230/240 and 400/480-Volt ASD Recommended Circuit Breaker Selection.

Model Number VT130P9U	HP	Continuous Output Current (Amps)	Circuit Breaker Part Number
2010	0.75	3.2	HLL36015
2015	1.0	4.2	
2025	2.0	6.8	
2035	3.0	9.6	HLL36025
2055	5.0	15.2	
2080	7.5	22.0	HLL36040
2110	10	28.0	HLL36050
2160	15	42.0	HLL36070
2220	20	54.0	HLL36090
2270	25	68.0	HLL36100
2330	30	80.0	
2400	40	104	HLL36125
2500	50	130	HLL36150
2600	60	154	JLL36200
2750	75	192	Contact TIC Customer Service
210K	100	248	
212K	125	312	
4015	1.0	2.1	HLL36015
4025	2.0	3.4	
4035	3.0	4.8	
4055	5	7.6	HLL36025
4080	7.5	11.0	
4110	10	14.0	HLL36040
4160	15	21.0	HLL36070
4220	20	27.0	
4270	25	34.0	HLL36090
4330	30	40.0	HLL36100
4400	40	52.0	
4500	50	65.0	HLL36125
4600	60	77.0	HLL36150
4750	75	96.0	JLL36200
410K	100	124	JLL36225
412K	125	156	JLL36250
415K	150	180	LIL36300
420K	200	240	
425K	250	302	LIL36400
430K	300	361	Contact TIC Customer Service
435K	350	414	
440K	400	477	Consult the NEC

# P9 ASD Optional Devices

The ASD may be equipped with several options which are used to expand the functionality. [Table 24](#) lists the available options and their functions.

Table 24. P9 Optional Devices and Functions.

Part Identifier	Device Name	Device Function
ASD-CAB-USB	H9 USB Communication Cable	Used to connect the ASD to a PC via the USB port of the PC.
ASD-EOI-HH-G9	Display Module Docking Station	Used to flash the 9-series display module.
ASD-MTG-KIT-P9	P9-ASD EOI Remote Mounting Kit	Hardware used to mount the P9 ASD EOI remotely.
ASD-EOI-N4	NEMA-4 EOI	A replacement NEMA-4 EOI (without Rotary Encoder)
ASD-EOI-N4-G9	9-Series EOI NEMA-4 Remote Mounting Kit	EOI Remote Mounting Kit for <b>NEMA 4</b> applications. See the section titled <a href="#">EOI Remote Mounting on pg. 33</a> for further information on mounting the EOI remotely.
ASD-TB1-SIM9	ASD Input/Output Signal Simulator	Used to simulate the ASD I/O monitor and control signals.
DEV002Z	DeviceNet Module	Allows the ASD to communicate via DeviceNet with other DeviceNet-supported equipment including a host computer.
ETB003Z	Expansion I/O Board 1	Expands the Input/Output functionality of the ASD.
ETB004Z	Expansion I/O Board 2	Expands the Input/Output functionality of the ASD.
PDP002Z	ProfiBus DP Module	Allows the ASD to communicate via ProfiBus with other ProfiBus-supported equipment including a host computer.
USB001Z	USB-to-Serial Converter	Allows for the USB port of a computer to be used as a communications port for monitoring and controlling the ASD.
VEC007Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a <b>5-volt</b> encoder).
VEC004Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a <b>12-volt</b> encoder).
VEC005Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a <b>15-volt</b> encoder).
VEC006Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a <b>24-volt</b> encoder).
<b>Note:</b> See the user manual of the applicable option for further information on each item.		

# Index

## Numerics

0 Hz Command Output, 130  
0 Hz Dead Band Signal, 129  
16-Bit Binary/BCD Input, 92

## A

AbFL, 262, 265  
Abnormal Speed Detection Time, 203  
Abnormal Speed Settings, 59  
Acc/Dec 1 – 4 Settings, 63  
Acc/Dec Pattern 1, 181  
Acc/Dec Pattern 1 – 4, 183  
Acc/Dec Pattern 2, 182  
Acc/Dec Special, 63  
Accel/Decel 1 Settings, 53  
Accel/Decel Operation After Torque Limit, 170  
Accel/Decel Suspend, 147  
Accel/Decel Switching Frequency 1, 183  
Acceleration, 85  
Acceleration Suspend Frequency, 147  
Acceleration Suspend Time, 148  
Acceleration Time 1, 85  
Acceleration Time 2, 179  
Acceleration Time 3, 184  
Acceleration Time 4, 185  
Acceleration/Deceleration Pattern 3, 185  
Acceleration/Deceleration Pattern 4, 186  
Acceleration/Deceleration Switching Frequency 2, 185  
Acceleration/Deceleration Switching Frequency 3, 186  
activate the battery backup, 28  
Adding Input Selection, 207  
AI2, 93  
AI2 (Option V/I) Input Bias, 174  
AI2 (Option V/I) Input Gain, 175  
Alarm Float, 252  
Alarms, 260, 262  
Always ON 1 Terminal 1, 93  
AM, 21, 23  
AM Bias Adjustment, 211  
AM Output, 49  
AM Output Gradient Characteristic, 210  
AM Output Terminal Adjustment, 208  
AM Output Terminal Function, 208  
AM/FM Output, 25  
Analog Filter, 61  
Analog Function Assigned Object 11, 242  
Analog Function Assigned Object 21, 243  
Analog Input Filter, 114  
Analog Input Function Target 11, 242  
Analog Input Function Target 21, 242  
Analog Output Terminals, 54  
Annual Average Ambient Temperature, 205  
ASD Capacity, 13  
ASD Input Phase Failure Detection, 200  
ASD Load, 49  
ASD Number, 218  
ASD OL (Overload) Trip, 49  
ASD Operation at Disconnect, 226  
ASD Output Phase Failure Detection, 199  
ASD Overload, 49, 204, 269  
ASD Side-Switching Delay, 150  
ASD-EOI-N4-G9, 33  
ASD-to-ASD Communications (2-Wire), 220  
ASD-to-ASD Communications (2-wire), 223  
Atn, 261  
At-Trip Recorded Parameters, 270  
Auto Accel/Decel, 37  
Auto Mode, 30  
Auto Restart, 138  
Automatic Acceleration/Deceleration, 81  
Automatic Function Selection, 90  
Automatic Torque Boost, 81  
Autotune Error, 267  
Autotuning, 10  
Autotuning 1, 159  
Autotuning 2, 160

## B

Base Frequency 1, 86  
Base Frequency 2, 103  
Base Frequency 3, 104  
Base Frequency 4, 105  
Base Frequency Voltage, 59  
Base Frequency Voltage 1, 162  
Base Frequency Voltage 2, 103  
Base Frequency Voltage 3, 104  
Base Frequency Voltage 4, 105  
Battery Backup, 28  
battery life, 28  
Baud Rate (2-Wire RS485), 218  
Baud Rate (4-Wire RS485), 222

- Bezel Plate Mounting Hardware, 33
- BIN Input Point 1 Frequency, 126
- BIN Input Point 1 Setting, 125
- BIN Input Point 2 Frequency, 126
- BIN Input Point 2 Setting, 126
- Block Read Data 1, 228
- Block Read Data 2, 228
- Block Read Data 3, 228
- Block Read Data 4, 229
- Block Read Data 5, 229
- Block Write Data 1, 227
- Block Write Data 2, 227
- Brake Answer Delay Time, 204
- Braking Mode Selection, 145
- Braking Resistance Overload Time (10x Rated Torque), 206
- Braking Time Learning Function, 147

## C

- Cable/Terminal Specifications, 281
- Carrier Frequency, 63
- Carrier Frequency Control Mode, 143
- CC, 21
- CCA, 21
- Change Step Selection 1, 213
- Change Step Selection 2, 214
- Changed From Default, 40, 58
- Changed From Default Screen, 40
- Changes by Installer, 27
- Charge Indicator LED, 9, 16
- Circuit Breaker Configuration, 15
- Clearing a Trip, 270
- CM1, 262
- CM2, 262
- CMOD/FMOD Change Lockout, 216
- Command Control Selections, 45
- Command Mode, 82
- Command Mode and Frequency Mode Control, 42
- Command Source, 38
- Commercial Power Switching Delay, 150
- Commercial Power Switching Freq. Hold Time, 150
- Commercial Power/ASD Output Switching, 149
- Commercial Power/ASD Switching Frequency, 150
- Communication Adjustments, 71
- Communication Error, 266
- Communication Settings, 71
- Communications Option (DeviceNet/Profibus) Setting 1, 223
- Communications Option (DeviceNet/Profibus) Setting 2, 224
- Communications Option (DeviceNet/Profibus) Setting 8, 225

- Communications Option Speed Switch Monitor DeviceNet/CC-Link, 227
- Communications Option Station Address Monitor, 226
- Communications Setting Changes, 40
- Communications Settings, 71
- Communications Time Out Time (2- and 4-Wire RS485), 218
- Communications Time-Out Action (2- and 4-wire RS485), 219
- Compensation Frequency, 49
- Conduit Plate Dimensions, 271
- Connect IICC to CCA, 110
- Connecting the ASD, 16
- Connection Diagram, 26
- Continuous Dynamic Braking Capacity, 142
- Contrast, 59
- Control Power Under-Voltage, 269
- Cooling Fan Control, 202
- CPU Fault, 266
- Creeping Frequency, 146
- Creeping Time, 146
- Cumulative Operation Time Alarm, 202
- Current Control Proportional Gain, 171
- Current/Voltage, 279
- Current/Voltage Specifications, 279
- Customer Support, 2

## D

- dbOn, 261
- DBR Load, 49
- DBR OL (Overload) Trip, 49
- DBR Over-Current, 284
- DBR Overload, 49
- DC Bus Voltage, 49
- DC Injection Braking, 59
- DC Injection Braking Current, 129
- DC Injection Braking Start Frequency, 129
- DC Injection Braking Time, 130
- Deceleration Suspend Frequency, 148
- Deceleration Suspend Time, 148
- Deceleration Time 1, 85
- Deceleration Time 2, 180
- Deceleration Time 3, 185
- Deceleration Time 4, 186
- Default Setting Changes, 40
- Direct Access, 56
- Disconnection Detection Extended Time, 226
- Discrete Input, 21, 25
- Discrete Input Terminals, 51
- Discrete Output, 21
- Display Bias, 213
- Display Gradient Characteristic, 213



- Display Parameters, 58
- Display Unit Multiplication Factor, 212
- Display Unit Selection, 213
- Display Units for Current and Voltage, 212
- Disposal, 3
- Drooping, 144
- Drooping Control, 67
- Drooping Gain, 144
- Drooping Insensitive Torque, 145
- Drooping Output Filter, 145
- Dynamic Braking, 59, 141
- Dynamic Braking Protection, 283
- Dynamic Braking Resistance, 142
- Dynamic Braking Resistor Over-Current, 268
- Dynamic Braking Resistor Overload, 269

## E

- E, 265
- E-10, 265
- E-11, 265
- E-12, 265
- E-13, 265
- E-17, 265
- E-18, 265
- E-19, 265
- E-20, 265
- E-21, 265
- E-22, 265
- E-23, 266
- E-24, 266
- E-25, 266
- E-26, 266
- EEP1, 266
- EEP2, 266
- EEP3, 266
- EEPROM Data Fault, 266
- EEPROM Fault, 266
- EF1, 266
- EF2, 266
- Electronic Operator Interface, 28
- Electronic Operator Interface Features, 30
- Emergency Off, 31, 265
- Emergency Off DC Injection Application Time, 199
- Emergency Off Mode Settings, 199
- Emergency Off Settings, 60
- EMG, 262
- Enclosure Dimensions, 271
- Encoder Loss, 265
- End Frequency, 129
- EOI ASD-MTG-KIT9 Mounting Dimensions, 35
- EOI Command Screen, 48
- EOI Installation Precautions, 34

- EOI Mounting Dimensions, 34
- EOI Operation, 28
- EOI Operation Jog Mode, 132
- EOI Remote Mounting, 29
- EOI Remote Mounting Using the ASD-MTG-KIT9, 35
- EOI Remote Mounting w/o the ASD-MTG-KIT9, 34
- EPHI, 266
- EPHO, 266
- Equipment Inspection, 3
- ERR2, 266
- ERR3, 266
- ERR4, 266
- ERR5, 266
- ERR6, 266
- ERR7, 266
- ERR8, 266
- ERR9, 267
- ESC Key, 30
- ETN, 267
- ETN1, 267
- ETN2, 267
- ETN3, 267
- ETYP, 267
- Excitation Current, 50
- Exciting Strengthening Coefficient, 163
- Exit>>, 39
- Extender Cables, 33
- External Overheat, 269

## F

- F, 21, 22
- Fan Control, 202
- Fault, 260
- Fault Relay, 25
- Faults, 260
- Feedback (1 second), 50
- Feedback (inst), 50
- Feedback Settings, 67
- FLA, 21, 23
- FLA, B, and C Switching Relationship, 24
- Flash Memory Fault, 267
- FLB, 23
- FLC, 21, 23, 24
- FM, 21, 23
- FM Bias Adjustment, 210
- FM Output, 49
- FM Output Gradient Characteristic, 210
- FM Output Terminal Adjustment, 83
- FM Output Terminal Function, 83
- FM Voltage/Current Output Switching, 210
- FMOD, 109
- Forward Run/Reverse Run Disable, 143

- Forward Speed Limit Input, 165
- Forward Speed Limit Level, 166
- Forward/Reverse DC Injection Braking Priority, 130
- Forward/Reverse Disable, 61
- Forward/Reverse Run Priority Selection, 91
- Forward/Reverse Run Selection, 84
- FP, 21, 23
- FP Output, 25
- FP Terminal Assignment, 209
- FP Terminal Frequency, 210
- Free Notes, 229
- Frequency, 61
- Frequency at Trip, 49
- Frequency Command Mode, 47
- Frequency Command Screen, 32, 39
- Frequency Control, 64
- Frequency Control Selections, 45
- Frequency Mode 1, 82
- Frequency Mode 2, 113
- Frequency Mode Control, 42
- Frequency Mode Priority Switching Frequency, 113
- Frequency Point Selection, 220
- Frequency Priority Selection, 109
- Frequency Reference, 49
- Frequency Reference Source, 39
- Frequency Setting, 47
- Frequency Settings, 53
- Fundamental, 53

## G

- Gate Array Fault, 266
- General Safety Information, 1
- Ground Fault, 266

## H

- Hand Mode, 30
- Hand/Auto Key, 30
- Handling and Storage, 3

## I

- I/O and Control, 21
- I/O Circuit Configurations, 25
- IICC, 21, 26, 110, 112
- Important Notice, 4
- Initial Setup, 36
- Initial UP/DOWN Frequency, 134
- Initial UP/DOWN Frequency Rewriting, 134
- Input Function Command 1, 229, 231, 232, 237, 238, 239, 240

- Input Function Command 2, 230, 231, 232, 237, 238, 239, 241
- Input Function Target 1, 229, 231, 232, 236, 238, 239, 240
- Input Function Target 2, 230, 231, 232, 237, 238, 239, 241
- Input Function Target 3, 230, 231, 233, 237, 238, 240, 241
- Input Phase Failure, 266
- Input Phase Failure Detection, 200
- Input Power, 50
- Input Special Functions, 55
- Input Terminal 1 (F) Function, 93
- Input Terminal 1 (F) Response Time, 100
- Input Terminal 10 (LI2) Function, 95
- Input Terminal 11 (LI3) Function, 95
- Input Terminal 12 (LI4) Function, 96
- Input Terminal 13 – 20 Response Time, 101
- Input Terminal 13 (LI5) Function, 96
- Input Terminal 14 (LI6) Function, 96
- Input Terminal 15 (LI7) Function, 97
- Input Terminal 16 (LI8) Function, 97
- Input Terminal 17 (B12) Function, 101
- Input Terminal 18 (B13) Function, 101
- Input Terminal 19 (B14) Function, 102
- Input Terminal 2 (R) Function, 93
- Input Terminal 2 (R) Response Time, 100
- Input Terminal 20 (B15) Function, 102
- Input Terminal 3 (ST) Function, 93
- Input Terminal 3 (ST) Response Time, 100
- Input Terminal 4 (RES) Function, 94
- Input Terminal 4 (RES) Response Time, 101
- Input Terminal 5 – 12 Response Time, 101
- Input Terminal 5 (S1) Function, 94
- Input Terminal 6 (S2) Function, 94
- Input Terminal 7 (S3) Function, 94
- Input Terminal 8 (S4) Function, 94
- Input Terminal 9 (LI1) Function, 95
- Input Terminal Delays, 55
- Input Terminal Priority, 92
- Installation and Connections, 14
- Installation Notes, 14
- Installation Precautions, 4
- isolated V/I input, 110

## J

- Jog Run Frequency, 131
- Jog Settings, 61
- Jog Setup Using the EOI, 131
- Jog Stop Pattern, 131
- Jump Frequencies, 64
- Jump Frequency 1, 135

Jump Frequency 1 Bandwidth, 136  
Jump Frequency 2, 136  
Jump Frequency 2 Bandwidth, 136  
Jump Frequency 3, 136  
Jump Frequency 3 Bandwidth, 136

## L

LCD Character/Font Information, 31  
LCD Screen, 30  
LCD Screen Display, 31  
Lead Length Specifications, 20  
LED Character/Font Information, 31  
LED Screen, 30  
LED Screen Display, 31  
LED/LCD Screen Information, 31  
Light Load Conditions, 11  
Line Power Switching, 56  
Linear Acceleration, 181  
Load Moment of Inertia 1, 171  
Load Moment of Inertia 2, 172  
Load Sharing Gain Input, 165  
Load-Produced Negative Torque, 12  
Lockout, 76  
Lockout All Keys, 216  
Low Suction Pressure Delay Timer, 178  
Low Suction/No Flow Cut Off, 262, 265  
Low Suction/No-Flow Cut Off, 53  
Low-Current, 266  
Low-Current Detection Current Hysteresis Width, 200  
Low-Current Detection Threshold, 201  
Low-Current Settings, 60  
Low-Current Trip, 200  
Low-Current Trip Threshold Time, 201  
Lower Limit Frequency, 86  
Lower-Limit Frequency, 37  
Low-Speed Operation, 10  
Low-Speed Signal Output Frequency, 91  
Lug Size, 281, 282

## M

Main Monitor, 59  
Main Monitor Selections, 51  
Manual Torque Boost 1, 87  
Manual Torque Boost 2, 103  
Manual Torque Boost 3, 104  
Manual Torque Boost 4, 105  
Manual Torque Limit Settings, 66  
Maximum Frequency, 85  
MCP Rating, 281, 282  
Mode Key, 30

MOFF, 262  
MON 1 Bias Adjustment, 211  
MON 1 Output Gradient Characteristic, 211  
MON 1 Voltage/Current Output Switching, 211  
MON 2 Bias Adjustment, 212  
MON 2 Output Gradient Characteristic, 212  
MON 2 Voltage/Current Output Switching, 211  
MON1 Terminal Adjustment, 209  
MON1 Terminal Meter Selection, 208  
MON2 Terminal Adjustment, 209  
MON2 Terminal Meter Selection, 209  
Monitor Mode, 49  
Monitor Output Function 11, 243  
Monitor Output Function 21, 244  
Monitor Output Function 31, 244  
Monitor Output Function 41, 245  
Monitor Output Function Command 11, 243  
Monitor Output Function Command 21, 244  
Monitor Output Function Command 31, 245  
Monitor Output Function Command 41, 245  
Monitor Screen, 32  
Motor 150% Overload Time Limit, 200  
Motor Braking, 12  
Motor Characteristics, 10  
Motor Connection Diagram, 17  
Motor Constant 1, 162  
Motor Constant 2, 162  
Motor Constant 3, 162  
Motor Constant 4, 162  
Motor Current Rating, 38  
Motor Load, 49  
Motor OL (Overload) Trip, 49  
Motor Overload, 269  
Motor Overload Protection Configuration, 87  
Motor Overload Protection Level 1, 198  
Motor Overload Protection Level 2, 103  
Motor Overload Protection Level 3, 104  
Motor Overload Protection Level 4, 105  
Motor Overload Real, 49  
Motor Rated Capacity, 161  
Motor Rated Current, 161  
Motor Rated RPM, 162  
Motor Set 1, 54  
Motor Set 2, 65  
Motor Set 3, 65  
Motor Set 4, 65  
Motor Settings, 65  
Motor Shaft Fixing Control, 130  
Motor/ASD Setup, 52  
Motor/Load Combinations, 11  
Mounting the ASD, 15  
Multiplying Input Selection, 207  
My Function, 68  
My Function Count Data 1, 236

- My Function Count Data 2, 236
- My Function Frequency Data 1, 234
- My Function Frequency Data 2, 234
- My Function Frequency Data 3, 234
- My Function Frequency Data 4, 235
- My Function Frequency Data 5, 235
- My Function Monitor, 70
- My Function Percent Data 1, 233
- My Function Percent Data 3, 234
- My Function Percent Data 4, 234
- My Function Percent Data 5, 234
- My Function Selection, 247
- My Function Time Data 1, 235
- My Function Time Data 2, 235
- My Function Time Data 3, 235
- My Function Time Data 4, 236
- My Function Time Data 5, 236

## N

- NEMA 4, 33
- NERR, 267
- Network Option Reset Settings, 229
- Number of PG Input Phases, 153
- Number of PG Input Pulses, 153

## O

- O1A/B, 21
- O2A/B, 23
- OC, 262
- OC1, 267
- OC1P, 268
- OC2, 268
- OC2P, 268
- OC3, 268
- OC3P, 268
- OCA1, 268
- OCA2, 268
- OCA3, 268
- OCL, 268
- OCR, 268
- OFF Float, 252
- OH, 263, 269
- OH2, 269
- OJ, 263
- OL1, 269
- OL2, 269
- OLI, 263
- OLM, 263
- OLR, 263, 269
- ON Float, 252

- OP, 263
- OP1, 269
- OP2, 269
- OP3, 269
- Operation (Hand), 39
- Operation Above 60 Hz, 10
- Operation Command Clear Selection When ST Off, 214
- Operation Mode, 72
- Operation Panel Parameters, 64
- Operational and Maintenance Precautions, 9
- Option V/I Terminal Voltage/Current Selection, 93
- Optional Devices, 286
- Options, 286
- OT, 263, 269
- OUT1, 21, 23
- Out1 Out2 FL, 51
- OUT1/OUT2 Output, 25
- OUT2, 23
- Output Current, 49
- Output Disconnect, 8
- Output Function Assigned, 230, 232, 233, 237, 239, 240, 241
- Output Phase Failure, 266
- Output Phase Failure Detection, 199
- Output Power, 50
- Output Terminal 1 (OUT1) Function, 97
- Output Terminal 10 (R3) Function, 102
- Output Terminal 11 (R4) Function, 102
- Output Terminal 2 (OUT2) Function, 97
- Output Terminal 3 (FL) Function, 98
- Output Terminal 4 (OUT3) Function, 98
- Output Terminal 5 (OUT4) Function, 98
- Output Terminal 6 (R1) Function, 99
- Output Terminal 7 (OUT5) Function, 99
- Output Terminal 8 (OUT6) Function, 99
- Output Terminal 9 (R2) Function, 100
- Output Terminals, 56
- Output Voltage, 49
- Over-Current During Acceleration, 267
- Over-Current During Deceleration, 268
- Over-Current During Run, 268
- Over-Current Protection, 13
- Overheat, 269
- Overheat During Acceleration, 268
- Overheat During Deceleration, 268
- Overheat During Run, 268
- Overload, 60
- Overload Protection, 10
- Overload Reduction Starting Frequency, 200
- Override Control, 68
- Override Hierarchy, 44
- Override Mode, 44
- Override Operation, 44
- Over-Speed, 265

- Over-Speed Detection Frequency Lower Band, 203
- Over-Speed Detection Frequency Upper Band, 203
- Over-Torque, 269
- Over-Torque Detection Hysteresis, 202
- Over-Torque Detection Level (Negative Torque), 202
- Over-Torque Detection Level (Positive Torque), 202
- Over-Torque Detection Time, 202
- Over-Torque Parameters, 60
- Over-Torque Trip, 201
- Over-Voltage During Acceleration, 269
- Over-Voltage During Deceleration, 269
- Over-Voltage Limit Operation, 141
- Over-Voltage Limit Operation Level, 203

## P

- P24, 21, 23
- P24 Output, 25
- PA/+, 16
- Panel Emergency Off Lockout, 215
- Panel Frequency Lockout, 215
- Panel Load Sharing Gain, 215
- Panel Override Multiplication Gain, 215
- Panel Reset Lockout, 216
- Panel Stop Pattern, 214
- Panel Tension Torque Bias, 215
- Panel Torque Bias, 146
- Panel Torque Command, 215
- Panel Torque Gain, 146
- Parameter Changes, 27
- Parameter Write Lockout, 212
- Parity (2- and 4-Wire RS485), 218
- Part Numbering Convention, 271
- Password, 76
- Past Trip 1, 50
- Past Trip 2, 50
- Past Trip 3, 51
- Past Trip 4, 51
- Pattern 1 Repeat, 187
- Pattern 2 Repeat, 190
- Pattern Group 1 Selection 1, 188
- Pattern Group 1 Selection 2, 189
- Pattern Group 1 Selection 3, 189
- Pattern Group 1 Selection 4, 189
- Pattern Group 1 Selection 5, 189
- Pattern Group 1 Selection 6, 190
- Pattern Group 1 Selection 7, 190
- Pattern Group 1 Selection 8, 190
- Pattern Group 2 Selection 1, 191
- Pattern Group 2 Selection 2, 191
- Pattern Group 2 Selection 3, 191
- Pattern Group 2 Selection 4, 191
- Pattern Group 2 Selection 5, 192
- Pattern Group 2 Selection 6, 192
- Pattern Group 2 Selection 7, 192
- Pattern Group 2 Selection 8, 192
- Pattern Group Cycle, 50
- Pattern Group Number, 50
- Pattern Group Preset, 50
- Pattern Operation Mode, 186
- Pattern Run, 72
- Pattern Time, 50
- PC/+, 16
- Permanent Magnet (PM) Motor Constant 1, 179
- Permanent Magnet (PM) Motor Constant 2, 179
- PG Disconnection Detection, 154
- PG Input Point 1 Frequency, 127
- PG Input Point 1 Setting, 127
- PG Input Point 2 Frequency, 128
- PG Input Point 2 Setting, 128
- PG Settings, 68
- PG Type/Connection Error, 265
- Phase Loss, 60
- PID Control Delay, 152
- PID Control Switching, 150
- PID Deviation Lower-Limit, 152
- PID Deviation Upper-Limit, 151
- PID Feedback, 50
- PID Feedback Delay Filter, 151
- PID Feedback Differential (D) Gain, 152
- PID Feedback Integral (I) Gain, 151
- PID Feedback Proportional (P) Gain, 151
- PID Feedback Signal, 151
- PID Output Lower-Limit, 153
- PID Output Upper-Limit, 152
- PM Motor, 65, 179
- PO, 16
- POFF, 264
- Point 1 Frequency, 221
- Point 1 Setting, 221
- Point 2 Frequency, 222
- Point 2 Setting, 221
- Power Connections, 16
- Power Factor Correction, 11
- Power Running Stall Continuous Trip Detection Time, 170
- Power Running Torque Limit 1, 168
- Power Running Torque Limit 1 Level, 168
- Power Running Torque Limit 2 Level, 169
- Power Running Torque Limit 3 Level, 169
- Power Running Torque Limit 4 Level, 169
- PP, 21, 23
- PP Output, 25
- Preset Speed 1, 88
- Preset Speed 1 Operation Mode, 196
- Preset Speed 10, 137
- Preset Speed 10 Operation Mode, 197

- Preset Speed 11, 137
- Preset Speed 11 Operation Mode, 197
- Preset Speed 12, 137
- Preset Speed 12 Operation Mode, 197
- Preset Speed 13, 137
- Preset Speed 13 Operation Mode, 197
- Preset Speed 14, 137
- Preset Speed 14 Operation Mode, 198
- Preset Speed 15, 138
- Preset Speed 15 Operation Mode, 198
- Preset Speed 2, 88
- Preset Speed 2 Operation Mode, 196
- Preset Speed 3, 89
- Preset Speed 3 Operation Mode, 196
- Preset Speed 4, 89
- Preset Speed 4 Operation Mode, 197
- Preset Speed 5, 89
- Preset Speed 5 Operation Mode, 197
- Preset Speed 6, 89
- Preset Speed 6 Operation Mode, 197
- Preset Speed 7, 89
- Preset Speed 7 Operation Mode, 197
- Preset Speed 8, 136
- Preset Speed 8 Operation Mode, 197
- Preset Speed 9, 137
- Preset Speed 9 Operation Mode, 197
- Preset Speed Operation Mode, 195
- Preset Speed Operation Selection, 226
- Preset Speeds, 61
- Primary Menus, 32
- Process Decreasing Rate, 153
- Process Increasing Rate, 153
- Process Lower-Limit, 152
- Process Upper-Limit, 152
- Program Menu, 32
- Program Mode Menu Navigation, 52
- Prohibition, 57
- Protection, 59
- PTC1 Thermal Selection, 205
- PTC2 Thermal Selection, 206
- PtSt, 264
- Pulse Width Modulation, 10
- PWM Carrier Frequency, 138

## Q

- Qualified Personnel, 2

## R

- R, 21, 22
- R/L1, 16

- RAM Fault, 266
- Random Mode, 143
- Reach Settings, 56
- Read Error, 266
- real-time clock, 270
- Real-Time Clock Setup, 57
- reciprocating load, 11
- Regenerative Braking Torque Limit 1, 168
- Regenerative Braking Torque Limit 1 Level, 169
- Regenerative Braking Torque Limit 2 Level, 169
- Regenerative Braking Torque Limit 3 Level, 169
- Regenerative Braking Torque Limit 4 Level, 170
- Regenerative Power Ridethrough Control Level, 204
- Regenerative Power Ridethrough Mode, 139
- Release Time, 146
- Remote EOI Hardware, 33
- RES, 21, 22
- Reset, 57, 84
- Retain Trip Record at Power Down, 198
- Retry Selection, 140
- Retry/Restart, 60
- Reverse Speed Limit Input, 166
- Reverse Speed Limit Input Level, 166
- Ridethrough Time, 142
- ROM Fault, 266
- Root Menu Mapping, 47
- Root Menus, 47
- Rotary Encoder, 30
- Rotation in Specified Direction ONLY, 167
- RR, 21, 22, 50
- RR Input, 25
- RR Input Bias, 173
- RR Input Gain, 173
- RR Input Point 1 Frequency, 115
- RR Input Point 1 Rate, 117
- RR Input Point 1 Setting, 115
- RR Input Point 2 Frequency, 116
- RR Input Point 2 Rate, 117
- RR Input Point 2 Setting, 116
- RS485 4-Wire Protocol Selection (TSB/ModBus), 223
- RS485 Send Delay (4-Wire RS485), 222
- Run Frequency, 128
- Run Frequency Hysteresis, 129
- Run Key, 30
- Run Time, 49
- Rush Relay Current Activation Time, 205
- RX, 21, 22, 50
- RX Input, 25
- RX Input Bias, 173
- RX Input Gain, 174
- RX Input Point 1 Frequency, 118
- RX Input Point 1 Rate, 120
- RX Input Point 1 Setting, 118
- RX Input Point 2 Frequency, 119



- RX Input Point 2 Rate, 120
- RX Input Point 2 Setting, 119
- RX2, 50
- RX2 (AI1) Input Bias, 174
- RX2 (AI1) Input Gain, 174
- RX2 (AI1) Input Point 1 Frequency, 122
- RX2 (AI1) Input Point 1 Rate, 123
- RX2 (AI1) Input Point 1 Setting, 121
- RX2 (AI1) Input Point 2 Frequency, 122
- RX2 (AI1) Input Point 2 Rate, 124
- RX2 (AI1) Input Point 2 Setting, 122

## S

- S/L2, 16
- S1, 21, 22
- S2, 21, 22
- S3, 21, 22
- S4, 21, 22
- Saving User Settings, 41
- SEAL, 269
- Sealing Water Error, 269
- Sealing Water/Vacuum Prime Enable, 178
- Second Speed Loop Proportional Gain, 172
- Second Speed Loop Stabilization Coefficient, 172
- Send Wait Time (2-wire), 219
- Setpoints, 66
- Short Circuit Detection At Start, 201
- Short Circuit Protection, 285
- Simple Positioning Completion Range, 154
- Sink, 24
- Sink/Source Setting Error, 265, 266
- Slip Frequency Gain, 160
- Source, 24
- SOUT, 269
- S-Pattern 1, 181
- S-Pattern 2, 181
- S-Pattern Acceleration Lower-Limit Adjustment, 184
- S-Pattern Acceleration Upper-Limit Adjustment, 184
- S-Pattern Deceleration Lower-Limit Adjustment, 184
- S-Pattern Deceleration Upper-Limit Adjustment, 184
- Special, 63
- Special Parameters, 64
- Special Protection Parameters, 61
- Speed 1 Operation Time, 193
- Speed 10 Operation Time, 194
- Speed 11 Operation Time, 194
- Speed 12 Operation Time, 194
- Speed 13 Operation Time, 195
- Speed 14 Operation Time, 195
- Speed 15 Operation Time, 195
- Speed 2 Operation Time, 193
- Speed 3 Operation Time, 193
- Speed 4 Operation Time, 193
- Speed 5 Operation Time, 193
- Speed 6 Operation Time, 193
- Speed 7 Operation Time, 194
- Speed 8 Operation Time, 194
- Speed 9 Operation Time, 194
- Speed at 0% Drooping Gain, 144
- Speed at F320 Drooping Gain, 144
- Speed Error, 265
- Speed Limit (torque=0) Band, 167
- Speed Limit (torque=0) Center Value, 167
- Speed Limit (torque=0) Center Value Reference, 166
- Speed Loop Proportional Gain, 171
- Speed Loop Stabilization Coefficient, 171
- Speed PID Switching Frequency, 172
- Speed Reach Detection Band, 91
- Speed Reach Frequency, 91
- Speed Reference Setpoints, 62
- ST, 21, 22
- Stall, 60
- Stall Prevention During Regeneration, 171
- Stall Prevention Factor 1, 163
- Stall Prevention Level, 198
- Standard Mode Selection, 54
- Standard Startup Wizard Parameter Requirements, 37
- Start Frequency, 128
- Startup and Test, 27
- Stepout Current Detection Level, 206
- Stepout Current Detection Time, 206
- Stop-Reset Key, 31
- SU+, 21, 23
- Supply Voltage Correction, 142
- Synchronized Acceleration Time, 144
- Synchronized Deceleration Time, 143
- System Configuration and Menu Options, 47
- System Grounding, 18
- System Integration Precautions, 7
- System Operation, 36

## T

- T/L3, 16
- TBA HOA Switch, 252
- Tension Torque Bias Input, 165
- Terminal, 54
- Terminal Board, 21, 24
- Terminal Descriptions, 22
- Time Limit For Lower-Limit Frequency Operation, 130
- Time-Based Alternation, 53, 161, 164
- Time-Based Alternation Direct Mode Emergency Setpoint, 171
- Time-Based Alternation Direct Mode Response Time, 168

- Time-Based Alternation Emergency Timer, 161
- Time-Based Alternation operation, 164
- Time-Based Alternation Period, 164
- Time-Based Alternation Process Hold Mode Response Time, 168
- Time-Based Alternation Pump Number, 167
- Time-Based Alternation Total Number of ASDs, 167
- Torque, 50, 66
- Torque Bias Input Selection, 145
- Torque Command Selection, 164
- Torque Control, 66
- Torque Current, 50
- Torque Limit Settings, 67
- Torque Reference, 50
- Torque Speed Limiting, 67
- Trace, 59
- Trace Cycle, 217
- Trace Data 1, 217
- Trace Data 2, 217
- Trace Data 3, 217
- Trace Data 4, 217
- Trace Selection, 216
- Transducer Setup, 52
- Trigger Float, 252
- Trip Code, 50
- Trip History, 270
- Trip History (read-only), 58
- trip records are retained, 270
- Trip Settings, 60
- Trouble Shooting, 260
- Type Reset, 57, 84
- Typeform Error, 267

## U

- U/T1, 16
- UC, 264
- UL 1995, 271
- Under-Voltage Trip, 203
- Under-Voltage Trip Detection Time, 204
- Under-Voltage/Ridethrough, 60
- unstable VLP operation, 179, 180
- UP/DOWN Frequency (down) Frequency Step, 134
- UP/DOWN Frequency (down) Response Time, 134
- UP/DOWN Frequency (up) Frequency Step, 134
- UP/DOWN Frequency (up) Response Time, 133
- UP/DOWN Frequency Functions, 61
- Up/Down Frequency Operation, 135
- UP1, 269
- UP2, 269
- U-Phase Over-Current, 268
- Upper Limit Frequency, 86
- Upper-Limit Frequency, 37

- User Notification Codes, 261
- Using the LCD Screen, 32
- Utilities, 56

## V

- V/f 5-Point Setting, 64
- V/f 5-Point Setting Frequency 1, 106
- V/f 5-Point Setting Frequency 2, 107
- V/f 5-Point Setting Frequency 3, 108
- V/f 5-Point Setting Frequency 4, 108
- V/f 5-Point Setting Frequency 5, 109
- V/f 5-Point Setting Voltage 1, 107
- V/f 5-Point Setting Voltage 2, 108
- V/f 5-Point Setting Voltage 3, 108
- V/f 5-Point Setting Voltage 4, 108
- V/f 5-Point Setting Voltage 5, 109
- V/f Pattern, 86
- V/I, 50, 61
- V/I Analog Input Broken Wire Detection Level, 205
- V/I Input, 25
- V/I Input Bias, 172
- V/I Input Broken-Wire Detection Level, 207
- V/I Input Gain, 173
- V/I Input Point 1 Frequency, 111
- V/I Input Point 1 Rate, 112
- V/I Input Point 1 Setting, 110
- V/I Input Point 2 Frequency, 111
- V/I Input Point 2 Rate, 113
- V/I Input Point 2 Setting, 111
- V/I Settings, 61
- V/T2, 16
- Vector Control, 13
- Vector Motor Model, 65
- Version, 56
- Viewing Trip Information, 270
- Virtual Input Terminal 1 Selection, 246
- Virtual Input Terminal 2 Selection, 246
- Virtual Input Terminal 3 Selection, 246
- Virtual Input Terminal 4 Selection, 246
- VIRTUAL LINEAR PUMP, 52
- Virtual Linear Pump Application Type, 157
- Virtual Linear Pump Command Source, 158
- Virtual Linear Pump Low Frequency Limit, 159
- Virtual Linear Pump Maximum, 158
- Virtual Linear Pump Minimum, 158
- Virtual Linear Pump Mode Switch, 157
- Virtual Linear Pump Transducer Maximum Reading, 158, 160
- Virtual Linear Pump Transducer Output Type/Range, 157
- VLP Application Operating Mode, 154
- VLP Auto Start-Stop Delay Timer, 156



VLP Auto Start-Stop Lower Level Threshold, 156  
VLP Auto Start-Stop Mode, 155  
VLP Auto Start-Stop Upper Level Threshold, 156  
VLP Enable/Disable, 252  
VLP External Device Delay Timer, 176  
VLP High Band Threshold, 177  
VLP Low Band Threshold, 177  
VLP Low Suction Pressure Mode, 177  
VLP Run External Devices, 52  
VLP Sealing Water, 53  
VLP Settings, 52  
VLP Setup Wizard, 52  
VLP Sleep Timer, 52, 154

VLP Sleep Timer Delay, 155  
VLP Start and Stop Points, 52  
Voltage and Frequency Rating of the Motor, 37  
Volts Per Hertz Setting, 38  
V-Phase Over-Current, 268

## W

W/T3, 16  
Warranty Card, 2  
W-Phase Over-Current, 268