
To assemble Push-Lok

1. Cut hose cleanly and squarely with a sharp knife or a Parker Push-Lok cut-off tool.
2. Lubricate the Push-Lok fitting and/or hose I.D., with light oil or soapy water only—do not use heavy oil or grease.
3. Insert fitting into hose until first barb is in the hose.
4. Place end fitting against a flat object (bench, wall). Grip hose approximately one inch from end and push with steady force until the end of the hose is covered by the yellow plastic cap.



To disassemble Push-Lok

1. Leave fitting in place, and cut hose lengthwise from the yellow plastic cap approximately one inch. **IMPORTANT:** Be careful not to nick barbs when cutting hose.
2. Grip hose and give a sharp downward tug to disengage from the fitting.



CAUTION: Push-Lok fittings will properly grip Push-Lok hose only when pushed all the way in, with the cut end of the hose completely concealed by the yellow plastic cap.

Sealing integrity may be damaged by use of exterior clamps.
